# Engine Electrical System (G4ED/ G4EE - GSL 1.6/1.4)

#### GENERAL

SPECIFICATION	
IGNITION SYSTEM	EE -2
STARTING SYSTEM	EE -2
CHARGING SYSTEM	EE -3
TROUBLESHOOTING	
IGNITION SYSTEM	EE -4
CHARGING SYSTEM	EE -4
STARTING SYSTEM	EE -5

#### IGNITION SYSTEM

DESCRIPTION	. EE -6
ON-VEHICLE INSPECTION	
SPARK TEST	. EE -6
INSPECT SPARK PLUG	. EE -8
INSPECT IGNITION COIL	. EE -9
REPLACEMENT	
IGNITION COIL	. EE -10

#### **CHARGING SYSTEM**

DESCRIPTION EE -11
ON-VEHICLE INSPECTION
CHECK BATTERY VOLTAGE EE -11
INSPECT DRIVE BELT EE -12
CHECK DISCHARGE WARNING LIGHT
CIRCUIT EE -12
INSPECT CHARGING SYSTEM EE -13

#### ALTERNATOR

REPLACEMENT	EE -16
COMPONENTS	EE -18
DISASSEMBLY	EE -19
INSPECTION	EE -20
BATTERY	
DESCRIPTION	EE -22

INSPECTION ...... EE -23

#### STARTING SYSTEM

DESCRIPTION STARTER CIRCULT TROUBLESHOOTING	EE	-26
STARTER SOLENOID TEST	EE ·	-27
FREE RUNNING TEST	EE ·	-27
STARTER		
REPLACEMENT	EE ·	-28
COMPONENTS	EE ·	-29
DISASSEMBLY	EE ·	-30
INSPECTION	EE ·	-32
STARTER RELAY		
INSPECTION	EE ·	-35



# GENERAL

# GENERAL E12522AB

#### SPECIFICATION

#### IGNITION SYSTEM

	5 <sup>20</sup>		cification
	Items	1.6 DOHC 1.4 DOHC	
	Primary resistance	0.87 ± 10 % (Ω)	
Ignition coll	Ignition coil Secondary resistance 13.0 ± 15 % (		15 % (kΩ)
	NGK	BKR5ES-11 RC10YC4 1.0 ~ 1.1 mm (0.0394 ~ 0.0433in.)	
Spark plugs (Unleaded)	CHAMPION		
(Officaded)	Gap		
	NGK	BKR5ES	
Spark plugs (Leaded)	CHAMPION	RC	C10YC
Gap 0.9 ~ 1.0 mm (0.0354 ~ 0.0		0.0354 ~ 0.0394in.)	

#### STARTING SYSTEM

			Specification	
	Items		1.6 DOHC	1.4 DOHC
	Rated voltage		12 V, 0.9 kW	
	No. of p	binion teeth	3,	<b>3</b>
	No-load characteristics tarter	Voltage	11.5	5 V
Starter		Ampere	60A,	MAX
		Speed	5,500 rp	om, MIN
	Commutator diameter	Standard	33 mm (1.2992in.)	
	Standard 0.5 m		0.5 mm (	0.0197in.)
	Under cut depth	Limit	0.2 mm (	0.0079in.)

#### CHARGING SYSTEM

Items		Specification	
	items	1.6 DOHC 1.4 DOHC	
	Туре	Battery voltage sensing	
	Rate voltage	13.5 V, 9	90A
Alternator	Speed in use	1,000 ~ 18,0	000 rpm
Alternator	Voltage regulator	Electronic built-in type	
Regulator setting voltage 14.55 ± 0.2 V		0.2 V	
	Temperature compensation	-7 ± 3 mV	/ / °C
	Туре	MF 454	λH
Battery	Cold cranking amperage [at -18°C(-0.4°F)]	410 A	
	Reserve capacity	80 mii	n
	Specific gravity [at 20°C(68°F)]	1.280 ± (	0.01

#### 

- COLD CRANKING AMPERAGE is the amperage a battery can deliver for 30 seconds and maintain a terminal voltage of 7.2V or greater at a specified temperature.
- RESERVE CAPACITY RATING is amount of time a battery can deliver 25A and maintain a minimum terminal voltage of 10.5V at 26.7°C(80.1°F).

#### TROUBLESHOOTING EF5DCBCE

#### IGNITION SYSTEM

Symptom	Suspect area	Remedy
Engine will not start or is hard to start (Cranks OK)	Ignition lock switch Ignition coil Spark plugs	Inspect ignition lock switch, or replace as required Inspect ignition coil, or replace as required Inspect spark plugs, or replace
	Ignition wiring disconnected or broken Spark plugs cable	as required Repair wiring, or replace as required Inspect cable, or replace as required
Rough idle or stalls	Ignition wiring Ignition coil Spark plugs cable	Repair wiring, or replace as required Inspect ignition coil, or replace as required Inspect cable, or replace as required
Engine hesitates / poor acceleration	Spark plugs and spark plug cables Ignition wiring	Inspect spark plugs / cable, or replace as required Repair wiring, or replace as required
Poor mileage	Spark plugs and spark plug cables	Inspect spark plugs / cable, or replace as required

#### CHARGING SYSTEM

Symptom	Suspect area	Remedy
Charging warning indicator does not light with ignition switch "ON" and engine off.	Fuse blown Light burned out Wiring connection loose Electronic voltage regulator	Check fuses Replace light Tighten loose connection Replace voltage regulator
Charging warning indicator does not go out with engine running. (Battery requires frequent recharging)	Drive belt loose or worn Battery cable loose, corroded or worn Electronic voltage regulator or alternator Wiring	Adjust belt tension or replace belt Inspect cable connection, repair or replace cable Replace voltage regulator or alternator Repair or replace wiring
Overcharge	Electronic voltage regulator Voltage sensing wire	Replace voltage regulator Repair or replace wiring
Discharge	Drive belt loose or worn Wiring connection loose or short circuit Electronic voltage regulator or alternator Poor grounding Worn battery	Adjust belt tension or replace belt Inspect wiring connection, repair or replace wiring Replace voltage regulator or alternator Inspect ground or repair Replace battery

# STARTING SYSTEM

Symptom	Suspect area	Remedy
Engine will not crank	Battery charge low Battery cables loose, corroded or worn out	Charge or replace battery Repair or replace cables
	Transaxle range switch (Vehicle with automatic transaxle only) Fuse blown Starter motor faulty Ignition switch faulty	Refer to TR group-automatic transaxle Replace fuse Replace Replace
Engine cranks slowly	Battery charge low Battery cables loose, corroded or worn out Starter motor faulty	Charge or replace battery Repair or replace cables Replace
Starter keeps running	Starter motor Ignition switch	Replace Replace
Starter spins but engine will not crank	Short in wiring Pinion gear teeth broken or starter motor Ring gear teeth broken	Repair wiring Replace Replace fly wheel or torque converter

#### ENGINE ELECTRICAL SYSTEM (G4ED/G4EE - GSL1.6/1.4)

# **IGNITION SYSTEM**

#### DESCRITION E9724F12


Ignition timing is controlled by the electronic control ignition timing system. The standard reference ignition timing data for the engine operating conditions are pre-programmed in the memory of the ECM (Engine Control Module).

The engine operating conditions (speed, load, warm-up condition, etc.) are detected by the various sensors. Based on these sensor signals and the ignition timing data, signals to interrupt the primary current are sent to the ECM. The ignition coil is activated, and timing is controlled.

#### ON-VEHICLE INSPECTION E4F36345


#### SPARK TEST

1. Remove the spark plug cable.



ACGE002A

- 2. Using a spark plug socket, remove the spark plug.
- 3. Install the spark plug to the spark plug cable.
- 4. Ground the spark plug to the engine.




ABGE001A

5. Check is spark occurs while engine is being cranked.

#### 🛈 ΝΟΤΕ


To prevent fuel being injected from injectors while the engine is being cranked, remove the fuel pump(A) relay from the fuse box.

Crank the engine for no more than 5 ~ 10 seconds.



ABJF010A

- 6. Inspect all the spark plugs.
- 7. Using a spark plug socket, install the spark plug.
- 8. Install the spark plug cable.




LBJF001A

#### INSPECT SPARK PLUG

1. Remove the spark plug cable.

#### 

When removing the spark plug cable, pull on the spark plug cable boot (not the cable), as it may be damaged.



ACGE002A

2. Using a spark plug socket, remove the spark plug.

#### 

Be careful that no contaminates enter through the spark plug holes.


3. Inspect the electrodes (A) and ceramic insulator (B).

#### **INSPECTION OF ELECTRODES**


Condition	Dark deposits	White deposits
Description	<ul> <li>Fuel mixture too rich</li> <li>Low air intake</li> </ul>	<ul> <li>Fuel mixture too lean</li> <li>Advanced ignition timing</li> <li>Insufficient plug tightening torque</li> </ul>

4. Check the electrode gap (A).

Standard
Unleaded : 1.0 ~ 1.1 mm (0.0394 ~ 0.0433 in.)
Leaded: 0.9 ~ 1.0 mm (0.0354 ~ 0.0394in.)



EBKD002L




EBKD002K

#### INSPECT SPARK PLUG CABLE


1. Carefully remove the spark plug cable by pulling on the rubber boots (A).

Check the condition of the spark plug cable terminals (B), if any terminal is corroded, cleans it, and if it broken or distorted, replace the spark plug cable.



#### INSPECT IGNITION COIL

1. Measure the primary coil resistance between terminals (+) and (-).




LBJF002A

ABGE009A

2. Connect the ohmmeter probes and measure resistance.

RESISTANCE :  $5.6k\Omega / m \pm 20\%$ 



EBKD002P

3. Resistance should not be higher than  $10k\Omega$  /m. If resistance is higher, replace the cable.


Standard value: 0.870 ± 10%

 Measure the secondary coil resistance between the high-voltage terminals for the No.1 and No. 4 cylinders, and between the high voltage terminals for the No. 2 and No. 3 cylinders.

Standard value: 13.0k<sub>Ω</sub> ± 15%

# 

Be sure, when measuring the resistance of the secondary coil, to disconnect the connector of the ignition coil.




EBKD002C

#### REPLACEMENT E0AFE6B4


#### **IGNITION COIL**

- 1. Remove the engine cover.
- 2. Disconnect the spark plug cables and the ignition coil connector.



ACGE002A

3. Remove the ignition coil (A).



EBKD003A

4. Installation is the reverse of removal.

# CHARGING SYSTEM


#### DESCRIPTION E024309A

The charging system included a battery, an alternator with a built-in regulator, and the charging indicator light and wire.

The Alternator has eight built-in diodes, each rectifying AC current to DC current.

Therefore, DC current appears at alternator "B" terminal. In addition, the charging voltage of this alternator is regulated by the battery voltage detection system.

The alternator is regulated by the battery voltage detection system. The main components of the alternator are the rotor, stator, rectifier, capacitor brushes, bearings and V-ribbed belt pulley. The brush holder contains a built-in electronic voltage regulator.



LBJF003A

#### ON-VEHICLE INPECTION EDEDEC50

#### 

- Check that the battery cables are connected to the correct terminals.
- Disconnect the battery cables when the battery is given a quick charge.
- Never disconnect the battery while the engine is running.

#### CHECK BATTERY VOLTAGE

- 1. If 20 minutes have not passed since the engine was stopped, turn the ignition switch ON and turn on the electrical system (headlamp, blower motor, rear defogger etc.) for 60 seconds to remove the surface charge.
- 2. Turn the ignition switch OFF and turn off the electrical systems.
- 3. Measure the battery voltage between the negative (-) and positive (+) terminals of the battery.

Standard voltage : 12.5 ~ 12.9V at 20°C(68°F)

If the voltage is less than specification, charge the battery.

#### CHECK THE BATTERY TERMINALS AND FUSES

- 1. Check that the battery terminals are not loose or corroded.
- 2. Check the fuses for continuity.


#### INSPECT DRIVE BELT

1. Visually check the belt for excessive wear, frayed cords etc.

If any defect has been found, replace the drive belt.

#### 🗊 ΝΟΤΕ

Cracks on the rib side of a belt are considered acceptable. If the belt has chunks missing from the ribs, it should be replaced.




EBKD004B

2. Measure the drive belt tension and adjust it. Apply a force of 98N (10kg, 22lb), and measure the deflection between the alternator and the water pump pulley.

#### DEFLECTION

New belt	3.3 ~ 3.7mm (0.1299 ~ 0.1457in.)
Used belt	4.2 ~ 4.7mm (0.1654 ~ 0.1850in.)

If the belt tension is not as specified, adjust it.



ABJF002A

#### 

- "New belt" refers to a belt which has been used less than 5 minutes on a running engine.
- "Used belt" refers to a belt which has been used on a running engine for 5 minutes or more.
- After installing a belt, check that it fits properly in the ribbed grooves.
- Check with your hand to confirm that the belt has not slipped out of the groove on the bottom of the pulley.
- After installing a new belt, run the engine for about 5 minutes and recheck the belt tension.

# VISUALLY CHECK ALTERNATOR WIRING AND LISTEN FOR ABNORMAL NOISES

- 1. Check that the wiring is in good condition.
- 2. Check that there is no abnormal noise from the alternator while the engine is running.

#### CHECK DISCHARGE WARNING LIGHT CIRCUIT

- 1. Warm up the engine and then turn it off.
- 2. Turn off all accessories.
- 3. Turn the ignition switch "ON". Check that the discharge warning light is lit.
- 4. Start the engine. Check that the light is lit. If the light does not go off as specified, troubleshoot the discharge light circuit.

#### ENGINE ELECTRICAL SYSTEM (G4ED/G4EE - GSL1.6/1.4)

#### INSPECT CHARGING SYSTEM

VOLTAGE DROP TEST OF ALTERNATOR OUTPUT WIRE

This test determines whether or not the wiring between the alternator "B" terminal and the battery (+) terminal is good by the voltage drop method.

#### PREPARATION

- 1. Turn the ignition switch to "OFF".
- Disconnect the output wire from the alternator "B" terminal. Connect the (+) lead wire of ammeter to the "B" terminal of alternator and the (-) lead wire of ammeter to the output wire. Connect the (+) lead wire of voltmeter to the "B" terminal of alternator and the (-) lead wire of voltmeter to the (+) terminal of battery.

#### TEST

- 1. Start the engine.
- 2. Turn on the headlamps and blower motor, and set the engine speed until the ammeter indicates 20A. And then, read the voltmeter at this time.


#### RESULT

1. The voltmeter may indicate the standard value.

Standard value: 0.2V max

- If the value of the voltmeter is higher than expected (above 0.2V max.), poor wiring is suspected. In this case check the wiring from the alternator "B" terminal to the battery (+) terminal. Check for loose connections, color change due to an over-heated harness, etc. Correct them before testing again.
- Upon completion of the test, set the engine speed at idle.
   Turn off the headlamps, blower motor and the ignition switch.

BBGE002A



#### OUTPUT CURRENT TEST

This test determines whether or not the alternator gives an output current that is equivalent to the normal output.

#### PREPARATION

1. Prior to the test, check the following items and correct as necessary.

Check the battery installed in the vehicle to ensure that it is good condition. The battery checking method is described in the section "Battery".

The battery that is used to test the output current should be one that has been partially discharged. With a fully charged battery, the test may not be conducted correctly due to an insufficient load.


Check the tension of the alternator drive belt. The belt tension check method is described in the section "Inspect drive belt".


- 2. Turn off the ignition switch.
- 3. Disconnect the battery ground cable.
- 4. Disconnect the alternator output wire from the alternator "B" terminal.
- 5. Connect a DC ammeter (0 to 150A) in series between the "B" terminal and the disconnected output wire. Be sure to connect the (-) lead wire of the ammeter to the disconnected output wire.

#### 🗊 ΝΟΤΕ

Tighten each connection securely, as a heavy current will flow. Do not rely on clips.

- Connect a voltmeter (0 to 20V) between the "B" terminal and ground. Connect the (+) lead wire to the alternator "B" terminal and (-) lead wire to a good ground.
- 7. Attach an engine tachometer and connect the battery ground cable.





EBKD013H

#### TEST

- Check to see that the voltmeter reads as the same value as the battery voltage. If the voltmeter reads 0V, and the open circuit in the wire between alternator "B" terminal and battery (-) terminal or poor grounding is suspected.
- 2. Start the engine and turn on the headlamps.
- 3. Set the headlamps to high beam and the heater blower switch to HIGH, quickly increase the engine speed to 2,500 rpm and read the maximum output current value indicated by the ammeter.



After the engine start up, the charging current quickly drops.

Therefore, the above operation must be done quickly to read the maximum current value correctly.

#### RESULT

1. The ammeter reading must be higher than the limit value. If it is lower but the alternator output wire is in good condition, remove the alternator from the vehicle and test it.

Limit value (90A alternator): 63A min.

#### 🗊 ΝΟΤΕ

- The nominal output current value is shown on the nameplate affixed to the alternator body.
- The output current value changes with the electrical load and the temperature of the alternator itself.

Therefore, the nominal output current may not be obtained. If such is the case, keep the headlamps on the cause discharge of the battery, or use the lights of another vehicle to increase the electrical load.

The nominal output current may not be obtained if the temperature of the alternator itself or ambient temperature is too high.

In such a case, reduce the temperature before testing again.


- 2. Upon completion of the output current test, lower the engine speed to idle and turn off the ignition switch.
- 3. Disconnect the battery ground cable.
- 4. Remove the ammeter and voltmeter and the engine tachometer.
- 5. Connect the alternator output wire to the alternator "B" terminal.
- 6. Connect the battery ground cable.

#### **REGULATED VOLTAGE TEST**

The purpose of this test is to check that the electronic voltage regulator controls voltage correctly.

#### PREPARATION

- Prior to the test, check the following items and correct if necessary.
   Check that the battery installed on the vehicle is fully charged. The battery checking method is described in the section "Battery".
   Check the alternator drive belt tension. The belt tension check method is described in the section "Inspect drive belt".
- 2. Turn ignition switch to "OFF".
- 3. Disconnect the battery ground cable.
- Connect a digital voltmeter between the "B" terminal of the alternator and ground. Connect the (+) lead of the voltmeter to the "B" terminal of the alternator. Connect the (-) lead to good ground or the battery (-) terminal.
- 5. Disconnect the alternator output wire from the alternator "B" terminal.
- Connect a DC ammeter (0 to 150A) in series between the "B" terminal and the disconnected output wire. Connect the (-) lead wire of the ammeter to the disconnected output wire.
- 7. Attach the engine tachometer and connect the battery ground cable.



EBKD013H

#### EE -16

#### TEST

1. Turn on the ignition switch and check to see that the voltmeter indicates the following value.

#### Voltage: Battery voltage

If it reads 0V, there is an open circuit in the wire between the alternator "B" terminal and the battery and the battery (-) terminal.

- 2. Start the engine. Keep all lights and accessories off.
- 3. Run the engine at a speed of about 2,500 rpm and read the voltmeter when the alternator output current drops to 10A or less

#### RESULT

1. If the voltmeter reading agrees with the value listed in the regulating voltage table below, the voltage regulator is functioning correctly. If the reading is other than the standard value, the voltage regulator or the alternator is faulty.

#### **REGULATING VOLTAGE TABLE**


Voltage regulator ambient temperature °C (°F)	Regulating voltage (V)
-20 (-4)	14.2 ~ 15.4 14.0 ~ 15.0
20 (68) 60 (140)	14.0 ~ 15.0 13.7 ~ 14.9
80 (176)	13.5 ~ 14.7

- 2. Upon completion of the test, reduce the engine speed to idle, and turn off the ignition switch.
- 3. Disconnect the battery ground cable.
- 4. Remove the voltmeter and ammeter and the engine tachometer.
- 5. Connect the alternator output wire to the alternator "B" terminal.
- 6. Connect the battery ground cable.

# ALTERNATOR


#### REPLACEMENT EAFC6680

- 1. Disconnect the battery negative terminal first, then the positive terminal.
- 2. Remove the drive belts.




KCPF021A

3. Disconnect the alternator connector (A), and remove the cable (B) from alternator "B" terminal.



ACGE014A


- 4. Remove the adjusting bolt (A) and mounting bolt (B), then remove the alternator drive belt.
- 5. Pull out the through bolt (C) and then remove the alternator (D).



KBPF002A

- 6. Installation is the reverse order of removal.
- 7. Adjust the alternator belt tension after installation.

#### COMPONENT E3F8E95F




- 1. Nut
- 2. Pulley
- 3. Spacer
- 4. Front cover assembly
- 5. Front bearing
- 6. Bearing cover
- 7. Bearing cover bolts
- 8. Rotor coil
- 9. Rear bearing
- 10. Bearing cover

- 11. Rear cover
- 12. Bolts
- 13. Seal
- 14. Rectifier assembly
- 15. Stud bolts
- 16. Brush holder assembly
- 17. Brush holder bolts
- 18. Slip ring guide
- 19. Cover

LBGE008A

#### DISASSEMBLY E43E1C51

Remove the alternator cover(A) using a screw 1. driver(B).






5.

4.

2. Loosen the mounting bolts(A) and disconnect the brush holder assembly(B).




Loosen the 4 through bolts(A).


EBKD301E

Disconnect the rotor(A) and cover(B). 6.

EBKD301B


Remove the slip ring guide(A). 3.





7. Reassembly is the reverse of disassembly.

EBKD301C




Remove the nut, pulley(A) and spacer.



#### INSPECTION EECF033F

#### **INSPECT ROTOR**

 Check that there is continuity between the slip rings (A).




EBKD008A

- 2. Check that there is no continuity between the slip rings and the rotor (B) or rotor shaft (C).
- 3. If the rotor fails either continuity check, replace the alternator.

#### **INSPECT STATOR**

1. Check that there is continuity between each pair of leads (A).



EBKD008B

- 2. Check that there is no continuity between each lead and the coil core.
- 3. If the coil fails either continuity check, replace the alternator.

# ALTERNATOR BELT INSPECTION AND ADJUSTMENT

#### NOTE

When using a new belt, first adjust the deflection or tension to the values for the new belt, then readjust the deflection or tension to the value for the used belt after running engine for five minutes.


#### **DEFLECTION METHOD:**

Apply a force of 98N (10kg, 22lb), and measure the deflection between the alternator and the water pump pulley.



#### NOTE

If the belt is worn or damaged, replace it.



ABJF002A

#### BELT TENSION GAUGE METHOD:


Attach the belt tension gauge to the belt and measure the tension. Follow the gauge manufacturer's instructions.

#### Tension

Used belt: 392.3 ~ 490.3N (40 ~ 50kg, 88.2 ~ 110.2lb) New belt: 637.4 ~ 735.5N (65 ~ 75kg, 143.3 ~ 165.3lb)

# 


If the belt is worn or damaged, replace it.



EBKD008D

#### IF ADJUSTMENT IS NECESSARY:

- 1. Loosen adjusting bolt (A) and the lock bolt (B).
- 2. Move the alternator to obtain the proper belt tension, then retighten the nuts.



#### EBKD008E

3. Recheck the deflection or tension of the belt.


#### **NOTE**

For the power steering pump belt and A/C compressor belt adjustments, refer to ST group - power steering pump and HA group - air compressor.

# BATTERY

#### DESCRIPTION EFAA5B7B

- 1. The maintenance-free battery is, as the name implies, totally maintenance free and has no removable battery cell caps.
- 2. Water never needs to be added to the maintenancefree battery.
- 3. The battery is completely sealed, except for small vent holes in the cover.




EBJD008A

INSPECTION EFCD68F1

**BATTERY DIAGNOSTIC TEST (1)** 

CHECKING FLOW



BBGE007A

#### LOAD TEST

- 1. Perform the following steps to complete the load test procedure for maintenance free batteries.
- 2. Connect the load tester clamps to the terminals and proceed with the test as follow:
  - If the battery has been on charge, remove the surface charge by connect a 300ampere load for 15 seconds.
  - 2) Connect the voltmeter and apply the specified load.
  - 3) Read the voltage after the load has been applied for 15 seconds.
  - 4) Disconnect the load.
  - 5) Compare the voltage reading with the minimum and replace the battery if battery test voltage is below that shown in the voltage table.

Voltage	Temperature		
9.6V	20°C (68.0°F) and above		
9.5V	16°C (60.8°F)		
9.4V	10°C (50.0°F)		
9.3V	4°C (39.2°F)		
9.1V	-1°C (30.2°F)		
8.9V	-7°C (19.4°F)		
8.7V	-12°C (10.4°F)		
8.5V	-18°C (-0.4°F)		

#### 🗊 ΝΟΤΕ

- If the voltage is greater shown in the table, the battery is good.
- If the voltage is less than shown in the table, replace the battery.


#### **BATTERY DIAGNOSTIC TEST (2)**

- 1. Make sure the ignition switch and all accessories are in the OFF position.
- 2. Disconnect the battery cables (negative first).
- 3. Remove the battery from the vehicle.

# **CAUTION**

Care should be taken in the event the battery case is cracked or leaking, to protect your skin from the electrolyte.

Heavy rubber gloves (not the household type) should be wore when removing the battery.




EBJD008B

- 4. Inspect the battery tray for damage caused by the loss of electrolyte. If acid damage is present, it will be necessary to clean the area with a solution of clean warm water and baking soda. Scrub the area with a stiff brush and wipe off with a cloth moistened with baking soda and water.
- 5. Clean the top of the battery with the same solution as described above.
- 6. Inspect the battery case and cover for cracks. If cracks are present, the battery must be replaced.
- 7. Clean the battery posts with a suitable battery post tool.
- 8. Clean the inside surface of the terminal clamps with a suitable battery cleaning tool. Replace damaged or frayed cables and broken terminal clamps.
- 9. Install the battery in the vehicle.
- 10. Connect the cable terminals to the battery post, making sure tops of the terminals are flush with the tops of the posts.

- 11. Tighten the terminal nuts securely.
- 12. Coat all connections with light mineral grease after tightening.

### 

When batteries are being charged, an explosive gas forms beneath the cover of each cell. Do not smoke near batteries being charged or which have recently been charged. Do not break live circuit at the terminals of batteries being charged. A spark will occur when the circuit is broken. Keep open flames away form battery.



EBJD008A

<sup>1</sup> No. suprementation and engeneral interaction in the started still used not creating the orthophytic reading and engeneration or registric as prevantally.

un in de la grant de la grant de la de la destruction de la d

# STARTING SYSTEM


#### DESCRIPTION E16E5DEF

The starting system includes the battery, starter, solenoid switch, ignition switch, inhibitor switch (A/T), ignition lock switch, connection wires and the battery cable.

When the ignition key is turned to the start position, current flows and energizes the starter motor's solenoid coil.

The solenoid plunger and clutch shift lever are activated, and the clutch pinion engages the ring gear.

The contacts close and the starter motor cranks. In order to prevent damage caused by excessive rotation of the starter armature when the engine starts, the clutch pinion gear overruns.




EBKD010A

# STARTER CIRCUIT TROUBLESHOOTING E0F08581

#### 🗊 ΝΟΤΕ

The battery must be in good condition and fully charged.

1. Remove the fuel pump relay from the fuse box.



2. With the shift lever in N or P (A/T) or clutch pedal pressed (M/T), turn the ignition switch to "START"

If the starter normally cranks the engine, starting system is OK. If the starter will not crank the engine at all, go to next step.

If it won't disengage from the ring gear when you release key, check for the following until you find the cause.

- · Solenoid plunger and switch malfunction.
- Dirty pinion gear or damaged overrunning clutch.
- 3. Check the battery condition. Check electrical connections at the battery, battery negative cable connected to the body, engine ground cables, and the starter for looseness and corrosion. Then try starting the engine again.

If the starter cranks normally the engine, repairing the loose connection repaired the problem. The starting system is now OK.

If the starter still does not crank the engine, go to next step.

4. Disconnect the connector from the S-terminal of solenoid. Connect a jumper wire from the B-terminal of solenoid to the S-terminal of solenoid.

If the starter cranks the engine, go to next step. If the starter still does not crank the engine, remove the starter, and repair or replace as necessary.


- 5. Check the following items in the order listed until you find the open circuit.
  - Check the wire and connectors between the driver's under-dash fuse/relay box and the ignition switch, and between the driver's under-dash fuse/relay box and the starter.
  - Check the ignition switch (Refer to BE group ignition system)
  - Check the transaxle range switch connector or ignition lock switch connector.
  - Inspect the starter relay.

ABJF010A

#### STARTING SYSTEM

#### STATER SOLENOID TEST

- 1. Disconnect the field coil wire from the M-terminal of solenoid switch.
- 2. Connect a 12V battery between S-terminal and the starter body.



BBGE004A

3. Connect the field coil wire to the M-terminal.


#### CAUTION

This test must be performed quickly (in less than 10 seconds) to prevent the coil from burning.

- If the pinion moves out, the pull-in coil of solenoid is working properly.
   If the pinion does not move, replace the solenoid.
  - .
- 5. Diconnect the field coil wire from the M-terminal.
- If the pinion has moved out, the hold-in coil of the solenoid is working properly.
   If the pinion moves in, replace the solenoid.



- 1. Place the starter motor in a vise equipped with soft jaws and connect a fully-charged 12-volt battery to starter motor as follows.
- 2. Connect a test ammeter (100-ampere scale) and carbon pile rheostats shown is the illustration.
- 3. Connect a voltmeter (15-volt scale) across starter motor.



BBGE005A


- 4. Rotate carbon pile to the off position.
- 5. Connect the battery cable from battery's negative post to the starter motor body.
- 6. Adjust until battery voltage shown on the voltmeter reads 11volts.
- 7. Confirm that the maximum amperage is within the specifications and that the starter motor turns smoothly and freely.

Current: 60A max		
Speed : 5,500 rpm		

# STARTER


#### REPLACEMENT E2F9D550

- 1. Disconnect the battery negative cable.
- 2. Remove the air cleaner assembly.



KCPF036A

 Disconnect the starter cable (A) from the B terminal (B) on the solenoid (C), then disconnect the connector (D) from the S terminal (E).



ABGE024A

- 4. Remove the 2 bolts holding the starter, then remove the starter.
- 5. Installation is the reverse of removal.
- 6. Connect the battery negative cable to the battery.

11、令寒夏紫色下门


收载 化二磺胺合 网络热的 制制制 化碘酸医吗啡白酸钾 机精确的第三人称单数 医外外的 化乙基乙基

가 가려 있는 것이 있는 것이 가지가 있는 것이 가지가 가지 않는 것이 있다. 이 가지가 하는 것이 가지 않는 것이 있는 것이 있 같은 것이 같은 것이 같은 것이 있는 것

<sup>1</sup> Contraction and the second secon second se

#### **STARTING SYSTEM**

#### COMPONENT EB04E4D2




- 1. Screw
- 2. Front bracket assembly
- 3. Stop ring
- 4. Stopper
- 5. Overrun clutch assembly
- 6. Lever 7. Plate
- 8. Lever packing 9. Internal gear assembly
- 10. Planet shaft assembly

- 11. Planetary gear assembly
- 12. Steel ball
- 13. Packing
- 14. Magnet switch assembly
- 15. Through bolt
- 16. Yoke assembly
- 17. Armature assembly
- 18. Brush holder assembly
- 19. Rear bracket
- 20. Screw

BBGE006A


#### DISASSEMBLY EEA12C44

1. Disconnect the M-terminal (A) on the magnet switch assembly (B).




EBKD011C

2. After loosening the 2 screws (A), detach the magnet switch assembly (B).




EBKD011D

3. Loosen the brush holder mounting screw (A) and through bolts (B).




4. Remove the rear bracket (A) and brush holder assembly (B).




EBKD011F

5. Remove the yoke (A) and armature (B).



EBKD011G


6. Remove the lever plate (A) and planetary shaft packing (B).



EBKD011H


EBKD011E

7. Disconnect the planetary gear(A).




EBKD011I

8. Disconnect the planetary shaft assembly and lever(B).




EBKD011J

9. Press the stop ring (A) using a socket (B).



EBKD011K


10. After removing the stopper (A) using stopper pliers (B).



EBKD011L

ļ

11. Disconnect the stop ring(A), overruning clutch(B), internal gear(C) and planet shaft(D).




EBKD011M

12. Reassembly is the reverse of disassembly.

🗊 ΝΟΤΕ

Using a suitable pulling tool (A), pull the overrunning clutch stop ring (B) over the stopper (C).




EBKD011O

#### INSPECTION E6B30AA7


#### ARMATURE INSPECTION AND TEST

- 1. Remove the starter.
- 2. Disassemble the starter as shown at the beginning of this procedure.
- 3. Inspect the armature for wear or damage from contact with the permanent magnet. If there is wear or damage, replace the armature.




EBKD012A

4. Check the commutator (A) surface. If the surface is dirty or burnt, resurface with emery cloth or a lathe within the following specifications, or recondition with #500 or #600 sandpaper (B).



Commutator diameter Standard (New) : 33.0 mm (1.2992 in) Service limit : 32.4 mm (1.2756 in)


ENGINE ELECTRICAL SYSTEM (G4ED/G4EE - GSL1.6/1.4)




EBKD012C

- 6. Measure the commutator (A) runout.
  - If the commutator runout is within the service limit, check the commutator for carbon dust or brass chips between the segments.
  - If the commutator run out is not within the service limit, replace the armature.

Commutator runout Standard (New): 0.02mm (0.0008in.) max Service limit: 0.05mm (0.0020in.)



EBKD012B




EBKD012D


#### STARTING SYSTEM

 Check the mica depth (A). If the mica is too high (B), undercut the mica with a hacksaw blade to the proper depth. Cut away all the mica (C) between the commutator segments. The undercut should not be too shallow, too narrow, or v-shaped (D).

Commutator mica depth Standard (New) : 0.5 mm (0.0197 in.) Limit : 0.2mm (0.0079 in.)




9. Check with an ohmmeter that no continuity exists between the commutator (A) and armature coil core (B), and between the commutator and armature shaft (C). If continuity exists, replace the armature.



EBKD012G

EBKD012E

8. Check for continuity between the segments of the commutator. If an open circuit exists between any segments, replace the armature.



EBKD012F

#### **INSPECT STARTER BRUSH**

Brushes that are worm out, or oil-soaked, should be replaced.

# Limit line


BBGE008A

# 

To seat new brushes, slip a strip of #500 or #600 sandpaper, with the grit side up, between the commutator and each brush, and smoothly rotate the armature. The contact surface of the brushes will be sanded to the same contour as the commutator.

#### STARTER BRUSH HOLDER TEST

1. Check that there is no continuity between the (+) brush holder (A) and (-) brush holder (B). If there is no continuity, replace the brush holder assembly.




ABHE012A

# 

Use a pipe (C) of suitable size for the brushes not to get removed from the brush holder.

#### INSPECT OVERRUNNING CLUTCH

- 1. Slide the overrunning clutch along the shaft. Replace it if does not slide smoothly.
- 2. Rotate the overrunning clutch both ways. Does it lock in one direction and rotate smoothly in reverse? If it does not lock in either direction of it locks in both directions, replace it.



ABHE013A

3. If the starter drive gear is worn or damaged, replace the overrunning clutch assembly. (the gear is not available separately).

Check the condition of the flywheel or torque converter ring gear if the starter drive gear teeth are damaged.


#### CLEANING

- 1. Do not immerse parts in cleaning solvent. Immersing the yoke assembly and/or armature will damage the insulation. Wipe these parts with a cloth only.
- 2. Do not immerse the drive unit in cleaning solvent. The overrun clutch is pre-lubricated at the factory and solvent will wash lubrication from the clutch.
- 3. The drive unit may be cleaned with a brush moistened with cleaning solvent and wiped dry with a cloth.

# STARTER RELAY

#### INSPECTION E553B0B9

- 1. Remove the fuse box cover.
- 2. Remove the starter relay (A).




ABJF011A

3. Using an ohmmeter, check that there is continuity between each terminal.

Terminal	Continuity
30 - 87	NO
- 85 - 86	YES

4. Apply 12V to terminal 85 and ground to terminal 86. Check for continuity between terminals 30 and 87.



LDAD510B

- 5. If there is no continuity, replace the starter relay.
- 6. Install the starter relay.
- 7. Install the fuse box cover.

