# Fuel System (D4FA - DSL 1.5)

#### GENERAL

SPECIFICATIONS	FLB-3
SERVICE STANDARD	FLB-6
TIGHTENING TORQUES	FLB-6
SPECIAL SERVICE TOOLS	FLB-7
BASIC TROUBLESHOOTING	FLB-8
ACTUATOR TEST	FLB-15
SYMPTOM TROUBLESHOOTING	
GUIDE CHART (I)	FLB-16
SYMPTOM TROUBLESHOOTING	
GUIDE CHART (II)	FLB-25
FAIL-SAFE CHART	FLB-29

#### DIESEL CONTROL SYSTEM

DESCRIPTION	FLB-31 FLB-34
ENGINE CONTROL MODULE (ECM) ECM HARNESS CONNECTOR ECM TERMINAL FUNCTION	FLB-39 FLB-39
ECM TERMINAL INPUT/OUTPUT SIGNAL CIRCUIT DIAGRAM	FLB-43 FLB-50
ECM PROBLEM INSPECTION PROCEDURE	FLB-54 FLB-54
ENGIEN COOLANT TEMPERATURE SENSOR (ECTS) CAMSHAFT POSITION SENSOR	FLB-56
(CMPS) CRANKSHAFT POSITION SENSOR (CKPS)	FLB-58
(CKPS) MASS AIR FLOW SENSOR (MAFS) RAIL PRESSURE SENSOR (RPS) BOOST PRESSURE SENSOR (BPS)	. FLB-62
INTAKE AIR TEMPERATURE SENSOR (IATS) ACCELERATION POSITION SENSOR	
(APS) VGT SOLENOID VALVE FUEL PRESSURE CONTROL VALVE RAIL PRESSURE CONTROL VALVE EGR SOLENOID VALVE THROTTLE CONTROL VALVE VARIABLE SWIRL ACTUATOR FUEL TEMPERATURE SENSOR (FTS) HEATED OXYGEN SENSOR	. FLB-69 . FLB-71 . FLB-73 . FLB-75 . FLB-77 . FLB-79 . FLB-81 FLB-84

## DTC TROUBLESHOOTING PROCEDURES

INSPECTION CHART FOR DIAGNOSTIC	TROUBLE
CODES (DTC) TROUBLESHOOTING FOR DTC	FLB-88
TROUBLESHOOTING FOR DTC	
P0031	FLB-92
P0032	
P0047	FLB-102
P0048	FLB-109
P0069	FLB-113
P0087	
P0088	FLB-122
P0089	FLB-123
P0091	-
P0092	
P0097	
P0098	
P0101	
P0102	
P0103	
P0107	
P0108	
P0112	
P0113	
P0117	
P0118	
P0182	
P0183	
P0192	
P0192	
P0201	
P0202	
P0202	
P0204	
P0237	
P0238	
P0252	
P0253	
P0254	
P0262	
P0265	
P0268	. FLB-234
P0271	
P0335	
P0336	
P0340	
P0341	·· == =• ·
P0381	
P0489	
P0490	
P0501	
P0504	
P0532	
P0533	
P0562	. FLB-301



#### TROUBLESHOOTING FOR DTC

P0563	FLB-307
P0602	
P0605	FLB-313
P0606	
P0611	FLB-316
P062D	FLB-322
P062E	FLB-324
P0642	
P0643	FLB-330
P0646	ELB-333
P0647	FLB-340
P0650	FLD-340
P0652	
P0653	
P0670	
P0685	FLB-363
P0698	FLB-370
P0699	
P0700	
P0701	
P0820	
P0830	
P1145	
P1185	
P1186	
P1586	FLB-398
P1587	
P1588	FLB-403
P1610	FLB-405
P1634	
P1652	
P1670	
P1671	
P2009	
P2010	
P2015	FLB-433
P2016	
P2017	
P2111	FLB-446
P2112	FLB-452
P2123	FLB-455
P2128	FLB-462
P2138	
P2238	ELB 471
P2239	
P2251	FLD-400
P2264	
P2299	
U0001	FLB-506
U0100	
U0101	
U0122	FLB-521
U0416	FLB-525

### FUEL DELIVERY SYSTEM-DIESEL

COMPONENTS	FLB-529
SCHEMATIC DIAGRAM	FLB-531
INJECTOR	
DESCRIPTION	FLB-532
CLEANING	FLB-532
REMOVAL	
REPLACEMENT	
INSTALLATION	
INSPECTION	
ACCUMULATOR	
DESCRIPTION	FLB-540
REMOVAL	
INSTALLATION	
HIGH PRESSURE PUMP	
DESCRIPTION	FLB-542
REMOVAL	
INSTALLATION	ELB-543
FUEL FILTER	0.0
COMPONENTS	ELB-545
REMOVAL	
INSTALLATION	
INSPECTION FUEL TANK	1 20 041
REMOVAL	
· · · · · · · · · · · · · · · · · · ·	
	×

# GENERAL

#### SPECIFICATION E3C953EE

#### FUEL DELIVERY SYSTEM

Items	Specification	
Fuel Tank	Capacity	45lit.(11.9 U.S.gal., 9.9 Imp.gal.)
Fuel Retrun System	Туре	Return
Fuel Filter	Туре	High pressure type (built in engine room)
High Pressure Fuel Pump	Туре	Mechanical
	Driven by	Belt
Fuel Pressure	Maximum pressure	1,600 bar (160 Mpa, 23,206 psi)

#### INPUT SENSORS

Mass Air Flow Sensor (MAFS)

- ▶ Type: Digital type
- Specification

#### INTAKE AIR TEMPERATURE:20°C(68°F)

Air Quantity(Kg/h)	Frequency(KHz)
8	1.96~1.97
10	2.01~2.02
40	2.50~2.52
105	3.18~3.23
220	4.26~4.35
480	7.59~7.94
560	9.08~9.89

#### INTAKE AIR TEMPERATURE:80°C(176°F)

Air Quantity(Kg/h)	Frequency(KHz)
10	2.00~2.02
40	2.49~2.53
105	3.16~3.25
480	7.42~8.12

#### ACCELERATOR POSITION SENSOR (APS)

- ▶ Type: Potentiometer
- Specification

Tost Condition	Output Voltage(V)	
Test Condition	APS 1(V)	APS 2(V)

Idle	0.14 ~ 0.16	0.073~0.077
Fully depressed	0.76 ~ 0.88	0.35~0.47

#### BOOST PRESSURE SENSOR(BPS)

- ▶ Type: Piezo-resistive type
- Specificiation

Pressure(kpa)	Output Voltage(V)
70	1.02~1.17
140	2.13~2.28
210	3.25~3.40
270	4.20~4.35

#### HEATED OXYGEN SENSOR(HO2S)

- ▶ Type: Zirconia sensor
- Specificiation

#### SENSOR

λ (Value)	Pumping Current(A)
0.65	-2.22
0.70	-1.82
0.80	-1.11
0.90	-0.50
1.01	0.00
1.18	0.33
1.43	0.67
1.70	0.94
2.42	1.38
Air (Atmosphere)	2.54

#### HEATER

Temperature ℃(°F)	Sensor Resistance ( $\Omega$ )
20(68)	9.2
100(212)	10.7
200(392)	13.1
300(572)	14.6
400(752)	17.7
500(932)	19.2
600(1112)	20.7
700(1292)	22.5

#### INTAKE AIR TEMPERATURE SENSOR (IATS)

▶ Type: Thermistor type (Intergrated with BPS)

Specificiation

# IATS1(INTEGRATED IN BOOST PRESSURE SENSOR)

Temperature ℃(°F)	Sensor Resistance (kΩ)
-20(-4)	12.66~15.12
-10(14)	7.94~9.31
0(32)	5.12~5.89
10(50)	3.38~3.83
20(68)	2.29~2.55
30(86)	1.57~1.75
40(104)	1.10~1.24
50(122)	0.78~0.89
60(140)	0.57~0.65
70(158)	0.42~0.49
80(176)	0.31~0.37
90(194)	0.24~0.29
100(212)	0.18~0.22
110(230)	0.14~0.18
120(248)	0.11~0.14
130(266)	0.11~0.14

#### IATS2(INTEGRATED IN MASS AIR FLOW SENSOR)

Temperature ℃(°F)	Sensor Resistance (\\\\\\\\)
-20(-4)	12.66~15.12
0(32)	5.2~5.9
20(68)	2.29~2.55
80(176)	0.31~0.37

#### FUEL TEMPERATURE SENSOR (FTS)

- ▶ Type: Thermistor type
- Specificiation

Sensor Resistance (kΩ)
15.67
9.45
5.89
2.27~2.73
1.17
0.60
0.30~0.32
0.176
0.112

# ENGINE COOLANT TEMPERATURE SENSOR (ECTS)

- ▶ Type: Thermistor type
- Specificiation

#### BETWEEN PIN 1 AND 3(FOR ECTS)

Temperature ℃(°F)	Sensor Resistance ( <sup>k</sup> Ω)
-20(-4)	14.13 ~ 16.83
0(32)	5.79
20(68)	2.31 ~ 2.59
40(104)	1.15
60(140)	0.59
80(176)	0.32
100(212)	0.19
110(230)	0.15
120(248)	0.17

#### BETWEEN PIN 1 AND 2(FOR GUAGE)

Temperature ℃(°F)	Sensor Resistance ( $\Omega$ )
60(140)	125
85(185)	42.6~54.2
110(230)	22.1~26.2
125(257)	15.2

# VEHICLE SPEED SENSOR (OR WHEEL SPEED SENSOR)

▶ Type: Inductive Type

- ▶ Type: Hall Effect Sensor
- Output Voltage (V): 0~5

#### CRANKSHAFT POSITION SENSOR (CKPS)

- Type: Inductive Type
- Output Voltage (V): 0~5
- Specificiation

Temperature ℃(°F)	Coil Resistance ( $\Omega$ )
20 (68)	860 ± 10 %

#### RAIL PRESSURE SENSOR(RPS)

- Type: Piezo-resistive type
- Specificiation

ltem	Idle	Fully depressed
Rail pressure(bar)	220~320	1800
Output Voltage(V)	Below 1.7	Approx. 4.5

#### OUTPUT ACTUATORS

#### INJECTOR

- ▶ Type: Electromagnetic type
- Number: 4
- Specificiation

Temperature ℃(°F)	Injector Resistance ( $\Omega$ )
20~70 (68~158)	0.22~0.30

#### VARIABLE SWIRL VALVE ACTUATOR

- Type: Motor driven(Position sensor installed)
- Specificiation

#### MOTOR

Temperature ℃(°F)	Resistance ( $\Omega$ )
20 (68)	3.2~4.4

#### POSITION SENSOR

Temperature ℃(°F)	Resistance ( $\Omega$ )
20 (68)	3.44~5.16

#### THROTTLE FLAP CONTROL SOLENOID VALVE

- ▶ Type: Double coil type
- Specificiation

Temperature ℃(°F)	Resistance ( $\Omega$ )
20 (68)	28.3~31.1

#### VARIABLE GEOMETRY TURBO CHARGER(VGT) CONTROL SOLENOID VALVE

- Type: Double coil type
- Specificiation

Temperature ℃(°F)	Resistance ( $\Omega$ )
20 (68)	14.7 ~ 16.1

#### ELECTRONIC EMISSION GAS RECIRCULATION(EGR) CONTROL VALVE

- Type: Linear solenoid(Electric type)
- Duty Cycle: 140Hz
- Specificiation

Temperature ℃(°F)	Resistance ( $\Omega$ )
19~25(66.2~77.0)	7.3 ~ 8.3

#### FUEL PRESSURE REGULATOR

- Control type: Inlet control
- Duty Cycle: 185Hz
- Specificiation

Temperature ℃(°F)	Resistance ( $\Omega$ )
20 (68)	2.6~3.15

#### RAIL PRESSURE REGULATOR

- Control type: Outlet control
- Duty Cycle: 1000Hz
- Specificiation

Temperature ℃(°F)	Resistance ( $\Omega$ )
20 (68)	3.42~3.78

# FLB -6

# FUEL SYSTEM

# SERVICE STANDARD E6B67938

Basic Idle rpm (after warm up)	A/C OFF	700±100
	A/C ON	750±100

# TIGHTENING TORQUES EDGOCBEF

#### ENGINE CONTROL SYSTEM

Items	N·m	kg∙m	lbf∙ft	
ECM Bracket	3.9~5.9	0.4~0.6	2.9~4.3	
Boost Pressure Sensor (BPS)	6.9~10.8	0.7~1.1	5.1~8.0	
Crankshaft Position Sensor (CKPS)	5.9~9.8	0.6~1.0	4.3~7.2	
Camshaft Position Sensor (CMPS)	6.9~9.8	0.7~1.0	5.1~7.2	
Engine Coolant Temperature Sensor (ECTS)	19.6~49.2	2.0~4.0	10.9~14.5	
Accelerator Position Sensor (APS)	5.9~7.9	0.6~0.8	4.3~5.8	
Vacuum Pump	9.8~11.8	1.0~1.2	7.4~8.9	
EGR Pipe to Exhaust System	31.4~37.3	3.2~3.8	23.6~28.0	
EGR Pipe to Inlet Manifold System	14.7~19.6	1.5~2.0	10.9~14.5	
EGR Valve	21.6~27.5	2.2 ~ 2.8	15.9 ~ 20.3	
Variable Swirl Valve Actuator	6.9~10.8	0.7 ~ 1.1	5.1~ 8.0	
Heated Oxygen Sensor(HO2S)	40~60	4~6	29.5~44.3	

#### FUEL DELIVERY SYSTEM

Fuel tank band installation bolt	39.2~53.9	4.0 ~ 5.5	28.9 ~ 39.8
Common Rail	14.7~21.6	1.5 ~ 2.2	10.9 ~ 15.9
High Pressure Fuel Pump	15 ~ 19.6	1.5 ~ 2.0	10.9 ~ 14.5
Injector Clamp Bolt	27.5~29.4	2.8 ~ 3.0	20.3 ~ 21.7
High Pressure Fuel Tube(Pump to Rail)	24.5~28.4	2.5 ~ 2.9	18.1~21.0
High Pressure Fuel Tube(Rail to Injectors)	24.5~28.4	2.5 ~ 2.9	18.1~21.0

# SPECIAL SERVICE TOOLS EC7B6262

Tool (Number and name)	Illustration	Application
09351-2A100 Injector Remover Adapter	LCGF062A	Removing the injector
09351-4A200 Injector Remover	LXGF022A	Removing the injector
09314-27110(14mm) 09314-27120(17mm) Torque Wrench Socket	AFAF201B	Installing the high pressure pipe
09331-2A000 High Pressure Pump Sprocket Remover	LXGF021A	Removing the high pressure fuel pump

# BASIC TROUBLESHOOTING EAECCA9C

#### BASIC TROUBLESHOOTING GUIDE

<i></i>	
1	Bring Vehicle to Workshop
2	Analyze Customer's Problem
Ø	Ask the customer about the conditions and environment relative to the issue (Use CUSTOMER PROBLEM ANALYSIS SHEET).
3	Verify Symptom, and then Check DTC and Freeze Frame Data
0	Connect Hi-Scan (Pro) to Diagnostic Link Connector (DLC). Record the DTC and freeze frame data.
	ΝΟΤΕ
	To erase DTC and freeze frame data, refer to Step 5.
4	Confirm the Inspection Procedure for the System or Part
٥	Using the SYMPTOM TROUBLESHOOTING GUIDE CHART, choose the correct inspection procedure for the system or part to be checked.
5	Erase the DTC and Freeze Frame Data
	NEVER erase DTC and freeze frame data before completing Step 2 MIL/DTC in "CUSTOMER PROBLEM ANALYSIS SHEET".
6	Inspect Vehicle Visually
0	Go to Step 11, if you recognize the problem.
7	Recreate (Simulate) Symptoms the DTC
0	Try to recreate or simulate the symptoms and conditions of the malfunction as described by customer. If DTC(s) is/are displayed, simulate the condition according to troubleshooting procedure for the DTC.
8	Confirm Symptoms of Problem
	If DTC(s) is/are not displayed, go to Step 9. If DTC(s) is/are displayed, go to Step 11.
9	Recreate (Simulate) Symptom
0	Try to recreate or simulate the condition of the malfunction as described by the customer.
10	Check the DTC
	If DTC(s) does(do) not occur, refer to INTERMITTENT PROBLEM PROCEDURE in BASIC INSPECTION PROCEDURE. If DTC(s) occur(s), go to Step 11.
11	Perform troubleshooting procedure for DTC
12	Adjust or repair the vehicle
13	Confirmation test
14	END

LXGF500A

#### CUSTOMER PROBLEM ANALYSIS SHEET

#### 1. VEHICLE INFORMATION

(I) VIN:	
(II) Production Date:	·
(III) Odometer Reading: (mile/ km)	С.

#### 2. SYMPTOMS

Unable to start	<ul> <li>Engine does not turn over</li> <li>Incomplete combustion</li> <li>Initial combustion does not occur</li> </ul>		
Difficult to start	Engine turns over slowly     Other		· · · · · · ·
Poor idling	<ul> <li>Rough idling I Incorrect idling</li> <li>Unstable idling (High: rpm, Low:rpm)</li> <li>Other</li> </ul>	• • • • •	
Engine stall	<ul> <li>Soon after starting</li> <li>After accelerator pedal depressed</li> <li>After accelerator pedal released</li> <li>During A/C ON</li> <li>Shifting from N to D-range</li> <li>Other</li> </ul>		
	<ul> <li>□ Poor driving (Surge)</li> <li>□ Knocking</li> <li>□ Poor fuel economy</li> <li>□ Back fire</li> <li>□ After fire</li> <li>□ Other</li> </ul>		. **. 6

# 3. ENVIRONMENT

Problem frequency	□ Constant □ Sometimes () □ Once only □ Other
Weather	☐ Fine ☐ Cloudy ☐ Rainy ☐ Snowy ☐ Other
Outdoor temperature	Approx. °C/°F
Place	☐ Highway ☐ Suburbs ☐ Inner City ☐ Uphill ☐ Downhill ☐ Rough road ☐ Other
Engine temperature	□ Cold □ Warming up □ After warming up □ Any temperature
Engine operation	<ul> <li>Starting </li> <li>Just after starting ( min) </li> <li>Idling </li> <li>Racing</li> <li>Driving </li> <li>Constant speed </li> <li>Acceleration </li> <li>Deceleration</li> <li>A/C switch ON/OFF </li> <li>Other</li> </ul>

#### 4. MIL/DTC

MIL (Malfunction Indicator Lamp)		🗆 Remains ON 🗆 Sometimes lig	hts up 🗌 Does not light	
DTC	Normal Check (Pre-check)	<ul> <li>□ Normal □ DTC (</li> <li>□ Freeze Frame Data</li> </ul>		)
	Check mode	<ul> <li>□ Normal □ DTC (</li> <li>□ Freeze Frame Data</li> </ul>	<sup>ra</sup> a some	)

#### BASIC INSPECTION PROCEDURE

# MEASURING CONDITION OF ELECTRONIC PARTS' RESISTANCE

The measured resistance at high temperature after vehicle running may be high or low. So all resistance must be measured at ambient temperature ( $20^{\circ}C$ ,  $68^{\circ}F$ ), unless there is any notice.


# 🗊 ΝΟΤΕ

The measured resistance in except for ambient temperature (20°C, 68°F) is reference value.

# INTERMITTENT PROBLEM INSPECTION PROCEDURE

Sometimes the most difficult case in troubleshooting is when a problem symptom occurs but does not occur again during testing. An example would be if a problem appears only when the vehicle is cold but has not appeared when warm. In this case, technician should thoroughly make out a "CUSTOMER PROBLEM ANALYSIS SHEET" and recreate (simulate) the environment and condition which occurred when the vehicle was having the issue.

- 1. Clear Diagnostic Trouble Code (DTC).
- Inspect connector connection, and check terminal for poor connections, loose wires, bent, broken or corroded pins, and then verify that the connectors are always securely fastened.



BFGE321A

3. Slightly shake the connector and wiring harness vertically and horizontally.

- 4. Repair or replace the component that has a problem.
- 5. Verify that the problem has disappeared with the road test.

#### SIMULATING VIBRATION

a. Sensors and Actuators
: Slightly vibrate sensors, actuators or relays with finger.

#### 😮 WARNING

Strong vibration may break sensors, actuators or relays

- b. Connectors and Harness
   : Lightly shake the connector and wiring harness vertically and then horizontally.
- SIMULATING HEAT
- a. Heat components suspected of causing the malfunction with a hair dryer or other heat sourre.

#### 🕲 WARNING

- DO NOT heat components to the point where they may be damaged.
- DO NOT heat the ECM directly.
- SIMULATING WATER SPRINKLING
- a. Sprinkle water onto vehicle to simulate a rainy day or a high humidity condition.


## 🕲 WARNING

DO NOT sprinkle water directly into the engine compartment or electronic components.

- SIMULATING ELECTRICAL LOAD
- a. Turn on all electrical systems to simulate excessive electrical loads (Radios, fans, lights, etc.).


#### CONNECTOR INSPECTION PROCEDURE

- 1. Handling of Connector
  - a. Never pull on the wiring harness when disconnecting connectors.




BFGE015F

b. When removing the connector with a lock, press or pull locking lever.




BFGE015G

c. Listen for a click when locking connectors. This sound indicates that they are securely locked.




d. When a tester is used to check for continuity, or to measure voltage, always insert tester probe from wire harness side.



BFGE015

e. Check waterproof connector terminals from the connector side. Waterproof connectors cannot be accessed from harness side.



BFGE015J


# 🛈 ΝΟΤΕ

- Use a fine wire to prevent damage to the terminal.
- Do not damage the terminal when inserting the tester lead.
- 2. Checking Point for Connector
  - While the connector is connected: Hold the connector, check connecting condition and locking efficiency.
  - When the connector is disconnected: Check missed terminal, crimped terminal or broken core wire by slightly pulling the wire harness. Visually check for rust, contamination, deformation and bend.
  - c. Check terminal tightening condition: Insert a spare male terminal into a female terminal, and then check terminal tightening conditions.

BFGE015H

#### FUEL SYSTEM

d. Pull lightly on individual wires to ensure that each wire is secured in the terminal.



BFGE015K

- 3. Repair Method of Connector Terminal
  - a. Clean the contact points using air gun and/or shop rag.

#### 🛈 NOTE

Never use sand paper when polishing the contact points, otherwise the contact point may be damaged.

b. In case of abnormal contact pressure, replace the female terminal.


#### WIRE HARNESS INSPECTION PROCEDURE

- 1. Before removing the wire harness, check the wire harness position and crimping in order to restore it correctly.
- 2. Check whether the wire harness is twisted, pulled or loosened.
- 3. Check whether the temperature of the wire harness is abnormally high.
- 4. Check whether the wire harness is rotating, moving or vibrating against the sharp edge of a part.
- 5. Check the connection between the wire harness and any installed part.
- 6. If the covering of wire harness is damaged; secure, repair or replace the harness.

#### ELECTRICAL CIRCUIT INSPECTION PROCEDURE

- CHECK OPEN CIRCUIT
- 1. Procedures for Open Circuit
  - Continuity Check
  - Voltage Check

If an open circuit occurs (as seen in [FIG. 1]), it can be found by performing Step 2 (Continuity Check Method) or Step 3 (Voltage Check Method) as shown below.



BFGE501A

2. Continuity Check Method




When measuring for resistance, lightly shake the wire harness above and below or from side to side.

Specification (Resistance)  $1\Omega$  or less  $\rightarrow$  Normal Circuit  $1 M\Omega$  or Higher  $\rightarrow$  Open Circuit

a. Disconnect connectors (A), (C) and measure resistance between connector (A) and (C) as shown in [FIG. 2].


In [FIG.2.] the measured resistance of line 1 and 2 is higher than  $1\Omega$  M $\Omega$  and below  $1\Omega$  respectively. Specifically the open circuit is line 1 (Line 2 is normal). To find exact break point, check sub line of line 1 as described in next step.



BFGE501B

b. Disconnect connector (B), and measure for resistance between connector (C) and (B1) and between (B2) and (A) as shown in [FIG. 3].

In this case the measured resistance between connector (C) and (B1) is higher than  $1M\Omega$  and the open circuit is between terminal 1 of connector (C) and terminal 1 of connector (B1).




BFGE501C

- 3. Voltage Check Method
  - a. With each connector still connected, measure the voltage between the chassis ground and terminal 1 of each connectors (A), (B) and (C) as shown in [FIG. 4].

The measured voltage of each connector is 5V, 5V and 0V respectively. So the open circuit is between connector (C) and (B).






BFGE501D

- CHECK SHORT CIRCUIT
- 1. Test Method for Short to Ground Circuit
  - Continuity Check with Chassis Ground

If short to ground circuit occurs as shown in [FIG. 5], the broken point can be found by performing below Step 2

(Continuity Check Method with Chassis Ground) as shown below.

FIG 5



BFGE501E

2. Continuity Check Method (with Chassis Ground)


## **NOTE**

Lightly shake the wire harness above and below, or from side to side when measuring the resistance.

Specification (Resistance)  $1\Omega$  or less  $\rightarrow$  Short to Ground Circuit  $1M\Omega$  or Higher  $\rightarrow$  Normal Circuit

 Disconnect connectors (A), (C) and measure for resistance between connector (A) and Chassis Ground as shown in [FIG. 6].


The measured resistance of line 1 and 2 in this example is below 1  $\Omega$  and higher than 1<sup>MQ</sup> respectively. Specifically the short to ground circuit is line 1 (Line 2 is normal). To find exact broken point, check the sub line of line 1 as described in the following step.



BFGE501F

Disconnect connector (B), and measure the resistance between connector (A) and chassis ground, and between (B1) and chassis ground as shown in [FIG. 7].

The measured resistance between connector (B1) and chassis ground is  $1\Omega$  or less. The short to ground circuit is between terminal 1 of connector (C) and terminal 1 of connector (B1).



#### BFGE501G

(a) A set of the se

a de la Servición de Calendaria. La composición de la La composición de la c

a sense en antes estas da ser procesa (c. 1977). 1980 - Maria Maria, a companya (c. 1977) 1989 - Carto Maria, a companya (c. 1977)



A. The Constant and the second state of the second st



n an an Araba an Araba an Araba an Araba an Araba. An Araba an Araba.

#### ACTUATOR TEST

The ACTUATOR TEST mode is to check if the relay, valve, actuator and so on are operated normally.

Before removing parts to inspect or replace them, performing the Actuator test is recommanded.

Perform the ACTUATOR TEST according to the below procedures.

- 2. Turn the ignition switch OFF.
- 3. Connect the Hi-Scan(or Pro) to the DLC connector.
- 4. Turn the ignition switch ON.
- 5. According to the display on tester, select the ACTUA-TOR TEST mode and perform it.

1. Warm up the engine.

TEST METHOD	TEST CONDITION
Control A/C compressor relay ON or OFF.	IG ON, ENG STOP
Control the FAN-LOW SPEED relay ON and operate the fan.	IG ON, ENG STOP
Control the FAN-HIGH SPEED relay ON and operate the fan.	IG ON, ENG STOP
Turn the lamp ON or OFF.	IG ON, ENG STOP
Turn the lamp ON or OFF.	IG ON, ENG STOP
Control glow relay ON or OFF.	IG ON, ENG STOP
Activate the EGR actuator ON or OFF	IG ON, ENG STOP
Activate the valve ON or OFF.	IG ON, ENG STOP
Turn the lamp ON or OFF.	IG ON, ENG STOP
Turn the lamp ON or OFF.	IG ON, ENG STOP
Activate the VGT actuator ON or OFF	IG ON, ENG STOP
Activate the throttle actuator ON or OFF	IG ON, ENG STOP
Activate Variable Swirl actuator ON or OFF	IG ON, ENG STOP
Activate the valve ON or OFF	IG ON, ENG STOP
Control PTC heater relay ON or OFF	IG ON, ENG STOP
	Control A/C compressor relay ON or OFF. Control the FAN-LOW SPEED relay ON and operate the fan. Control the FAN-HIGH SPEED relay ON and operate the fan. Turn the lamp ON or OFF. Turn the lamp ON or OFF. Control glow relay ON or OFF. Activate the EGR actuator ON or OFF. Activate the valve ON or OFF. Turn the lamp ON or OFF. Turn the lamp ON or OFF. Turn the lamp ON or OFF. Activate the VGT actuator ON or OFF Activate the throttle actuator ON or OFF Activate the throttle actuator ON or OFF Activate the valve ON or OFF

#### SYMPTOM TROUBLESHOOTING GUIDE CHART(I)

Problem	Possible cause
Engine does not start	Run out of fuel
	Starter faulty
	Pump hose supply cut
	High pressure leakage
	Fuse out of order
	The compensation of individual injector not adapted
	Drift of the rail pressure sensor not detected
	Cam and Crank signals missing simultaneously
	Battery voltage too low
	Faulty antitheft or immobilizer
	EGR valve blocked open
	Fuel pressure regulator valve contaminated, stuck, jammed
	Rail pressure control valve contaminated, stuck, jammed
	Fuel quality / presence of water
	Inversion of low pressure fuel connections
	Fuel filter not adapted
	Low pressure fuel circuit sealed
	Sealed fuel filter
	Intermittent fault connection
	Air ingress in the low pressure fuel circuit
	Fuel return circuit of the pump sealed
	Engine compression too low
	Leakage at the injector valve
en men en e	Low pressure fuel pump faulty
	High pressure fuel pump faulty
<ul> <li>March 2010 Control of the second secon</li></ul>	Injector jammed open
	Bug software or hardware fault not detected

Problem	Possible cause				
Engine starts with difficulty	Run out of fuel				
or starts and stalls	Fuel return hose of nozzle holder cut				
	High pressure leakage				
	Fuse faulty				
	Air filter sealed				
	Alternator or voltage regulator faulty				
	The compensation of individual injector not adapted				
	Drift of the engine coolant temperature sensor not detected				
	Drift of the rail pressure sensor not detected				
	Battery voltage too low				
	EGR valve blocked open				
	Fuel pressure regulator valve contaminated, stuck, jammed				
F	Rail pressure control valve contaminated, stuck, jammed				
	Fuel quality / presence of water				
	Inversion of low pressure fuel connections				
	Low pressure fuel circuit sealed				
	Sealed fuel filter				
	Oil level too high/too low				
	Catalytic converter sealed or damaged				
	Intermittent fault connection				
	Air ingress in the low pressure fuel circuit				
	Fuel return circuit of the pump sealed				
	Glow system faulty				
	Engine compression too low				
	Fuel return hose of nozzle holder sealed				
	Carbon deposit on the injector (sealed holes)				
	Needle stuck (injection possible over a certain pressure)				
	Petrol in fuel				
	Bug software or hardware fault not detected				

Possible cause
The compensation of individual injector not adapted
Drift of the rail pressure sensor not detected
EGR valve blocked open
Fuel pressure regulator valve contaminated, stuck, jammed
Rail pressure control valve contaminated, stuck, jammed
Air filter sealed
Air ingress in the low pressure fuel circuit
Fuel quality / presence of water
Fuel return circuit of the pump sealed
Sealed fuel filter
Engine compression too low
Intermittent fault connection
Carbon deposit on the injector (sealed holes)
Needle stuck (injection possible over a certain pressure)
Petrol in fuel
Bug software or hardware fault not detected
Fuel return hose of nozzle holder cut
The compensation of individual injector not adapted
Drift of the rail pressure sensor not detected
Harness resistance increased
Air ingress in the low pressure fuel circuit
Fuel quality / presence of water
Sealed fuel filter
Air filter sealed
Fuel return hose of nozzle holder sealed
High pressure leakage
Glow system faulty
Engine compression too low
Bad flanging of the injector
High pressure pump out of order
Injector not adapted
Carbon deposit on the injector (sealed holes)
Needle stuck (injection possible over a certain pressure)
Injector jammed open
Drift of the engine coolant temperature sensor not detected
Incorrect state of the electrical pack devices
Alternator or voltage regulator faulty
Clutch not well set
Bug software or hardware fault not detected

Problem	Possible cause
Blue, white, black smokes	The compensation of individual injector not adapted
	Drift of the engine coolant temperature sensor not detected
	Drift of the rail pressure sensor not detected
	EGR valve blocked open
	Fuel pressure regulator valve contaminated, stuck, jammed
	Rail pressure control valve contaminated, stuck, jammed
	Oil level too high/too low
	Fuel quality / presence of water
	Catalytic converter sealed or damaged
	Air filter sealed
	Oil suction (engine racing)
	Glow system faulty
	Engine compression too low
	Bad flanging of the injector
	Injector washer not adapted, forgotten, doubled
	Injector not adapted
	Carbon deposit on the injector (sealed holes)
	Injector jammed open
	Petrol in fuel
Engine rattling, noisy engine	The compensation of individual injector not adapted
	EGR valve blocked closed (noisy engine)
	EGR valve blocked open
	Drift of the engine coolant temperature sensor not detected
	Glow system faulty
	Engine compression too low
	Fuel return hose of nozzle holder sealed
	Drift of the rail pressure sensor not detected
	Injector washer not adapted, forgotten, doubled
	Injector not adapted
	Carbon deposit on the injector (sealed holes)
	Needle stuck (injection possible over a certain pressure)
	Injector jammed open
Burst noise	The compensation of individual injector not adapted
	Intermittent fault connection
	Exhaust system sealed
	Drift of the rail pressure sensor not detected
	Fuel pressure regulator valve contaminated, stuck, jammed
	Rail pressure control valve contaminated, stuck, jammed
	Bug software or hardware fault not detected

Problem	Possible cause
Untimely acceleration/deceler-	Accelerator position sensor blocked
ation and engine racing	EGR valve blocked open
	Intermittent fault connection
	Oil suction (engine racing)
	Drift of the rail pressure sensor not detected
	Bug software or hardware fault not detected
Gap when accelerating and at	Air inlet circuit open
re-coupling (response time)	Incorrect state of the electrical pack devices
	Accelerator position sensor blocked
	EGR valve blocked open
	Turbo charger damaged
	Sealed fuel filter
	Engine compression too low
	High pressure leakage
	Fuel pressure regulator valve contaminated, stuck, jammed
	Rail pressure control valve contaminated, stuck, jammed
	Needle stuck (injection possible over a certain pressure)
	Bug software or hardware fault not detected
Engine stop/ stalling	Run out of fuel
	Pump hose supply cut
	High pressure leakage
	Fuse faulty
	Fuel quality / presence of water
	Low pressure fuel circuit sealed
	Sealed fuel filter
	Cam and Crank signals missing simultaneously
	EGR valve blocked open
	Fuel pressure regulator valve contaminated, stuck, jammed
	Rail pressure control valve contaminated, stuck, jammed
	Alternator or voltage regulator faulty
	Intermittent fault connection
	Catalytic converter sealed or damaged
	Oil suction (engine racing)
	Low pressure fuel pump faulty
	High pressure pump faulty
	Faulty ignition key
	Petrol in fuel
	Bug software or hardware fault not detected

Problem	Possible cause
Engine judder	Run out of fuel
	Fuel return hose of nozzle holder cut
	Incorrect state of the electrical pack devices
	The compensation of individual injector not adapted
	EGR valve blocked open
	Fuel filter not adapted
	Air ingress in the low pressure fuel circuit
	Fuel quality / presence of water
	Sealed fuel filter
	Intermittent fault connection
	Harness resistance increased
	Glow system faulty
	Engine compression too low
	Fuel return hose of nozzle holder sealed
	Valve clearance
	Low pressure fuel pump faulty
	Injector washer not adapted, forgotten, doubled
	Carbon deposit on the injector (sealed holes)
	Needle stuck (injection possible over a certain pressure)
	Injector jammed open and and a streamting and
2. So the second of the sec	Petrolain, fuel associations for a company of
	Bug software or hardware fault not detected
Lack of power	The compensation of individual injector not adapted
	Accelerator position sensor blocked
	Incorrect state of the electrical pack devices
	EGR valve blocked open
	Air inlet circuit open
	Air filter sealed
	Oil level too high/too low
	Catalytic converter sealed or damaged
	Turbo charger damaged
	Sealed fuel filter
	Leakage at the injector valve
	Fuel return circuit of the pump sealed
	Fuel return hose of nozzle holder sealed
	Engine compression too low
	Injector not adapted
	Carbon deposit on the injector (sealed holes)

Problem	Possible cause
Too much power	EGR valve blocked closed (noisy engine)
	The compensation of individual injector not adapted
	Oil suction (engine racing)
	Bug software or hardware fault not detected
Excessive fuel consumption	Fuel return hose of nozzle holder cut
	Leakage at the Fuel pressure regulator valve
	Leakage at fuel temperature sensor
	Leakage at the spacers
	High pressure leakage
	Air inlet circuit open
	Air filter sealed
	The compensation of individual injector not adapted
	EGR valve blocked open
	Incorrect state of the electrical pack devices
	Oil level too high/too low
	Fuel quality / presence of water
	Catalytic converter sealed or damaged
	Turbo charger damaged
	Engine compression too low
	Injector not adapted
	Bug software or hardware fault not detected
Over speed engine when	Accelerator position sensor blocked
changing the gear box ratio	The compensation of individual injector not adapted
	Intermittent fault connection
	Clutch not well set
	Oil suction (engine racing)
	Turbo charger damaged
	Injector not adapted
	Bug software or hardware fault not detected

C T C C T C C B I r C C B I r C C N I n D C C N I n B I r S mokes (black, white, blue) T I when acceleration	EGR valve blocked open Oil suction (engine racing) Turbo charger damaged Oil level too high/too low The compensation of individual injector not adapted Catalytic converter sealed or damaged Bad flanging of the injector Injector washer not adapted, forgotten, doubled Injector not adapted Carbon deposit on the injector (sealed holes) Needle stuck (injection possible over a certain pressure) Injector jammed open Bug software or hardware fault not detected The compensation of individual injector not adapted EGR valve blocked open
T C T C B Ir In C N In S Smokes (black, white, blue) T I when accelerating	Turbo charger damaged Oil level too high/too low The compensation of individual injector not adapted Catalytic converter sealed or damaged Bad flanging of the injector Injector washer not adapted, forgotten, doubled Injector not adapted Carbon deposit on the injector (sealed holes) Needle stuck (injection possible over a certain pressure) Injector jammed open Bug software or hardware fault not detected The compensation of individual injector not adapted
C T C B Ir In In C N In Smokes (black, white, blue) T T when accelerating	Oil level too high/too low The compensation of individual injector not adapted Catalytic converter sealed or damaged Bad flanging of the injector Injector washer not adapted, forgotten, doubled Injector not adapted Carbon deposit on the injector (sealed holes) Needle stuck (injection possible over a certain pressure) Injector jammed open Bug software or hardware fault not detected The compensation of individual injector not adapted
T C B In In C N N In Smokes (black, white, blue) T I when accelerating	The compensation of individual injector not adapted Catalytic converter sealed or damaged Bad flanging of the injector Injector washer not adapted, forgotten, doubled Injector not adapted Carbon deposit on the injector (sealed holes) Needle stuck (injection possible over a certain pressure) Injector jammed open Bug software or hardware fault not detected The compensation of individual injector not adapted
C B Ir In C N In Smokes (black, white, blue) T When accelerating	Catalytic converter sealed or damaged Bad flanging of the injector Injector washer not adapted, forgotten, doubled Injector not adapted Carbon deposit on the injector (sealed holes) Needle stuck (injection possible over a certain pressure) Injector jammed open Bug software or hardware fault not detected The compensation of individual injector not adapted
B Ir In C N N In B Smokes (black, white, blue) T I when accelerating	Bad flanging of the injector Injector washer not adapted, forgotten, doubled Injector not adapted Carbon deposit on the injector (sealed holes) Needle stuck (injection possible over a certain pressure) Injector jammed open Bug software or hardware fault not detected The compensation of individual injector not adapted
In In C N In B Smokes (black, white, blue) TI	Injector washer not adapted, forgotten, doubled Injector not adapted Carbon deposit on the injector (sealed holes) Needle stuck (injection possible over a certain pressure) Injector jammed open Bug software or hardware fault not detected The compensation of individual injector not adapted
In C N In B Smokes (black, white, blue) T When accelerating	Injector not adapted Carbon deposit on the injector (sealed holes) Needle stuck (injection possible over a certain pressure) Injector jammed open Bug software or hardware fault not detected The compensation of individual injector not adapted
C N In Smokes (black, white, blue) T	Carbon deposit on the injector (sealed holes) Needle stuck (injection possible over a certain pressure) Injector jammed open Bug software or hardware fault not detected The compensation of individual injector not adapted
N In B Smokes (black, white, blue) The scelerating	Needle stuck (injection possible over a certain pressure) Injector jammed open Bug software or hardware fault not detected The compensation of individual injector not adapted
Smokes (black, white, blue)	Injector jammed open Bug software or hardware fault not detected The compensation of individual injector not adapted
B Smokes (black, white, blue) TI	Bug software or hardware fault not detected The compensation of individual injector not adapted
Smokes (black, white, blue)	The compensation of individual injector not adapted
when accelerating	
when accelerating	EGR valve blocked open
A	Air filter sealed
F	Fuel quality / presence of water
0	Dil level too high/too low
π	Turbo charger damaged to a state of the stat
C	Catalytic converter sealed or damaged
	Dil suction (engine racing)
Ai	Air heaters out of order
	Engine compression too low
Hi	High pressure leakage
	ntermittent fault connection
	Bad flanging of the injector
In	njector washer not adapted, forgotten, doubled
Inj	njector not adapted
Ca	Carbon deposit on the injector (sealed holes)
Ne	Needle stuck (injection possible over a certain pressure)
Inj	njector jammed open
Pe	Petrol in fuel
Bu	Bug software or hardware fault not detected
Fuel smells Pu	Pump hose supply cut
Fu	uel return hose of nozzle holder cut
Le	eakage at the Fuel pressure regulator valve
	eakage at fuel temperature sensor
	eakage at the spacers
	ligh pressure leakage

Problem	Possible cause				
The engine collapses at take off	Accelerator position sensor blocked				
	Incorrect state of the electrical pack devices				
	Air filter sealed				
	Inversion of low pressure fuel connections				
	Fuel filter not adapted				
	Fuel quality/presence of water				
	Air ingress in the low pressure fuel circuit				
	Sealed fuel filter				
	Catalytic converter sealed or damaged				
	Clutch not well set				
	Intermittent fault connection				
	Drift of the rail pressure sensor not detected				
	Fuel pressure regulator valve contaminated, stuck, jammed				
	Rail pressure control valve contaminated, stuck, jammed				
	Petrol in fuel				
	Bug software or hardware fault not detected				
The engine does not stop	Faulty ignition key				
	Oil suction (engine racing)				
	Bug software or hardware fault not detected				
Different mechanical noises	Buzzer noise (discharge by the injectors)				
	Clip broken (vibrations, resonance, noises)				
	Incorrect state of the electrical pack devices				
	Catalytic converter sealed or damaged				
	Air inlet circuit open				
	Bad flanging of the injector				
	Clutch not well set				
	Turbo charger damaged				
	Valve clearance				

# GENERAL

# SYMPTOM TROUBLESHOOTING GUIDE CHART (II)

Trouble symtoms Check items	Engine will not start	Engine shut off and then restart	Engine starts only with difficult	High idle no throttle take-up	Knocking on accel. (warm-up phases)	Vibration at idle	Reduced power	Engine does not run smothly, misfiring, knocking	Bucking
Self-diagnosis	1	1	1	1	1	1	1	1	1
Immobilizer	2								
Vehicle supply voltage	3		2					9	3
Main Relay	4	3	3					11	4
Fuse/plug wiring harness	5	2						8	2
Ignition switch signal	6	4	4					10	5
Crankshaft Position Sensor	7							12	
No fuel	8								
Wrong fuel	9	5	7			2	5	3	
Lack of fuel								2	
Air in fuel system	10	6	8			3		4	
Low-pressure circuit (fuel)	11	7	13			4	6	7	
High-pressure circuit (fuel)	16	8	14			14	19	16	
Fuel filter	12		9			5	7	5	
Electric fuel pump	15	· · · · · · ·	11					6	
Fuel pre-heater	13		10	·		6	8		
Fuel pressure regulator valve / Rail pressure control valve	18	9	16	· · ·		13		15	
Incorrect connection of injector	14		17		3	11		13	
Injector	17	10	19		4	10	18	14	
Engine mechanical components (compression, valve clearance)	19		20				20	19	9
Defective ECM	20								
Camshaft Position sensor			5						
Engine Coolant Temperature Sensor			15		2		16		
Loss of coolant									
Glow-plug system			16						

LGJF500A

# FUEL SYSTEM

Trouble symtoms Check items	Engine will not start	Engine shut off and then restart	Engine starts only with difficult	High idle no throttle take-up	Knocking on accel. (warm-up phases)	Vibration at idle	Reduced power	Engine does not run smothly, misfiring, knocking	Bucking
Rail Pressure Sensor	21		18			12	17	17	
Accelerator Position Sensor				2			9		
Mechanical fault in accelerator pedal				3			10		
EGR						7	11		
Mass Air Flow Sensor						9	15		
Air filter clogged			12			8	4		
Vacuum system leaking							2		
Turbocharger defective							12		
VGT valve connection							13		
Boost Pressure Sensor							3		
Checking timing belt tension								18	
Clutch switch									6
Brake switch						:			7
Vehicle speed signal									8
Checking oil level									
Radiator fan									
Radiator defective or clogged									
Ignition switch defective					-				
A/CON compressor switch									
A/CON switch									
Plug contacts			6						
Leak in connecting surface between turbochager and Intake manifold							14		
High pressure pump	22		21				21		

LXGF502A

F	L	В	-2	7
---	---	---	----	---

Trouble symtoms Check items	Engine overrun, Accel.	White/Blue smoke	Clouds of black smoke	Engine overheating	Can not shut off with ignition key	Diagnosis lamp not go out or flickers	A/CON cannot be switched on	Radiator fan constantly in operation
Self-diagnosis	1	1	1	1	1	1	1	1
Immobilizer		1	1			1		
Vehicle supply voltage						·		
Main Relay							-	-
Fuse/plug wiring harness					4	2	2	4
Ignition switch signal					3	2	2	
Crankshaft Position Sensor					3			
No fuel								
Wrong fuel				2				
Lack of fuel								
Air in fuel system		3						
Low-pressure circuit (fuel)		6						
High-pressure circuit (fuel)	7						and and a second	
Fuel filter		4				s prostana a	a tigat ya ku	
Electric fuel pump						1 2 1 1 2 5	n ta si Nga sa	
Fuel pre-heater		5					and the sould	4
Fuel pressure Regulator Valve / Raill pressure control Valve	6	- - -	· · ·					
Incorrect connection of injector						****		
Injector								
Engine mechanical components (compression, valve clearance)			8	7		-		
Defective ECM					5		· · · · ·	
Camshaft Position sensor								
Engine Coolant Temperature Sensor	8	2	7	3			5	3
Loss of coolant				6				
Glow-plug system								

LGJF500B

		0		b	1	ot		tion
Trouble symtoms Check items	Engine overrun, Accel.	White/Blue smoke	Clouds of black smoke	Engine overheating	Can not shut off with ignition key	Diagnosis lamp not go out or flickers	A/CON cannot be switched on	Radiator fan constantly in operation
	ΞĂ	3	Sr C	Ш	Ú ≩	Дğ	A N	щ S
Rail Pressure Sensor								
Accelerator Position Sensor	3						6	
Mechanical fault in accelerator pedal	2							
EGR			3					
Mass Air Flow Sensor			6					
Air filter clogged			2					
Vacuum system leaking			4					
Turbocharger defective	4							
VGT valve connection	5							
Boost Pressure Sensor	9		5					
Checking timing belt tension								
Clutch switch								
Brake switch								
Vehicle speed signal								
Checking oil level		7						
Radiator fan		·		4				
Radiator defective or clogged				5				
Ignition switch defective					2			
A/CON compressor switch							4	2
A/CON switch							3	
Plug contacts								
Leak in connecting surface between turbochager and Intake manifold								

LXGF504A

#### FAIL-SAFE CHART

When any of the following codes is recorded, the ECM enters into the fail-safe mode.

DTC	Fail-Safe Operation	Deactivation Condition			
P0047	Fuel injection and engine power are restricted.	Normal state is kept for 1.0 sec.			
P0048	Fuel injection and engine power are restricted.	Normal state is kept for 1.0 sec.			
P0069	Boost pressure sensor output is fixed at 1000hPa.	Normal state is kept for 0.5 sec.			
P0097	Intake air temperature sensor(Integrated in BPS) out-				
P0098	put is fixed at 28°C.	Normal state is kept for 0.5 sec.			
P0101	Fuel injection and engine power are restricted.	Normal state is kept for 1.5 sec.			
P0102	Fuel injection and engine power are restricted.	Normal state is kept for 1.0 sec.			
P0103	Boost pressure sensor output is fixed at 1000hPa.	Normal state is kept for 1.0 sec.			
P0107	Parametic propauro is fixed at 1000hDe				
P0108	Barometic pressure is fixed at 1000hPa.	Normal state is kept for 0.5 sec.			
P0112	Intake air temperature sensor(Integrated in MAFS) out-				
P0113	put is fixed at 50°C.	Normal state is kept for 0.5 sec.			
P0117	If DTC being detected after cranking, ECM senses coolant				
P0118	temperature is 80℃. If DTC being detected in cranking, ECM senses coolant temperature is -10℃. • A/C and auxilary heater operation is inhibited.	Normal state is kept for 0.48 sec.			
	Cooling fan keeps being operated.				
P0182	Fuel temperature sensor output is fixed at 40℃.	Normal state is kept for 0.5 sec.			
P0183					
P0192	Rail pressure sensor output is fixed at 330bar.	Normal state is kept for 0.48 sec.			
P0193					
P0237	Boost pressure sensor output is fixed at 1000hPa.	Normal state is kept for 1.0 sec.			
P0238					
P0532	A/C pressure is fixed at 4000hPa.	Normal state is kept for 0.6 sec.			
P0533					
P0562	Battery voltage is fixed at 7.9V.	Normal state is kept for 0.1 sec.			
P0563					
P0642	Engine speed is fixed at 1200 rpm.	Normal state is kept for 0.1 sec.			
P0643	Engine speed is fixed at 1200 rpm.	Normal state is kept for 0.1 sec.			
P0652	Engine speed is fixed at 1200 rpm.     Bail propagate concern subject is fixed at 2001 r	Normal state is kept for 0.1 sec.			
P0653	<ul> <li>Rail pressure sensor output is fixed at 330bar.</li> </ul>				
P0698	A/C pressure is fixed at 4000hPa.	Normal state is kept for 0.1 sec.			
P0699					
P2123	Engine speed is fixed at 1200 rpm.	Normal state is kept for 0.1 sec.			
P2128	Engine speed is fixed at 1200 rpm.	Normal state is kept for 0.1 sec.			
P2138	Engine speed is fixed at 1200 rpm.	Normal state is kept for 0.1 sec.			

## FUEL SYSTEM

DTC	Fail-Safe Operation	Deactivation Condition
P2264	Fuel injection and engine power are restricted.	Soon after normal state
P2299	Engine speed is fixed at 1200 rpm.	Normal state is kept for 0.1 sec.

#### DESCRIPTION E0210BEB

If the Diesel Engine Control system components (sensors, ECM, injector, etc.) fail, interruption to the fuel supply or failure to supply the proper amount of fuel for various engine operating conditions will result. The following situations may be encountered.

- 1. Engine is hard to start or does not start at all.
- 2. Unstable idle.
- 3. Poor driveability

If any of the above conditions are noted, first perform a routine diagnosis that includes basic engine checks (Ignition system malfunction, incorrect engine adjustment, etc.). Then, inspect the Diesel Engine Control system components with the HI-SCAN (Pro).

#### 🛈 ΝΟΤΕ

- Before removing or installing any part, read the diagnostic trouble codes and then disconnect the battery negative (-) terminal.
- Before disconnecting the cable from battery terminal, turn the ignition switch to OFF. Removal or connection of the battery cable during engine operation or while the ignition switch is ON could cause damage to the ECM.
- When checking the generator for the charging state, do not disconnect the battery '+' terminal to prevent the ECM from damage due to the voltage.
- When charging the battery with the external charger, disconnect the vehicle side battery terminals to prevent damage to the ECM.

#### **MALFUNCTION INDICATOR LAMP (MIL)**

#### [EOBD]


A malfunction indicator lamp illuminates to notify the driver that there is a problem with the vehicle. However, the MIL will go off automatically after 3 subsequent sequential driving cycles without the same malfunction. Immediately after the ignition switch is turned on (ON position - do not start), the MIL will illuminate continuously to indicate that the MIL operates normally.

Faults with the following items will illuminate the MIL.

- Mass Air Flow Sensor (MAFS)
- Vacuum Modulator for EGR

# 🗊 ΝΟΤΕ

Refer to "INSPECTION CHART FOR DIAGNOSTIC TROUBLE CODES (DTC)" for more information.



EWPF601N

#### [NON-EOBD]


A malfunction indicator lamp illuminates to notify the driver that there is a problem with the vehicle. However, the MIL will go off automatically after 3 subsequent sequential driving cycles without the same malfunction. Immediately after the ignition switch is turned on (ON position - do not start), the MIL will illuminate continuously to indicate that the MIL operates normally.

Faults with the following items will illuminate the MIL

- EGR
- EEEP ROM
- Injector
- Fuel pressure sensor
- Fuel pressure monitoring
- Variable Geometry Turbocharger(VGT)
- Accelerator Position Sensor (APS)
- Mass Air Flow Sensor (MAFS)
- Fuel pressure regulator

**NOTE** 

Refer to "INSPECTION CHART FOR DIAGNOSTIC TROUBLE CODES (DTC)" for more information.



EWPF601N

#### [INSPECTION]

- 1. After turning ON the ignition key, ensure that the light illuminates for about 5 seconds and then goes out.
- 2. If the light does not illuminate, check for an open circuit in the harness, a blown fuse or a blown bulb.


#### SELF-DIAGNOSIS

The ECM monitors the input/output signals (some signals at all times and the others under specified conditions). When the ECM detects an irregularity, it records the diagnostic trouble code, and outputs the signal to the Data Link connector. The diagnosis results can be read with the MIL or HI-SCAN (Pro). Diagnostic Trouble Codes (DTC) will remain in the ECM as long as battery power is maintained. The diagnostic trouble codes will, however, be erased when the battery terminal or ECM connector is disconnected, or by the HI-SCAN (Pro).

# **NOTE**

If a sensor connector is disconnected with the ignition switch turned on, the diagnostic trouble code (DTC) is recorded. In this case, disconnect the battery negative terminal (-) for 15 seconds or more, and the diagnosis memory will be erased.

THE RELATION BETWEEN DTC AND DRIVING PATTERN IN EOBD SYSTEM



- 1. When the same malfunction is detected and maintained during two sequential driving cycles, the MIL will automatically illuminate.
- 2. The MIL will go off automatically if no fault is detected after 3 sequential driving cycles.


LGGE150A

- 3. A Diagnostic Trouble Code(DTC) is recorded in ECM memory when a malfunction is detected after two sequential driving cycles. The MIL will illuminate when the malfunction is detected on the second driving cycle.
- 4. A Diagnostic Trouble Code(DTC) will automatically erase from ECM memory if the same malfunction is not detected for 40 driving cycles.

# **NOTE**

- A "warm-up cycle" means sufficient vehicle operation such that the coolant temperature has risen by at least 40 degrees Fahrenheit from engine starting and reaches a minimum temperature of 160 degress Fahrenheit.
- A "driving cycle" consists of engine startup, vehicle operation beyond the beginning of closed loop operation.


#### COMPONENTS E987D34A





- 1. Mass Air Flow Sensor (MAFS)
- 2. Intake Air Temperature Sensor1 (IATS1)
- 3. Engine Coolant Temperature Sensor (ECTS)
- Camshaft Position Sensor (CMPS)
   Crankshaft Position Sensor (CKPS)
- 6. Rail Pressure Sensor (RPS)
- 7. Boost Pressure Sensor (BPS)
- 8. Accelerator Position Sensor (APS)
- 9. Vehicle Speed Sensor (VSS)
- 10. Injector
- 11. VGT solenoid valve


- 12. EGR Valve
- 13. Fuel Pressure Regulator Valve
- 14. Main Relay
- 15. ECM
- 16. DLC (Data Link Connector)
- 17. Throttle Flap solenoid valve
- 18. Variable Swirl Valve Actuator
- 19. Rail Pressure Control Valve
- 20. Heated Oxygen Sensor (HO2S)
- 21. Fuel Temperature Sensor 22. Intake Air Temperature Sensor2 (IATS2)

EWPF600A










## ENGINE CONTROL MODULE

#### ECM E241F76D

#### 1. ECM HARNESS CONNECTOR



#### 2. ECM TERMINAL FUNCTION

#### < C201-1 CONNECTOR >

PIN	FUNCTION	CONNECTED TO
1	Injector for Cylinder3(high side)	Injector3
2	Injector for Cylinder2(high side)	Injector2
3	N.A	-
4	Rail pressure control valve supply from BAT+a	Rail pressure control valve
5	N.A	<ul> <li>State 2 Structure (State 2 State 2 Structure)</li> </ul>
6	Variable swirl valve position sendor Ground	Variable swirl valve
7	Crankshaft position sensor shield	Crankshaft position sensor
8	Rail pressure sensor ground	Rail pressure sensor
9	N.A	-
10	N.A	-
11	N.A	-
12	Crankshaft sensor minus signal:AT Crankshaft sensor plus signal:MT	Crankshaft position sensor
13	Boost pressure sensor supply	Boost pressure sensor
14	N.A	-
15	N.A	-
16	Injector for Cylinder1(high side)	Injector1
17	Injector for Cylinder4(high side)	Injector4
18	N.A	-
19	Fuel pressure regulator valve "high side"(MPROP)	Fuel pressure regulator valve
20	Camshaft position sensor ground	Camshaft position sensor
21	N.A	-

PIN	FUNCTION	CONNECTED TO
22	N.A	-
23	Boost pressure sensor ground	Boost pressure sensor
24	N.A	-
25	N.A	-
26	Variable swirl valve position sensor supply	Variable swirl valve
27	Crankshaft sensor minus signal:MT Crankshaft sensor plus signal:AT	Crankshaft position sensor
28	Rail pressure sensor supply	Rail pressure sensor
29	N.A	-
30	Variable swirl valve motor(-)	Variable swirl valve
31	Injector for Cylinder2(low side)	Injector2
32	N.A	-
33	Injector for Cylinder4(low side)	Injector4
34	Rail pressure control valve (low side)	Rail pressure control valve
35	N.A	-
36	N.A	-
37	Mass Air Flow Sensor Reference Frequency	Mass Air Flow Sensor
38	N.A	-
39	N.A	-
40	Boost pressure sensor signal	Boost pressure sensor
41	Engine Coolant temperature sensor ground	Engine Coolant temperature sensor
42	Mass Air Flow sensor signal	Mass Air Flow sensor
43	Rail pressure sensor signal	Rail pressure sensor
44	Mass Air Flow sensor ground	Mass Air Flow sensor
45	N.A	-
46	Injector for Cylinder3(low side)	Injector3
47	Injector for Cylinder1(low side)	Injector1
48	N.A	-
49	Fuel pressure regulator valve "low side"(MPROP)	Fuel pressure regulator valve
50	Camshaft position sensor signal	Camshaft position sensor
51	N.A	-
52	N.A	-
53	Intake Air Temperature Sensor signal(Integrated in BPS)	Boost pressure sensor
54	N.A	-
55	N.A	-
56	Variable swirl valve position sensor signal	Variable swirl valve
57	N.A	-
58	Engine Coolant temperature sensor signal	Engine Coolant temperature sensor

PIN	FUNCTION	CONNECTED TO
59	Linear EGR control	EGR
60	Variable swirl valve motor(+)	Variable swirl valve

#### < C201-2 CONNECTOR >

1	Battery plus via Fuse(10A)	Main relay
2	ECM ground	ECM ground
3	Battery plus via Fuse(20A)	Main relay
4	ECM ground	ECM ground
5	Battery plus via Fuse(20A)	Main relay
6	ECM ground	ECM ground
7	Fan High	A/C fan relay
8	Accelerator position sensor 2 ground	Accelerator position sensor
9	Accelerator position sensor 1 signal	Accelerator position sensor
10	Fuel temperature sensor ground	Fuel temperature sensor
11	Fuel temperature sensor signal	Fuel temperature sensor
12	A/C Pressure Transducer ground	A/C Pressure Tranducer
13	A/C Pressure Transducer signal	A/C Pressure Tranducer
14	N.A	-
15	N.A	
16	Immobilizer SMARTRA ground	Immobilizer
17	NA OPAR OPPODE DE SE	Real Andrewski (1997) and an and a second and a
18	N.A	
19	N.A	-
20	N.A	-
21	N.A	-
22	A/C Pressure Transducer supply	A/C Pressure Tranducer
23	N.A	-
24	Cruise Control Supply	Cruise control unit
25	ISO-K interface	Diagnostic link connector
26	N.A	-
27	Fuel consumption signal	Trip computer
28	Terminal 15(switched bat.+)	Ignition key
29	VGT control	VGT solenoid valve
30	Accelerator position sensor 1 ground	Accelerator position sensor
31	Accelerator position sensor 2 signal	Accelerator position sensor
32	N.A	-
33	N.A	-
34	N.A	-
35	N.A	-

36	N.A	-
37	N.A	-
38	Brake main switch signal	Brake switch
39	N.A	-
40	Water sensor signal	Water sensor
41	N.A	-
42	Blower switch input signal	Blower switch
43	N.A	-
44	N.A	-
45	Accelerator position sensor 1 supply	Accelerator position sensor
46	Accelerator position sensor 2 supply	Accelerator position sensor
47	Immobilizer imterface	Immobilizer
48	Engine speed output signal	Tachometer
49	Cruise Control Set Lamp	Cluster
50	N.A	-
51	Heated oxygen sensor heater control	Heated oxygen sensor
52	N.A	-
53	N.A	-
54	A/C switch ON signal	A/C switch
55	N.A	
56	A/C compressure switch signal input	A/C compressure switch
57	Neutral recognition switch signal input	Neutral recognition switch
58	N.A	-
59	N.A	-
60	N.A	-
61	N.A	-
62	N.A	-
63	N.A	-
64	Heated oxygen sensor supply	Heated oxygen sensor
65	Heated oxygen sensor current pump	Heated oxygen sensor
66	N.A	-
67	N.A	-
68	Malfunction indication lamp (MIL)	Cluster
69	Glow indication lamp	Cluster
70	A/C compressor relay control	A/C compressor relay
71	Fan Low	Radiator fan relay
72	Main relay control	Main relay
73	N.A	-
74	N.A	-
75	Vehicle speed sensor signal	Vehicle speed sensor

76	N.A	- :
77	N.A	-
78	N.A	-
79	Clutch switch signal	Clutch switch
80	Redundant brake switch signal	Brake switch
81	MT/AT Auto Recognition	MT/AT Auto Recognition switch
82	N.A	-
83	CAN LOW	ТСМ
84	CAN HIGH	ТСМ
85	N.A	-
86	Heated oxygen sensor ground	Heated oxygen sensor
87	Heated oxygen sensor signal	Heated oxygen sensor
88	N.A	-
89	Intake air temperature sensor signal	Intake air temperature sensor
90	Throttle flap control	Throttle flap solenoid valve
91	Cruise Control on Lamp(Low Side)	Cluster
92	Immobilizer indication lamp	Cluster
93	Glow relay control	Glow relay
94	Auxiliary electric heater control	Auxiliary electric heater

#### 3. ECM TERMINAL INPUT/OTPUT SIGNAL

#### < C201-1 CONNECTOR >

Pin	PinDescription	Vahiala atatua	Chook status	Inp	ut/Output signal
PIII		Vehicle status	Check status	Туре	Level
1	Injector for Cylinder3(high side)	Engine running	Injector operation	Current	17 - 19А 0А LGJF500Р
2	Injector for Cylinder2(high side)	Engine running	Injector operation	Current	0A LGJF500P
3	N.A				
4	Rail pressure control valve supply from BAT+a	Ignition ON	All	DC	Vbatt
5	N.A				
6	Variable swirl valve position sendor Ground	All	All		Ground (0 ~ 0.5 Volt)
7	Crankshaft position sensor shield	All	All		Ground (0 ~ 0.5 Volt)
8	Rail pressure sensor ground	All	All		Ground (0 ~ 0.5 Volt)
9	N.A				

Din	DipDoporintion	Vahiele status	Charle status	Inp	out/Output signal
Pin	PinDescription	Vehicle status	Check status	Туре	Level
10	N.A				
11	N.A				
12	Crankshaft sensor minus signal:AT Crankshaft sensor plus signal:MT	Engine running	All	Sine wave	Above 1.65V Below -1.65V LGJF500O
13	Boost pressure sensor supply	Ignition ON	All	DC	4.9 ~ 5.1 Volt
14	N.A				
15	N.A				
16	Injector for Cylinder1(high side)	Engine running	Injector operation	Current	0A LGJF500P
17	Injector for Cylinder4(high side)	Engine running	Injector operation	Current	
18	N.A	на н		-	
19	Fuel pressure regulator valve "high side"(MPROP)	Engine running	All	PWM 172~185Hz	U batt
20	Camshaft position sensor ground	All	All		Ground (0 ~ 0.5 Volt)
21	N.A				
22	N.A				
23	Boost pressure sensor ground	All	All		Ground (0 ~ 0.5 Volt)
24	N.A				
25	N.A				
26	Variable swirl valve position sensor supply	Ignition ON	All	DC	4.9 ~ 5.1 Volt
27	Crankshaft position sensor minus signal:MT Crankshaft position sensor plus signal:AT	Engine running	All	Sine wave	
28	Rail pressure sensor supply	Ignition ON	All	DC	4.9 ~ 5.1 Volt
29	N.A				
30	Variable swirl valve motor(-)	Ignition ON	All	PWM 1000Hz	↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓
31	Injector for Cylinder2(low side)				
32	N.A				

Pin	PinDescription	Vehicle status	Check status	Ing	out/Output signal
				Туре	Level
33	Injector for Cylinder4(low side)				
34	Rail pressure control valve (low side)	Engine running	All	PWM 1kHz	V batt 
35	N.A				
36	N.A		· · · · · · · · · · · · · · · · · · ·		
37	Mass Air Flow Sensor Reference Frequency	Ignition ON	All	PWM 19Hz	5V 0 ~ 0.5 V LGJF500L
38	N.A		·		
39	N.A				
40	Boost pressure sensor signal	Ignition ON	All	Analog	4.8V 0.2V LGJF500I
41	Engine Coolant temperature sensor ground	All	All		Ground (0 ~ 0.5 Volt)
42	N.A		All	Pulse	→ → → → → → → → → → → → → → → → → → →
		Notes to the set of th	A CARLEY AND A CAR	. 4. (	LGJF500L
43	Rail pressure sensor signal	Engine running		Analog	4.5V 0.5V
		A 11			LGJF500J
44 45	Mass Air Flow sensor ground	All	All		Ground (0 ~ 0.5 Volt)
46	Injector for Cylinder3(low side)				
47	Injector for Cylinder1(low side)				
48	N.A			r	
49	Fuel pressure regulator valve "low side"(MPROP)	Engine running	All	PWM 1kHz	V batt 0 - 0.5 V LGJF500K
50	Camshaft position sensor signal	Engine running	All	Analog	4.8 - 24V Below 0.6V LGJF500N
51	N.A				
52	N.A				

	DipDescription	Vehiele status	Charly status	Input/Output signal	
Pin	PinDescription	Vehicle status	Check status	Туре	Level
53	Intake Air Temperature Sensor signal(Integrated in BPS)	Ignition ON	All	Analog	4.5V 0.5V LGJF500J
54	N.A				
55	N.A				
56	Variable swirl valve position sensor signal	Ignition ON	All	Analog	4.5V 
57	N.A				
58	Engine Coolant temperature sensor signal	Ignition ON	20deg/80deg	Analog	above3.5V/below1.8V
59	Linear EGR control	Engine running	All	PWM 140Hz	UgjF500K
60	Variable swirl valve motor(+)	Ignition ON	All	PWM 1000Hz	↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓

#### < C201-2 CONNECTOR >

1	Battery plus via Fuse(10A)	Ignition ON	All	DC	V batt
2	ECM ground	All	All		Ground (0 ~ 0.5 Volt)
3	Battery plus via Fuse(20A)	Ignition ON	All	DC	V batt
4	ECM ground	All	All		Ground (0 ~ 0.5 Volt)
5	Battery plus via Fuse(20A)	Ignition ON	All	DC	V batt
6	ECM ground	All	All	2000	Ground (0 ~ 0.5 Volt)
7	Fan High	Engine running	fan on/off	DC	0~0.5V/Vbatt
8	Accelerator position sensor 2 ground	All	All		Ground (0 ~ 0.5 Volt)
9	Accelerator position sensor 1 signal	Ignition ON	IDLE/WOT	Analog	0.6~0.85V/3.5~4.7V
10	Fuel temperature sensor ground	All	All		Ground (0 ~ 0.5 Volt)
11	Fuel temperature sensor signal	Ignition ON	All	Analog	4.8V 0.2V LGJF500I
12	A/C Pressure Transducer ground	All	All		Ground (0 ~ 0.5 Volt)
13	A/C Pressure Transducer signal	Ignition ON	All	Analog	4.8V 0.2V LGJF500I


14	N.A			;	
15	N.A				· · ·
16	Immobilizer SMARTRA ground	All	All		Ground (0 ~ 0.5 Volt)
17	N.A				
18	N.A				
19	N.A				
20	N.A				
21	N.A				
22	A/C Pressure Transducer supply	Ignition ON	All	DC	4.9 ~ 5.1 Volt
23	N.A				
24	Cruise Control Supply	Ignition ON	All	DC	V batt
25	ISO-K interface				
26	N.A				· ·
27	Fuel consumption signal	Engine running	All	Pulse	3.8V 0 ~ 0.5 V LGJF500M
28	Terminal 15(switched bat.+)	Ignition ON	All	DC	V batt
29	VGT control	Engine running	All	PWM 300 Hz	V batt 0 - 0.5 ∨ LGJF500K
30	Accelerator position sensor 1 ground	All	All		Ground (0 ~ 0.5 Volt)
31	Accelerator position sensor 2 signal	Ignition ON	IDLE/WOT	Analog	0.25~0.51V/1.6~2.5V
32	N.A				
33	N.A				
34	N.A		· · · ·		
35	N.A				
36	N.A			ĺ.	
37	N.A				
38	Brake main switch signal	Ignition ON	Brake press / release	DC	Vbatt / 0~0.5V
39	N.A				·
40	Water sensor signal	Ignition ON	ON / OFF	DC	0~0.5V / Vbatt
41	N.A				
42	Blower switch input signal	Ignition ON	ON / OFF	DC	0~0.5V / Vbatt
43	N.A		,		
44	N.A				
45	Accelerator position sensor 1 supply	Ignition ON	All	DC	4.9 ~ 5.1 Volt

46	Accelerator position sensor 2 supply	Ignition ON	All	DC	4.9 ~ 5.1 Volt
47	Immobilizer imterface				
48	Engine speed output signal	Engine running	All	Pulse	V batt 0 ~ 0.5 ∨ LGJF500K
49	Cruise Control Set Lamp	Engine running	ON / OFF	DC	0~0.5V / Vbatt
50	N.A				
51	Heated oxygen sensor heater control	Engine running & Hearter ON	All	PWM 100Hz	V batt 0 ~ 0.5 ∨ LGJF500K
52	N.A				
53	N.A				
54	A/C switch ON signal	Engine running	Switch ON / OFF	DC	Vbatt / 0~0.5V
55	N.A				
56	A/C compressure switch signal input	Engine running	Switch ON / OFF	DC	Vbatt / 0~0.5V
57	Neutral recognition switch signal input	Ignition ON	Neutral / other gear	DC	0~0.5V / Vbatt
58	N.A				
59	N.A				
60	N.A				
61	N.A				
62	N.A				
63	N.A				
64	Heated oxygen sensor supply	Engine running & Hearter ON	All	DC	~ 3.0 V
65	Heated oxygen sensor current pump	Engine running & Hearter ON	All	DC	
66	N.A				
67	N.A	· · · · · · · · · · · · · · · · · · ·			
68	Malfunction indication lamp (MIL)	Ignition ON	ON / OFF	DC	0~0.5V / Vbatt
69	Glow indication lamp	Ignition ON	ON / OFF	DC	0~0.5V / Vbatt
70	A/C compressor relay control	Ignition ON	ON / OFF	DC	0~0.5V / Vbatt
71	Fan Low	Engine running	ON / OFF	DC	0~0.5V/ Vbatt
72	Main relay control	Ignition ON	ON / OFF	DC	0~0.5V / Vbatt
73	N.A				
74	N.A				

75	Vehicle speed sensor signal	Vehicle running	ALL	Pulse	V batt 0 - 0.5 V LGJF500K
76	N.A				
77	N.A	· ·			
78	N.A				
79	Clutch switch signal	Ignition ON	Press / Release	DC	0~0.5V / Vbatt
80	Redundant brake switch signal	Ignition ON	Brake press / release	DC	0~0.5V / Vbatt
81	MT/AT Auto Recognition	Ignition ON	MT / AT	DC	Vbatt / 0~0.5V
82	N.A				
83	CAN LOW				
84	CAN HIGH				
85	N.A				
86	Heated oxygen sensor ground	Engine running & Hearter ON	All	DC	~ 2.5 V
87	Heated oxygen sensor signal	Engine running & Hearter ON	All	DC	
88	N.A	· · · · · · · · · · · · · · · · · · ·			
89	Intake air temperature sensor signal	Ignition ON	All	Analog	4.8V 0.2V LGJF500I
90	Throttle flap control	Ignition ON	Ignition OFF	PWM 300Hz	
91	Cruise Control on Lamp(Low Side)	Vehicle running	ON / OFF	DC	0~0.5V / Vbatt
92	Immobilizer indication lamp	Ignition ON	ON / OFF	DC	0~0.5V / Vbatt
93	Glow relay control	Ignition ON	ON / OFF	DC	0~0.5V / Vbatt
94	Auxiliary electric heater control	Engine running	ON / OFF	DC	0~0.5V / Vbatt

**FUEL SYSTEM** 

#### CIRCUIT DIAGRAM ED1887E2



EWPF601T

	ECM	]
MIL		
Glew lamp		
Glow lamp	69(C201-2)-GLOW LAMP CONTROL	
BATTERY(+) after IG key		
Refer to "Blower & A/C"		
	71(C201-2)-FAN LOW	4
	47(C201-2))-IMMOBILIZER DATA LINE	
lyin	16(C201-2)-IMMOBILIZER GND	
↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓		
Immobilizer lamp		
	92(C201-2)-IMMOBILIZER LAMP CONTROL	
Battery(+)	CONTROL	
Engine Coolant Temp. Sensor(ECTS)		
	58(C201-1)-ECTS SIGNAL	
to Cluster		in the state
3	41(C201-1)-ECTS GND	
Boost Pressure Sensor(BPS)		
4	23(C201-1)-BPS GND	- 
	53(C201-1)-IATS SIGNAL	
	13(C201-1) - BPS SUPPLY(+5V)	
	40(C201-1)-BPS SIGNAL	
		- 
Accelerator Position Sensor(APS)	45(C201-2)-APS1 SUPPLY	н 1997 на 19 година — Прила Парана, прила 19 година — Прила Парана, прила Парана, прила Парана, прила Парана, прила Парана 19 година — Прила Парана, пр
6		
2	9(C201-2)-APS1 SIGNAL	e a
	30(C201-2)-APS1 GND	
	46(C201-2)-APS2 SUPPLY	
	31(C201-2)-APS2 SIGNAL	
4	8(C201-2)-APS2 GND	1
Rail Pressure Sensor(RPS)		
3		
	28(C201-1)-RPS SUPPLY(+5V)	
	43(C201-1)-RPS SIGNAL	
Crankshaft Position Sensor(CKPS)		
	12(C201-1)-CKPS SIGNAL( - ):AT/( + ):MT	
	27(C201-1)-CKPS SIGNAL( + ):AT/( - ):MT	
	7(C201-1)-CKPS SHIELD GND	
Mass Air Flow Sensor(MAFS)	44(C201-1)-MAFS GND	
2	-	
	89(C201-2)-IATS SIGNAL	
5	42(C201-1)-MAFS SIGNAL	
Battery(+)		
	37(C201-1)-MAFS REFERANCE FREQUENCY	


EWPF601U

FUEL SYSTEM

Rail Pressure Control Valve	ECM	
	4(C201-1)-RAIL PRESSURE CONTROL VALVE(HIGH SIDE)	
Fuel Pressure Regulator Valve	34(C201-1)-RAIL PRESSURE CONTROL VALVE(LOW SIDE)	
	19(C201-1)-FUEL PRESSURE REGULATOR VALVE(HIGH SIDE)	
	49(C201-1)-FUEL PRESSURE REGULATOR VALVE(LOW SIDE)	ъ.,
EGR Control Solenoid Valve	59(C201-1)-EEGR CONTROL	
After Main Relay		
	29(C201-2)-VGT CONTROL	
After Main Relay		
Throttle Flap Actuator	90(C201-2)-THROTTLE FLAP CONTROL	
After Main Relay		
	- 16(C201-1)-INJECTOR 1(HIGH SIDE)	
	47(C201-1)-INJECTOR 1(LOW SIDE)	
	-1(C201-1)-INJECTOR 3(HIGH SIDE)	
	46(C201-1)-INJECTOR 3(LOW SIDE)	
	33(C201-1)-INJECTOR 4(LOW SIDE)	
	2(C201-1)-INJECTOR 2(HIGH SIDE)	
	31(C201-1)-INJECTOR 2(LOW SIDE)	
Vehicle Speed Signal	75(C201-2)-VEHICLE SPEED	
	84(C201-2)-CAN HIGH	
	83(C201-2)-CAN LOW	
	48(C201-2)-ENGINE SPEED	
	81(C201-2)-MT/AT RECOGNITION S/W(AT ONLY)	
	27(C201-2)-FUEL CONSUMPTION	
	94(C201-2)-PTC HEATER CONTROL	
	25(C201-2)-DIAGNOSIS LINE (K-LINE)	
Neutral switch	57(C201-2)-NEUTRAL S/W SIGNAL(MT ONLY)	
Clutch switch	79(C201-2)-CLUTCH S/W SIGNAL(MT ONLY)	

EWPF601V

FLB -53



EWPF601W

#### ECM PROBLEM INSPECTION PROCEDURE E36DBCA4

 TEST ECM GROUND CIRCUIT: Measure resistance between ECM and chassis ground using the backside of ECM harness connector as ECM side check point. If the problem is found, repair it.

Specification (Resistance) Between terminal 2 of C201-2 connector and chassis ground :  $1\Omega$  or less Between terminal 4 of C201-2 connector and chassis ground :  $1\Omega$  or less Between terminal 6 of C201-2 connector and chassis ground :  $1\Omega$  or less


- 2. TEST ECM CONNECTOR: Disconnect the ECM connector and visually check the ground terminals on ECM side and harness side for bent pins or poor contact contact pressure. If the problem is found, repair it.
- 3. If problem is not found in Step 1 and 2, the ECM could be faulty. If so, replace the ECM with a new one, and then check the vehicle again. If the vehicle operates normally then the problem was likely with the ECM.
- 4. RE-TEST THE ORIGINAL ECM : Install the original ECM (may be broken) into a known-good vehicle and check the vehicle. If the problem occurs again, replace the original ECM with a new one. If problem does not occur, this is intermittent problem (Refer to INTERMITTENT PROBLEM PROCEDURE in BASIC INSPECTION PROCEDURE)

#### REPLACEMENT EC1BE30E

#### 


When exchanging ECMS, be sure to input injector data (7 digits) of each cylinder into a new ECM using a Hi-scan(pro).

- 1. After turning ignition switch off, wait for 30sec..
- 2. Remove the battery cable(-).
- 3. Remove the ECM connector.



EWPF600S


- 4. Remove the ECM from the air cleaner assembly.
- 5. Install a new ECM with air cleaner assembly.
- 6. Fasten four mounting bolts.
- 7. Using a Hi-scan(pro), input the injector data (7 digits) into a new ECM as next procedure.



## ENGINE COOLANT TEMPERATURE SENSOR (ECT)

#### DESCRIPTION E4D48A54

The ECTS is located in the engine coolant passage. It detects the coolant temperature and sends to the ECM. It has a thermistor which is sensitive to change according to the coolant temperature. The electric resistance of a thermistor decreases in response to temperature rise. The ECM uses this information to control the injection quantity and fan operation.



AFGF300F

EFNF537A

#### SPECIFICATION


Between Pin 1 and 3 (For ECTS)

Temperature °C (°F)	Sensor Resistance ( <sup>k</sup> Ω)
-20 (-4)	14.13 ~16.83
0 (32)	5.79
20 (68)	2.31 ~ 2.59
40 (104)	1.15
60 (140)	0.59
80 (176)	0.32
100 (212)	0.19
110 (230)	0.15
120 (248)	0.17

#### Between Pin 1 and 2 (For Gauge)

Temperature ℃ (°F)	Sensor Resistance (Ω)
60 (140)	125
85 (185)	42.6 ~ 54.2
110 (230)	22.1 ~ 26.2
125 (257)	15.2

#### **CIRCUIT DIAGRAM**




EWPF601X

#### SIGNAL WAVEFORM

FR	CH A	0.5 (	5.	0 S	CH E	1.0	U
:	: :		: :	÷			÷
. i		(*************************************	ġuneşner Çî	3ğı 2 - 3	** <b>5</b>	} {	
		÷	ļ				·· [····· {····
		1	* ÷	: ::::::::::::::::::::::::::::::::::::		; ;+;;,;	.;
	،،،،،،،،،،،،،،،،،،،،،،،،،،،،،،،،،،،،،	*******	د		,	v-s-Jeven	witz,
			- 6				·  ·····
	¦	ķ	t : 2	: 		; 	·!;
b			 	: 			
P				Ē	: :		
In	01.0 2	zoon	CURS	MEr	O REC	m a	ENU


#### COMPONENT INSPECTION

- 1. Remove the ECTS from the engine coolant passage.
- 2. With the temperature sensing portion of the ECTS immersed in hot engine coolant, check the resistance.(Refer to "SPECIFICATION")




EFNF541A

<Sensor connector>



LGJF500W

3. If the resistance deviates from the standard value greatly, replace the sensor.



EFNF539A


FLB -57

## CAMSHAFT POSITION SENSOR (CMP)

#### DESCRIPTION E84EAA29


CMPS detects the teeth target wheel and provides ECM with the information on the current position of piston and cylinder.

ECM uses this signal to determine the fuel injection timing and ignition timing.



EWPF600C

#### CIRCUIT DIAGRAM



#### SIGNAL WAVWFORM

At	CHIA	2.0	V 2.0	l ms	CH B	5.0V
			: : CMP re	forono	i i i	
ແມສເລກເມ		n in in			e point	
			ļ			
				ļ		·····
Þ		·••			: المعليجية 	
- <b>A</b> -A-	Å A A	Å-A-A-P	A	A A A I	-	AAAAA
VVl	似我	444		WW		VV-VV-V-V
		- Çeseri ( 22.22		»	(1 x x x x x ) 1 x x x x x y	
na in the second se Second second		CK	P refere	ence po	oint	
÷.						

This illustration shows waveform of Crankshaft Position Sensor(CKPS) and Camshaft Position Sensor(CMPS) simultaneously. The middle area indicates reference points of CKPS and CMPS.


LGJF500Y

## CRANKSHAFT POSITION SENSOR (CKP)

#### DESCRIPTION E2F286D2

Piston position on combustion chamber is the substantial to define the starting of injection timing. All engine pistons are connected to crankshaft by connecting rod. Sensor on crankshaft can supply the informations concerning all piston positions, revolution speed is defined by revolution per minute of crankshaft. Prior input variable is determined at ECM by using signal induced from crankshaft position sensor.as

#### **CIRCUIT DIAGRAM**



 CKPS
 ECM

 Image: Side
 Image: Side

 CKPS
 Call

 Image: Side

 CKPS

 Image: Side

 CKPS

 Image: Side

 Image: Side

#### SIGNAL WAVEFORM

At	CH A	2.0	V 2	. Ø	mS	01	:	5.0	U
			CMP	ref	erenc	i i	nt "		*****
ستجت	فسيقمده	سأحتمن				- poi	مذور	بەل چىدى	بمنسحة
							-		
۵							Ĵ		
.A.A.	Å . A . A .	л.д.Д.	۸À	A	A A .	1.A.A		<b>Λ.Α.</b> Δ.	n
	Q/Q/	WД		۱.	山			ΨŲ	V.U.
V-V-V	₩.₩.Ψ	¥ V V	-  <b> </b>   }	J.	V V V	<b>₩</b> ₩	Ψ¥	₩¥ V	. h. h.
	1 7	1 1	KP refe			· ·			

This illustration shows waveform of Crankshaft Position Sensor(CKPS) and Camshaft Position Sensor(CMPS) simultaneously. The middle area indicates reference points of CKPS and CMPS.

LGJF500Y

EWPF600D


# AIR FLOW SENSOR (MAF AND IAT)

#### DESCRIPTION E1EA208B

MAFS uses a hot-film type sensing element to measure the mass of intake air entering the engine, and send the signal to ECM.

A large amount of intake air represents acceleration or high load conditions while a small amount of intake air represents deceleration or idle.

The ECM uses this information to control the EGR solenoid valve and correct the fuel amount.



#### SPECIFICATION


ntake Air Temperature: 20 °C					
Frequency (KHz)					
1.96 ~ 1.97					
2.01 ~ 2.02					
2.50 ~ 2.52					
3.18 ~ 3.23					
4.26 ~ 4.35					
7.59 ~ 7.94					
9.08 ~ 9.89					

## Intake Air Temperature: 80 °C Mass air flow (kg/h) Frequency (KHz)

	1
10	2.00 ~ 2.02
40	2.49 ~ 2.53
105	3.16 ~ 3.25
480	7.42 ~ 8.12


LGJF501B

#### **CIRCUIT DIAGRAM**



#### SIGNAL EAVEFORM

EWPF602A



#### COMPONENT INSPECTION


- 1. Check the MAFS visually.
  - Mounting direction correct.
  - Any contamination, corrosion or damage on connector.
  - Air cleaner's clogging or wet.
  - MAFS cylinder's deforming or blocking by any foreign material.
- 2. Check any leakage on intake system and intercooler system.

LGJF501C

## RAIL PRESSURE SENSOR (RPS)

#### DESCRIPTION EOFE1EGD

In order to output a voltage signal to the ECM which corresponds to the applied pressure, the rail pressure sensor must measure the instantaneous pressure in the rail. The fuel flows to the rail pressure sensor through an opening in the rail, the end of which is sealed off by the sensor diaphragm. Pressurized fuel reaches the sensor's diaphragm through a blind hole. The sensor element (semiconductor device) for converting the pressure to an electric signal is mounted on this diaphrgam. The signal tenerated by the sensor is inputted to an evaluation circuit which amplifies the measuring signal and sends it to the ECM.




AWJF300I

#### SPECIFICATION

	Engine idle state	Available maximum detecting pressure	
Rail Pressure	220 ~ 320 bar (22 ~ 32Mpa)	1500bar (150Mpa)	
Signal Voltage	below 1.7V	Approx. 4.5V	

#### CIRCUIT DIAGRAM



#### FLB -63

#### SIGNAL WAVEFORM

FR	CH (	1.0	J 200	mS	CH B	1.0 V
:	: :			; ;		÷ ÷ ÷
2110)-Ç14174 	-Erreradore 	* * * Çewer * * * * * * * * * *	1 i f			•••{}•••••••••;••••••;••••• •••• •••• ••
·····	 i i	····				
AF	S1:	signal		annstanne I		
دورونې د دورو ماله وې محمد و			<u>in the second s</u>		·····	، مېرىكى مېرىكى مېرى مېرىكى مېرىكى
·						
			· · · · · · · · · · · · · · · · · · ·			
	PS sig	gnal 🔆 🗠	កំណត់ពាលឆ្នំ	فستشتر		k
<del>ار زمي</del>	<u>į najo</u>	<del>nine</del> ja-	<u> </u>	<u> </u>		م الم مغالم
D	į. Ž					
				: :	l Commu	Inant
F	IX	PART	FULL	HELF	GRPH	RCRD

Rail Pressure Sensor (RPS) is to provide to the ECM the voltage signal corresponding to rail pressure. The change in resistance is preportional to the rail pressure acting upon the diaphragm and rail pressure increases as load increases.

EFNF550A


## **BOOST PRESSURE SENSOR**

#### DESCRIPTION E564B29A

Boost pressure sensor (BPS) is installed on surge tank to measure the absolute intake manifold pressure.

BPS input voltage is changed in proportion with absolute pressure in manifold.

This information is used to control Variable Geometery Turbocharger(VGT) by ECM.



#### EWPF600E

#### SPECIFICATION

Pressure (Kpa)	Output Voltage (V)
70	1.02 ~ 1.17
140	2.13 ~ 2.28
210	3.25 ~ 3.40
270	4.20 ~ 4.35

#### **CIRCUIT DIAGRAM**

BPS & IATS 2 4 C201-1(23) GROUND з C201-1(53) IATS1 Signal 2 C201-1(13) 1 5V supply C204 Harness side C201-1(40) 1 **BPS** signal

EWPF602C

LGJF501E

#### SIGNAL WAVEFORM

FR	CH (	1.6	) V	2(5)	) mS	C	HB	0.5	V	
÷	: :	: :	:	:	:	:	:	:	•	
nançure L	identiniĝos E E	nnistieweri   	******	aleinna -	≩errra‡ozá ⊒	11 X ( 444 6 6 )	(******)	11113(2011) <u>2</u>	13286911 2	14+2 ? I
		····						····	- - -	
····		į		÷	}		<u> </u>	····		
		···* Pa	: ost Pi	:	: : uro Sc	;		~~! <sup></sup>		
									 	380.01
					مريني مريد	londe .		÷	-	
		-	-	, <b>A</b> <i>A</i>	x 4 x 4	;	NC-		متديرميه	بقيتونا
 }			 		 		‡	····	-	
		<u>i</u> i	·····			•••	·	····è····		
1999-0-1110 N		********					1			
:	-		:	:	: :	:		<u> </u>		
	end)	<b>Z00</b> r	1 <b>(</b> 1	1885	MEM	0	RECI	DIM	enu	


This illustration represents waveform of BPS when accelerating and decelerating.

EFNF553B

## AIR TEMPERATURE SENSOR(ATS)

#### DESCRIPTION E4531124


Intake Air Temperature Sensor (IATS) is Negative Temperature Charcteristics(NTC) thermistor which is installed into both Mass Air Flow Sensor(MAFS) and Boost Pressure



Sensor(BPS), It senses intake air temperature which are installed in front of turbocharger (inside of MAFS) and behind it (inside of BPS).

Comparing air temperature from both sensors (one is intake air temperature, the other is air temperature passing through turbo charger), more accurate sensing of intake air temperature is possible.

ECM uses intake air temperature signal to performs EGR control correction and fuel injection quantity correction.



EWPF600T

#### SPECIFICATION


#### [IATS (INSTALLED INTO BPS)]


Temperature ℃(°F)	Resistance(kΩ )				
-20(-4)	13.89 ~ 16.03				
-10(14)	8.50 ~ 9.71				
0(32)	5.38 ~ 6.09				
10(50)	3.48 ~ 3.90				
20(68)	2.31 ~ 2.57				
30(86)	1.56 ~ 1.74				
40(104)	1.08 ~ 1.21				
50(122)	0.76 ~ 0.85				
60(140)	0.54 ~ 0.62 0.40 ~ 0.45				
70(158)					
80(176)	0.29 ~ 0.34				
90(194)	0.22 ~ 0.26				
100(212)	0.17 ~ 0.20				
110(230)	0.13 ~ 0.15				
120(248)	0.10 ~ 0.12				
130(266)	0.08 ~ 0.10				

#### [IATS (INSTALLED INTO MAFS)]

Temperature℃(°F)	Resistance(kΩ )
-20	12.66 ~ 15.12
0	5.2 ~ 5.9
20	2.29 ~ 2.55
80	0.31 ~ 0.37

#### CIRCUIT DIAGRAM






#### SIGNAL WAVEFORM

FR	CH (	1.0	V S	0 S	CH B 1	.0V
		: :				
						÷
						<u>;    ;    ;    ;</u> .
-						
····÷···	·!···:	···:{·····.	******		····•	÷····•
						;;;;
÷	÷ ÷	÷ ÷	÷ ÷			: : :
•••••	·••••	••••	•••••••		····	·····
	.j				····;····.	
	ni an in					๛๛๛๛๛๛๛๛๛๛๛๛๛๛๛๛๛๛๛๛๛๛๛๛๛๛๛๛๛๛๛๛๛๛๛๛
·····		: :				·····
			·	·····		
þ						
		ROOM		[serves]	[nnon]	
R.	<u>DD</u>	ZOOM	CURS	MEMO	RECD	MENU


#### COMPONENT INSPECTION

#### [IATS 1]

- 1. Turn the ignition key off.
- 2. Disconnect Boost Pressure Sensor connector.
- 3. Measure resistance between the terminals 3 and 2 of MAFS connector.




LGJF501H



LGJF501I

4. Refering to "SPECIFICATION", check that the resistance is within specification.



LGJF501J

4. Refering to "SPECIFICATION", check that the resistance is within specification.


#### [IATS 2]

- 1. Turn the ignition key off.
- 2. Disconnect Boost Pressure Sensor connector.
- 3. Measure resistance between the terminals 3 and 4 of BPS connector.

## ACCELERATION POSITION SENSOR (APS)

#### DESCRIPTION EE8C7C26

On electronic injection systems, there is no longer a load lever that mechanically controls the fuelling. The flow is caculated by the ECM depending on a number of parameters, including pedal position, which is measured using a potentiometer. The pedal sensor has two potentiometers whoses slides are mechanically solid. The two potentiometers are supplied from distinct and different power sources so there is built in redundancy of information giving reliable driver's request information. A voltage is generated across the potentiometer in the acceleration position sensor as a function of the accelerator-pedal setting. Using a peogrammed characteristic curve, the pedal's position is then calculated from this voltage.




EWPF600F

#### SPECIFICATION


Test Condition	Output Voltage (V)				
Test condition	APS1	APS2			
Idle	0.14 ~ 0.16	0.073 ~ 0.077			
Fully depressed	0.76 ~ 0.88	0.35 ~ 0.47			

#### **CIRCUIT DIAGRAM**




EWPF602F

#### SIGNAL WAVEFORM



#### COMPONENT INSPECTION

- 1. Disconnect APS connector and connect the voltimeter to the terminals 2 and 5 of APS connector.
- 2. Supply the terminal 6 with DC 5V.




AWJF301S

3. Check the voltage between the terminals 2 and 5 on operating pedal.

ldle: 0.14 ~ 0.16V Fully depressed: 0.76 ~ 0.88V

- 4. Disconnect the voltimeter and DC 5V.
- 5. Connect the voltimeter to the terminals 1 and 4 of APS connecotr.
- 6. Supply the terminal 3 with DC 5V.



AWJF301T

7. Check the voltage between the terminal 1 and 4 on operating pedal.


Idle 0.073 ~ 0.077V Fully depressed: 0.35 ~ 0.47V

## VGT SOLENOID VALVE

#### DESCRIPTION EFAB686C


Variable Geometry Turbocharger (VGT) is used to charge additional air into combustion chamber for improvement of combustion efficiency.

ECM controls the duty of VGT solenoid valve according to engine load.



EWPF600J

#### **CIRCUIT DIAGRAM**




#### SIGNAL WAVEFORM

FR	CHA2.	0 V	8.5 mS	CHB	0.5	U	As the VGT actuator is opened increasingly, the tir
			<u>т</u>			:	becomes shorter.
in the second	- E	i i same i dege	himmer i here	******			
	- hours	1 I I I					
h-time							
	1 1 1	1 1					
	*********	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	(*************************************	******	13 14 14 12 14 14 14 14 14 14 14 14 14 14 14 14 14		
U. E.						:	
						1	
1							
	÷				· • • • • • • • • • • • • • • • •		
		: :					
	**********	1	mominista		. has gerrard		
	4. I I I				1 2 3		
	1	!		••••••			
P				*******			
	VGT operation	otina rai					
	var open	auny la	ige :				
10100500			RS MEMO	REC	D ME	CRIE E	

**COMPONENT INSPECTION** 

- 1. Turn the ignition key off.
- 2. Disconnect the VGT actuator.
- 3. Measure resistance between the terminals 1 and 2 of the VGT actuator.

EFNF561A



LGJF503F


4. Refering to " SPECIFICATION", check that the resistance is within specification.

# FUEL PRESSURE CONTROL VALVE


#### DESCRIPTION E5FBFF44

The fuel pressure-control vlave sets the correct pressure in the rail as a function of engine loading, and manitains it at this level. If the rail pressure is excessive, the pressure-control valve opens and a portion of the fuel returns from the rail to the fuel tank via a collector line. If the rail pressure is too low, the pressure-control valve closes and seals off the high-pressure stage from the low-pressure stages. Fuel pressure control valve is integrated in high-pressure pump.


#### SPECIFICATION



#### CIRCUIT DIAGRAM




#### SIGNAL WAVEFORM



The cycle time "T" becomes shorter while idling and the fuel pressure regulator is opening to allow a large amount of fuel to be returned to the fuel tank.

The cycle time "T" becomes longer when accelerating and the fuel pressure regulator is closing to allow a small amount of fuel to be returned to the fuel tank.

EFNF557A




EWPF600K

#### COMPONENT INSPECTION

**FUEL SYSTEM** 

- 1. Turn the ignition key off.
- 2. Disconnect the fuel pressure regulator connector.
- 3. Measure resistance between the terminals 1 and 2 of the fuel pressure regulator connector.



LGJF501Q

4. Refering to "SPECIFICATION", check that the resistance is within specification.

## RAIL PRESSURE CONTROL VALVE

#### DESCRIPTION EC70259C

Rail pressure control valve(PCV) is installed in common rail.

If controls common rail pressure fast as regulating returning quantity if fuel which is delivered to common rail when fast rise of rail pressure is required like the moment of turning engine ON or when fast relief of pressure is required like at the point of receleration.


#### SPECIFICATION


Temperature ℃(°F)	Resistance (Ω)
20(68)	3.42 ~ 3.78

#### CIRCUIT DIAGRAM

PCV ECM


 1
 C201-1(4)
 Rail pressure control valve(High)






AWJF300V

#### SIGNAL WAVEFORM



#### COMPONENT INSPECTION

- 1. Turn the ignition key off.
- 2. Disconnect the rail pressure control valve connector.
- 3. Measure resistance between the terminals 1 and 2 of the rail pressure control valve connector.



LGJF501Q

4. Refering to "SPECIFICATION", check that the resistance is within specification.

## EGR SOLENOID VALVE

#### DESCRIPTION EF2F538D

The EGR(Exhaust Gas Recirculation) system is used to add the exhaust gas to intake air in order to reduce an excess of air and the temperature in the combustion chamber.

The EGR valve is directly controlled by ECM's control signal directly not by vacuum.


ECM controls the EGR valve with duty.

The duty control of the solenoid valve is determind by ECM depending on engine load and the need of intake air.

#### SPECIFICATION

OI LOINDANION		
	Temperature℃(°F)	Resistance(Ω )
	19 ~ 25 (66.2 ~ 77)	7.3 ~ 8.3

#### CIRCUIT DIAGRAM



EGR


EWPF600I

#### SIGNAL WAVEFORM

		: [mv:-v-i] [	
			··••··•••
	·····	••••••	
····		·····	
			······
HOLD	ZOOM CURS	MEMO RECD	MENU
	HOLD	HOLD ZOOM CURS	HOLD ZOOM CURS MEMO RECD

#### COMPONENT INSPECTION

- 1. Turn the ignition key off.
- 2. Disconnect the EGR valve connector.
- 3. Measure resistance between the terminals 1 and 2 of the EGR valve connector.




LGJF501W

4. Refering to "SPECIFICATION", check that the resistance is within specification.

## THROTTLE CONTROL

## DESCRIPTION E1355670

At the moment ignition switch turns off, throttle flap closing movement prevents engine stalling.



#### SPECIFICATION

Temperature ℃(°F)	Resistance (Ω)
20 (68)	28.3 ~ 31.1

#### CIRCUIT DIAGRAM

	Throttle flap solenoid	ECM
C219 Harness side		1 C201-2(90) Throttle flap control Signature in the second sec
		EWPF601C

LGJF501Y


#### SIGNAL WAVEFORM

FR CHA 2.0 V 1.0 mS CH B 5.0 V MIN: 284.5mV AVE: 10.1 V MAX: 15.5 V	FR CHA 2.0 V 1.0 mS CHB 5.0 V MIN: 71.5mV AVE: 1.6 V MAX: 14.3 V
FREQ: 202.02 Hz DUTY: 61 %	FREQ: 303.03 Hz DUTY: 10 %
HOLD ZOOM CURS MEMO RECD MENU	HOLD ZOOM CURS MEMO RECD MENU
Fig.1	Fig.2
Monorada and the state of the second state of the state o	tion : 38% duty is always outputted at ignition switch "ON" and v

Fig.2) Waveform of throttle flap actuator without throttle flap operation : 90% duty is outputted for about 1 sec. at ignition switch "OFF".

#### **COMPONENT INSPECTION**

- 1. Turn the ignition key off.
- 2. Disconnect the throttle flap actuator solenoid valve connector.
- 3. Measure resistance between the terminals 1 and 2 of throttle flap actuator solenoid valve connecotr.




LGJF502B

4. Refering to "SPECIFICATION", check that the resistance is within specification.

## VARIABLE SWIRL ACTUATOR

#### DESCRIPTION E7D54EE2

Variable swirl actuator consists of DC motor and valve position sensor which detects the position of swirl valve. At idle and below 3000rpm, swirl valve is closed to take swirl effect. This swirl effect increases air flow rate.



EWPF600O

#### OPERATION PRINCIPLE


ltem	Low and Middle Load	High Load
Engine speed	below 3000rpm	above 3000rpm
Valve operation	close	open
<b>Description</b> illustration		
	AWJF302A	AWJF302B
Fail-safe	Variable Swirl Va	lve is opened fully

\* To prevent swirl valve and shaft from being stuck by foreign material and to learn max opening and closing position of swirl valve, it is always fully opened and closed twice at engine stop.

#### SPECIFICATION

Item	Temperature ℃(°F)	<b>Resistance(</b> Ω )
Motor	20 (68)	3.2 ~ 4.4
Position sensor	20 (68)	3.44 ~ 5.16

#### **CIRCUIT DIAGRAM**




#### SIGNAL WAVEFORM

FR	CH A	5.0	V	0.2	mS	CH I	8 5.0	Ø		₿↑	CH	<u>a</u> 5	.0	V Ø.	5 mS		CH B	5.4	) U	
	ć, <sup>su</sup>		~						i ja					Moto	or(+) ····					
	······································		····;···			(****** ***** 	·)·····			1	h	ĥ	<b>«</b>	Π	<u>Ì</u>	<u>Ì</u>		)	1	
		Ň	lotor :	(+)					-											]
		·····	••••••	 []&	Mo	otor(-)	••••• ••••		~		<u> </u> \	<b>ال</b> ـــــة								
														1	/lotor(-	)				
Berten	· [ •			· · · · · · ·			·›ba;													-
Œ	OLD [	zoom	CL	JRS	MEMO		D ME	NU			IOLD	ZO	om	CURS	: ME	MO	REC	D M	ENU	
Fig.										Fig.	2									
	Swirl Swirl									. 4				,						

LGJF502D

#### **COMPONENT INSPECTION**


- 1. Turn ignition switch OFF.
- 2. Disconnect Variable swirl actuator connector.
- 3. Check that swirl valve is stuck by foreign material.
- 4. Supply the terminal 1 of variable swirl actuator connector (component side) with 12V and ground the terminal 2 of it.
- 5. Check swirl valve operation.



LGJF502E

6. Measure resistance between the terminals 1 and 2 of variable swirl actuator connector (component side).


Resistence : 3.2 ~ 4.4Ω (20℃)



LGJF502F

7. Measure resistance between the terminals 4 and 5 of variable swirl actuator connector (component side).

Resistence : 3.44 ~ 5.16Ω (20℃)




LGJF502G

# FUEL TEMPERATURE SENSOR (FTS)

#### DESCRIPTION E3C9D690

Fuel Temperature Sensor(FTS) is negative temperature characteristic thermistor installed in fuel supplying line. It senses the termperature of fuel supplied to high pressure pump. Fuel temperature is limmited to protect fuel such as high pressure pump and injectors from damages due to rapid deterioration by vapor-lock which can occur at high temperature or destruction of oil membrance.




EWPF600R

#### SPECIFICATION

Temperature °C (°F)	Resistance(kΩ )	Temperature ℃ (°F)	Resistance(kΩ )		
-30(-22)	27	80(176)	0.30 ~ 0.32		
-20(-4)	15.67	85(185)	0.269		
-10(14)	9.45	90(194)	0.231		
0(32)	5.89	95(203)	0.205		
20(68)	2.27 ~ 2.73	100(212)	0.176		
40(104)	1.17	105(221)	0.158		
50(122)	0.826	110(230)	0.137		
60(140)	0.597	120(248)	0.112		
70(158)	0.434	130(266)	0.088		

#### **CIRCUIT DIAGRAM**




#### SIGNAL WAVEFORM

FR	CH A	0.5 V	5.	0 3	S	CH	B	1.0	0	Ų.	This illustration shows the waveform of fuel	
÷				:			÷	-	-	÷	temperature sensor at 50°C.	
·····		÷·····;·····;· : : :	••••		·····		····:	····	••••	·····;····· :	The higher fuel temperature rises, the lower signal	
		÷									voltage becomes.	
	·····	÷										
			: : ;;		ļ							
								< -				
•		hayaa kiyoo aa iyo		• •	• •	•	•	· · · · · · · ·	مار <del>ال</del>	weetheess		
		÷•••••••••••••••••••••••••••••••••••••										
····	··!····	<u> </u>				•••••	····•					
	··!····.		····•		····-			···•				
		;;;;				;	;		;.			
		<u> </u>					÷					
									_			

#### COMPONENT INSPECTION

- 1. Turn the ignition key off.
- 2. Disconnect Fuel Temperature Sensor connector.
- 3. Measure resistance between the terminals 1 and 2 of FTS connector.



LGJF502J

4. Refering to "SPECIFICATION", check that the resistance is within specification.

LGJF5021

#### **FUEL SYSTEM**

## HEATED OXYGEN SENSOR


#### DESCRIPTION E5E1D083

O2 sensor installed at exhaust manifold is linear O2 sensor and it senses O2 density of exhaust gas for accurate EGR control through fuel correction. It also limits smoke which is generated by reach air-fuel mixture at engine maximum loading condition. ECM controls pumping current in order to fit  $\lambda$  -value from linear O2 sensor to 1.0.

Lean air-fuel mixture( $1.0 < \lambda < 1.1$ ): ECM supplies pumping current to O2 sensor (+pumping current) and activates it for O2 sensor to have the characteristic at  $\lambda = 1.0$  (0.0 pumping current). With the value of pumping current supplied to O2 sensor, ECM detects O2 density of exhaust gas.

Rich air-fuel mixture( $0.9 < \lambda < 1.0$ ) : ECM takes away pumping current from O2 sensor (-pumping current) and deactivates it for O2 sensor to have the characteristic at  $\lambda = 1.0$  (0.0 pumping current). With the value of pumping current taken away from O2 sensor, ECM detects O2 density of exhaust gas.

This performance is the most active and fast at normal operating temp. ( $450 \degree \sim 600 \degree$ ) thus, in order to reach normal operating temp. and last at that temp., heater (heating coil) is integrated with O2 sensor. Heater coil is controlled by ECM as PWM. The resistance of heater coil is low when coil is cold thus, current through it increases while resistance is high when coil is hot thus, current decreases. With this principle, O2 sensor temp. is measured and O2 sensor heater operation varies based on the data.




EWPF600Q

#### SPECIFICATION

$\lambda$ -value	0.65	0.70	0.80	0.90	1.01	1.18	1.43	1.70	2.42	Air
Pump- ing cur- rent	-2.22	-1.82	-1.11	-0.50	0.00	0.33	0.67	0.94	1.38	2.54

#### **CIRCUIT DIAGRAM**



EWPF602L

#### SIGNAL WAVEFORM

AT CHA 1.0 V 200 ms	S CH B Ø.5 V	This illustration represents the waveform of oxygen sensor signa
MIN: 0.5 V AVE: 2.5	5 V MAX: 2.6 V	at ignition switch "ON" and engine running.
FREQ: 25.00 Hz DUT	ry: 43 %	
*		
HOLD ZOOM CURS ME	EMO RECD MENU	

LGJF502L

## INSPECTION CHART FOR DIAGNOSTIC

TROUBLE CODES (DTC) E3DA068E

DTC	DESCRIPTION	MIL	PAGE
P0031	HO2S Heater Circuit low (Bank 1 / Sensor 1)		FLB-92
P0032	HO2S Heater Circuit high (Bank 1 / Sensor 1)		FLB-98
P0047	VGT Vaccum Modulator- Circuit Low		FLB-102
P0048	VGT Vaccum Modulator- Circuit High	· <b>A</b>	FLB-109
P0069	Boost Press. Sensor - Malfunction		FLB-113
P0087	Rail Pressure Monitoring-Minimum Pressure at Engine Speed Too Low	· 0	FLB-118
P0088	Rail Pressure Monitoring-Maximum Pressure Exceeded	0	FLB-122
P0089	Rail Press. Regulator(PCV) - Circuit Over Current	0	FLB-123
P0091	Rail Press. Regulator(PCV) - Circuit Low	0	FLB-129
P0092	Rail Press. Regulator(PCV) - Circuit High	0	FLB-132
P0097	Intake Air Temperature Sensor - Circuit Low Input		FLB-135
P0098	Intake Air Temperature Sensor - Circuit High Input		FLB-140
P0101	Mass or Volume Air Flow Circuit Range/Performance	0	FLB-144
P0102	Mass or Volume Air Flow Circuit Low Input	0	FLB-151
P0103	Mass or Volume Air Flow Circuit high Input		FLB-155
P0107	Boost Press. Sensor Circuit-Low Input		FLB-159
P0108	Boost Press. Sensor Circuit-High Input		FLB-162
P0112	Intake Air Temperature Sensor1 Circuit Low Input		FLB-164
P0113	Intake Air Temperature Sensor1 Circuit High Input		FLB-170
P0117	Engine Coolant Temperature Circuit Low Input		FLB-174
P0118	Engine Coolant Temperature Circuit High Input		FLB-180
P0182	Fuel Temp Sensor A Circuit Low Input		FLB-184
P0183	Fuel Temp Sensor A Circuit High Input		FLB-189
P0192	Fuel Rail Press. Sensor-Low input	0	FLB-193
P0193	Fuel Rail Press. Sensor-High Input	0	FLB-200
P0201	Injector Circuit/Open-Cylinder 1	0	FLB-205
P0202	Injector Circuit/Open-Cylinder 2	0	FLB-205
P0203	Injector Circuit/Open-Cylinder 3	0	FLB-205
P0204	Injector Circuit/Open-Cylinder 4	0	FLB-205

DTC	DESCRIPTION	MIL	PAGE
P0237	Boost Press. Sensor - Circuit High Input	٨	FLB-211
P0238	Boost Press. Sensor - Circuit Low Input		FLB-217
P0252	Fuel Press. Regulator(MPROP) - Circuit Over Current	0	FLB-222
P0253	Fuel Press. Regulator(MPROP) - Circuit Low	0	FLB-228
P0254	Fuel Press. Regulator(MPROP) - Circuit High	0	FLB-231
P0262	Cylinder 1-Injector Circuit High	0	FLB-234
P0265	Cylinder 2-Injector Circuit High	0	FLB-234
P0268	Cylinder 3-Injector Circuit High	0	FLB-234
P0271	Cylinder 4-Injector Circuit High	0	FLB-234
P0335	Crankshaft Position Sensor A Circuit	0	FLB-241
P0336	Crankshaft Position Sensor A Circuit Range/Performance	0	FLB-249
P0340	Camshaft Position Sensor A Circuit Malfunction (Bank 1 or Single Sensor)	0	FLB-254
P0341	Camshaft Position Sensor A Circuit Range/Performance (Bank 1 or Single Sensor)	0	FLB-261
P0381	Glow Indicator Lamp - Circuit Malfunction		FLB-265
P0489	Exhaust Gas Recirculation Control Circuit Low Voltage	0	FLB-269
P0490	Exhaust Gas Recirculation Control Circuit High Voltage		FLB-276
P0501	Vehicle Speed Sensor A Range/Performance and additional decision of gradient set	ne tê 🛦 🔬	FLB-279
P0504	Brake Switch "A"/"B" Correlation		FLB-285
P0532	A/C Refrigerant Pressure Sensor "A" Circuit Low Input	· 🛦	FLB-291
P0533	A/C Refrigerant Pressure Sensor "A" Circuit High Input	A	FLB-296
P0562	System Voltage Low		FLB-301
P0563	System Voltage High		FLB-307
P0602	EEPROM-Programing Error	٨	FLB-311
P0605	Internal Control Module Read Only Memory(ROM) Error		FLB-313
P0606	ECM/PCM Processor(ECM-SELF TEST Failed)	0	FLB-314
P0611	Injector - Circuit Malfunction (More than two injectors)	0	FLB-316
P062D	Voltage regulator #1 for injector - Malfunction	0	FLB-322
P062E	Voltage regulator #2 for injector - Malfunction	0	FLB-324
P0642	Sensor Reference Voltage "A" Circuit Low		FLB-325
P0643	Sensor Reference Voltage "A" Circuit High		FLB-330
P0646	A/C Clutch Relay Control Circuit Low		FLB-333
P0647	A/C Clutch Relay Control Circuit High		FLB-340
P0650	Malfunction Indicator Lamp(MIL) Control Circuit	<b>A</b>	FLB-344

DTC	DESCRIPTION	MIL	PAGE
P0652	Sensor Reference Voltage "B" Circuit Low		FLB-348
P0653	Sensor Reference Voltage "B" Circuit High		FLB-353
P0670	Glow Relay - Circuit Malfunction		FLB-356
P0685	ECM/PCM Power Relay Control Circuit /Open		FLB-363
P0698	Sensor Reference Voltage "C" Circuit Low		FLB-370
P0699	Sensor Reference Voltage "C" Circuit High		FLB-375
P0700	TCU Request for MIL On	0	FLB-378
P0701	TCM status Error		FLB-379
P0820	Neutral S/W Malfunction		FLB-380
P0830	Clutch S/W Malfunction		FLB-385
P1145	Overrun monitoring error		FLB-391
P1185	Fuel Pressure Monitoring-Maximum Pressure Exceeded	0	FLB-393
P1186	Fuel Pressure Monitoring-Minimum Pressure at Engine Speed Too Low	0	FLB-397
P1586	MT/AT Encoding	<b>A</b>	FLB-398
P1587	CAN communication error (MT/AT recognition error)		FLB-401
P1588	Signal Change through MT/AT line (during engine running)	. 🔺	FLB-403
P1610	Non - Immobilizer - EMS Connected to An Immobilizer		FLB-405
P1634	AUX. Heater Malfunction		FLB-406
P1652	IG S/W Malfunction		FLB-413
P1670	Injector Classification Error	0	FLB-417
P1671	Check-sum error	0	FLB-420
P2009	Intake Manifold Runner Control Circuit Low(Bank 1)		FLB-422
P2010	Intake Manifold Runner Control Circuit High(Bank 1)		FLB-429
P2015	Intake Manifold Runner Position Sensor/Switch Circuit Range/Performance(Bank 1)		FLB-433
P2016	Intake Manifold Runner Position Sensor/Switch Circuit Low(Bank 1)		FLB-437
P2017	Intake Manifold Runner Position Sensor/Switch Circuit High(Bank 1)		FLB-441
P2111	Throttle Flap Vaccum Modulator- Circuit High		FLB-446
P2112	Throttle Flap Vaccum Modulator- Circuit Low		FLB-452
P2123	Throttle/Pedal Position Sensor/Switch "D" Circuit High Input	0	FLB-455
P2128	Throttle/Pedal Position Sensor/Switch "E" Circuit High Input	0	FLB-462
P2138	Throttle/Pedal Position Sensor/Switch "D" / "E" Voltage Correlation	0	FLB-466
P2238	HO2S Pumping Current Circuit Low-Bank 1, Sensor 1	•	FLB-471
P2239	HO2S Pumping Current Circuit High-Bank 1, Sensor 1		FLB-480


DTC	DESCRIPTION	MIL	PAGE
P2251	HO2S Reference Ground Circuit/Open-Bank 1 Sensor 1		FLB-486
P2264	Detection of Water in fuel	٨	FLB-492
P2299	Brake switch " acc pedal sensor signals input simultaneously at times		FLB-498
U0001	CAN Communication Malfunction		FLB-506
U0100	CAN-Time Out ECU		FLB-513
U0101	Serial Communication Problem with TCU (Timeout)		FLB-517
U0122	ECM-TCS CAN Error	٨	FLB-521
U0416	Abnormal Torque rise request from TCS	٨	FLB-525

○ : MIL ON & FAULT CODE MEMORY

▲ : MIL OFF & FAULT CODE MEMORY

## DTC P0031 HO2S HEATER CIRCUIT LOW (BANK 1 / SENSOR 1)

#### COMPONENT LOCATION E0A7B5A0



LGJF009C

#### GENERAL DESCRIPTION E94F52E2

O2 sensor installed at exhaust manifold is linear O2 sensor and it senses O2 density of exhaust gas for accurate EGR control through fuel correction. It also limits smoke which is generated by reach air-fuel mixture at engine maximum loading condition. ECM controls pumping current in order to fit  $\lambda$  -value from linear O2 sensor to 1.0.

Lean air-fuel mixture( $1.0 < \lambda < 1.1$ ): ECM supplies pumping current to O2 sensor (+pumping current) and activates it for O2 sensor to have the characteristic at  $\lambda$  =1.0 (0.0 pumping current). With the value of pumping current supplied to O2 sensor, ECM detects O2 density of exhaust gas.

Rich air-fuel mixture  $(0.9 < \lambda < 1.0)$ : ECM takes away pumping current from O2 sensor (-pumping current) and deactivates it for O2 sensor to have the characteristic at  $\lambda$  =1.0 (0.0 pumping current). With the value of pumping current taken away from O2 sensor, ECM detects O2 density of exhaust gas.

This performance is the most active and fast at normal operating temp.  $(450 \degree \sim 600 \degree)$  thus, in order to reach normal operating temp. and last at that temp., heater(heating coil) is integrated with O2 sensor. Heater coil is controlled by ECM as PWM. the resistance of heater coil is low when coil is cold thus, current through it increases while resistance is high when coil is hot thus, current decreases. With this principle, O2 sensor temp. is measured and O2 sensor heater operation varies based on the data.

#### DTC DESCRIPTION E402A45C

P0031 is set when open or short to ground in O2 sensor control circuit is detected for more than 2.0 sec. at O2 sensor heater control condition. This code is due to 1)open or short to ground in heater control circuit or 2)O2 sensor heater internal short.


#### DTC DETECTING CONDITION EBAEB9D4

Item		Detecting	Possible Cause	
DTC Strategy	<ul> <li>Voltage mor</li> </ul>	nitoring		
Enable Conditions	<ul> <li>Engine runr</li> </ul>	ning		
ThresholdValue			nsor heater control circuit ter control circuit	
DiagnosticTime	• 2.0 sec.			O2 sensor heater circuit     O2 sensor component
	Fuel Cut	NO		<ul> <li>O2 sensor component</li> </ul>
Tall Cofe	EGR Off	NO		
Fail Safe	Fuel Limit	NO		
	MIL	NO		

#### SPECIFICATION E9DFB28A

Temperature (℃)	O2 sensor heater resistance(Ω)	Temperature (℃)	O2 sensor heater resistance(Ω )	O2 sensor heater control Hz
20	9.2	400	17.7	
100	10.7	500	19.2	100 Hz
200	13.1	600	20.7	
300	14.6	700	22.5	

#### SCHEMATIC DIAGRAM E2324FBA



SIGNAL WAVEFORM AND DATA E42EC33A

FREQ		2.86	Hz	DUT	Y: 9	36 %		
	1							
····;	·!····?	····÷···†	····÷		····;···	··!····?···	······	•••
÷	÷ :	÷ :	÷ :	÷ ÷	÷	÷ ÷	÷ ÷ ÷	
	· • • • • • • • • • • • • • • • • • • •			•••••	••••			•••
		j.						
	-				÷			
····		: :	····?		••••	: :		•••
	. <b>;</b> ;	į						
					÷			
	:	: :	: : :	···· : :	:	: :		•••
1920295		<u>. : :</u>	<u>; ;</u> _	;	<u> </u>	: :		
	)LD	ZOOM	ICUR	S ME	MO	RECD	MENU	

Fig.1) Waveform of O2 sensor heater power. It is battery voltage. Fig.2) Waveform of O2 sensor heater control at idle.

41 41 N :				CH B Ø MAX:	
			DUTY:	_	
:					
Ì		Ì			
÷	÷				
:		···	·······		
<u></u>	<u>mi ji i</u>				÷ i i i i i i i i i i i i i i i i i i i
····•			······		
<b>D</b> ;	 ·····¥····	···•····			
İR	ZOOM	CURS	MEMO	RECD	MENU

LGJF009O

#### TERMINAL AND CONNECTOR INSPECTION E290B193

- 1. Electrical systems consist of a lot of harness and connectors, poor connection of terminals can cause various problems and damge of component.
- 2. Perform checking procedure as follows.
  - 1) Check damage of harness and terminals : Check terminals for contact resistance, corrosion and deformation.
  - 2) Check connecting condition of ECM and component connector : Check terminal seperation, damage of locking device and connecting condition between terminal and wiring.

#### **NOTE**

Disconnect the pin which requires checking at male connector and insert it to the terminal at female connector for checking connecting condition. ( after checking, reconnect the pin at correct position. )

3. Is the problem found?

## YES

Repair the trouble causing part and go to "Verification of Vehicle Repair".



▶ Go to "Power Circuit Inspection".

S	pecification:11.0V~13.0V(Main relay ON power)	
4.	Measure the voltage of O2 sensor connector terminal 2.	and the second
3.	IG KEY "ON".	
2.	Disconnect O2 sensor connector meeting added and in the	na na tanàna ilay kaominina dia kaominina dia kaominina.
1.	IG KEY "OFF", ENGINE "OFF".	
PC	WER CIRCUIT INSPECTION E5F12FD7	स्ति स्ति वर्ष दिन्द्रिय स्वार्थ्य के विस्तर्थ स्ति हो।

#### YES

▶ Go to "Control Circuit Inspection".

NO

▶ Repair open in Main relay power circuit and E/R FUSE & RELAY BOX 10A SNSR fuse and go to "Verification of Vehicle Repair".

#### CONTROL CIRCUIT INSPECTION E40804E1

- 1. Check O2 sensor heater control circuit voltage
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect O2 sensor connector.

- 3) IG KEY "ON".
- 4) Measure the voltage of O2 sensor connector terminal 5.

Specification : 2.0V~2.5V

5) Is the measured voltage within the specification?

#### YES

Go to "Component Inspection".

#### NO

- No voltage is detected : Go to "2. Check open in O2 sensor heater control circuit" as follows.
- ▶ High voltage is detected : Repair short to battery in control circuit and go to "Verification of Vehicle Repair".

2. Check open in O2 sensor heater control circuit

- 1) IG KEY "OFF", ENGINE "OFF".
- 2) Disconnect O2 sensor connector and ECM connector.
- 3) Check continuity between O2 sensor connector terminal 5 and ECM connector terminal 51.

Specification : Continuity (below  $1.0\Omega$  )

4) Is the measured resistance within the specification?

#### YES

Repair short to ground in control circuit and go to "Verification of Vehicle Repair".

#### NO

Repair open in O2 sensor heater control circuit and go to "Verification of Vehicle Repair".

#### COMPONENT INSPECTION E2FE7E4A

- 1. Check O2 sensor component heater coil resistance
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect O2 sensor connector.
  - 3) Check continuity between O2 sensor component connector 2 and 5.

Specification : Refer to "Specification" of "General Information"

4) Is the measured resistance within the specification?



Go to "Verification of Vehicle Repair".



Replace O2 sensor and go to "Verification of Vehicle Repair".

#### VERIFICATION OF VEHICLE REPAIR E57E4C99

After a repair, it is essential to verify that the fault is corrected.

- 1. After connecting Scantool select "DIAGNOSTIC TROUBLE CODES(DTCs)" mode.
- 2. Clear recorded DTC using Scantool.
- 3. Drive the vehicle within DTC "Enable conditions" in "General information".
- 4. After selecting "DIAGNOSTIC TROUBLE CODES(DTCs)" mode and check if DTC is recorded again.
- 5. Are any DTCs recorded ?

## YES

Go to the DTC guide of recorded NO. in Scantool.

#### NO

System operates within specification.

LGJF009S

## DTC P0032 HO2S HEATER CIRCUIT HIGH (BANK 1 / SENSOR 1)

#### COMPONENT LOCATION E096EDCE

Refer to DTC P0031.

#### GENERAL DESCRIPTION EBC21B32

Refer to DTC P0031.

#### DTC DESCRIPTION EOBO666F

P0032 is set when short to battery in O2 sensor control circuit is detected for more than 2.0 sec. at O2 sensor heater control condition. This code is due to 1)short to battery in heater control circuit or 2)O2 sensor heater internal open.

#### DTC DETECTING CONDITION E32BE7D4

ltem		Detecting Condition				Possible Cause
DTC Strategy	<ul> <li>Voltage mor</li> </ul>	nitoring				
Enable Conditions	<ul> <li>Engine runn</li> </ul>	ing				
ThresholdValue	<ul> <li>Short to batt</li> </ul>	ery in O2 s	ensor heater	control cire	cuit	
DiagnosticTime	• 2.0 sec.			×.		O2 sensor heater circuit
	Fuel Cut	NO				<ul> <li>O2 sensor component</li> </ul>
Foil Cofe	EGR Off	NO				
Fail Safe	Fuel Limit	NO	]			
	MIL	NO			1. S. S.	

#### SPECIFICATION EE1CA68F

Temperature (℃)	O2 sensor heater resistance(Ω )	Temperature (℃)	O2 sensor heater resistance(Ω )	O2 sensor heater control Hz
20	9.2	400	17.7	
100	10.7	500	19.2	100 11-
200	13.1	600	20.7	100 Hz
300	14.6	700	22.5	

#### SCHEMATIC DIAGRAM EA54C912

Refer to DTC P0031.

#### SIGNAL WAVEFORM AND DATA EOBAA3B9

MIN	:	13	. 6	Ų	A١	E:	1	4.	2 V	I	MA}	{:	14	ł.7	V
FRE	Q:		2	. 8	6	Hz		DU	TY:	9	6 %	5			
		:			-	:	:				:	:	-	÷	
·····							 					·····	 		
·····	·····	····;			: :	: :	; ;	•••••	·····	•••••	: :	: :	: :		
·····												<u>.</u>			
,	į	<u></u>			dan eş		·····				: 				
									;		: 	; ;			
, i						<u>.</u>					: 		<u>.</u>		
	÷	÷											-		
	HOI	Ð	Z	00	1	CU	RS	M	emo	1	REC	D	ME	NU	




Fig.2

Fig.1) Waveform of O2 sensor heater power. It is battery voltage. Fig.2) Waveform of O2 sensor heater control at idle.

#### 

Refer to DTC P0031.

#### POWER CIRCUIT INSPECTION EEIDB8BD

1. IG KEY "OFF", ENGINE "OFF".

- 2. Disconnect O2 sensor connectoridely to maintegrate/ at og ens trumis testade di provide at trade regione el
- 3. IG KEY "ON".
- 4. Measure the voltage of O2 sensor connector terminal 2.

Specification: 11.0V~13.0V (Main relay ON power)

5. Is the measured voltage within the specification?



Go to "Control Circuit Inspection".

NO

Repair open in Main relay power circuit and E/R FUSE & RELAY BOX 10A SNSR fuse and go to "Verification of Vehicle Repair".

#### CONTROL CIRCUIT INSPECTION E5ADCD7F

- 1. Check O2 sensor heater control circuit voltage
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect O2 sensor connector.

FLB -99

LGJF009O

- 3) IG KEY "ON".
- 4) Measure the voltage of O2 sensor connector terminal 5.

Specification : 2.0V~2.5V

5) Is the measured voltage within the specification?

#### YES

Go to "Component Inspection".

#### NO

- No voltage is detected : Go to "2. Check open in O2 sensor heater control circuit" as follows.
- ▶ High voltage is detected : Repair short to battery in control circuit and go to "Verification of Vehicle Repair".
- 2. Check open in O2 sensor heater control circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect O2 sensor connector and ECM connector.
  - 3) Check continuity between O2 sensor connector terminal 5 and ECM connector terminal 51.24 (14)

Specification : Continuity (below  $1.0\Omega$  )

4) Is the measured resistance within the specification?

#### YES

Repair short to ground in control circuit and go to "Verification of Vehicle Repair".


#### NO

Repair open in O2 sensor heater control circuit and go to "Verification of Vehicle Repair".

#### COMPONENT INSPECTION E68F479A

- 1. Check O2 sensor component heater coil resistance
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect O2 sensor connector.
  - 3) Check continuity between O2 sensor component connector 2 and 5.

Specification : Refer to "Specification" of "General Information"



LGJF009S

4) Is the measured resistance within the specification?

#### YES

▶ Go to "Verification of Vehicle Repair".



Replace O2 sensor and go to "Verification of Vehicle Repair".

#### VERIFICATION OF VEHICLE REPAIR E350F2CC

Refer to DTC P0031.


, de servición de la contraction de la servición de la constante entre entre de la constante de la constante e e servición de la constante de la contractione de constante enclante a develocidade de la formación de constante e constante de la constante establica establica de la Companya entre de la constante de la constante d constante e constante de la constante establica establica de la companya establica.



(2) An example of the second s second s second s second s second se

## DTC P0047 VGT VACCUM MODULATOR- CIRCUIT LOW


#### COMPONENT LOCATION E2F28FCF



EWPF602M

#### GENERAL DESCRIPTION EB518DD6

VGT(Variable Geometric Turbocharger) is the device which increases the efficiency of turbocharger at low rpm and lasts optimum turbo efficiency at high rpm as varying the cross sectional area through which exhaust gas passes turbocharger impeller. It relieves turbo lag at low speed and increse engine power genetation.Engine speed, APS signal, MAFS and Boost pressure sensor information is inputted to ECM. ECM actuates vacuum diafragm which controls exhaust gas line as controlling VGT actuator duty to maintain optimum state of air compression.



LGJF003D

#### DTC DESCRIPTION E60F6BDF

P0047 is set when "0"A is detected in VGT actuator control circuit for more than 1 sec.. This code is due to open or short to ground in VGT actuator circuit, or open in VGT actuator component.

## DTC DETECTING CONDITION E40FF3AB


Item		Detecting	Possible Cause				
DTC Strategy	<ul> <li>Signal mon</li> </ul>	itoring					
Enable Conditions							
ThresholdValue							
DiagnosticTime	• 1000ms		<ul> <li>VGT actuator circuit</li> </ul>				
	Fuel Cut	NO		<ul> <li>VGT actuator component</li> </ul>			
Fail Safe	EGR Off	YES	<ul> <li>VGT actuator duty is</li> </ul>	•			
raii Sale	Fuel Limit	YES	fixed at 31.4%.				
	MIL	NO					

#### SPECIFICATION EA2E2E2C

VGT actuator component resistance	VGT actuator operating Hz	VGT actuator operating duty		
14.7 ~ 16.1Ω (20℃)	300Hz	75% at idle, decreases as accelerating		

## SCHEMATIC DIAGRAM EEC0632B

1997 - 1997 - Alexandria Statistica (m. 1997) 1997 - Alexandria Statistica (m. 1997) 1997 - Alexandria Statistica (m. 1997)



EWPF001D

U

#### SIGNAL WAVEFORM AND DATA E39B2AB8

FR CH	A 2.0 V	1.0 mS	CH B 5	.0V	FR CH	A 2.0 V	1.0 mS	CH B 5.0	a v
MIN: 7:	L.5mV AVE	: 3.9 4	J MAX:	15.3 V	MIN: 71	.5mV AVE	2: 8.2 V	MAX:	15.2
FREQ: 3	303.03 H:	z DUTY	: 25 %		FREQ: 3	03.03 H	Iz DUTY:	54 %	
<b></b>			<b></b>	<b>F</b>			)	· · · · · · · · · · · · · · · · · · ·	
				·····			···· · · · · · · · · · · · · · · · · ·		
HOLD	ZOOM CI	JRS MEMO		MENU	HOLD	ZOOM	URS MEMO	RECD	1ENU


Fig.1) VGT actuator output waveform at 75% duty. Duty decreases as boost pressure increases. Fig.2) VGT actuator duty decreased at acceleration.

LGJF003F

#### MONITOR SCANTOOL DATA ECD34CB9

- 1. Connect scantool to Data Link Cable. (DLC)
- 2. Warm engine up to normal operating temperature.
- Turn "OFF" electrical devices and A/C. 3.
- Monitor "BOOST PRESS. SENSOR" parameter on the Scantool. 4.

Specification : 1028hpa ± 100hpa(VGT actuator : 75%) at idle



#### Figu

Fig1) Monitor "BOOST PRESSURE SENSOR" parameter on the Scantool at idle after warming engine up. 1000hpa ±100hpa(approx. 1 atm) is correct value.

Fig.2) VGT actuator duty decreases and boost pressure increases as accelerating. If boost pressure rises and reaches certain value, VGT actuator duty stops to drop and keeps steady. Releasing accelerator pedal at this moment, VGT actuator duty drops to 9.8%, then if RPM drops to idle range, duty returns to 75%.

LGJF012Y

#### TERMINAL AND CONNECTOR INSPECTION 667149F7

- 1. Electrical systems consist of a lot of harness and connectors, poor connection of terminals can cause various problems and damge of component.
- 2. Perform checking procedure as follows.
  - 1) Check damage of harness and terminals : Check terminals for contact resistance, corrosion and deformation.
  - 2) Check connecting condition of ECM and component connector : Check terminal seperation, damage of locking device and connecting condition between terminal and wiring.

#### **NOTE**

Disconnect the pin which requires checking at male connector and insert it to the terminal at female connector or checking connecting condition. (after checking, reconnect the pin at correct position.)

3. Is the problem found?

#### YES

Repair the trouble causing part and go to "Verification of Vehicle Repair".

#### NO

▶ Go to "Power Circuit Inspection".

#### POWER CIRCUIT INSPECTION E7D984B2

- 1. Check power circuit voltage
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect VGT actuator connector
  - 3) IG KEY "ON"
  - 4) Measure the voltage of terminal 2 of VGT actuator

Specification : 11.5V~13.0V

5) Is the measured voltage within the specification?

#### YES

Go to "Control Circuit Inspection".

NO

Repair E/R FUSE & RELAY BOX 15A INJ fuse and related circuit and go to "Verification of Vehicle Repair".

#### CONTROL CIRCUIT INSPECTION EC078E95

- 1. Check monitoring voltage in control circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect VGT actuator connector

- 3) IG KEY "ON"
- 4) Measure the voltage of terminal 1 of VGT actuator

Specification: 3.2V~3.7V

5) Is the measured voltage within the specification?

#### YES

▶ Go to "Component Inspection".

NO

- ▶ When voltage is not detected : Go to "2. Check open in control circuit" as follows.
- ▶ When high voltage is detected : Repair short to battery and go to "Verification of Vehicle Repair".

#### 2. Check open in control circuit

- IG KEY "OFF", ENGINE "OFF".
   Disconnect VGT actuator connector and ECM connector.
  - 3) Check continuity between VGT actuator connector terminal 1 and ECM connector terminal 24.

specification : Continuity (below 1.0Ω)

4) Is the measured resistance within the specification?

#### YES

▶ Repair short to ground and go to "Verification of Vehicle Repair".


#### NO

Repair open in control circuit and go to "Verification of Vehicle Repair".

#### COMPONENT INSPECTION EC756A8D

- 1. Check VGT actuator component resistance
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect VGT actuator connector.
  - 3) Measure the resistance between VGT actuator component terminal 1 and 2.

Specification : 14.7 ~ 16.1Ω (20℃)



4) Is VGT actuator component resistance within the specification?



Go to "2.Check VGT actuator operation" as follows.



- Replace VGT actuator and go to "Verification of Vehicle Repair".
- 2. Check VGT actuator operation
  - 1) IG KEY "ON", ENGINE "ON".
  - 2) Check that VGT actuator operating duty is 75% after warming engine up.
  - 3) Check if vacuum generates after disconnecting VGT valve vacuum hose.
  - 4) Check if vacuum generates when decelerating after rapid acceleration (VGT actuator operating duty 9.8%).

Specification : VGT actuator duty 75% : vacuum generates VGT actuator duty 9.8% : vacuum does not generate

## YES

Go to "Verification of Vehicle Repair".

#### NO

- Replace VGT actuator and go to "Verification of Vehicle Repair".
- \* Repeat this process 2~3 times.

#### VERIFICATION OF VEHICLE REPAIR E965F19B

After a repair, it is essential to verify that the fault is corrected.

- 1. After connecting Scantool select "DIAGNOSTIC TROUBLE CODES(DTCs)" mode.
- 2. Clear recorded DTC using Scantool.
- 3. Drive the vehicle within DTC "Enable conditions" in "General information".
- 4. After selecting "DIAGNOSTIC TROUBLE CODES(DTCs)" mode and check if DTC is recorded again.

LGJF003J

5. Are any DTCs recorded ?

## YES

▶ Go to the DTC guide of recorded NO. in Scantool.



System operates within specification.

# DTC P0048 VGT VACCUM MODULATOR- CIRCUIT HIGH

#### COMPONENT LOCATION EE53AB7F

Refer to DTC P0047.

#### GENERAL DESCRIPTION EA15054F

Refer to DTC P0047.

#### DTC DESCRIPTION E63A371D

P0048 is set when excessive current is detected in VGT actuator control circuit for more than 1 sec.. This code is due to short to battery in control circuit or internal short of VGT actuator component.

#### DTC DETECTING CONDITION E5A33358

Item		Detecting	Possible Cause	
DTC Strategy	<ul> <li>Signal mon</li> </ul>	itoring		
Enable Conditions	<ul> <li>Engine run actuator op</li> </ul>	(monitoring o erating cond		
ThresholdValue	Short to ba	ttery	2011年4月,19月1日(1915年) 1月1日日(1915年) 1月1日日(1915年) 1月1日日(1915年)	
DiagnosticTime	• 1000ms			<ul> <li>VGT actuator circuit</li> </ul>
	Fuel Cut	NO	and the second sec	VGT actuator component
	EGR Off	NO	VGT actuator duty is	n e sector tribuic se a chie
Fail Safe	Fuel Limit	YES	fixed at 31.4%.	
	MIL	NO		

## SPECIFICATION E3A81103

VGT actuator component resistance	VGT actuator operating Hz	VGT actuator operating duty	
14.7 ~ 16.1Ω <b>(20</b> ℃)	300Hz	75% at idle, decreases as accelerating	

## SCHEMATIC DIAGRAM EF3AAC31

Refer to DTC P0047.

#### SIGNAL WAVEFORM AND DATA E73679D8

Refer to DTC P0047.

#### MONITOR SCANTOOL DATA EABA5E5D

Refer to DTC P0047.

## TERMINAL AND CONNECTOR INSPECTION E84CF356

Refer to DTC P0047.

#### POWER CIRCUIT INSPECTION EA4B5B3D

- 1. Check power circuit voltage
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect VGT actuator connector
  - 3) IG KEY "ON"
  - 4) Measure the voltage of terminal 2 of VGT actuator

Specification : 11.5V~13.0V

5) Is the measured voltage within the specification?

#### YES

Go to "Control Circuit Inspection".

NO

▶ Repair E/R FUSE & RELAY BOX 15A INJ fuse and related circuit and go to "Verification of Vehicle Repair".

#### CONTROL CIRCUIT INSPECTION E1596E45

- 1. Check monitoring voltage in control circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect VGT actuator connector
  - 3) IG KEY "ON"
  - 4) Measure the voltage of terminal 1 of VGT actuator

Specification: 3.2V~3.7V

5) Is the measured voltage within the specification?

#### YES

Go to "Component Inspection".



- ▶ When voltage is not detected : Go to "2. Check open in control circuit" as follows.
- ▶ When high voltage is detected : Repair short to battery and go to "Verification of Vehicle Repair".
- 2. Check open in control circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect VGT actuator connector and ECM connector.

#### DTC TROUBLESHOOTING PROCEDURES

3) Check continuity between VGT actuator connector terminal 1 and ECM connector terminal 24.

specification : Continuity ( below  $1.0\Omega$  )

4) Is the measured resistance within the specification?

## YES

Repair short to ground and go to "Verification of Vehicle Repair".




Repair open in control circuit and go to "Verification of Vehicle Repair".

#### COMPONENT INSPECTION E5D0F656

- 1. Check VGT actuator component resistance
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect VGT actuator connector.
  - 3) Measure the resistance between VGT actuator component terminal 1 and 2.

Specification : 14.7 ~ 16.1Ω (20℃)



LGJF003J

4) Is VGT actuator component resistance within the specification?

#### YES

▶ Go to "2.Check VGT actuator operation" as follows.

#### NO

- Replace VGT actuator and go to "Verification of Vehicle Repair".
- 2. Check VGT actuator operation
  - 1) IG KEY "ON", ENGINE "ON".
  - 2) Check that VGT actuator operating duty is 75% after warming engine up.
  - 3) Check if vacuum generates after disconnecting VGT valve vacuum hose.

4) Check if vacuum generates when decelerating after rapid acceleration (VGT actuator operating duty 9.8%).

Specification : VGT actuator duty 75% : vacuum generates VGT actuator duty 9.8% : vacuum does not generate

# YES

▶ Go to "Verification of Vehicle Repair".

NO


- ▶ Replace VGT actuator and go to "Verification of Vehicle Repair".
- \* Repeat this process 2~3 times.

## VERIFICATION OF VEHICLE REPAIR EE31A66D

Refer to DTC P0047.

## DTC P0069 BOOST PRESS. SENSOR - MALFUNCTION

#### COMPONENT LOCATION E44823E6



EWPF602N

#### GENERAL DESCRIPTION EACF3942

Boost Pressure Sensor(BPS) is installed in intake manifold and senses the pressure of air inside of intake manifold which is compressed by turbo charager. Measuring mass air flow accurately with the information of intake mainfold pressure, mass air flow and intake air temperature, ECM performs actuating correction of EGR and VGT. When excessive intake manifold pressure is detected, engine power generation is limited to protect engine because too highly compressed pressure due to turbo charger may harm engine.

## DTC DESCRIPTION EC637312

P0069 is set when the difference between BPS output voltage and atmospheric pressure sensor output voltage is above 300hpa at below 100RPM(in other word, IG KEY ON condition) for more than 2.0 sec. This code is due to abnormal output characteristic of BPS component.


Item		Detecting	Possible Cause	
DTC Strategy	<ul> <li>Voltage mor</li> </ul>	nitoring		
Enable Conditions	<ul> <li>IG KEY "ON</li> </ul>	N" (below 10	00RPM)	
ThresholdValue	<ul> <li>Boost press</li> <li>is above 30</li> </ul>			
DiagnosticTime	• 2.0 sec		<ul><li>BPS circuit</li><li>BPS component</li></ul>	
	Fuel Cut	NO		• BF3 component
	EGR Off	YES	<ul> <li>Boost pressure is fixed</li> </ul>	
Fail Safe	Fuel Limit	YES	at 1000 hpa.	n en anti-ser a ser a Ser a ser br>Ser a ser
	MIL	NO		

#### DTC DETECTING CONDITION E302362C

#### SPECIFICATION E78DBB35

Pressure [Kpa]	20	100	190	250
Outpur voltage [V]	0.4±0.077	1.878±0.063	3.541±0.063	4.650±0.077

#### SCHEMATIC DIAGRAM E1454C35



#### SIGNAL WAVEFORM AND DATA E584BCA6




Fig1) This is the waveform of BPS as accelerating from idle state. Signal voltage rises as accelerating.

LGJF012X

#### MONITOR SCANTOOL DATA E91034F2

1. Connect Scantool to Data Link Connector (DLC).

## DTC TROUBLESHOOTING PROCEDURES

- 2. Warm engine up to normal operating temperature.
- 3. Turn "OFF" electrical devices and A/C.
- 4. Monitor "BOOST PRESS. SENSOR" parameter on the Scantool.

Specification : 1028hpa ± 100hpa(VGT actuator : 75%) at idle




Fig1) Monitor "BOOST PRESSURE SENSOR" parameter on the Scantool at idle after warming engine up. 1000hpa ± 100hpa(approx. 1 atm) is correct value.

Fig.2) VGT actuator duty decreases and boost pressure increases as accelerating. If boost pressure rises and reaches certain value, VGT actuator duty stops to drop and keeps steady. Releasing accelerator pedal at this moment, VGT actuator duty drops to 9.8%, then if RPM drops to idle range, duty returns to 75%.

LGJF014P

#### TERMINAL AND CONNECTOR INSPECTION E22436A0

- 1. Electrical systems consist of a lot of harness and connectors, poor connection of terminals can cause various problems and damge of component.
- 2. Perform checking procedure as follows.
  - 1) Check damage of harness and terminals : Check terminals for contact resistance, corrosion and deformation.
  - 2) Check connecting condition of ECM and component connector : Check terminal seperation, damage of locking device and connecting condition between terminal and wiring.

# **ΝΟΤΕ**

Disconnect the pin which requires checking at male connector and insert it to the terminal at female connector for checking connecting condition. (after checking, reconnect the pin at correct position.)

3. Is the problem found?



Repair the trouble causing part and go to "Verification of Vehicle Repair".

#### NO

Go to "Component Inspection ".

#### COMPONENT INSPECTION E78D0986

- 1. BPS visual iInspection
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect BPS connector.
  - 3) Check if corrosion and damage in BPS terminal is detected.
  - 4) Check BPS mounting state, leakage at O'ring, clogged carbon at pressure detecting hall.
  - 5) Are the problems relevant to BPS found?

#### YES

▶ Replace BPS if necessary and go to "Verification of Vehicle Repair".

#### NO

- ▶ Go to "2. Check BPS output voltage at IG KEY ON" as follows.
- 2. Check BPS output voltage at IG KEY ON
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Connect Scantool to Data Link Connector (DLC).
  - 3) IG KEY "ON"
  - 4) Monitor "ATMOSPHERIC PRESSURE" and "BOOST PRESSURE SENSOR" parameters on scantool.
  - Check if both "ATMOSPHERIC PRESSURE" and "BOOST PRESSURE SENSOR" indicates similar value at IG KEY "ON".

Specification : Refer to "Monitor Scantool Data" of Scantool diagnostics parameters.

6) Is any BPS related problem is detedcted?

#### YES

▶ Go to "Verification of Vehicle Repair".

NO

Replace BPS and go to "Verification of Vehicle Repair".

#### VERIFICATION OF VEHICLE REPAIR EEEF90E5

After a repair, it is essential to verify that the fault is corrected.

- 1. After connecting Scantool select "DIAGNOSTIC TROUBLE CODES(DTCs)" mode.
- 2. Clear recorded DTC using Scantool.
- 3. Drive the vehicle within DTC "Enable conditions" in "General information".
- 4. After selecting "DIAGNOSTIC TROUBLE CODES(DTCs)" mode and check if DTC is recorded again.
- 5. Are any DTCs recorded ?





Go to the DTC guide of recorded NO. in Scantool.




System operates within specification.

이제 이 이 제가 지수는 것 같아. 지수는 것 같아. 이 나는 것 같아. 이 것이 같아요.

a. Letter any measure of example on a charactery of a consistence of the first of the first of the construction of the cons

# DTC P0087 RAIL PRESSURE MONITORING-MINIMUM PRESSURE AT ENGINE SPEED TOO LOW

#### COMPONENT LOCATION E86CFC46



EWPF007Y

#### GENERAL DESCRIPTION E7160F8A

As inputted rail pressure sensor signal, ECM of Commom rail diesel engine controls fuel metering unit(MPROP-integrated with high press. pump) and rail pressure control valve(PCV-integrated with common rail) in order to maintain optimum rail pressure according to current engine rpm and load. However when the problem that leads rail pressure to out of target value intended by ECM occurs due to mechanical or electronical reason, ECM shuts engine down and sets DTC by limiting fuel (stops injector operation) in order to prevent engine from being controlled abnormally. "rail pressure monitoring error" is the DTC which diagnose 1).supplying state of low pressure fuel and 2).mechanical operating conditions of high pressure pump and 3). RPCV indirectly based on RPS output voltage and RPS duty. thus, repair relavant to this DTC requires mechanics the total understand of fuel system.

#### DTC DESCRIPTION E9049A0C

P0087 is set when rail pressure is lower than target rail pressure by more than 250bar for more than 1.0 sec. in condition that rail press. is controlled by rail pressure control valve(PCV) or rail pressure is below the minimum limiting value(200bar). This code is due to 1)fuel less than target value supplied to common rail or 2)excessive return of fuel supplied to common rail or 3)short to low voltage line in fuel press. sensor.

## DTC DETECTING CONDITION E785DE65

Item		Detecting	Possible Cause	
DTC Strategy	<ul> <li>Voltage mo</li> </ul>	nitoring		
Enable Conditions	<ul> <li>Engine run</li> </ul>	ning	стана страна br>Страна страна br>Страна страна	
ThresholdValue	<ul> <li>Rail pressur by more that valve(PCV)</li> <li>Rail pressur value(200bat operating composition</li> </ul>	an 250bar a operating c re is below ar) at rail pre	<ul> <li>fuel metering unit (close stuck)</li> <li>rail pressure control valve (open stuck)</li> </ul>	
DiagnosticTime	• 1.0 sec.			<ul> <li>Rail pressure sensor (Output fixed at low)</li> </ul>
	Fuel Cut	NO		voltage line)
Foil Sofo	EGR Off	NO	1	
Fail Safe	Fuel Limit	YES		
	MIL	YES		

## MONITOR SCANTOOL DATA E68A427F

- 1. Monitoring rail pressure data
  - 1) Connect Scantool to Data Link Connector (DLC).
  - 2) Warm engine up to normal operating temperature.
  - 3) Turn "OFF" electrical devices and A/C.
  - 4) Monitor "FUEL PRESSURE MEASURED", "FUEL PRESSURE-TARGET", "RAIL PRESS. REGULATOR1", "INJ. PUMP REGULATOR" parameter on the Scantool.

Specification : FUEL PRESSURE MEASURED : similar to "FUEL PRESSURE-TARGET" FUEL PRESSURE-TARGET : 28 ± 5 Mpa RAIL PRESS. REGULATOR1 : 20 ± 5% INJ. PUMP REGULATOR : 40 ± 5%




Fig.1) Monitor "FUEL PRESSURE MEASURED" at idle after warming engine up.


LGJF010R

Check if "FUEL PRESSURE MEASURED" data is similar to "FUEL PRESSURE-TARGET". Not only former two data but also "RAIL PRESS. REGULATOR1" and "INJ. PUMP REGULATOR" should be monitored carefully. Although "FUEL PRESSURE MEASURED" is similar to "FUEL PRESSURE-TARGET", if "RAIL PRESS. REG-ULATOR1" and "INJ. PUMP REGULATOR" is out of specification, it means wear, leakage, stuck of fuel system.

- 2. Monitoring rail pressure data at acceleration(loading condition).
  - 1) Connect Scantool to Data Link Connector (DLC).
  - 2) Warm engine up to normal operating temperature.
  - 3) Turn "OFF" electrical devices and A/C.
  - 4) Monitor "FUEL PRESSURE MEASURED", "RAIL PRESS. REGULATOR1", "INJ. PUMP REGULATOR" parameter on the Scantool.

#### **SPECIFICATION** :

	Idle(without load)	Accelerating(stall test)	Diagnosis
INJ. PUMP REGULATOR	38 ± 5%	32 ± 5%	duty decreases
FUEL PRESSURE MEASURED	28.5 ± 5 Mpa	145 ± 10 Mpa	press. increases
RAIL PRESS. REGULATOR1	19 ± 5%	48 ± 5%	duty increases






Fig.1) The position of curser on the graph represents idle data. Fig.2) Data during acceleration(stall test).


LGJF010S

# 

The waveform of fuel metering unit installed at high pressure pump(fuel detecting MPROP) shows 38% duty at idle, duty drops to approx. 32% at acceleration to raise rail pressure. Duty drop means the decrease of current.  $\rightarrow$  Fuel delivered to common rail increases as current drops.

The waveform of rail pressure control valve installed at common rail shows 19% duty at idle, duty rises to approx. 48% at acceleration to raise rail pressure. Duty rise means the increase of current.

→ If current rises, the returning quantity of fuel deliverd to common rail decreases and common rail pressure rises.



LGJF014Q

## VERIFICATION OF VEHICLE REPAIR E92AF7F4

After a repair, it is essential to verify that the fault is corrected.

- 1. After connecting Scantool select "DIAGNOSTIC TROUBLE CODES(DTCs)" mode.
- 2. Clear recorded DTC using Scantool.
- 3. Drive the vehicle within DTC "Enable conditions" in "General information".
- 4. After selecting "DIAGNOSTIC TROUBLE CODES(DTCs)" mode and check if DTC is recorded again.
- 5. Are any DTCs recorded ?

## YES

Go to the DTC guide of recorded NO. in Scantool.

## NO

System operates within specification.

# DTC P0088 RAIL PRESSURE MONITORING-MAXIMUM PRESSURE EXCEEDED

#### COMPONENT LOCATION EEB87294

Refer to DTC P0087.

#### GENERAL DESCRIPTION E47E3290

Refer to DTC P0087.

#### DTC DESCRIPTION E7B6A1D7

P0088 is set if measured rail pressure is higher than target rail pressure by more than 200bar when rail pressure is regulated by rail pressure control valve(PCV) or rail pressure is above the max limiting value. This code is due to 1)fuel more than target value supplied to common rail or 2)poor return of fuel supplied to common rail or 3)short to high voltage line in fuel press. sensor.

#### DTC DETECTING CONDITION E7E83317

Item		Detecting	Possible Cause	
DTC Strategy	<ul> <li>Voltage mor</li> </ul>	nitoring		
Enable Conditions	Engine runr	ning		
ThresholdValue	<ul> <li>Rail pressur than 200bar operating co</li> <li>Rail pressur value(1750b operating co</li> </ul>	at rail prese ondition 40 re is above par) at rail pr	<ul> <li>fuel metering unit (open stuck)</li> <li>rail pressure control valve (close stuck)</li> <li>Rail pressure sensor</li> </ul>	
DiagnosticTime	<ul> <li>Refer to three</li> </ul>	eshold Value	Output fixed at high	
	Fuel Cut	NO	voltage line)	
	EGR Off	NO		
Fail Safe	Fuel Limit	YES		
	MIL	YES		

#### MONITOR SCANTOOL DATA E60EF9AE


Refer to DTC P0087.

#### VERIFICATION OF VEHICLE REPAIR E30BC8C2

Refer to DTC P0087.

#### RAIL PRESS. REGULATOR(PCV) - CIRCUIT OVER CURRENT **DTC P0089**

#### COMPONENT LOCATION E08A4A26



## GENERAL DESCRIPTION EC2F4A1E

Rail press. control valve(PCV) is installed in common rail and controls common rail pressure fast as regulating returning quantity of fuel which is delivered to common rail when fast rise of rail pressure is required like the moment of turning engine ON or when fast relief of pressure is required like at the point of deceleration. The lower RPCV current is, the more fuel is supplied to common rail. Thus it leads rail pressure to be high. On the contrary, the higher RPCV current is, the less fuel is supplied to common rail.

#### DTC DESCRIPTION EAFED85E

P0089 is set when excessive current in control circuit of Rail Pressure control valve(integrated with high common rail) is detected for more than 0.22 sec.. This code is due to short to battery in control circuit or Rail Pressure control valve internal short.


#### DTC DETECTING CONDITION EA334640

ltem	Detecting Condition					Po	ssible Cause
DTC Strategy	<ul> <li>Voltage mor</li> </ul>	nitoring				-	
Enable Conditions	<ul> <li>IG KEY "ON</li> </ul>	۷"	- - -				
ThresholdValue	<ul> <li>Short to bat pressure co</li> </ul>		I circuit of ra	il			
DiagnosticTime	• 220ms	1				• RPCV	
	Fuel Cut	NO		· · ·			component
	EGR Off	NO				All and a second s	
Fail Safe	Fuel Limit	YES					
	MIL	YES	na star References		in a sta Mara		


#### SPECIFICATION E5882898

rail pressure control valve resistance	Operating frequancy
3.42 ~ 3.78Ω (20℃)	1000Hz(1KHz)

## SCHEMATIC DIAGRAM E15311A8



SIGNAL WAVEFORM AND DATA EDD6E6CD






Fig.1) Waveform of rail pressure control valve at idle. It shows approx. 20% duty.

Fig.2) Waveform of rail pressure control valve as accelerating. Approx. 50% duty is outputted as engine load increases.

(When rail pressure increases as accelerating, rail pressure control valve duty(current) rises.)

LGJF014B

#### MONITOR SCANTOOL DATA EAE8A75B

- Connect Scantool to Data Link Connector (DLC). 1.
- Warm engine up to normal operating temperature. 2.
- Turn "OFF" electrical devices and A/C. 3.
- Monitor "FUEL PRESSURE MEASURED", "RAIL PRESS. REGULATOR1", "INJ. PUMP REGULATOR" parameter 4 on the Scantool.

#### SPECIFICATION :

	Idle(without load)	Accelerating(stall test)	Diagnosis
INJ. PUMP REGULATOR	38 ± 5%	32 ± 5%	duty decreases
FUEL PRESSURE MEASURED	28.5 ± 5 Mpa	145 ± 10 Mpa	press. increases
RAIL PRESS. REGULATOR1	19 ± 5%	48 ± 5%	duty increases




Fig.1) The position of curser on the graph represents idle data. Fig.2) Data during acceleration(stall test).

#### LGJF013U

## **NOTE**

The waveform of fuel metering unit installed at high pressure pump(fuel detecting MPROP) shows 38% duty at idle, duty drops to approx. 32% at acceleration to raise rail pressure. Duty drop means the decrease of current. → Fuel delivered to common rail increases as current drops.

The waveform of rail pressure control valve installed at common rail shows 19% duty at idle, duty rises to approx. 48% at acceleration to raise rail pressure. Duty rise means the increase of current.  $\rightarrow$  If current rises, the returning quantity of fuel deliverd to common rail decreases and common rail pressure rises.

#### TERMINAL AND CONNECTOR INSPECTION E72D1175

- Electrical systems consist of a lot of harness and connectors, poor connection of terminals can cause various prob-1. lems and damge of component.
- 2. Perform checking procedure as follows.
  - 1) Check damage of harness and terminals : Check terminals for contact resistance, corrosion and deformation.

2) Check connecting condition of ECM and component connector : Check terminal seperation, damage of locking device and connecting condition between terminal and wiring.

## 🛈 ΝΟΤΕ

Disconnect the pin which requires checking at male connector and insert it to the terminal at female connector for checking connecting condition. ( after checking, reconnect the pin at correct position. )

3. Is the problem found?

#### YES

Repair the trouble causing part and go to "Verification of Vehicle Repair".

#### NO

Go to "Power Circuit Inspection".

#### POWER CIRCUIT INSPECTION E521FAOB

- 1. Check power circuit voltage
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect RPCV connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of RPCV connector terminal 1.

specification: 11.5V~13.0V	a and a start of the	and the second sec	*	4 ( 16 <u>)</u> )	

5) Is the measured voltage within the specification?

## YES

▶ Go to "Control Circuit Inspection".

#### NO

Repair open between rail pressure control valve connector terminal 1 and ECM connector terminal 4 and go to "Verification of Vehicle Repair".

#### CONTROL CIRCUIT INSPECTION E9F70E15

- 1. Check monitoring voltage in control circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect RPCV connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of RPCV connector terminal 2.

specification : 3.2V~3.7V

5) Is the measured voltage within the specification?

## YES

▶ Go to "Component Inspection"



- When voltage is not detected : Go to "2. Check open in control circuit" as follows.
- When high voltage is detected : Repair short to battery and go to "Verification of Vehicle Repair".
- 2. Check open in control circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect RPCV connector and ECM connector.
  - 3) Check continuity between RPCV connector terminal 2 and ECM connector terminal 34.

specification : Continuity ( below  $1.0\Omega$  )

4) Is the measured resistance within the specification?

## YES

▶ Repair short to ground in RPCV control circuit and go to "Verification of Vehicle Repair".


NO

Repair open in RPCV control circuit and go to "Verification of Vehicle Repair".

#### COMPONENT INSPECTION E9A377DD

- 1. Check RPCV component resistance
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect RPCV connector.
  - 3) Check RPCV component resistance.

Specification : 3.42 ~ 3.78Ω (20℃)



LGJF014F

4) Is the measured resistance within the specification?



▶ Go to "Verification of Vehicle Repair".

## NO

▶ Replace common rail assy' and go to "Verification of Vehicle Repair".

#### VERIFICATION OF VEHICLE REPAIR EC36A680

After a repair, it is essential to verify that the fault is corrected.

- 1. After connecting Scantool select "DIAGNOSTIC TROUBLE CODES(DTCs)" mode.
- 2. Clear recorded DTC using Scantool.
- 3. Drive the vehicle within DTC "Enable conditions" in "General information".
- 4. After selecting "DIAGNOSTIC TROUBLE CODES(DTCs)" mode and check if DTC is recorded again.
- 5. Are any DTCs recorded ?

## YES

▶ Go to the DTC guide of recorded NO. in Scantool.

#### NO

System operates within specification.

## DTC P0091 RAIL PRESS. REGULATOR(PCV) - CIRCUIT LOW

#### COMPONENT LOCATION EB124628

Refer to DTC P0089.

#### GENERAL DESCRIPTION E863D1EC

Refer to DTC P0089.

#### DTC DESCRIPTION E088DA1E

P0091 is set when "0"A in control circuit of Rail Pressure control valve(integrated with common rail) is detected for more than 0.11 sec.. This code is due to open of short to ground in control circuit or Rail Pressure control valve internal open.

#### DTC DETECTING CONDITION E482C258

ltem	Detecting Condition			Possible Cause
DTC Strategy	<ul> <li>Voltage mo</li> </ul>	nitoring		
Enable Conditions	• IG KEY "O	N"		
ThresholdValue	Short to GI	ND, Wiring a		
DiagnosticTime	• 110ms		RPCV circuit	
	Fuel Cut	NO		<ul> <li>RPCV component</li> </ul>
	EGR Off	NO		
Fail Safe	Fuel Limit	YES	4. j.	
	MIL	YES		hanna 1 Sid Saaraha (1997)

## SPECIFICATION E53A9866

ad in the state

rail pressure control valve resistance	Operating frequancy
3.42 ~ 3.78Ω (20℃)	1000Hz(1KHz)

## SCHEMATIC DIAGRAM E71AD417

Refer to DTC P0089.

#### SIGNAL WAVEFORM AND DATA E24549F9

Refer to DTC P0089.

## MONITOR SCANTOOL DATA E38265D1

Refer to DTC P0089.

#### TERMINAL AND CONNECTOR INSPECTION E23FDADE

Refer to DTC P0089.

#### POWER CIRCUIT INSPECTION E3D53627

- 1. Check power circuit voltage
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect RPCV connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of RPCV connector terminal 1.

specification : 11.5V~13.0V

5) Is the measured voltage within the specification?

#### YES

Go to "Control Circuit Inspection".

#### NO

Repair open between rail pressure control valve connector terminal 1 and ECM connector terminal 4 and go to "Verification of Vehicle Repair".

#### CONTROL CIRCUIT INSPECTION EF66C70C

- 1. Check monitoring voltage in control circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect RPCV connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of RPCV connector terminal 2.

specification : 3.2V~3.7V

5) Is the measured voltage within the specification?



Go to "Component Inspection"

NO

- When voltage is not detected : Go to "2. Check open in control circuit" as follows.
- When high voltage is detected : Repair short to battery and go to "Verification of Vehicle Repair".
- 2. Check open in control circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect RPCV connector and ECM connector.
  - 3) Check continuity between RPCV connector terminal 2 and ECM connector terminal 34.

## DTC TROUBLESHOOTING PROCEDURES

specification : Continuity ( below  $1.0 \Omega$  )

4) Is the measured resistance within the specification?

## YES

▶ Repair short to ground in RPCV control circuit and go to "Verification of Vehicle Repair".

#### NO

Repair open in RPCV control circuit and go to "Verification of Vehicle Repair".

#### COMPONENT INSPECTION E17252D3

- 1. Check RPCV component resistance
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect RPCV connector.
  - 3) Check RPCV component resistance.

Specification : 3.42 ~ 3.78Ω (20℃)



4) Is the measured resistance within the specification?

YES

▶ Go to "Verification of Vehicle Repair".



Replace common rail assy' and go to "Verification of Vehicle Repair".

## VERIFICATION OF VEHICLE REPAIR EB21C4E5

Refer to DTC P0089.

LGJE014E

# DTC P0092 RAIL PRESS. REGULATOR(PCV) - CIRCUIT HIGH

## COMPONENT LOCATION E47A3BE8

Refer to DTC P0089.

#### GENERAL DESCRIPTION E2922B81

Refer to DTC P0089.

#### DTC DESCRIPTION EBE03968

P0092 is set when excessive current in power circuit of Fuel Pressure control valve(integrated with common rail) is detected for more than 0.14 sec.. This code is due to short to battery in power circuit or Rail pressure control valve internal short.

#### DTC DETECTING CONDITION E7705A81

Item		Detecting	Possible Cause	
DTC Strategy	<ul> <li>Voltage mo</li> </ul>	nitoring		
Enable Conditions	• IG KEY "O	N"		
ThresholdValue	<ul> <li>Short to ba control valv</li> </ul>			
DiagnosticTime	• 140ms	,		RPCV circuit     BDCV component
· ·	Fuel Cut	NO		RPCV component
	EGR Off	NO		
Fail Safe	Fuel Limit	YES		
	MIL	YES		$= \frac{1}{2} \sum_{i=1}^{N-1} \sum_{j=1}^{N-1} \frac{1}{i_j} \sum_{i=1}^{N-1} \frac{1}{i_j} \sum_{i$

#### SPECIFICATION E6E50987

rail pressure control valve resistance	Operating frequancy
3.42 ~ 3.78Ω (20℃)	1000Hz(1KHz)

#### SCHEMATIC DIAGRAM EC505BA3

Refer to DTC P0089.

#### SIGNAL WAVEFORM AND DATA EC434343

Refer to DTC P0089.

#### MONITOR SCANTOOL DATA ED6A8383

Refer to DTC P0089.

## TERMINAL AND CONNECTOR INSPECTION E331FDF9

Refer to DTC P0089.

#### POWER CIRCUIT INSPECTION E53108AD

- 1. Check power circuit voltage
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect RPCV connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of RPCV connector terminal 1.

specification : 11.5V~13.0V

5) Is the measured voltage within the specification?

#### YES

▶ Go to "Control Circuit Inspection".

#### NO

Repair open between rail pressure control valve connector terminal 1 and ECM connector terminal 4 and go to "Verification of Vehicle Repair".

#### CONTROL CIRCUIT INSPECTION EC943DCD

- 1. Check monitoring voltage in control circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect RPCV connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of RPCV connector terminal 2.

specification : 3.2V~3.7V

5) Is the measured voltage within the specification?

## YES

▶ Go to "Component Inspection"



- When voltage is not detected : Go to "2. Check open in control circuit" as follows.
- ▶ When high voltage is detected : Repair short to battery and go to "Verification of Vehicle Repair".
- 2. Check open in control circuit
  - 1) IG KEY "OFF", ENGINE "OFF".

LGJF014F

- 2) Disconnect RPCV connector and ECM connector.
- 3) Check continuity between RPCV connector terminal 2 and ECM connector terminal 34.

specification : Continuity ( below  $1.0\Omega$  )

4) Is the measured resistance within the specification?

#### YES

Repair short to ground in RPCV control circuit and go to "Verification of Vehicle Repair".

#### NO

Repair open in RPCV control circuit and go to "Verification of Vehicle Repair".

#### COMPONENT INSPECTION E37DCC4C

- 1. Check RPCV component resistance
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect RPCV connector.
  - 3) Check RPCV component resistance.

Specification : 3.42 ~ 3.78Ω (20℃)



4) Is the measured resistance within the specification?

#### YES

Go to "Verification of Vehicle Repair".


#### NO

Replace common rail assy' and go to "Verification of Vehicle Repair".

## VERIFICATION OF VEHICLE REPAIR ED04126D

Refer to DTC P0089.

## COMPONENT LOCATION EC9B3109



EWPF602N

#### GENERAL DESCRIPTION E837DADE

Intake Air Temperature Sensor(IATS) is NTC thermistor. Installed inside of both AFS and BPS, it senses intake air temperature. In case of EURO-4 diesel engine, IATS is installed in front of turbocharger(inside of AFS) and behind it(inside of BPS). Comparing air temperature from both sensors(one is intake air temperature, the other is air temperature passing through turbo charger), more accurate sensing of intake air temperature is possible. With intake air temperature signal, ECM performs EGR control correction and fuel injection quantity correction. (AFS is needed for EGR FEED BACK control in electronically controlled diesel engine. The calculation of air density at certain temperature is required to perform EGR FEED BACK control correctly.)

#### DTC DESCRIPTION E98840D9

P0097 is set when the voltage below 73mV(0.11V) - minimum output voltage of IATS(integrated with BPS) - is detected for more than 2.0 sec. This code is due to short to ground in IATS signal circuit.


Item	Detecting Condition			Possible Cause	
DTC Strategy	<ul> <li>Voltage more</li> </ul>	nitoring	· · · · · · · · · · · · · · · · · · ·		
Enable Conditions	• IG KEY "OI	N"			
ThresholdValue	Output sign:	al below mir			
DiagnosticTime	• 2.0 sec.		<ul> <li>IATS circuit</li> </ul>		
	Fuel Cut	NO		<ul> <li>IATS component</li> </ul>	
Fail Safe	EGR Off	NO			
	Fuel Limit	NO			
	MIL	NO	- -		

#### DTC DETECTING CONDITION E662A1A7

## SPECIFICATION E4DF499B

Temp.	<b>-40</b> ℃	<b>-20</b> °C	<b>℃</b>	<b>20</b> ℃	<b>40</b> ℃	<b>60</b> °С	<b>30 ℃</b>
Resistance	35.14	12.66	5.12	2.29	1.10	0.57	0.31
	~43.76KΩ	~15.12KΩ	~5.89KΩ	~2.55KΩ	~1.24KΩ	~0.65KΩ	~0.37KΩ

## SCHEMATIC DIAGRAM EC26661B



EWPF001L

#### SIGNAL WAVEFORM AND DATA EA610C96




Fig.1) IATS output waveform at 25 °C. The higher temperature is, the lower voltage becomes.

LGJF007Z

## DTC TROUBLESHOOTING PROCEDURES

#### FLB -137

LGJF008A

# MONITOR SCANTOOL DATA EBDCA4EB

- 1. Connect Scantool to Data Link Connector (DLC).
- 2. Warm engine up to normal operating temperature.
- 3. Turn "OFF" electrical devices and A/C.
- 4. Monitor "AIR TEMPERATURE SENSOR" parameter on the Scantool.

specification : current intake air temperture is displayed.

		1.	2 CUR	RENT	DA	ľA	13/	54
								Å
×	FUEL	PRESSU	RE ME	asuri	ED	28.5	MPa	
×	RAIL	PRESS.	REGU	LAT OI	R1	22.7	%	
¥	AIR	MASS PE	RCYLI	NDER		346.9	∂mg∕st	龖
×	AIR '	rempera	TURE	SENSO	DR	37.8	°C	
×	EGR (	ACTUATO	R			6.0	%	
×	WATE	R TEMP.	SENSO	3		92.7	°C	
×	ENGI	NE SPEE	d sens	SOR		794	rpm	
	BOOST	r Pressi	URE SI	ENSOI	}		segar di	
								Ţ
	FIX		FULL			GRPH	RCRD	1

#### Fight

Fig.1) Check if current temperature is same as the value displayed on the Scantool.

# TERMINAL AND CONNECTOR INSPECTION EAFEIIGHE

1. Electrical systems consist of a lot of harness and connectors, poor connection of terminals can cause various problems and damge of component.

Them a provide the standard and ECM connector

- 2. Perform checking procedure as follows.
  - 1) Check damage of harness and terminals : Check terminals for contact resistance, corrosion and deformation.
  - 2) Check connecting condition of ECM and component connector : Check terminal seperation, damage of locking device and connecting condition between terminal and wiring.

# **NOTE**

Disconnect the pin which requires checking at male connector and insert it to the terminal at female connector for checking connecting condition. ( after checking, reconnect the pin at correct position. )

3. Is the problem found?

## YES

Repair the trouble causing part and go to "Verification of Vehicle Repair".

## NO

Go to "Signal Circuit Inspection".

#### SIGNAL CIRCUIT INSPECTION EA5DODD7

- 1. Check signal circuit voltage
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect BPS connector.
  - 3) IG KEY "ON"
  - 4) Check the voltage of BPS connector terminal 3.

Specification: 4.8V~5.1V

5) Is the measured voltage within the specificaiton?

#### YES

▶ Go to "Component Inspection".

#### NO

- ▶ Repair "2. Check short to ground in signal circuit" as follows.
- 2. Check short to ground in signal circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect BPS connector and ECM connector.
  - 3) Check continuity between BPS connector terminal 3 and chassis ground.

Specification : Discontinuity (Infinite  $\Omega$ )

4) Is the measured resistance within the specification?

## YES

▶ Go to"Component Inspection".

#### NO


Repair short to ground in signal circuit and go to "Verification of Vehicle Repair".

#### COMPONENT INSPECTION E4869B91

- 1. IG KEY "OFF", ENGINE "OFF".
- 2. Disconnect BPS connector.
- 3. Measure resistance between IATS component terminal 3 and 4, referring to resistance characteristic table of specification of General information.

Specification : Refer to Specification of General Information

LGJF008B



4. Is the measured resistance at certain temperature within the specified resisance range at the temperature?

## YES

▶ Go to "Verification of Vehicle Repair".

#### NO

Replace BPS assy' and go to "Verification of Vehicle Repair".

## VERIFICATION OF VEHICLE REPAIR EB85468D

After a repair, it is essential to verify that the fault is corrected.

- 1. After connecting Scantool select "DIAGNOSTIC TROUBLE CODES(DTCs)" mode.
- 2. Clear recorded DTC using Scantool.
- 3. Drive the vehicle within DTC "Enable conditions" in "General information".
- 4. After selecting "DIAGNOSTIC TROUBLE CODES(DTCs)" mode and check if DTC is recorded again.
- 5. Are any DTCs recorded ?

## YES

Go to the DTC guide of recorded NO. in Scantool.

#### NO

System operates within specification.

# DTC P0098 INTAKE AIR TEMPERATURE SENSOR - CIRCUIT HIGH INPUT

#### COMPONENT LOCATION EF236B71

Refer to DTC P0097.

#### GENERAL DESCRIPTION E46D488B

Refer to DTC P0097.

#### DTC DESCRIPTION E7953E3A

P0098 is set when the voltage above 4965mV - maximum output voltage of IATS(integrated with BPS) - is detected for more than 2.0 sec.. This code is due to 1) open or 2) short to ground or 3) short to battery in IATS signal circuit.

## DTC DETECTING CONDITION E8921549

Item		Detecting	Possible Cause		
DTC Strategy	<ul> <li>Voltage mor</li> </ul>	nitoring			
Enable Conditions	• IG KEY "Of	V"			
ThresholdValue	Output signa	al above ma			
DiagnosticTime	• 2.0 sec.			IATS circuit	
	Fuel Cut	NO		<ul> <li>IATS component</li> </ul>	
Foil Sofo	EGR Off	NO			
Fail Safe	Fuel Limit	NO			
	MIL	NO			

#### SPECIFICATION EBEF4882

Temp.	<b>-40</b> °C	<b>-20</b> C	<b>0°C</b>	<b>20</b> °C	<b>40</b> ℃	<b>60</b> °С	<b>80</b> °С
Resistance	35.14	12.66	5.12	2.29	1.10	0.57	0.31
	~43.76KΩ	~15.12KΩ	~5.89KΩ	~2.55KΩ	~1.24KΩ	~0.65KΩ	~0.37KΩ

#### SCHEMATIC DIAGRAM E63A0D58

Refer to DTC P0097.

## SIGNAL WAVEFORM AND DATA E502960D

Refer to DTC P0097.

#### MONITOR SCANTOOL DATA EFD6BC8C

Refer to DTC P0097.

#### TERMINAL AND CONNECTOR INSPECTION E1F865CE

Refer to DTC P0097.

# DTC TROUBLESHOOTING PROCEDURES FLB -141 SIGNAL CIRCUIT INSPECTION E58DB05E Check signal circuit voltage 1. 1) IG KEY "OFF", ENGINE "OFF". 2) Disconnect BPS connector. IG KEY "ON" 3) 4) Check the voltage of BPS connector terminal 3. Specification: 4.8V~5.1V 5) Is the measured voltage within the specificaiton? YES Go to "Ground Circuit Inspection". NO Go to "2.Check open in signal circuit" as follows. 2. Check open in signal circuit 1) IG KEY "OFF", ENGINE "OFF". 2) Disconnect BPS connector and ECM connector. Check continuity between BPS connector terminal 3 and ECM connector terminal 53. 3) Specification : Continuity (below 1.00) 4) Is the measured resistance within the specification? YES Go to "3. Check short to battery in signal circuit" as follows. NO Repair open in signal circuit and go to "Verification of Vehicle Repair". 3. Check short to battery in signal circuit 1) IG KEY "OFF", ENGINE "OFF". 2) Disconnect BPS connector and ECM connector. 3) IG KEY "ON" 4) Check the voltage of BPS connector terminal 3. Specification : 0.0V~0.1V

5) Is the measured voltage within the specification?(with both connector disconnected)

#### YES

Repair short to battery in signal circuit and go to "Verification of Vehicle Repair".

NO

Go to "Ground Circuit Inspection".

#### GROUND CIRCUIT INSPECTION EA94E638

- 1. IG KEY "OFF", ENGINE "OFF".
- 2. Disconnect BPS connector.
- 3. IG KEY "ON".
- 4. Measure the voltage of BPS connector terminal 3. [TEST "A"]
- 5. Measure the voltage between BPS connector terminal 3 and 4. [TEST "B"] (terminal 3 : Check + prove, terminal 4 : Check prove)

Specification : [TEST "A"] Voltage - [TEST "B"] Voltage = below 200mV

6. Is the measured voltage within the specification?

#### YES

Go to "Component Inspection".

NO


When "B" voltage is not detected : Repair open in ground circuit and go to "Verification of Vehicle Repair".
 When the voltage difference between "A" and "B" is above 200mV : Eliminate the causes of excessive resistance and go to "Verification of Vehicle Repair".

#### COMPONENT INSPECTION E8D31BE3

- 1. IG KEY "OFF", ENGINE "OFF".
- 2. Disconnect BPS connector.
- Measure resistance between IATS component terminal 3 and 4, referring to resistance characteristic table of specification of General information.

Specification : Refer to Specification of General Information

LGJF008B



4. Is the measured resistance at certain temperature within the specified resisance range at the temperature?

## YES

Go to "Verification of Vehicle Repair".

## NO

Replace BPS assy' and go to "Verification of Vehicle Repair".

## VERIFICATION OF VEHICLE REPAIR EOC7E226

Refer to DTC P0097. Protection of the second second of the second of the second of the test of the second of th

## ans D


and a second of the state of the second s

#### 요즘 것 좀 이가로 깔끔 같아. 이가 ?

ander 1995 - Standard Marine, ander and 1995 - Standard Marine, ander ander ander

## DTC P0101 MASS OR VOLUME AIR FLOW CIRCUIT RANGE/PERFORMANCE

#### COMPONENT LOCATION EEC18160



EWPF602P

#### GENERAL DESCRIPTION E7982ADA

Air Flow Sensor(AFS) is digital sensor. Measuring mass of air flow, signal is outputted as frequency(Hz). ECM performs EGR system feed back control with the information of measured mass air flow. (The role of AFS in diesel engine is different from gasoline engine. Fuel injection quantity is decided by AFS signal in gasoline engine.)When EGR gas(contains no oxygen) flowing into combustion chamber increases, the air passing through AFS(contains oxygen) decreases. Thus, with the output signal change of AFS accompanied by EGR actuator actuation, ECM determines the amount of recirculated EGR gas quantity.

#### 🛈 ΝΟΤΕ

NOx is produced from the reaction of nitrogen and oxygen.

If least intake air required for complete combustion flows into combustion chamber by controlling EGR gas(contains no oxygen) which is recirculated to combustion chamber, NOx decreases because there is no supplementary oxygen to react with nitrogen.

#### DTC DESCRIPTION EC30E569

P0101 is set when AFS output voltage above 4.8V is detected for more than 1.0 sec.. This code is due to short to battery in signal circuit or open in ground circuit.

### DTC DETECTING CONDITION E67E5502


Item		Detecting Condition		Possible Cause
DTC Strategy	<ul> <li>Voltage mo</li> </ul>	oltage monitoring		
Enable Conditions	Engine run	ning		
ThresholdValue	Shrot to battery in AFS circuit			
DiagnosticTime	• 1.0 sec.	• 1.0 sec.		AFS circuit
	Fuel Cut	NO		AFS component
	EGR Off	YES		
Fail Safe	Fuel Limit	YES		•••••
	MIL	YES	1	

### SPECIFICATION E98E611A

Intelse ein euertite (Kerle)	Output frequ		
Intake air quantity (Kg/h)	<b>20</b> ℃	<b>80</b> ℃	deviation [ % ]
8	1.97		±3
10	2.01	2.01	±2
40	2.50	2.50	±2
105	3.20	3.20	±2
220	4.30		±2
480	7.80	7.80	±2
560	9.50	and Atal Ca	MACTEV <b>±3</b> 2 except

FLB -145

### SCHEMATIC DIAGRAM EDD2A950



#### SIGNAL WAVEFORM AND DATA E2821B80




Fig.1) AFS signal waveform at IG KEY "ON". It shows digital signal of 50% duty, 1.8KHz.

Fig.2) AFS signal waveform at idle(830RPM, EGR actuator duty 9.4%, air flow for each cylinder 340mg/st).

It shows digital signal of 50% duty, 2.0~2.5KHz.

LGJF012Q

🚺 ΝΟΤΕ

Signal frequency increases as RPM rises.

#### MONITOR SCANTOOL DATA EEBA325B

- 1. Connect Scantool to Data Link Connector (DLC).
- 2. Warm engine up to normal operating temperature.
- 3. Turn "OFF" electrical devices and A/C.
- 4. Monitor "AIR MASS PERCYLINDER" parameter on the Scantool.

Specification : When EEGR actuator does not operate 6% duty) at idle : 340 mg/st  $\pm$  50 mg/st When EEGR actuator operates(50% duty) at idle : 200 ms/st  $\pm$  50 mg/st

		1.2	CUR	RENT	DA	ľA	12/	54
								4
×	FUEL	PRESSUE	E-TA	RGET		28.5	MPa	
×	FUEL	PRESSUF	IE ME	asuri	ED	28.5	MPa	龖
×	AIR	MASS PER	CYLI	NDER		359.7	?mg∕st	
×	AIR 3	T emperat	URE	SENSO	)R	38.6	°C	d.
×	EGR (	ACTUATOF				6.0	%	
×	ACCE	L PEDAL	SENS	OR		0.0	%	
×	ENGI	NE SPEED	SEN	SOR		794	rpm	
	CALC	ulat.loa	D VA	LUE.				
								V
	FIX		FULL			GRPH	RCRD	1

		1.2 CURRENT D	ATA	12/	54
					Å
¥	FUEL	PRESSURE-TARGET	28.5	MPa	
×	FUEL	PRESSURE MEASURED	28.5	MPa	躢
¥	AIR	MASS PERCYLINDER	192.	?mg/st	
×	AIR	TEMPERATURE SENSOR	39.4	°C	
×	EGR	ACTUATOR	56,6	%	
×	ACCE	L PEDAL SENSOR	0.0	%	
×	ENGI	NE SPEED SENSOR	794	rpm	
	CALC	ULAT.LOAD VALUE.			
					Ţ
	FIX	FULL	GRPH	RCRD	I

#### Fig.1

Fig.1) Check if "AIR MASS PERCYLINDER" output signal is 340mg/st ± 50mg/st without EEGR operation at warm idle (EEGR actuator 6% duty)

Fig.2) Check if "AIR MASS PERCYLINDER" output signal is 200mg/st ± 50mg/st with EEGR operation at warm idle (EEGR actuator 50% duty)

\* EEGR actuator operates as decelerating after rapid acceleration when idle EEGR does not operate, EEGR actuator operating duty decreases as time goes by. This controlling process lasts for about 3 min. and EEGR actuator turns "OFF" (duty 6%) after 3 min.

LGJF012R

#### TERMINAL AND CONNECTOR INSPECTION E9F22FD5

- 1. Electrical systems consist of a lot of harness and connectors, poor connection of terminals can cause various problems and damge of component.
- 2. Perform checking procedure as follows.
  - 1) Check damage of harness and terminals : Check terminals for contact resistance, corrosion and deformation.
  - 2) Check connecting condition of ECM and component connector : Check terminal seperation, damage of locking device and connecting condition between terminal and wiring.

#### 🗊 ΝΟΤΕ

Disconnect the pin which requires checking at male connector and insert it to the terminal at female connector for checking connecting condition. (after checking, reconnect the pin at correct position.)

3. Is the problem found?

#### YES

Repair the trouble causing part and go to "Verification of Vehicle Repair".

#### NO

Go to "Power Circuit Inspection".

#### POWER CIRCUIT INSPECTION E30C6CF7

- 1. Check power circuit voltage
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect AFS connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of AFS connector terminal 1 and 4.

```
Specification : Terminal 4 : 4.8V~5.1V (Sensor power)
Terminal 1 : 11.5V~13.0V (IG Power)
```

5) Is the measured voltage within the specification?

#### YES

▶ Go to "Signal Circuit Inspection".



When output voltage is not detected at terminal 1 :

Repair open in In-pannel junction box 10A ECU fuse and related circuit and go to "Verification of Vehicle Repair".

When output voltage is not detected at terminal 4 :

☞ Repair open between AFS connector terminal 4 and ECM connector 37, and go to "Verification of Vehicle Repair".

#### SIGNAL CIRCUIT INSPECTION E36372C7

- 1. Check signal circuit voltage
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect AFS connector and ECM connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of AFS connector terminal 5.

Specification : 4.8~5.1V

5) Is the measured voltage within the specification?

#### YES

▶ Go to "Ground Circuit Inspection".

#### NO

Repair short to battery in signal circuit and go to "Verification of Vehicle Repair".

#### GROUND CIRCUIT INSPECTION EFBC28E3

- 1. IG KEY "OFF", ENGINE "OFF".
- 2. Disconnect AFS connector.
- 3. IG KEY "ON".
- 4. Measure the voltage of AFS connector terminal 4. [ TEST "A" ]
- 5. Measure the voltage between AFS connector terminal 4 and 2. [TEST "B"] (terminal 4 : Check + prove, terminal 2 : Check prove)

Specification : [TEST "A"] Voltage - [TEST "B"] Voltage = below 200mV

6. Is the measured voltage within the specification?

### YES

Go to "Component Inspection".

#### NO

When "B" voltage is not detected : Repair open in ground circuit and go to "Verification of Vehicle Repair".
 When the voltage difference between "A" and "B" is above 200mV : Eliminate the causes of excessive resistance and go to "Verification of Vehicle Repair".

#### COMPONENT INSPECTION E80298AD

- 1. IG KEY "OFF", ENGINE "OFF".
- 2. Check that AFS is installed in correctly according to the direction of arrow on AFS assy'.
- 3. Check contamination of air cleaner filter.
- 4. IG KEY "ON", ENGINE "ON".
- 5. Let IDLE RPM last after warming engine up.
- 6. Check the leakage of intake system(the leakage or damage of intercooler).
- 7. Check that VGT operates correctly.( Check if vacuum operating state of VGT actuator is appropriate, if VGT diaphragm and unison ring are stuck.)
- Check that EEGR actuator does not operate.
   (EEGR actuator turns "OFF" and 6% duty is outputted 3 min after rapid acceleration. Disconnect EEGR actuator connector if needed. )
- 9. Monitor signal voltage of AFS when engine speed lasts at approx. 800RPM using Scantool.
- 10. Check AFS output signal at idle after rapid acceleration.(EEGR actuator duty 50%)

Specification : When EEGR actuator does not operate (6%) at idle : 340mg/st ± 50 mg/st EEGR When EEGR actuator operates(50%) at idle : 200ms/st ± 50 mg/st

11. Is output signal within the specification?

#### YES

▶ Go to "Verification of Vehicle Repair".

NO

Replace AFS assy' and go to "Verification of Vehicle Repair".

### VERIFICATION OF VEHICLE REPAIR EBF3613A

After a repair, it is essential to verify that the fault is corrected.

- 1. After connecting Scantool select "DIAGNOSTIC TROUBLE CODES(DTCs)" mode.
- 2. Clear recorded DTC using Scantool.
- 3. Drive the vehicle within DTC "Enable conditions" in "General information".
- 4. After selecting "DIAGNOSTIC TROUBLE CODES(DTCs)" mode and check if DTC is recorded again.
- 5. Are any DTCs recorded ?

#### YES

▶ Go to the DTC guide of recorded NO. in Scantool.

#### NO

System operates within specification.

## DTC P0102 MASS OR VOLUME AIR FLOW CIRCUIT LOW INPUT

### COMPONENT LOCATION E67BD653

Refer to DTC P0101.

### GENERAL DESCRIPTION EED47B5E

Refer to DTC P0101.

### DTC DESCRIPTION EC364715

P0102 is set when AFS output voltage below 0.2V(below 1200Hz) is detected for more than 1.0 sec. This code is due to 1)open in power circuit 2) open or short to ground in signal circuit.

### DTC DETECTING CONDITION E609BDE5

Item		Detecting Condition		Possible Cause
DTC Strategy	<ul> <li>Voltage mo</li> </ul>	nitoring		
Enable Conditions	<ul> <li>Engine run</li> </ul>	ning		
ThresholdValue	Abnormal minimum output signal( below 1200Hz )			
DiagnosticTime	• 1.0 sec.		AFS circuit	
	Fuel Cut	NO		<ul> <li>AFS component</li> </ul>
	EGR Off	YES	inatonasi	
Fail Safe	Fuel Limit	YES	1	
	MIL	YES		

#### SPECIFICATION EFA5917B

	Output frequ			
Intake air quantity (Kg/h)	<b>20</b> °C	<b>80</b> ී	deviation [ % ]	
8	1.97		<b>±3</b> 0,000,000,000,000,000,000,000,000,000,	
10	2.01	2.01	±2	
40	2.50	2.50	±2	
105	3.20	3.20	±2	
220	4.30		±2	
480	7.80	7.80	±2	
560	9.50		±3	

#### SCHEMATIC DIAGRAM E3DA1CE8

Refer to DTC P0101.

#### SIGNAL WAVEFORM AND DATA E675FF23

Refer to DTC P0101.

#### MONITOR SCANTOOL DATA EB6D9EB9

Refer to DTC P0101.

#### TERMINAL AND CONNECTOR INSPECTION EEF13FE6

Refer to DTC P0101.

#### POWER CIRCUIT INSPECTION E9298D0A

- 1. Check power circuit voltage
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect AFS connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of AFS connector terminal 1 and 4.

```
Specification : Terminal 4 : 4.8V~5.1V (Sensor power)
Terminal 1 : 11.5V~13.0V (IG Power)
```

5) Is the measured voltage within the specification?

### YES

Go to "Signal Circuit Inspection".

#### NO

When output voltage is not detected at terminal 1 :

Repair open in In-pannel junction box 10A ECU fuse and related circuit and go to "Verification of Vehicle Repair".

When output voltage is not detected at terminal 4 :

Repair open between AFS connector terminal 4 and ECM connector 37, and go to "Verification of Vehicle Repair".

#### SIGNAL CIRCUIT INSPECTION EA62F383

- 1. Check signal circuit voltage
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect AFS connector and ECM connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of AFS connector terminal 5.

Specification : 4.8~5.1V

5) Is the measured voltage within the specification?

### YES

Go to "Ground Circuit Inspection".

### NO

Go to "2. Check open in signal circuit" as follows.

#### 2. Check short to ground in signal circuit

- 1) IG KEY "OFF", ENGINE "OFF".
- 2) Disconnect AFS sensor connector and ECM connector.
- 3) Check continuity between AFS connector terminal 5 and ECM connector terminal 42.

Specification : Discontinuity (Infinite  $\Omega$ )

4) Is the measured resistance within the specification?

### YES

Go to "3. Check short to ground in signal circuit" as follows.

#### NO

- Repair open in signal circuit and go to "Verification of Vehicle Repair".
- 3. Check short to ground in signal circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect AFS sensor connector and ECM connector.
  - 3) Check continuity between AFS connector terminal 5 and chassis ground.

Specification : Discontinuity(Infinite  $\Omega$ )

4) Is the measured resistance within the specification?

#### YES

Go to "Ground Circuit Inspection".

NO

Repair short to ground in signal circuit and go to "Verification of Vehicle Repair".

### GROUND CIRCUIT INSPECTION EA33B6F0

- 1. IG KEY "OFF", ENGINE "OFF".
- 2. Disconnect AFS connector.
- 3. IG KEY "ON".
- 4. Measure the voltage of AFS connector terminal 4. [ TEST "A" ]
- 5. Measure the voltage between AFS connector terminal 4 and 2. [TEST "B"] (terminal 4 : Check + prove, terminal 2 : Check - prove)

Specification : [TEST "A"] Voltage - [TEST "B"] Voltage = below 200mV

6. Is the measured voltage within the specification?

#### YES

Go to "Component Inspection".

#### NO

When "B" voltage is not detected : Repair open in ground circuit and go to "Verification of Vehicle Repair".
 When the voltage difference between "A" and "B" is above 200mV : Eliminate the causes of excessive resistance and go to "Verification of Vehicle Repair".

#### COMPONENT INSPECTION E9B14E12

- 1. IG KEY "OFF", ENGINE "OFF".
- 2. Check that AFS is installed in correctly according to the direction of arrow on AFS assy'.
- 3. Check contamination of air cleaner filter.
- 4. IG KEY "ON", ENGINE "ON".
- 5. Let IDLE RPM last after warming engine up.
- 6. Check the leakage of intake system(the leakage or damage of intercooler).
- 7. Check that VGT operates correctly.( Check if vacuum operating state of VGT actuator is appropriate, if VGT diaphragm and unison ring are stuck.)
- Check that EEGR actuator does not operate.
   (EEGR actuator turns "OFF" and 6% duty is outputted 3 min after rapid acceleration. Disconnect EEGR actuator connector if needed. )
- 9. Monitor signal voltage of AFS when engine speed lasts at approx. 800RPM using Scantool.
- 10. Check AFS output signal at idle after rapid acceleration.(EEGR actuator duty 50%)

Specification : When EEGR actuator does not operate (6%) at idle : 340 mg/st  $\pm$  50 mg/st EEGR When EEGR actuator operates(50%) at idle : 200 ms/st  $\pm$  50 mg/st

11. Is output signal within the specification?

#### YES

▶ Go to "Verification of Vehicle Repair".

#### NO

Replace AFS assy' and go to "Verification of Vehicle Repair".

#### VERIFICATION OF VEHICLE REPAIR E568894F

Refer to DTC P0101.

#### MASS OR VOLUME AIR FLOW CIRCUIT HIGH INPUT **DTC P0103**

#### COMPONENT LOCATION E2FA3233

Refer to DTC P0101.

#### GENERAL DESCRIPTION EE2B623B

Refer to DTC P0101.

#### DTC DESCRIPTION EA3BB6AD

P0103 is set when AFS output voltage above 14100Hz is detected for more than 1.0 sec. This code is due to excessive output voltage from sensor component or poor connection in sensor circuit.

### DTC DETECTING CONDITION E2A1D422

ltem		Detecting	Possible Cause	
DTC Strategy	Voltage monitoring			
Enable Conditions	Engine running			
ThresholdValue	Abnormal maximum output signal( above 14100Hz )			an a
DiagnosticTime	• 1.0 sec.			• AFS circuit
	Fuel Cut	NO		<ul> <li>AFS component</li> </ul>
Fail Safe	EGR Off	YES	(Cadaeq8	机组造组织 的现在分词 化二氟二氟
	Fuel Limit	YES		
	MIL	YES		6.45. m.8.30°

#### SPECIFICATION EDUEF6B8

Intoka air anantitu (Kalh)	Output frequ			
Intake air quantity (Kg/h)	20°C 80°C		deviation [ % ]	
8	1.97		±3	
10	2.01	2.01	±2	
40	2.50	2.50	±2	
105	3.20	3.20	±2	
220	4.30		±2	
480	7.80	7.80	±2	
560	9.50		±3	

### SCHEMATIC DIAGRAM E3A3EDE1

Refer to DTC P0101.

### SIGNAL WAVEFORM AND DATA E4639CCF

Refer to DTC P0101.

#### MONITOR SCANTOOL DATA E4B4D728

Refer to DTC P0101.

#### TERMINAL AND CONNECTOR INSPECTION E3508D2B

Refer to DTC P0101.

#### POWER CIRCUIT INSPECTION EBCC1181

- 1. Check power circuit voltage
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect AFS connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of AFS connector terminal 1 and 4.

```
Specification : Terminal 4 : 4.8V~5.1V (Sensor power)
Terminal 1 : 11.5V~13.0V (IG Power)
```

5) Is the measured voltage within the specification?

#### YES

Go to "Signal Circuit Inspection".

#### NO

When output voltage is not detected at terminal 1 :

Repair open in In-pannel junction box 10A ECU fuse and related circuit and go to "Verification of Vehicle Repair".

When output voltage is not detected at terminal 4 :

Repair open between AFS connector terminal 4 and ECM connector 37, and go to "Verification of Vehicle Repair".

#### SIGNAL CIRCUIT INSPECTION E88C1E1D

- 1. Check signal circuit voltage
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect AFS connector and ECM connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of AFS connector terminal 5.

Specification: 4.8~5.1V

5) Is the measured voltage within the specification?

#### YES

Go to "Ground Circuit Inspection".

FLB -157

		NO		an An an Anna an Anna an Anna Anna Anna
		Go to "2. Check open in signal circuit" as follows.	the second states of the	an a
2.	Ch	Check short to ground in signal circuit		
	1)	1) IG KEY "OFF", ENGINE "OFF".	• • • • • • • • • • • • • • • • • • •	1. 19 1. 1. 1. 1. 1. 1.
	2)	2) Disconnect AFS sensor connector and ECM connector.		
	3)	3) Check continuity between AFS connector terminal 5 and ECM connecto	r terminal 42.	◎愛師・第二、○○○○○○○○○○○○○○○○○○○○○○○○○○○○○○○○○○○○
5	Specif	ecification : Discontinuity ( Infinite $\Omega$ )		
	4)	4) Is the measured resistance within the specification?		
		YES		
		Go to "3. Check short to ground in signal circuit" as follows.	en de la companya de Este en la companya de la companya d	
		63/Maryev/asses	and and an and a second se	vi .
		Received and a second		ey, in the second
~		Repair open in signal circuit and go to "Verification of Vehicle Repair".		e sur els recu
3.		Check short to ground in signal circuit		
		1) – IG KEY "OFF", ENGINE "OFF". 1999 – OV flistsingmuss strotestas 1 OV id etais beitenage meuner tainen (* 19		
	2)	<ol> <li>Disconnect AFS sensor connector and ECM connector.</li> </ol>	(stack mensi	at Angles Son
<u></u>	3)	3) Check continuity between AFS connector terminal 5 and chassis ground.		·蒙伦哈里尔的第三人称单数 1990年1月1日
_S	pecifi	cification : Discontinuity(Infinite $\Omega$ )		
	4)	Is the measured resistance within the specification?		
		▶ Go to "Ground Circuit Inspection".		
		ΝΟ		
		Repair short to ground in signal circuit and go to "Verification of Vehicle	e Repair".	
GF	ROUI			
1.		G KEY "OFF", ENGINE "OFF".		$ \begin{array}{c} \sum\limits_{i=1}^{n} \sum\limits_{j=1}^{n} \sum\limits_{j=1}^{n} \sum\limits_{j=1}^{n} \sum\limits_{i=1}^{n} \sum\limits_{j=1}^{n} \sum \sum\limits_{j=1}^{n} \sum\limits_{j=1}^{n} \sum\limits_{j=1}$
2.		Disconnect AFS connector.		(如) 《 考
3.				a provinsi se
4.	Mea	leasure the voltage of AFS connector terminal 4. [TEST "A"]		
5.	Mea	leasure the voltage between AFS connector terminal 4 and 2. [TEST "B" ] terminal 4 : Check + prove , terminal 2 : Check - prove )		

Specification : [TEST "A"] Voltage - [TEST "B"] Voltage = below 200mV

6. Is the measured voltage within the specification?

#### YES

▶ Go to "Component Inspection".

### NO

When "B" voltage is not detected : Repair open in ground circuit and go to "Verification of Vehicle Repair".
 When the voltage difference between "A" and "B" is above 200mV : Eliminate the causes of excessive resistance and go to "Verification of Vehicle Repair".

#### COMPONENT INSPECTION E9B307D1

- 1. IG KEY "OFF", ENGINE "OFF".
- 2. Check that AFS is installed in correctly according to the direction of arrow on AFS assy'.
- 3. Check contamination of air cleaner filter.
- 4. IG KEY "ON", ENGINE "ON".
- 5. Let IDLE RPM last after warming engine up.
- 6. Check the leakage of intake system(the leakage or damage of intercooler).
- 7. Check that VGT operates correctly.( Check if vacuum operating state of VGT actuator is appropriate, if VGT diaphragm and unison ring are stuck.)
- Check that EEGR actuator does not operate.
   (EEGR actuator turns "OFF" and 6% duty is outputted 3 min after rapid acceleration. Disconnect EEGR actuator connector if needed. )
- 9. Monitor signal voltage of AFS when engine speed lasts at approx. 800RPM using Scantool.
- 10. Check AFS output signal at idle after rapid acceleration.(EEGR actuator duty 50%)

Specification : When EEGR actuator does not operate (6%) at idle : 340 mg/st  $\pm$  50 mg/st EEGR When EEGR actuator operates(50%) at idle : 200 ms/st  $\pm$  50 mg/st

11. Is output signal within the specification?



Go to "Verification of Vehicle Repair".

#### NO

Replace AFS assy' and go to "Verification of Vehicle Repair".

#### VERIFICATION OF VEHICLE REPAIR E761E5CE

Refer to DTC P0101.

## DTC P0107 BOOST PRESS. SENSOR CIRCUIT-LOW INPUT

### COMPONENT LOCATION E9F40043

$(1 + 1)^{-1} \sum_{i=1}^{n} (1 + 1)^{-1} \sum_{i=1$
A strategie of the second s

EWPF602Q

### GENERAL DESCRIPTION E86D171D

Atmospheric sensor is installed in ECM and senses atmospheric pressure where the vehicle is.Based on singal of atmospheric sensor, air density is calculated. And atmospheric sensor is used to detect mass air flow with MAFS, IATS. This sensor is required to perform 1) fuel injection quantity correction in high altitude and 2) EGR control. Atmospheric pressure is fixed at 900hpa when atmospheric sensor fails.

### DTC DESCRIPTION E09A9210

8 83 - 06743408 - 68.8 X

P0107 is set when the voltage below 250mV - minimum output voltage of Atmospheric pressure sensor - is detected for more than 0.4 sec. This code is due to the failure of the sensor inside of ECM.

# DTC DETECTING CONDITION E8866967

Item		Detecting	Condition equate	Possible Cause		
DTC Strategy	<ul> <li>Voltage mo</li> </ul>	nitoring				
Enable Conditions	• IG KEY "O	N"				
ThresholdValue	<ul> <li>When output voltage is below the minimum value.(below 152mV)</li> </ul>					
DiagnosticTime	• 2.0 sec.			Atmospheric pressure		
	Fuel Cut	NO		sensor (ECM component)		
Foil Sofo	EGR Off	YES	Atmospheric pressure			
Fail Safe	Fuel Limit	YES	is fixed at 1000hpa.			
	MIL	NO				

LGJF003B

#### **SPECIFICATION** E40B9D80

#### 1ATM IS SAME AS

hpa (hecto pascal)	mb	mmHg
1013	1013	760

#### MONITOR SCANTOOL DATA E541B385

- Connect scantool to Data Link Cable. (DLC) 1.
- Warm engine up to normal operating temperature. 2.
- Turn "OFF" electrical devices and A/C. 3
- Monitor "ATMOSPHERIC PRESS. SNSR" parameter on the scantool. 4.

Specification : Approx. 1 atm is displayed

	1.2 CURRENT DA	TA	16/	<b>′54</b>
	-			
×	FUEL PRESSURE MEASURED	28.2	MPa	的复数变得。 负担保留利用的 一口
×	RAIL PRESS. REGULATOR1	22.7		
×	AIR MASS PERCYLINDER	359.	7mg/st	💼 metyski eko mesnisis oli 👎 de ur sekelor usonos olimu. Ekonomi
×	ATMOSPHERIC PRESS.SNSR	1001	hPa	and the first of the second statement of the second statement.
×	ACCEL PEDAL SENSOR	0.0	%	n i smean te kaal moniki mettij al 3) feel algaditaa geanter ootan at te nite feelo in 1920 taan oo nakabeete xedaale tais
×	BOOST PRESSURE SENSOR	1015	hPa	2. 新聞の「「新文」には1000には新聞のないので、「「「「「「「「「「「」」」」」」」」」」」」」」」」」」」」」」」」」」
×	VGT ACTUATOR	60.0	%	Line of the state
×	ENGINE SPEED SENSOR	794	rpm	· · · · · · · · · · · · · · · · · · ·
			- /) s 54	🔽 este des des des des des des des des des de
	FIX FULL	GRPH	RCRD	

#### Fight

Fig.1) The atmospheric pressure where the vehicle is displayed. atmospheric pressure decreases as vehicle going up to higher altitude. The pressure at average level of sea surface is regarded as 1atm and, check if the pressure different from 1 atm is displayed. (1 atm is correct pressure)

#### **COMPONENT INSPECTION** E65371A3

- 1. ECM Component Inspection
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect ECM.
  - 3) Replace ECM, check if abnormal operations disappear.
  - If problems are corrected, replace ECM. 4)

#### VERIFICATION OF VEHICLE REPAIR E1028F8A

After a repair, it is essential to verify that the fault is corrected.

1. After connecting Scantool select "DIAGNOSTIC TROUBLE CODES(DTCs)" mode.

### DTC TROUBLESHOOTING PROCEDURES

- 2. Clear recorded DTC using Scantool.
- 3. Drive the vehicle within DTC "Enable conditions" in "General information".
- 4. After selecting "DIAGNOSTIC TROUBLE CODES(DTCs)" mode and check if DTC is recorded again.
- 5. Are any DTCs recorded ?



▶ Go to the DTC guide of recorded NO. in Scantool.



System operates within specification.

### DTC P0108 BOOST PRESS. SENSOR CIRCUIT-HIGH INPUT

COMPONENT LOCATION E8720404

Refer to DTC P0107.

#### GENERAL DESCRIPTION E27C4D2D

Refer to DTC P0107.

#### DTC DESCRIPTION EF61D998

P0108 is set when the voltage above 4.85V - maximum output voltage of Atmospheric pressure sensor - is detected for more than 0.4 sec.. This code is due to fhe failure of the sensor inside of ECM.

#### DTC DETECTING CONDITION E1918F99

Item		Detecting	Possible Cause			
DTC Strategy	<ul> <li>Voltage more</li> </ul>	nitoring				
Enable Conditions	• IG KEY "OI	N"				
ThresholdValue	<ul> <li>When output value. (abo)</li> </ul>	-	above the maximum			
DiagnosticTime	• 2.0 sec.			• Atmospheric pressure		
	Fuel Cut	NO		sensor (ECM component)		
	EGR Off	YES	Atmospheric pressure			
Fail Safe	Fuel Limit	YES	is fixed at 1000hpa.			
	MIL	NO	]			

#### SPECIFICATION E57B423D

#### 1ATM IS SAME AS

hpa (hecto pascal)	mb	mmHg
1013	1013	760

#### MONITOR SCANTOOL DATA EB1223B6

Refer to DTC P0107.

#### COMPONENT INSPECTION E98E4A16

- 1. ECM Component Inspection
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect ECM.
  - 3) Replace ECM, check if abnormal operations disappear.
  - 4) If problems are corrected, replace ECM.


## VERIFICATION OF VEHICLE REPAIR ETOAE12C

Refer to DTC P0107.

en en service de la composición de la c

### DTC P0112 INTAKE AIR TEMPERATURE SENSOR1 CIRCUIT LOW INPUT

#### COMPONENT LOCATION E6F92D4C



EWPF602P

#### GENERAL DESCRIPTION EB502D74

Intake Air Temperature Sensor(IATS) is NTC thermistor. Installed inside of both AFS and BPS, it senses intake air temperature. In case of EURO-4 diesel engine, IATS is installed in front of turbocharger(inside of AFS) and behind it(inside of BPS). Comparing air temperature from both sensors(one is intake air temperature, the other is air temperature passing through turbo charger), more accurate sensing of intake air temperature is possible.With intake air temperature signal, ECM performs EGR control correction and fuel injection quantity correction.(AFS is needed for EGR FEED BACK control in electronically controlled diesel engine. The calculation of air density at certain temperature is required to perform EGR FEED BACK control correctly.)

#### DTC DESCRIPTION EAE63B7C

P0112 is set when the voltage below 73mV - minimum output voltage of IATS(inside of AFS) - is detected for more than 2.0 sec. This code is due to short to ground in IATS signal circuit.

Item		Detecting	Condition	Possible Cause
DTC Strategy	Voltage Mor	nitoring		
Enable Conditions	• IG KEY "OI	N"		
ThresholdValue	<ul> <li>When output value ( below</li> </ul>	-	pelow the minimum	
DiagnosticTime	• 2.0 sec.	· · · · · · · · · · · · · · · · · · ·		<ul><li>IATS circuit</li><li>IATS component</li></ul>
	Fuel Cut	NO		
Fail Safe	EGR Off	NO	Intake air temperature	
	Fuel Limit	NO	is regarded as 50℃	
	MIL	NO		


#### DTC DETECTING CONDITION E23B3AC9

### DTC TROUBLESHOOTING PROCEDURES

### SPECIFICATION EDA0141D

Tempera- ture	<b>-40</b> ℃	<b>-20</b> ℃	<b>0</b> °C	<b>20</b> ℃	<b>40</b> °C	<b>60</b> °C	80°C
Resistance	35.14	12.66	5.12	2.29	1.10	0.57	0.31
	~43.76KΩ	~15.12KΩ	~5.89KΩ	~2.55KΩ	~1.24KΩ	~0.65KΩ	~0.37KΩ

### SCHEMATIC DIAGRAM E4D87594



EWPF001W

LGJF004P

### SIGNAL WAVEFORM AND DATA E55F3DEC




Fig.1) IATS output signal at 25°C. The higher temperature rises, the lower signal voltage becomes.

#### MONITOR SCANTOOL DATA ED7D5A3F

- 1. Connect scantool to Data Link Cable. (DLC)
- 2. Warm engine up to normal operating temperature.
- 3. Turn "OFF" electrical devices and A/C.
- 4. Monitor "AIR TEMPERATURE SENSOR" parameter on the scantool.

Specification : Intake air temperature is displayed

		1.	2 CURR	ENT D	ATA	13/	54
					<i></i>	-	۸
×	FUEL	PRESSU	RE MEA	SURED	28.2	MPa	
×	RAIL	PRESS.	REGUL	ATOR1	22.7	%	<b>*</b>
¥	AIR M	ASS PE	RCYLIN	DER	359.	7mg∕st	
×	AIR T	EMPERA	TURE S	ENSOR	34.7	°C	
×	EGR A	CTUATO	R		6.0	%	
×	WATER	TEMP.	SENSOR	1	93.5	°C	
×	ENGIN	E SPEE	d sens	OR	794	rpm	
	CALCU	LAT.LO	AD VAL	UE.			
							Ţ
	FIX		FULL		GRPH	RCRD	1

#### Fig.1

Fig.1) "AIR TEMPERATURE SENSOR" value should not change according to engine state.

LGJF004Q

#### TERMINAL AND CONNECTOR INSPECTION EBAB5DFC

1. Electrical systems consist of a lot of harness and connectors, poor connection of terminals can cause various problems and damge of component.

- 2. Perform checking procedure as follows.
  - 1) Check damage of harness and terminals : Check terminals for contact resistance, corrosion and deformation.
  - 2) Check connecting condition of ECM and component connector : Check terminal seperation, damage of locking device and connecting condition between terminal and wiring.

## 

Disconnect the pin which requires checking at male connector and insert it to the terminal at female connector or checking connecting condition. (after checking, reconnect the pin at correct position.)

#### 3. Is the problem found?

### YES

Repair the trouble causing part and go to "Verification of Vehicle Repair".

#### NO

▶ Go to "Signal Circuit Inspection".

### SIGNAL CIRCUIT INSPECTION EEE76E97

- 1. Check signal circuit voltage
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect IATS connector
  - 3) IG KEY "ON"
  - 4) Measure the voltage of terminal 3 of AFS connector.

Speci	fication : 4.8V~5.1V	
5)	Is the measured voltage within the specification?	
	Go to "Component Inspection".	na se stanta en en
	NO	an La ch
	Go to "2.Check short to ground in signal circuit" as follows.	
2. Ch	eck short to ground in signal circuit	
1)	IG KEY "OFF", ENGINE "OFF".	
2)	Disconnect AFS connector and ECM connector	
3)	Check continuity between AFS connector terminal 3 and chassis ground.	

#### Specification : Discontinuity (Infinite $\Omega$ )

4) Is the measured resistance within the specification?

### YES

Go to "Component Inspection".




Repair short to ground in signal circuit and go to "Verification of Vehicle Repair".

#### COMPONENT INSPECTION EAE87388

- 1. Ignition "OFF", Turn Engine "OFF".
- 2. Disconnect AFS connector.
- 3. Measure resistance of IATS component terminal 3 and 2, referring to resistance characteristic table of specification of General information.

Specification : Refer to Specification of General Information.



LGJF004S

化物质学学校的 人名法格德尔 自己分词转换

4. Is the measured resistance at certain temperature within the specified resisance range at the temperature?

#### YES

Go to "Verification of Vehicle Repair".

#### NO

▶ Replace AFS ASSY' and go to "Verification of Vehicle Repair".

#### VERIFICATION OF VEHICLE REPAIR EF5AF913

After a repair, it is essential to verify that the fault is corrected.

- 1. After connecting Scantool select "DIAGNOSTIC TROUBLE CODES(DTCs)" mode.
- 2. Clear recorded DTC using Scantool.
- 3. Drive the vehicle within DTC "Enable conditions" in "General information".
- 4. After selecting "DIAGNOSTIC TROUBLE CODES(DTCs)" mode and check if DTC is recorded again.
- 5. Are any DTCs recorded ?

#### FLB -169

### YES

▶ Go to the DTC guide of recorded NO. in Scantool.



System operates within specification.

### DTC P0113 INTAKE AIR TEMPERATURE SENSOR1 CIRCUIT HIGH INPUT

#### COMPONENT LOCATION E23CBC8B

Refer to DTC P0112.

#### GENERAL DESCRIPTION E74D312E

Refer to DTC P0112.

#### DTC DESCRIPTION E54686EC

P0113 is set when the voltage above 4886mV - maximum output voltage of IATS - is detected for more than 2.0 sec. This code is due to 1) open or 2) short to ground or 3) short to battery in IATS signal circuit.

#### DTC DETECTING CONDITION E8666032

Item		Detecting	Condition	Possible Cause	
DTC Strategy	<ul> <li>Voltage Mor</li> </ul>	nitoring			
Enable Conditions	IG KEY "Of	N"			
ThresholdValue	<ul> <li>When output value ( above</li> </ul>	-	above the maximum )		
DiagnosticTime	• 2.0 sec.			IATS circuit	
	Fuel Cut	NO		<ul> <li>IATS component</li> </ul>	
Fail Safe	EGR Off	NO	<ul> <li>Intake air temperature</li> </ul>		
	Fuel Limit	NO	is regarded as 50 ℃		
	MIL	NO			

### SPECIFICATION E4FDA9DC

Tempera- ture	<b>-40</b> ℃	<b>-20</b> ℃	0°C	20°C	<b>40</b> ℃	<b>60</b> ℃	<b>30℃</b>
Resistance	35.14	12.66	5.12	2.29	1.10	0.57	0.31
	~43.76KΩ	~15.12KΩ	~5.89KΩ	~2.55KΩ	~1.24KΩ	~0.65KΩ	~0.37KΩ

### SCHEMATIC DIAGRAM EA04F377

Refer to DTC P0112.

#### SIGNAL WAVEFORM AND DATA EB11A129

Refer to DTC P0112.

#### MONITOR SCANTOOL DATA E5DF25E2

Refer to DTC P0112.

### TERMINAL AND CONNECTOR INSPECTION EFFECTION

Refer to DTC P0112.

#### SIGNAL CIRCUIT INSPECTION E3173A5C

- 1. Check signal circuit voltage
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect AFS connector
  - 3) IG KEY "ON"
  - 4) Measure the voltage of terminal 3 of AFS connector.

Specification : 4.8V~5.1V

5) Is the measured voltage within the specification?

### YES

Go to "Component Inspection"

#### NO

- Go to "2.Check open in signal circuit" as follows.
- 2. Check open in signal circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect AFS connector and ECM connector
  - 3) Check continuity between AFS connector terminal 3 and ECM connector terminal 89.

Specification : Continuity (below  $1.0\Omega$ )

4) Is the measured resistance within the specification?



Go to "3.Check short to battery in signal circuit " as follows



- Repair open spots in signal circuit and go to "Verification of Vehicle Repair".
- 3. Check short to battery in signal circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect AFS connector and ECM connector
  - 3) IG KEY "ON"
  - 4) Measure the voltage of terminal 3 of AFS connector.

Specification : 0.0V~0.1V

5) Is abnormal voltage detected in the circuit with both connector disconnected?

#### YES

Repair short to battery and go to "Verification of Vehicle Repair".

NO

Go to "Ground Circuit Inspection".

#### GROUND CIRCUIT INSPECTION E30D3F0E

- 1. IG KEY "OFF", ENGINE "OFF".
- 2. Disconnect AFS connector and ECM connector
- 3. IG KEY "ON"
- 4. Measure the voltage of terminal 3 of AFS connector. [ TEST "A" ]
- 5. Measure the voltage of AFS terminal 3 and terminal 2. [TEST "B"] (terminal 3 : Check + prove, terminal 2 : Check - prove)

Specification : the voltage difference between TEST "A" and TEST "B" is within 200mV

6. Is the measured voltage within the specification?

## YES

Go to "Component Inspection".

#### NO


When "B" voltage is not detected : Repair open in ground circuit and go to "Verification of Vehicle Repair".
 When the voltage difference between "A" and "B" is above 200mV : Eliminate the causes of excessive resistance and go to "Verification of Vehicle Repair".

#### COMPONENT INSPECTION EBFA973F

- 1. Ignition "OFF", Turn Engine "OFF".
- 2. Disconnect AFS connector.
- 3. Measure resistance of IATS component terminal 3 and 2, referring to resistance characteristic table of specification of General information.

Specification : Refer to Specification of General Information.

LGJF004S



4. Is the measured resistance at certain temperature within the specified resisance range at the temperature?

## YES

▶ Go to "Verification of Vehicle Repair".

#### NO


Replace AFS ASSY' and go to "Verification of Vehicle Repair".

# VERIFICATION OF VEHICLE REPAIR EA1C9682

#### Refer to DTC P0112.

# DTC P0117 ENGINE COOLANT TEMPERATURE CIRCUIT LOW INPUT

#### COMPONENT LOCATION E8DC9AD8



LGJF012E

#### GENERAL DESCRIPTION E6B8228B

Engine Coolant Temperature Sensor(ECTS), installed in coolant line, senses engine coolant temperature. With the information about engine coolant temperature, ECM performs fuel injection quantity correction, cooling fan control and glow relay operating duration control. Especially, because ECTS signal is main variable of fuel injection quantity correction when engine is cold, sensor trouble makes starting engine difficult when engine is cold. If engine is running when ECTS is out of order, ECM regards engine coolant temperature as 80°C. And during cranking, ECM considers engine coolant temperature as -10°C. Besides, cooling fan, which is controlled based on ECTS signal, operates at HIGH-MODE to prevent engine overheat and supplementary heater is deactivated.

#### DTC DESCRIPTION E5D85804

P0117 is set when the voltage below 225mV - minimum output voltage of ECTS - is detected for more than 2.0 sec. This code is due to short to ground in signal circuit.


### DTC DETECTING CONDITION EF7D1EDB

Item		Detecting	Condition	Possible Cause		
DTC Strategy	<ul> <li>Voltage mor</li> </ul>	nitoring				
Enable Conditions	• IG KEY "Of	٧"				
ThresholdValue	<ul> <li>Output signation</li> <li>below 225m</li> </ul>					
DiagnosticTime	• 2.0 sec.		······································			
	Fuel Cut	NO	A/C condensor fan			
	EGR Off	YES	control operation based on engine			
	Fuel Limit	NO	coolant temperature	ECTS circuit		
Fail Safe	MIL	NO	<ul> <li>inhibited.</li> <li>PTC heater inhibited.</li> <li>Cooling fan is fixed at HIGH-MODE.</li> <li>during engine operation : temperature is fixed at 80 ℃ at cranking : temperature is fixed at -10 ℃</li> </ul>	ECTS component		

# SPECIFICATION EBC62BF1


Temperature	<b>-40</b> ℃	-20℃	<b>0</b> °C	20°C	<b>40</b> ℃
Resistance	48.14 <sup>k</sup> Ω	15.48±1.35 <sup>k</sup> Ω	5.790 kΩ	2.45±0.14 kΩ	1.148 <sup>k</sup> Ω
Temperature	<b>60</b> С	<b>80</b> ℃	<b>100</b> C	<b>110</b> °C	<b>120</b> ℃
Resistance	0.586 kΩ	0.322 kΩ	0.188 <sup>k</sup> Ω	0.147±0.002 <sup>k</sup> Ω	0.116 kΩ

### SCHEMATIC DIAGRAM E68C4B31



#### SIGNAL WAVEFORM AND DATA E939FD20

FR	СН	A 0.5	U)	5.0	S	CHB	1.0 V	а. 1
						1	: :	÷
:		: :		( * )	: : :			
				·····	*********** :			·····
					••- •			••••••
					* :		··	··· :
		····			·····			· · · · ·
mala				wh				÷.
····								••••••
	····•	···•	···· •					·
		····			:;.		··	· · · · · ·
		ZOOM		: N 29	EMO	RECD	MENI	i



### MONITOR SCANTOOL DATA EB12FAOC

- 1. Connect Scantool to Data Link Connector (DLC).
- 2. Warm engine up to normal operating temperature.
- 3. Turn "OFF" electrical devices and A/C.
- 4. Monitor "ECTS" parameter on the Scantool.

#### LGJF012G

Specification : Current enigne coolant temperature is displayed.

	1.2 CURRENT DATA 17/5	i4
×	FUEL PRESSURE MEASURED 28.5 MPa	
×	AIR MASS PERCYLINDER 346.9mg/st	
×	AIR TEMPERATURE SENSOR 37.1 °C	龖
×	EGR ACTUATOR 6.0 %	
×	WATER TEMP.SENSOR 93.5 °C	
×	ACCEL PEDAL SENSOR 0.0 %	
×	VEHICLE SPEED SENSOR Ø km/h	
×	ENGINE SPEED SENSOR 794 rpm	
		<b>\$</b>
	FIX FULL GRPH RCRD	
E	.1	

Fig.1) Check if 1) incorrect value is displayed 2) coolant temperature is fixed at 80 °C suddenly during driving 3)coolant temperature is fixed at -10 °C when turning IG KEY "ON". That coolant temperature is fixed at -10 °C or 80 °C means failure of ECTS. To prevent overheat of engine due to ECTS, if ECTS fails, cooling fan operates continuously.

LGJF012H

### TERMINAL AND CONNECTOR INSPECTION E878EAA6

- 1. Electrical systems consist of a lot of harness and connectors, poor connection of terminals can cause various problems and damge of component.
- 2. Perform checking procedure as follows.
  - 1) Check damage of harness and terminals : Check terminals for contact resistance, corrosion and deformation.
  - 2) Check connecting condition of ECM and component connector : Check terminal seperation, damage of locking device and connecting condition between terminal and wiring.

### **NOTE**

Disconnect the pin which requires checking at male connector and insert it to the terminal at female connector for checking connecting condition. (after checking, reconnect the pin at correct position.)

3. Is the problem found?

### YES

Repair the trouble causing part and go to "Verification of Vehicle Repair".

### NO

Go to "Signal Circuit Inspection ".

### SIGNAL CIRCUIT INSPECTION E2460B02

- 1. Check signal circuit voltage
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect ECTS connector.

#### FLB -178

- 3) IG KEY "ON".
- 4) Measure the voltage of ECTS connector terminal 1.

Specification : 4.8V~5.1V

5) Is the measured voltage within the specification?

#### YES

▶ Go to "Component Inspection".

#### NO

- ▶ Go to "2.Check short to ground in signal circuit" as follows.
- 2. Check short to ground in signal circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect ECTS connector and ECM connector.
  - 3) Check continuity between ECTS connector terminal 1 and chassis ground.

Specification : Discontinuity (Infinite  $\Omega$ )

4) Is the measured resistance within the specification?

#### YES

▶ Go to "Component Inspection".




Repair short to ground in signal circuit and go to "Verification of Vehicle Repair".

#### COMPONENT INSPECTION ED9E9948

- 1. IG KEY "OFF", ENGINE "OFF".
- 2. Disconnect ECTS connector.
- 3. Measure resistance between ECTS terminal 1 and 3, referring to resistance characteristic table of specification of General information.

Specification : Refer to Specification of General Information



4. Is the measured resistance at certain temperature within the specified resisance range at the temperature?

### YES

▶ Go to "Verification of Vehicle Repair".

### NO

Replace ECTS and go to "Verification of Vehicle Repair".

### VERIFICATION OF VEHICLE REPAIR EF5716DD

After a repair, it is essential to verify that the fault is corrected.

- 1. After connecting Scantool select "DIAGNOSTIC TROUBLE CODES(DTCs)" mode.
- 2. Clear recorded DTC using Scantool.
- 3. Drive the vehicle within DTC "Enable conditions" in "General information".
- 4. After selecting "DIAGNOSTIC TROUBLE CODES(DTCs)" mode and check if DTC is recorded again.
- 5. Are any DTCs recorded ?

#### YES

Go to the DTC guide of recorded NO. in Scantool.

#### NO

System operates within specification.

LGJF012I

# DTC P0118 ENGINE COOLANT TEMPERATURE CIRCUIT HIGH INPUT

#### COMPONENT LOCATION E3748580

Refer to DTC P0117.

#### GENERAL DESCRIPTION EA34F789

Refer to DTC P0117.

#### DTC DESCRIPTION EC516E76

P0118 is set when the voltage above 4965mV - maximum output voltage of ECTS - is detected for more than 2.0 sec. This code is due to open or short to battery in signal circuit or open in ground circuit.

### DTC DETECTING CONDITION E367E4AE

Item	Detecting Condition			Possible Cause	
DTC Strategy	<ul> <li>Voltage mor</li> </ul>	nitoring			
Enable Conditions	• IG KEY "01	٧"			
ThresholdValue	<ul> <li>Output signation above 4965</li> </ul>				
DiagnosticTime	• 2.0 sec.	·····			
	Fuel Cut	NO	<ul> <li>A/C condensor fan control operation based on engine coolant temperature</li> </ul>	an an an an an an Angla ga an an an	
	EGR Off	YES		en de la constante de la const La constante de la constante de	
	Fuel Limit	NO		ECTS circuit	
Fail Safe	MIL	NO	<ul> <li>inhibited.</li> <li>PTC heater inhibited.</li> <li>Cooling fan is fixed at HIGH-MODE.</li> <li>during engine operation : temperature is fixed at 80°C at cranking : temperature is fixed at -10°C</li> </ul>	• ECTS component	

### SPECIFICATION EC83690E

Temperature	<b>-40</b> ℃	-20 ℃	<b>0</b> °C	<b>20</b> ℃	<b>40</b>
Resistance	48.14 kΩ	15.48±1.35 <sup>k</sup> Ω	5.790 kΩ	2.45±0.14 kΩ	1.148 kΩ
Temperature	<b>60</b> ී	ට <b>ී 08</b>	<b>100</b> °C	110℃	<b>120</b> C
Resistance	0.586 kΩ	0.322 kΩ	0.188 kΩ	0.147±0.002 <sup>k</sup> Ω	0.116 kΩ

### SCHEMATIC DIAGRAM E6E9BDEA

Refer to DTC P0117.

# SIGNAL WAVEFORM AND DATA E0AF45C1

Refer to DTC P0117.

## MONITOR SCANTOOL DATA E25E8995

Refer to DTC P0117.

## TERMINAL AND CONNECTOR INSPECTION E1406196

Refer to DTC P0117.

#### SIGNAL CIRCUIT INSPECTION EDDBEE2B

- 1. Check signal circuit voltage
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect ECTS connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of ECTS connector terminal 1.

Specification: 4.8V~5.1V

5) Is the measured voltage within the specification?

#### YES

▶ Go to "Component Inspection".

NO

Go to "2.Check open in signal circuit" as follows.

#### 2. Check open in signal circuit

- 1) IG KEY "OFF", ENGINE "OFF".
- 2) Disconnect ECTS connector and ECM connector.
- 3) Check continuity between ECTS connector terminal 1 and ECM connector terminal 58.

Specification : continuity ( below  $1.0\Omega$  )

4) Is the measured resistance within the specification?

# YES

Go to "3.Check short to battery in signal circuit" as follows.



- Repair open in signal circuit and go to "Verification of Vehicle Repair".
- 3. Check short to battery in signal circuit

- 1) IG KEY "OFF", ENGINE "OFF".
- 2) Disconnect ECTS connector and ECM connector.
- 3) IG KEY "ON".
- 4) Measure the voltage of ECTS connector terminal 1.

```
Specification : 0.0V~0.1V
```

5) Is the measured voltage within the specification?

#### YES

Go to "Ground Circuit Inspection".



Repair short to battery in signal circuit and go to "Verification of Vehicle Repair".

#### GROUND CIRCUIT INSPECTION EEF18541

- 1. IG KEY "OFF", ENGINE "OFF".
- 2. Disconnect ECTS connector.
- 3. IG KEY "ON".
- 4. Measure the voltage of ECTS connector terminal 1. [TEST "A"]
- 5. Measure the voltage between ECTS connector terminal 1 and 3. [TEST "B"] (terminal 1 : Check + prove, terminal 3 : Check prove)

Specification : [TEST "A"] Voltage - [TEST "B"] Voltage = below 200mV

6. Is the measured voltage within the specification?

## YES

Go to "Component Inspection".

#### NO


When "B" voltage is not detected : Repair open in ground circuit and go to "Verification of Vehicle Repair".
 When the voltage difference between "A" and "B" is above 200mV : Eliminate the causes of excessive resistance and go to "Verification of Vehicle Repair".

#### COMPONENT INSPECTION EB98F37C

- 1. IG KEY "OFF", ENGINE "OFF".
- 2. Disconnect ECTS connector.
- Measure resistance between ECTS terminal 1 and 3, referring to resistance characteristic table of specification of General information.

Specification : Refer to Specification of General Information

LGJF012I



4. Is the measured resistance at certain temperature within the specified resisance range at the temperature?



Go to "Verification of Vehicle Repair".



Replace ECTS and go to "Verification of Vehicle Repair".


# VERIFICATION OF VEHICLE REPAIR EB7954D4

## Refer to DTC P0117.

N stom tel beloefab els lucitud 2017 to agostos incurrentes site.

# DTC P0182 FUEL TEMP SENSOR A CIRCUIT LOW INPUT

### COMPONENT LOCATION EOB3F071



EWPF602R

#### GENERAL DESCRIPTION E995A094

Fuel Temperature Sensor is NTC thermistor installed in fuel supplying line. It senses the temperature of fuel supplied to high pressure pump.Fuel temperature is limited (engine power is limited) to keep fuel temperature from reaching at 120 °C. This limit is to protect fuel line such as high pressure pump and injectors from damages due to rapid deterioration by vapor-lock phenomenon which can occur at high temperature or destruction of oil membrane.

#### DTC DESCRIPTION EBFBA02D

P0183 is set when the voltage below 53mV(0.053V) - minimum voltage of FTS output - is detected for more than 2.0 sec.. This code is due to short to ground in FTS signal circuit.

Item	Detecting Condition			Possible Cause
DTC Strategy	<ul> <li>Voltage Mor</li> </ul>	nitoring		
Enable Conditions	• IG KEY "ON"			
ThresholdValue	<ul> <li>When output signal is below the minimum value.(below 53mV)</li> </ul>			
DiagnosticTime	• 2.0sec.			FTS circuit
	Fuel Cut	NO		FTS component
Fail Safe	EGR Off	NO		
Fall Sale	Fuel Limit	NO		
	MIL	NO		


# DTC DETECTING CONDITION EE5AC201

# DTC TROUBLESHOOTING PROCEDURES

# SPECIFICATION E93B9415

Temperature	<b>-30</b> ℃	-20 ℃	-10℃	<b>0°0</b>	<b>20</b> °C
Resistance	22.22~31.78 <sup>k</sup> Ω	13.24~18.10 <sup>k</sup> Ω	8.16~10.74 kΩ	5.18~6.60 kΩ	2.27~2.73 kΩ
Temperature	<b>40</b> ℃	<b>50</b> ℃	<b>60</b> °С	70℃	
Resistance	1.059~1.281 kΩ	0.748~0.904 kΩ	0.538~0.650 kΩ	0.392~0.476 <sup>k</sup> Ω	

# SCHEMATIC DIAGRAM EC6FCA38



EWPF002E

# SIGNAL WAVEFORM AND DATA E67891F9





Fig.1) FTS output signal at 50 °C. The higher temperature rises, the lower signal voltage becomes.

LGJF006J

#### MONITOR SCANTOOL DATA E6773B66

- 1. Connect Scantool to Data Link Connector (DLC).
- 2. Warm engine up to normal operating temperature.
- 3. Turn "OFF" electrical devices and A/C.
- 4. Monitor "FUEL TEMPERATURE" parameter on the scantool.

Specification :Fuel temperature is displayed



#### Fig.1

Fig.1) Check if too high or low temperature is displayed.(too high or low temperature is abnormal value.)

LGJF006K

# TERMINAL AND CONNECTOR INSPECTION EE504BC3

- Electrical systems consist of a lot of harness and connectors, poor connection of terminals can cause various problems and damge of component.
- 2. Perform checking procedure as follows.
  - 1) Check damage of harness and terminals : Check terminals for contact resistance, corrosion and deformation.
  - 2) Check connecting condition of ECM and component connector : Check terminal seperation, damage of locking device and connecting condition between terminal and wiring.

## **NOTE**

Disconnect the pin which requires checking at male connector and insert it to the terminal at female connector or checking connecting condition. (after checking, reconnect the pin at correct position.)

3. Is the problem found?



Repair the trouble causing part and go to "Verification of Vehicle Repair".

NO

Go to "Signal Circuit Inspection ".

## SIGNAL CIRCUIT INSPECTION ED624926

- 1. Check signal circuit voltage
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect FTS connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of terminal 2 of FTS connector.

Specification : 4.8V~5.1V

5) Is the measured voltage within the specification?

# YES

▶ Go to "Component Inspection".

#### NO

- Go to "2.Check short to ground in signal circuit" as follows.
- 2. Check short to ground in signal circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect FTS connector and ECM connector.
  - 3) Check continuity between FTS connector terminal 2 and chassis ground.

Specification : Discontinuity (Infinite  $\Omega$ )

4) Is the measured resistance within the specification?

# YES

Go to "Component Inspection".




Repair short to ground in signal circuit and go to "Verification of Vehicle Repair".

# COMPONENT INSPECTION ED27E035

- 1. IG KEY "OFF", ENGINE "OFF".
- 2. Disconnect FTS connector.
- 3. Measure resistance of FTS component terminal 1 and 2, referring to resistance characteristic table of specification of General information.

Specification : Refer to Specification of General Information.

LGJF006L



4. Is the measured resistance at certain temperature within the specified resisance range at the temperature?

#### YES

▶ Go to "Verification of Vehicle Rapair".

#### NO

Replace FTS and go to "Verification of Vehicle Rapair".

#### VERIFICATION OF VEHICLE REPAIR E405D5F1

After a repair, it is essential to verify that the fault is corrected.

- 1. After connecting Scantool select "DIAGNOSTIC TROUBLE CODES(DTCs)" mode.
- 2. Clear recorded DTC using Scantool.
- 3. Drive the vehicle within DTC "Enable conditions" in "General information".
- 4. After selecting "DIAGNOSTIC TROUBLE CODES(DTCs)" mode and check if DTC is recorded again.
- 5. Are any DTCs recorded ?

#### YES

▶ Go to the DTC guide of recorded NO. in Scantool.

#### NO

System operates within specification.

# DTC P0183 FUEL TEMP SENSOR A CIRCUIT HIGH INPUT

# COMPONENT LOCATION E4A6D711

Refer to DTC P0182.

# GENERAL DESCRIPTION E98FOFB3

Refer to DTC P0182.

#### DTC DESCRIPTION E7DBD244

P0183 is set when the voltage above 4912mV - maximum voltage of FTS output - is detected for more than 2.0 sec.. This code is due to 1)open or short to battery in FTS signal circuit or 2)open in ground circuit.

# DTC DETECTING CONDITION E81D13EF

	Detecting	Condition	Possible Cause
<ul> <li>Voltage Mo</li> </ul>	nitoring	· · · · · · · · · · · · · · · · · · ·	
• IG KEY "O	N"	******	
<ul> <li>When output value.(abov/</li> </ul>	ut signal is a e 4912mV)	en Diversity of the constant	
• 2.0sec.		an a	FTS circuit
Fuel Cut	NO		<ul> <li>FTS component</li> </ul>
EGR Off	NO		
Fuel Limit	NO		
MIL	NO		a tha an an tha agus 19 an an t
	<ul> <li>IG KEY "O</li> <li>When output value.(abov)</li> <li>2.0sec.</li> <li>Fuel Cut</li> <li>EGR Off</li> <li>Fuel Limit</li> </ul>	<ul> <li>Voltage Monitoring</li> <li>IG KEY "ON"</li> <li>When output signal is a value.(above 4912mV)</li> <li>2.0sec.</li> <li>Fuel Cut NO</li> <li>EGR Off NO</li> <li>Fuel Limit NO</li> </ul>	<ul> <li>Voltage Monitoring</li> <li>IG KEY "ON"</li> <li>When output signal is above the maximum value.(above 4912mV)</li> <li>2.0sec.</li> <li>Fuel Cut NO</li> <li>EGR Off NO</li> <li>Fuel Limit NO</li> </ul>

FLB -189

## SPECIFICATION EE6D55B8

Temperature	-30 ℃	<b>-20</b> ്റ	<b>-10</b> °C	<b>3</b> 0	20 °C
Resistance	22.22~31.78 <sup>k</sup> Ω	13.24~18.10 <sup>k</sup> Ω	8.16~10.74 kΩ 5.18~6.60 kΩ		2.27~2.73kΩ
Temperature	<b>40</b> ℃	<b>50</b> ℃	<b>60</b> ℃	<b>70</b> ℃	
Resistance	1.059~1.281 <sup>k</sup> Ω	0.748~0.904 <sup>k</sup> Ω	0.538~0.650 <sup>k</sup> Ω	0.392~0.476 <sup>k</sup> Ω	

## SCHEMATIC DIAGRAM E098FF07

Refer to DTC P0182.

#### SIGNAL WAVEFORM AND DATA EFC959E7

Refer to DTC P0182.

#### MONITOR SCANTOOL DATA E04A4EC8

Refer to DTC P0182.

# TERMINAL AND CONNECTOR INSPECTION E9C1A781

Refer to DTC P0182.

### SIGNAL CIRCUIT INSPECTION E1822999

- 1. Check signal circuit voltage
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect FTS connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of terminal 2 of FTS connector.

Specification: 4.8V~5.1V

5) Is the measured voltage within the specification?

#### YES

▶ Go to "Ground Circuit Inspection".

NO

- ▶ Go to "2.Check open in signal circuit" as follows.
- 2. Check open in signal circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect FTS connector and ECM connector.

#### DTC TROUBLESHOOTING PROCEDURES

3) Check continuity between FTS connector terminal 2 and ECM connector terminal 11.

Specification : Continuity (below  $1.0\Omega$ )

4) Is the measured resistance within the specification?



Go to "3. Check short to battery in signal circuit" as follows.



- Repair open in signal circuit and go to "Verification of Vehicle Repair".
- 3. Check short to battery in signal circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect FTS connector and ECM connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of FTS connector terminal 2.

Specification : 0.0V~0.1V

5) Is abnormal voltage detected in the circuit with both connector disconnected?

# YES

Repair short to battery and go to "Verification of Vehicle Repair".

#### NO

▶ Go to "Ground Circuit Inspection".

#### GROUND CIRCUIT INSPECTION ED9E34FC

- 1. IG KEY "OFF", ENGINE "OFF".
- 2. Disconnect FTS connector and ECM connector.
- 3. IG KEY "ON".
- 4. Measure the voltage of terminal 2 of FTS connector.[ TEST "A" ]
- 5. Measure the voltage between FTS connector terminal 2 and 1. [TEST "B"] (terminal 2 : Check + prove, terminal 1 : Check - prove)

Specification : [TEST "A"] Voltage - [TEST "B"] Voltage = below 200mV

6. Is the measured voltage within the specification?



Go to "Component Inspection".


### NO

When "B" voltage is not detected : Repair open in ground circuit and go to "Verification of Vehicle Repair".
 When the voltage difference between "A" and "B" is above 200mV : Eliminate the causes of excessive resistance and go to "Verification of Vehicle Repair".

#### COMPONENT INSPECTION E844DE8C

- 1. IG KEY "OFF", ENGINE "OFF".
- 2. Disconnect FTS connector.
- 3. Measure resistance of FTS component terminal 1 and 2, referring to resistance characteristic table of specification of General information.

Specification : Refer to Specification of General Information.



LGJF006L

4. Is the measured resistance at certain temperature within the specified resisance range at the temperature?

#### YES

▶ Go to "Verification of Vehicle Rapair".

#### NO


Replace FTS and go to "Verification of Vehicle Rapair".

VERIFICATION OF VEHICLE REPAIR EE19FABA

Refer to DTC P0182.

# DTC P0192 FUEL RAIL PRESS. SENSOR-LOW INPUT


#### COMPONENT LOCATION E8F9ED39



LGJF010M

# GENERAL DESCRIPTION E9B22E57

RPS(Rail Pressure Sensor), consists of piezzo electric element, measures rail pressure inside of common rail.ECM determines optimum fuel injection quantity at specific engine condition based on RPS signal. RPS signal is also used as rail pressure regualtor feed back signal in order to achieve optimum rail pressure at certain engine condition.



LGJF010N


# DTC DESCRIPTION E7338707

P0192 is set when RPS output voltage is below the minimum value of 254mV for more than 0.2 sec.. This code is due to the open in power circuit or the short to ground in signal circuit.

# DTC DETECTING CONDITION E7F15B94


Item		Detecting	Possible Cause	
DTC Strategy	<ul> <li>Voltage mo</li> </ul>	nitoring		
Enable Conditions	Engine run	ning		
ThresholdValue	Output sina	l below mini		
DiagnosticTime	• 200ms			RPS circuit
	Fuel Cut	NO		<ul> <li>RPS component</li> </ul>
Fail Safe	EGR Off	NO	<ul> <li>Rail press. Sensor value fixed at 330bar</li> </ul>	
	Fuel Limit	YES		
	MIL	YES		

# SPECIFICATION E09485C0




LGJF010O

### SCHEMATIC DIAGRAM E9CD3767



# SIGNAL WAVEFORM AND DATA E113D177



#### Fig.1

Fig.1) APS 1 and RPS signals are measured simultaneously. This waveform shows the rise of RPS output voltage at rapid acceleration.

# MONITOR SCANTOOL DATA ED506749

- 1. Connect Scantool to Data Link Connector (DLC).
- 2. Warm engine up to normal operating temperature.
- 3. Turn "OFF" electrical devices and A/C.


#### LGJF010Q

## FLB -196

 Monitor "FUEL PRESSURE MEASURED", "RAIL PRESS. REGULATOR1", "INJ. PUMP REGULATOR" parameter on the Scantool.

SP	Е	С	IF	IC	AT	IC	N	:

	Idle(without load)	Accelerating(stall test)	Diagnosis
INJ. PUMP REGULATOR	38 ± 5%	32 ± 5%	duty decreases
FUEL PRESSURE MEASURED	28.5 ± 5 Mpa	145 ± 10 Mpa	press. increases
RAIL PRESS. REGULATOR1	19 ± 5%	48 ± 5%	duty increases






Fig.1) The position of curser on the graph represents idle data. Fig.2) Data during acceleration(stall test).

LGJF013U

# 

The waveform of fuel metering unit installed at high pressure pump(fuel detecting MPROP) shows 38% duty at idle, duty drops to approx. 32% at acceleration to raise rail pressure. Duty drop means the decrease of current.  $\rightarrow$  Fuel delivered to common rail increases as current drops.

The waveform of rail pressure control valve installed at common rail shows 19% duty at idle, duty rises to approx. 48% at acceleration to raise rail pressure. Duty rise means the increase of current.

→ If current rises, the returning quantity of fuel deliverd to common rail decreases and common rail pressure rises.

## TERMINAL AND CONNECTOR INSPECTION ED6B4438

- 1. Electrical systems consist of a lot of harness and connectors, poor connection of terminals can cause various problems and damge of component.
- 2. Perform checking procedure as follows.
  - 1) Check damage of harness and terminals : Check terminals for contact resistance, corrosion and deformation.
  - 2) Check connecting condition of ECM and component connector : Check terminal seperation, damage of locking device and connecting condition between terminal and wiring.

# 🗊 ΝΟΤΕ

Disconnect the pin which requires checking at male connector and insert it to the terminal at female connector for checking connecting condition. ( after checking, reconnect the pin at correct position. )

# DTC TROUBLESHOOTING PROCEDURES

3.	ls	the problem found?					
	2	/ES				en an l	
		Repair the trouble causing part and go to "Verification	of Vehicle Repair	4			
		NO					
	•	Go to "Power Circuit Inspection".		9 S. P			
			terre en en en	and the second			
P	JWI	ER CIRCUIT INSPECTION E9023C84				••• ***	4.
1.	IG	KEY "OFF", ENGINE "OFF".					
2.	Di	sconnect RPS connector.				5 1	
3.	IG	KEY "ON".					
4.	Me	easure the voltage of RPS connector terminal "1".					
S	peci	fication : 4.8V~5.1V		4.1.18 <u>.</u>			
5.	le i	the measured voltage within the specification?	<u> </u>	ing stars	÷.,		
0.	<b>Distant</b>				n at a		
						,	
		Go to "Signal Circuit Inspection".					
	D						
		Repair open in RPS power circuit and go to "Verification	on of Vehicle Repa	ir".	in anf	2.5 <sub>7</sub>	fe e e
	[C	heck between RPS connector terminal 1 and ECM con	nnector terminal28	<b>ed</b> e gaarse oorde	agtoria di	19 - 1 - 1 - 1 1 - 1 - 1 - 1 - 1 - 1 - 1 -	<u>2</u> .
SI	GN/	AL CIRCUIT INSPECTION EC26AA51					
1.	Ch	eck signal circuit voltage		· · · · · · · · · · · · · · · · · ·		• • • •	
	1)	IG KEY "OFF", ENGINE "OFF".					
	2)	Disconnect RPS connector.		- 44 			
	3)	IG KEY "ON".					
	4)	Measure the voltage of RPS connector terminal 2.		e a statu			ng saint an Tha
Sp	pecif	ication : 4.8V~5.1V		8		<u></u>	
APROLOGIC	-						<u>, j</u>
	5)	Is the measured voltage within the specification?	. F	en e			
		YES	1. 1 1 1 1 1 1 1 1.			izelati u	
		Go to "Component Inspection".					

NO

Repair short to ground in signal circuit and go to "Verification of Vehicle Repair".

#### COMPONENT INSPECTION E0674767

- 1. Visual Inspection of RPS
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect RPS connector.
  - 3) Check if corrosion and damage in RPS terminal is detected.
  - 4) Check RPS mounting torque and oil leakage.
  - 5) Are the problems relevant to RPS found?

# YES

▶ Replace RPS if necessary and go to "Verification of Vehicle Repair".

### NO

▶ Go to "RPS waveform Inspection".

#### 2. RPS Waveform Inspection

- 1) IG KEY "OFF", ENGINE "OFF".
- 2) Connect RPS connector.
- 3) Connect an Oscilloscope to RPS connector terminal 2.
- 4) After turning engine "ON", Check waveform at idle and during acceleration.

Specification : Refer to "Signal Waveform & Data" of "General Information".

5) Does RPS waveform look similar to standard "Signal Waveform & Data"?

## YES

go to "Verification of Vehicle Repair".

#### NO

Replace RPS and go to "Verification of Vehicle Repair".

#### VERIFICATION OF VEHICLE REPAIR E3F52C6A

After a repair, it is essential to verify that the fault is corrected.

- 1. After connecting Scantool select "DIAGNOSTIC TROUBLE CODES(DTCs)" mode.
- 2. Clear recorded DTC using Scantool.
- 3. Drive the vehicle within DTC "Enable conditions" in "General information".
- 4. After selecting "DIAGNOSTIC TROUBLE CODES(DTCs)" mode and check if DTC is recorded again.
- 5. Are any DTCs recorded ?

# YES

▶ Go to the DTC guide of recorded NO. in Scantool.

# NO

System operates within specification.

# DTC P0193 FUEL RAIL PRESS. SENSOR-HIGH INPUT

## COMPONENT LOCATION E4FB6064

Refer to DTC P0192.

#### GENERAL DESCRIPTION EOC1B3B6

Refer to DTC P0192.


### DTC DESCRIPTION E81611DF

P0193 is set when RPS output voltage is above the maximum value of 4830mV(4.8V) for more than 0.2 sec.. This code is due to the open or short in 1) RPS signal circuit 2) RPS ground circuit.

# DTC DETECTING CONDITION EA17BB2A

ltem		Detecting	Possible Cause	
DTC Strategy	<ul> <li>Voltage mo</li> </ul>	nitoring		
Enable Conditions	Engine run	ning		
ThresholdValue	<ul> <li>Output sign 4750mV)</li> </ul>	al above the		
DiagnosticTime	• 200ms			RPS circuit
	Fuel Cut	NO		RPS component
Fail Safe	EGR Off	NO	Rail press. Sensor	
	Fuel Limit	YES	value fixed at 330bar	
	MIL	YES		

### SPECIFICATION EC8CDE47



LGJF010O

# SCHEMATIC DIAGRAM EAF332BC

Refer to DTC P0192.

#### SIGNAL WAVEFORM AND DATA E2A9B687

Refer to DTC P0192.

## MONITOR SCANTOOL DATA ED8E6409

Refer to DTC P0192.

# TERMINAL AND CONNECTOR INSPECTION EDOB9DF4

Refer to DTC P0192.

# POWER CIRCUIT INSPECTION EFCDOB07

- 1. IG KEY "OFF", ENGINE "OFF".
- 2. Disconnect RPS connector.
- 3. IG KEY "ON".
- 4. Measure the voltage of RPS connector terminal "1".

Specification : 4.8V~5.1V

5. Is the measured voltage within the specification?

# YES

▶ Go to "Signal Circuit Inspection".

#### NO

Repair open in RPS power circuit and go to "Verification of Vehicle Repair".
[ Check between RPS connector terminal 1 and ECM connector terminal28. ]

# SIGNAL CIRCUIT INSPECTION E15ECEFC

- 1. Check signal circuit voltage
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect RPS connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of RPS connector terminal 2.

Specification: 4.8V~5.1V

5) Is the measured voltage within the specification?

### YES

Go to "Component Inspection".

NO

- ▶ Go to "2. Check open in signal circuit" as follows.
- 2. Check open in signal circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect RPS connector and ECM connector.
  - 3) Check continuity between RPS connector terminal 2 and ECM connector terminal 43.

Specification : continuity ( below  $1.0\Omega$  )

4) Is the measured resistance within the specification?

#### YES

▶ Go to "3. Check short to battery in signal circuit" as follows.

#### NO

Repair open in RPS signal circuit and go to "Verification of Vehicle Repair".
[Check the circuit between Rail Pressure sensor terminal 2 and ECM connector terminal 43.]

- 3. Check short to battery in signal circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect RPS connector and ECM connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of RPS connector terminal 2.

Specification : 0.0V~0.1V

5) Is abnormal voltage measured in signal circuit(with both connectors disconnected)?

#### YES

Repair short to battery in signal circuit and go to "Verification of Vehicle Repair".

#### NO

▶ Go to "Component Inspection".

#### GROUND CIRCUIT INSPECTION EF38C26F

- 1. IG KEY "OFF", ENGINE "OFF".
- 2. Disconnect RPS connector.
- 3. IG KEY "ON".

## DTC TROUBLESHOOTING PROCEDURES

- 4. Measure the voltage of RPS connector terminal 2. [TEST "A"]
- 5. Measure the voltage between RPS connector terminal 2 and 3. [TEST "B"] (terminal 2 : Check + prove, terminal 3 : Check - prove)

Specification : [TEST "A"] Voltage - [TEST "B"] Voltage = below 200mV

6. Is the measured voltage within the specification?

# YES

▶ Go to "Component Inspection".

# NO

When "B" voltage is not detected : Repair open in ground circuit and go to "Verification of Vehicle Repair".
 When the voltage difference between "A" and "B" is above 200mV : Eliminate the causes of excessive resistance and go to "Verification of Vehicle Repair".

#### COMPONENT INSPECTION EEF2E0FD

- 1. Visual Inspection of RPS
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect RPS connector.
  - 3) Check if corrosion and damage in RPS terminal is detected.
  - 4) Check RPS mounting torque and oil leakage.
  - 5) Are the problems relevant to RPS found?

# YES.

Replace RPS if necessary and go to "Verification of Vehicle Repair".

#### NO

- Go to "RPS waveform Inspection".
- 2. RPS Waveform Inspection
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Connect RPS connector.
  - 3) Connect an Oscilloscope to RPS connector terminal 2.
  - 4) After turning engine "ON", Check waveform at idle and during acceleration.

Specification : Refer to "Signal Waveform & Data" of "General Information".

5) Does RPS waveform look similar to standard "Signal Waveform & Data"?

# YES

▶ Go to "Verification of Vehicle Repair".

# NO

▶ Replace RPS and go to "Verification of Vehicle Repair".


# VERIFICATION OF VEHICLE REPAIR EE2C6827

Refer to DTC P0192.

FLB	-205
-----	------

DTC	P0201	INJECTOR	<b>CIRCUIT/OPEN-CYLINDER</b>	1
DTC	P0202	<b>INJECTOR</b>	CIRCUIT/OPEN-CYLINDER	2
Band H wash	P0203	INJECTOR	CIRCUIT/OPEN-CYLINDER	3
DTC	P0204	INJECTOR	CIRCUIT/OPEN-CYLINDER	4


## COMPONENT LOCATION EC6F0A3B



EWPF602S

## GENERAL DESCRIPTION E2512634

Injectors spray fuel in the highly compressed combustion chamber, and power generates through combustion process. Fuel pressure is raised to 1600bar in common rail diesel engine for the purpose of making fuel into minute particles. And fuel devided into minute particles leads smoke reduction, high power generation, and improved fuel efficiency. To control pressure of 1600bar with solenoid, oil pressure surbo is applied. And injector solenoids is actuated by solenoid operating voltage raised to 80V with the method of current control. Niddle valve inside of injector is located between A and B chamber. If applied pressure to B chamber is relived by injector solenoid, niddle valve is raised by the pressure of A chamber then, fuel is injected. If same pressure is applied to A and B chamber, niddle valve closes by the elasticity then, fuel injection stops. As electronically controlled injector is applied instead of mechanical injector, pilot and post injection, injection duration and quantity control are achieved. And engine performance is improved by these control.



LGJF008D

# DTC DESCRIPTION ECC30721

DTC is set when no current is detected in injector power and control circuit at injector operating condition. This code is due to open in injector circuit or open in injector component coil.


# DTC DETECTING CONDITION EE337B06

ltem	Detecting Condition			Possible Cause	
DTC Strategy	<ul> <li>Current mor</li> </ul>	nitoring			
Enable Conditions	• IG KEY "ON"				
ThresholdValue	Open in injector circuit				
DiagnosticTime	Immediately			<ul> <li>Open in injector circuit</li> </ul>	
	Fuel Cut	NO		<ul> <li>Injector component</li> </ul>	
Fail Safe	EGR Off	NO			
	Fuel Limit	YES			
	MIL	YES			

# SPECIFICATION E9EA99ED

Injector Component Resistance	Injector Operating Voltage	Injector Operating Current	Injector Control Type
0.255Ω ±0.04 (20℃).	80V	Peak current:18±1A Hold in current:12±1A Recharging current:7A	Current control

# SCHEMATIC DIAGRAM E5875CB7



EWPF002O

#### SIGNAL WAVEFORM AND DATA EC9AF2CF




Fig.1) Injector operating waveform at Low side, It shows 2 pilot and 1 main injection.

Fig.2) Magnified waveform of main injection at Fig.1)

Fig.3) Injector voltage and current waveforms are measured at the same time using current prove of scope meter.

Fig.4) Magnified waveform of pilot injection at Fig.3)

LGJF008F

# TERMINAL AND CONNECTOR INSPECTION EEB7CF43

- 1. Electrical systems consist of a lot of harness and connectors, poor connection of terminals can cause various problems and damge of component.
- 2. Perform checking procedure as follows.
  - 1) Check damage of harness and terminals : Check terminals for contact resistance, corrosion and deformation.
  - 2) Check connecting condition of ECM and component connector : Check terminal seperation, damage of locking device and connecting condition between terminal and wiring.

## **NOTE**

Disconnect the pin which requires checking at male connector and insert it to the terminal at female connector for checking connecting condition. (after checking, reconnect the pin at correct position.)

3. Is the problem found?

# YES

Repair the trouble causing part and go to "Verification of Vehicle Repair".

## NO

Go to "Power Circuit Inspection".

# POWER CIRCUIT INSPECTION EE471886

- 1. Check open in power circuit(High side)
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect injector connector and ECM connector.
  - 3) Check continuity between injector connector terminal 2 and ECM connector terminal.

Specification : Continuity (below  $1.0\Omega$  ) 4) Is the measured resistance within the specification? YES Go to "Control Circuit Inspection". NO Repair open in injector power circuit and go to "Verification of Vehicle Repair". CONTROL CIRCUIT INSPECTION E813BC27 Check open in control circuit(Low side) 1. 1) IG KEY "OFF", ENGINE "OFF". 2) Disconnect injector connector and ECM connector. Check continuity between injector connector terminal 1 and ECM connector terminal. 3) Specification : Continuity (below  $1.0\Omega$  ) Is the measured resistance within the specification? 4) YES Go to "Component Inspection". NO Repair open in injector control circuit and go to "Verification of Vehicle Repair".


# COMPONENT INSPECTION EOB3873C

1. Check injector component resistance

LGJF008I

- 1) IG KEY "OFF", ENGINE "OFF".
- 2) Disconnect injector connector.
- 3) Measure the resistance between injector component terminal 1 and 2.

Specification : 0.255Ω ±0.04 (20℃).



4) Is the measured resistance(of injector solenoid) within the specification?

#### YES

Go to "Verification of Vehicle Repair".



Replace injector and go to "Verification of Vehicle Repair".

# 🗊 ΝΟΤΕ

Replacing injectors, peculiar IQA code of each injector should be inputted to ECM Perform this process using "Injector data input" function on scantool, Refer to P1670, P1671 for more detailed information.

### VERIFICATION OF VEHICLE REPAIR ECD4AC32

After a repair, it is essential to verify that the fault is corrected.

- 1. After connecting Scantool select "DIAGNOSTIC TROUBLE CODES(DTCs)" mode.
- 2. Clear recorded DTC using Scantool.
- 3. Drive the vehicle within DTC "Enable conditions" in "General information".
- 4. After selecting "DIAGNOSTIC TROUBLE CODES(DTCs)" mode and check if DTC is recorded again.
- 5. Are any DTCs recorded ?

#### YES


Go to the DTC guide of recorded NO. in Scantool.



System operates within specification.

# DTC P0237 BOOST PRESS. SENSOR - CIRCUIT HIGH INPUT

# COMPONENT LOCATION E7B3A26C



EWPF602N

# GENERAL DESCRIPTION E5A416B9

Boost Pressure Sensor(BPS) is installed in intake manifold and senses the pressure of air inside of intake manifold which is compressed by turbo charager. Measuring mass air flow accurately with the information of intake mainfold pressure, mass air flow and intake air temperature, ECM performs actuating correction of EGR and VGT. When excessive intake manifold pressure is detected, engine power generation is limited to protect engine because too highly compressed pressure due to turbo charger may harm engine.

# DTC DESCRIPTION E0D9152E

P0237 is set when the voltage below 200mV - mimimum output voltage of BPS - is detected for more than 2.0 sec.. This code is due to short to ground in signal circuit.


# DTC DETECTING CONDITION ED99499B

ltem	Detecting Condition			Possible Cause		
DTC Strategy	Voltage monitoring					
Enable Conditions	• IG KEY "ON"					
ThresholdValue	<ul> <li>Output signal below minimum value(below 200mV)</li> </ul>					
DiagnosticTime	• 2.0 sec.	2.0 sec.		BPS circuit		
	Fuel Cut	NO	· · · · · · · · · · · · · · · · · · ·	<ul> <li>BPS component</li> </ul>		
Fail Safe	EGR Off	YES	<ul> <li>Boost pressure is fixed</li> </ul>			
	Fuel Limit	YES	1 -1 4000 have	n an		
	MIL	NO	1			

## SPECIFICATION E9BBA07E

Pressure [Kpa]	20	100	190	250	
Outpur voltage [V]	0.4±0.077	1.878±0.063	3.541±0.063	4.650±0.077	

# SCHEMATIC DIAGRAM E9C84C74



#### SIGNAL WAVEFORM AND DATA E60DC901




Fig1) This is the waveform of BPS as accelerating from idle state. Signal voltage rises as accelerating.

LGJF012X

# MONITOR SCANTOOL DATA E1DDEF54

- 1. Connect Scantool to Data Link Connector (DLC).
- 2. Warm engine up to normal operating temperature.
- 3. Turn "OFF" electrical devices and A/C.
- 4. Monitor "BOOST PRESSURE SENSOR" parameter on the Scantool.

Specification : 1028hpa ± 100hpa(VGT actuator : 75%) at idle

	1.2 CURRENT DA	TA 34/	54	7	Wymbelde Samery Arres	
					00	1.2 CURRENT DATA
1	FUEL PRESSURE-TARGET	28.5 MPa		34	99	×BOOST PRESSURE SENSOR hPa
×	FUEL PRESSURE MEASURED	28.5 MPa		10	G1	$\sim$
×	AIR MASS PERCYLINDER	346.9mg/st				
×	EGR ACTUATOR	6.0 %		0		
×	ACCEL PEDAL SENSOR	0.0 %		10	0.0	VGT ACTUATOR %
×	BOOST PRESSURE SENSOR	1001 hPa				x
×	VGT ACTUATOR	60.0 %		60	A	
×	ENGINE SPEED SENSOR	794 rpm			<u> </u>	
ļ	and the second		ş	0.0	0	
	FIX FULL	GRPH RCRD	]		FIX	
Fig				Flg	.2	

Fig1) Monitor "BOOST PRESSURE SENSOR" parameter on the Scantool at idle after warming engine up. 1000hpa ±100hpa(approx. 1 atm) is correct value.

Fig.2) VGT actuator duty decreases and boost pressure increases as accelerating. If boost pressure rises and reaches certain value, VGT actuator duty stops to drop and keeps steady. Releasing accelerator pedal at this moment, VGT actuator duty drops to 9.8%, then if RPM drops to idle range, duty returns to 75%.

LGJF012Y

# TERMINAL AND CONNECTOR INSPECTION EIDD39AA

- 1. Electrical systems consist of a lot of harness and connectors, poor connection of terminals can cause various problems and damge of component.
- 2. Perform checking procedure as follows.
  - 1) Check damage of harness and terminals : Check terminals for contact resistance, corrosion and deformation.
  - 2) Check connecting condition of ECM and component connector : Check terminal seperation, damage of locking device and connecting condition between terminal and wiring.

# **NOTE**

Disconnect the pin which requires checking at male connector and insert it to the terminal at female connector for checking connecting condition. ( after checking, reconnect the pin at correct position. )

3. Is the problem found?

## YES

Repair the trouble causing part and go to "Verification of Vehicle Repair".

#### NO

Go to "Power Circuit Inspection".

# POWER CIRCUIT INSPECTION E60A4229

- 1. IG KEY "OFF", ENGINE "OFF".
- 2. Disconnect BPS connector.

#### FLB -214

- 3. IG KEY "ON".
- 4. Measure the voltage of BPS connector terminal 2.

Specification: 4.8V~5.1V

5. Is the measured voltage within the specification?

# YES

▶ Go to "Signal Circuit Inspection".

#### NO

Repair open in power circuit and go to "Verification of Vehicle Repair".

#### SIGNAL CIRCUIT INSPECTION EEDBAF7C

- 1. Check open in signal circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect BPS connector and ECM connector.
  - 3) Check continuity between BPS connector terminal 1 and ECM connector terminal 40.

Specification : Continuity (below  $1.0\Omega$ )

4) Is the measured resistance within the specification?

# YES

▶ Go to "2. Check short to ground in signal circuit" as follows.

#### NO

- ▶ Repair open in signal circuit and go to "Verification of Vehicle Repair".
- 2. Check short to ground in signal circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect BPS connector and ECM connector.
  - 3) Check continutity between BPS connector terminal 1 and chassis ground.

Specification : Discontinuity (Infinite  $\Omega^{-}$ )

4) Is the measured resistance within the specification?

# YES

▶ Go to "Component Inspection".



Repair short to ground in signal circuit and go to "Verification of Vehicle Repair".

## COMPONENT INSPECTION E1C2A70A


- 1. BPS visual inspection
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect BPS connector.
  - 3) Check if corrosion and damage in BPS terminal is detected.
  - 4) Check BPS mounting state, leakage at O'ring, clogged carbon at pressure detecting hall.
  - 5) Are the problems relevant to BPS found?

# YES

Replace BPS if necessary and go to "Verification of Vehicle Repair".

## NO

- Go to "2. Check VGT Turbo charger and leakage in intake system".
- 2. Check VGT turbo charger and leakage in intake system
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Check if VGT actuating rod which is connected to diaphragm of VGT turbo charger assy' is at the bottom position.
  - 3) IG KEY "ON"., ENGINE "ON".
  - 4) Check if VGT actuating rod is pulled upward Approx. 10mm when engine is about to start.
  - 5) As accelerating and decelerating, Check if VGT actuating rod moves upward and downward.
  - 6) Check if intake air leak is detected at intake hose at acceleration. (Check if intake hose inflates properly.)



7) Are the problems relevant to VGT turbo charger and intake hose found?



VGT actuating rod does not work.

EWPF600J

If any problem is not detected after checking connecting condition of VGT actuator vacuum hose and VGT actuator operating states (refer to "Component Inspection" of P0048 ), VGT actuator variable controlling part is considered as stuck. Replace VGT turbo charger in this case.

- Intake air leak is detected.
- Provide the construction of the construction o

If trouble causing parts are repaired, go to "Verification of Vehicle Repair".



- Go to "3. BPS Waveform inspection".
- 3. BPS Waveform inspection
  - 1) IG KEY "ON", ENGINE "OFF".
  - 2) Connect BPS.
  - 3) Connect Oscilloscope to BPS connector terminal 1.
  - 4) Monitor the waveform at idle and acceleration after ENGINE "ON".

Specification : Refer to "Signal Waveform & Data" of "General Information".

5) Is BPS waveform displayed correctly?



Go to "Verification of Vehicle Repair".



Replace BPS and go to "Verification of Vehicle Repair".

#### VERIFICATION OF VEHICLE REPAIR EB3DB713

After a repair, it is essential to verify that the fault is corrected.

- 1. After connecting Scantool select "DIAGNOSTIC TROUBLE CODES(DTCs)" mode.
- 2. Clear recorded DTC using Scantool.
- 3. Drive the vehicle within DTC "Enable conditions" in "General information".
- 4. After selecting "DIAGNOSTIC TROUBLE CODES(DTCs)" mode and check if DTC is recorded again.
- 5. Are any DTCs recorded ?

#### YES

Go to the DTC guide of recorded NO. in Scantool.

#### NO

System operates within specification.

# DTC P0238 BOOST PRESS. SENSOR - CIRCUIT LOW INPUT

### COMPONENT LOCATION E0E946E3

Refer to DTC P0237.

# GENERAL DESCRIPTION EE99A58C

Refer to DTC P0237.

# DTC DESCRIPTION EOBE1232

P0238 is set when the voltage above 4900mV - maximum output voltage of BPS - is detected for more than 2.0 sec.. This code is due to short to battery in BPS signal circuit or open in ground circuit.

# DTC DETECTING CONDITION EC8143C7

Item	Detecting Condition			Possible Cause
DTC Strategy	<ul> <li>Voltage mo</li> </ul>	nitoring		
Enable Conditions	• IG KEY "O	N"		
ThresholdValue	<ul> <li>Output sign</li> </ul>	al above ma		
DiagnosticTime	• 2.0 sec		anna - an ann an Annaiste ann an Annaiste an Annaiste an Annaiste an Annaiste an Annaiste an Annaiste an Annais	BPS circuit
	Fuel Cut	NO		<ul> <li>BPS component</li> </ul>
	EGR Off	YES	<ul> <li>Boost pressure is fixed</li> </ul>	
Fail Safe	Fuel Limit	YES	at 1000 hpa.	
	MIL	NO	- Marian Station Station	

# SPECIFICATION EDCB1FF0

Pressure [Kpa]	20	100	190	250
Outpur voltage [V]	0.4±0.077	1.878±0.063	3.541±0.063	4.650±0.077

### SCHEMATIC DIAGRAM E13E9282

Refer to DTC P0237.

# SIGNAL WAVEFORM AND DATA ED717784

Refer to DTC P0237.

### MONITOR SCANTOOL DATA EDFC284F

Refer to DTC P0237.

# TERMINAL AND CONNECTOR INSPECTION E505DAA5

Refer to DTC P0237.

#### POWER CIRCUIT INSPECTION E5CCBFFA

- 1. IG KEY "OFF", ENGINE "OFF".
- 2. Disconnect BPS connector.
- 3. IG KEY "ON".
- 4. Measure the voltage of BPS connector terminal 2.

Specification: 4.8V~5.1V

5. Is the measured voltage within the specification?

# YES

▶ Go to "Signal Circuit Inspection".

#### NO

Sensor power too high : Refer to circuit inspection of P0653.

#### SIGNAL CIRCUIT INSPECTION E34860F2

- 1. Check signal circuit voltage
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect BPS connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of BPS connector terminal 1.

Specification : below 0.1V

5) Is the measured voltage within the specification?

## YES

▶ Go to "Ground Circuit Inspection".

NO

▶ Repair short to battery in signal circuit and go to "Verification of Vehicle Repair".

#### GROUND CIRCUIT INSPECTION EFA43CBC

- 1. IG KEY "OFF", ENGINE "OFF".
- 2. Disconnect BPS connector.
- 3. IG KEY "ON".
- 4. Measure the voltage of BPS connector terminal 2. [ TEST "A" ]
- 5. Measure the voltage between BPS connector terminal 2 and 4. [TEST "B"] (terminal 2 : Check + prove, terminal 4 : Check - prove)

6. Is the measured voltage within the specification?



▶ Go to "Component Inspection".

#### NO

When "B" voltage is not detected : Repair open in ground circuit and go to "Verification of Vehicle Repair".
 When the voltage difference between "A" and "B" is above 200mV : Eliminate the causes of excessive resistance and go to "Verification of Vehicle Repair".

#### COMPONENT INSPECTION E67D5C45


- 1. BPS visual inspection
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect BPS connector.
  - 3) Check if corrosion and damage in BPS terminal is detected.
  - 4) Check BPS mounting state, leakage at O'ring, clogged carbon at pressure detecting hall.
  - 5) Are the problems relevant to BPS found?



Replace BPS if necessary and go to "Verification of Vehicle Repair".

#### NO

- Go to "2. Check VGT Turbo charger and leakage in intake system".
- 2. Check VGT turbo charger and leakage in intake system
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Check if VGT actuating rod which is connected to diaphragm of VGT turbo charger assy' is at the bottom position.
  - 3) IG KEY "ON"., ENGINE "ON".
  - 4) Check if VGT actuating rod is pulled upward Approx. 10mm when engine is about to start.
  - 5) As accelerating and decelerating, Check if VGT actuating rod moves upward and downward.
  - 6) Check if intake air leak is detected at intake hose at acceleration. (Check if intake hose inflates properly.)



EWPF600J

7) Are the problems relevant to VGT turbo charger and intake hose found?

## YES

VGT actuating rod does not work.

If any problem is not detected after checking connecting condition of VGT actuator vacuum hose and VGT actuator operating states (refer to "Component Inspection" of P0048 ), VGT actuator variable controlling part is considered as stuck. Replace VGT turbo charger in this case.

Intake air leak is detected.

Checking intake hose is not damaged and band clamp is fastened well, repair trouble causing parts.

If trouble causing parts are repaired, go to "Verification of Vehicle Repair".



Go to "3. BPS Waveform inspection".

- 3. BPS Waveform inspection
  - 1) IG KEY "ON", ENGINE "OFF".
  - 2) Connect BPS.
  - 3) Connect Oscilloscope to BPS connector terminal 1.
  - 4) Monitor the waveform at idle and acceleration after ENGINE "ON".

Specification : Refer to "Signal Waveform & Data" of "General Information".

5) Is BPS waveform displayed correctly?



Go to "Verification of Vehicle Repair".




Replace BPS and go to "Verification of Vehicle Repair".

# VERIFICATION OF VEHICLE REPAIR EB6109CC

Refer to DTC P0237.

# DTC P0252 FUEL PRESS. REGULATOR(MPROP) - CIRCUIT OVER CURRENT

### COMPONENT LOCATION EGEOOBBD



EWPF602T

### GENERAL DESCRIPTION EF1B13D1

Fuel metering unit(MPROP) is integrated with high pressure pump and controls common rail pressure as regulating the quantity of fuel which is delivered to common rail. In order to control rail pressure to be optimum to current driving condition, ECM controls fuel pressure regulator operating current(with the method of duty-control) using RPCV signal, RPM and APS signal. The lower Fuel metering unit current is, the more fuel is supplied to common rail. Thus it leads rail pressure to be high. On the contrary, the higher Fuel metering unit current is, the less fuel is supplied to common rail. Thus it leads rail pressure to be low. Therefore, when Fuel metering unit current becomes "0", as if there is open spot in Fuel metering unit circuit or connector is disconnected, maximum fuel quantity is supplied to common rail, so the pressure of common rail rise to maximum value.

#### DTC DESCRIPTION E85B627E

P0252 is set when excessive current in control circuit of Fuel metering unit(integrated with high pressure pump) is detected for more than 0.22 sec.. This code is due to short to battery in control circuit or Fuel metering unit internal short.

ltem	Detecting Condition			Possible Cause
DTC Strategy	Voltage monitoring			
Enable Conditions	• IG KEY "ON"			
ThresholdValue	Short to battery (control circuit in FMU)			
DiagnosticTime	• 220ms			FMU circuit
	Fuel Cut	Fuel Cut NO • FMU col	FMU component	
	EGR Off	NO		
Fail Safe	Fuel Limit	YES		
	MIL	YES		

#### DTC DETECTING CONDITION E73BA131

# DTC TROUBLESHOOTING PROCEDURES

### SPECIFICATION EA4095E7

rail pressure control valve resistance	Operating frequancy	
2.9 ~ 3.15Ω (20℃)	185 Hz	

#### SCHEMATIC DIAGRAM ED7D8F9B




Fig.1) Waveform of fuel metering unit at idle. It shows approx. 38% duty.

Fig.2) Waveform of fuel metering unit as accelerating. Approx. 32% duty is outputted as engine load increases.

HOLD ZOOM CURS

Fig.2

MEMO

RECD

MENU

(When rail pressure increases as accelerating, rail pressure control valve duty(current) drops.)

LGJF013T

### MONITOR SCANTOOL DATA EDC545CD

Fig.1

- 1. Connect Scantool to Data Link Connector (DLC).
- Warm engine up to normal operating temperature. 2.


### FLB -224

3. Turn "OFF" electrical devices and A/C.

4. Monitor "FUEL PRESSURE MEASURED", "RAIL PRESS. REGULATOR1", "INJ. PUMP REGULATOR" parameter on the Scantool.

#### SPECIFICATION :

	Idle(without load)	Accelerating(stall test)	Diagnosis
INJ. PUMP REGULATOR	38 ± 5%	32 ± 5%	duty decreases
FUEL PRESSURE MEASURED	28.5 ± 5 Mpa	145 ± 10 Mpa	press. increases
RAIL PRESS. REGULATOR1	19 ± 5%	48 ± 5%	duty increases






Fig.1) The position of curser on the graph represents idle data. Fig.2) Data during acceleration(stall test).

LGJF013U

# 🛈 ΝΟΤΕ

The waveform of fuel metering unit installed at high pressure pump(fuel detecting MPROP) shows 38% duty at idle, duty drops to approx. 32% at acceleration to raise rail pressure. Duty drop means the decrease of current.  $\rightarrow$  Fuel delivered to common rail increases as current drops.

The waveform of rail pressure control valve installed at common rail shows 19% duty at idle, duty rises to approx. 48% at acceleration to raise rail pressure. Duty rise means the increase of current.  $\rightarrow$  If current rises, the returning quantity of fuel deliverd to common rail decreases and common rail pressure rises.

## TERMINAL AND CONNECTOR INSPECTION E718EDF5

- 1. Electrical systems consist of a lot of harness and connectors, poor connection of terminals can cause various problems and damge of component.
- 2. Perform checking procedure as follows.
  - 1) Check damage of harness and terminals : Check terminals for contact resistance, corrosion and deformation.
  - 2) Check connecting condition of ECM and component connector : Check terminal seperation, damage of locking device and connecting condition between terminal and wiring.

## **NOTE**

Disconnect the pin which requires checking at male connector and insert it to the terminal at female connector for checking connecting condition. (after checking, reconnect the pin at correct position.)

3. Is the problem found?

# YES

Repair the trouble causing part and go to "Verification of Vehicle Repair".

# NO

▶ Go to "Power Circuit Inspection".

### POWER CIRCUIT INSPECTION E9666380

- 1. Check power circuit voltage
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect FMU connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of FMU connector terminal 1.

specification: 11.5V~13.0V

5) Is the measured voltage within the specification?

# YES

Go to "Control Circuit Inspection".

## NO

▶ Repair open between FMU connector terminal 1 and ECM connector terminal 19 and go to "Verification of Vehicle Repair".

# CONTROL CIRCUIT INSPECTION EEDB55EA

- 1. Check monitoring voltage in control circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect FMU connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of FMU connector terminal 2.

specification : 3.2V~3.7V

5) Is the measured voltage within the specification?

LGJF013Y

# YES

▶ Go to "Component Inspection"

NO

- When voltage is not detected : Go to "2. Check open in control circuit" as follows.
- When high voltage is detected : Repair short to battery and go to "Verification of Vehicle Repair".
- 2. Check open in control circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect FMU and ECM connector.
  - 3) Check continuity between FMU connector terminal 2 and ECM connector terminal 49.

specification : Continuity (below  $1.0\Omega$ )

4) Is the measured resistance within the specification?

# YES

Repair short to ground in FMU control circuit and go to "Verification of Vehicle Repair".

NO


Repair open in FMU control circuit and go to "Verification of Vehicle Repair".

#### COMPONENT INSPECTION E4E86BD0

1. Check FMU component resistance

- 1) IG KEY "OFF", ENGINE "OFF".
- 2) Disconnect rail pressure control valve connector.
- 3) Check FMU component resistance.

Specification : 2.9 ~ 3.15Ω (20℃)



4) Is FMU component resistance within the specification?



▶ Go to "Verification of Vehicle Repair".

### NO

▶ Replace High pressure pump ass'y and go to "Verification of Vehicle Repair".

# VERIFICATION OF VEHICLE REPAIR E78272F7

After a repair, it is essential to verify that the fault is corrected.

- 1. After connecting Scantool select "DIAGNOSTIC TROUBLE CODES(DTCs)" mode.
- 2. Clear recorded DTC using Scantool.
- 3. Drive the vehicle within DTC "Enable conditions" in "General information".
- 4. After selecting "DIAGNOSTIC TROUBLE CODES(DTCs)" mode and check if DTC is recorded again.
- 5. Are any DTCs recorded ?

# YES

▶ Go to the DTC guide of recorded NO. in Scantool.

# NO

System operates within specification.

# DTC P0253 FUEL PRESS. REGULATOR(MPROP) - CIRCUIT LOW

COMPONENT LOCATION EBC57532

Refer to DTC P0252.

#### GENERAL DESCRIPTION EC216C69

Refer to DTC P0252.

### DTC DESCRIPTION EBB2EDEB

P0253 is set when "0"A in control circuit of Fuel metering unit(integrated with high pressure pump) is detected for more than 0.22 sec.. This code is due to open of short to ground in control circuit or Fuel metering unit internal open.

## DTC DETECTING CONDITION E1DD7F88

Item	Detecting Condition			Possible Cause
DTC Strategy	<ul> <li>Voltage mo</li> </ul>	nitoring		
Enable Conditions	• IG KEY "ON"			
ThresholdValue	Short to GND, Wiring open			
DiagnosticTime	• 220ms			<ul> <li>FMU circuit</li> </ul>
	Fuel Cut	NO		<ul> <li>FMU component</li> </ul>
	EGR Off	NO		
Fail Safe	Fuel Limit	YES		
	MIL	YES		

# SPECIFICATION ED740895

rail pressure control valve resistance	Operating frequancy	
2.9 ~ 3.15Ω (20℃)	185 Hz	

#### SCHEMATIC DIAGRAM E8F05EC2

Refer to DTC P0252.

#### SIGNAL WAVEFORM AND DATA E5DA9E51

Refer to DTC P0252.

### MONITOR SCANTOOL DATA EADOBEC2

Refer to DTC P0252.

# TERMINAL AND CONNECTOR INSPECTION E29C6F50

Refer to DTC P0252.

#### POWER CIRCUIT INSPECTION EE8352BE

- 1. Check power circuit voltage
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect FMU connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of FMU connector terminal 1.

specification : 11.5V~13.0V

5) Is the measured voltage within the specification?



Go to "Control Circuit Inspection".



▶ Repair open between FMU connector terminal 1 and ECM connector terminal 19 and go to "Verification of Vehicle Repair".

# CONTROL CIRCUIT INSPECTION ED748B4E

- 1. Check monitoring voltage in control circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect FMU connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of FMU connector terminal 2.

specification : 3.2V~3.7V

5) Is the measured voltage within the specification?

YES

Go to "Component Inspection"

NO

- ▶ When voltage is not detected : Go to "2. Check open in control circuit" as follows.
- When high voltage is detected : Repair short to battery and go to "Verification of Vehicle Repair".
- 2. Check open in control circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect FMU and ECM connector.
  - 3) Check continuity between FMU connector terminal 2 and ECM connector terminal 49.

LGJF013Y

specification : Continuity ( below  $1.0\Omega$  )

4) Is the measured resistance within the specification?

# YES

Repair short to ground in FMU control circuit and go to "Verification of Vehicle Repair".


NO

Repair open in FMU control circuit and go to "Verification of Vehicle Repair".

#### COMPONENT INSPECTION E1D35925

- 1. Check FMU component resistance
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect rail pressure control valve connector.
  - 3) Check FMU component resistance.

Specification : 2.9 ~ 3.15Ω (20℃)



4) Is FMU component resistance within the specification?



▶ Go to "Verification of Vehicle Repair".



▶ Replace High pressure pump ass'y and go to "Verification of Vehicle Repair".

# VERIFICATION OF VEHICLE REPAIR E884EB73

Refer to DTC P0252.

# DTC P0254 FUEL PRESS. REGULATOR(MPROP) - CIRCUIT HIGH

### COMPONENT LOCATION ECA933F8

Refer to DTC P0252.

### GENERAL DESCRIPTION E23BBBD5

Refer to DTC P0252.

### DTC DESCRIPTION E742D130

P0254 is set when excessive current in power circuit of Fuel metering unit(integrated with high pressure pump) is detected for more than 0.22 sec.. This code is due to short to battery in power circuit or Fuel metering unit internal short.

# DTC DETECTING CONDITION E3A18C47

Item	Detecting Condition			Possible Cause	
DTC Strategy	<ul> <li>Voltage mo</li> </ul>	nitoring	**************************************		
Enable Conditions	• IG KEY "O	N"			
ThresholdValue	<ul> <li>Short to bar</li> </ul>	ttery (power	circuit in Fuel metering unit)	and the second second	
DiagnosticTime	• 220ms	*******		• FMU circuit	
	Fuel Cut	NO		<ul> <li>FMU component</li> </ul>	
	EGR Off	NO	e entre a tra	$\sum_{i=1}^{n-1} \frac{1}{2} \sum_{i=1}^{n-1} \frac{1}{2$	
Fail Safe	Fuel Limit	YES			
	MIL	YES			

# SPECIFICATION E04569E8

rail pressure control valve resistance	Operating frequancy
2.9 ~ 3.15Ω (20℃)	185 Hz

### SCHEMATIC DIAGRAM E4793CC3

Refer to DTC P0252.

# SIGNAL WAVEFORM AND DATA E13BEF5C

Refer to DTC P0252.

#### MONITOR SCANTOOL DATA EF9D2347

Refer to DTC P0252.

# TERMINAL AND CONNECTOR INSPECTION E3E475EE

Refer to DTC P0252.

#### POWER CIRCUIT INSPECTION E52A2577

- 1. Check power circuit voltage
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect FMU connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of FMU connector terminal 1.

specification : 11.5V~13.0V

5) Is the measured voltage within the specification?

### YES

▶ Go to "Control Circuit Inspection".

#### NO

▶ Repair open between FMU connector terminal 1 and ECM connector terminal 19 and go to "Verification of Vehicle Repair".

#### CONTROL CIRCUIT INSPECTION E00E1FOB

- 1. Check monitoring voltage in control circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect FMU connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of FMU connector terminal 2.

specification : 3.2V~3.7V

5) Is the measured voltage within the specification?

### YES

Go to "Component Inspection".

# NO

- When voltage is not detected : Go to "2. Check open in control circuit" as follows.
- When high voltage is detected : Repair short to battery and go to "Verification of Vehicle Repair".
- 2. Check open in control circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect FMU and ECM connector.
  - 3) Check continuity between FMU connector terminal 2 and ECM connector terminal 49.

LGJF013Y

specification : Continuity ( below  $1.0\Omega$  )

4) Is the measured resistance within the specification?

### YES

Repair short to ground in FMU control circuit and go to "Verification of Vehicle Repair".


NO

Repair open in FMU control circuit and go to "Verification of Vehicle Repair".

# COMPONENT INSPECTION ED5E9D8A

- 1. Check FMU component resistance
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect rail pressure control valve connector.
  - 3) Check FMU component resistance.

Specification : 2.9 ~ 3.15Ω (20℃)



4) Is FMU component resistance within the specification?

#### YES

Go to "Verification of Vehicle Repair".




Replace High pressure pump ass'y and go to "Verification of Vehicle Repair".

# VERIFICATION OF VEHICLE REPAIR E7640AAC

Refer to DTC P0252.

DTC	P0262	CYLINDER	<b>1-INJECTOR</b>	CIRCUIT	HIGH
DTC	P0265	CYLINDER	<b>2-INJECTOR</b>	CIRCUIT	HIGH
DTC	P0268	CYLINDER	<b>3-INJECTOR</b>	CIRCUIT	HIGH
DTC	P0271	CYLINDER	<b>4-INJECTOR</b>	CIRCUIT	HIGH


#### COMPONENT LOCATION E2A48422



EWPF602S

#### GENERAL DESCRIPTION E919A28B

Injectors spray fuel in the highly compressed combustion chamber, and power generates through combustion process. Fuel pressure is raised to 1600bar in common rail diesel engine for the purpose of making fuel into minute particles. And fuel devided into minute particles leads smoke reduction, high power generation, and improved fuel efficiency. To control pressure of 1600bar with solenoid, oil pressure surbo is applied. And injector solenoids is actuated by solenoid operating voltage raised to 80V with the method of current control. Niddle valve inside of injector is located between A and B chamber. If applied pressure to B chamber is relived by injector solenoid, niddle valve is raised by the pressure of A chamber then, fuel is injected. If same pressure is applied to A and B chamber, niddle valve closes by the elasticity then, fuel injection stops. As electronically controlled injector is applied instead of mechanical injector, pilot and post injection, injection duration and quantity control are achieved. And engine performance is improved by these control.



LGJF008D

# DTC DESCRIPTION EDC5COBD


DTC is set when short between injector power circuit(High side) and control circuit(Low side), short to battery in control circuit. This code is due to 1)the detection of over current from opened injector circuit or 2)short of coil inside of injector.

# DTC DETECTING CONDITION EF154DE6

Item	Detecting Condition			Possible Cause
DTC Strategy	Current monitoring			· · · · · · · · · · · · · · · · · · ·
Enable Conditions	• IG KEY "ON"			
ThresholdValue	Short in injector circuit			
DiagnosticTime	Immediately			<ul> <li>Short in injector circuit</li> </ul>
	Fuel Cut	YES		Injector component
Fail Cafe	EGR Off	NO		
Fail Safe	Fuel Limit	NO		
	MIL	YES		

# SPECIFICATION EA47EB7B

Injector Component Resistance	Injector Operating Voltage	Injector Operating Current	Injector Control Type
0.255Ω ±0.04 (20℃).	80V	Peak current:18±1A Hold in current:12±1A Recharging current:7A	Current control



FUEL SYSTEM

### SIGNAL WAVEFORM AND DATA E58615AA




Fig.1) Injector operating waveform at Low side, It shows 2 pilot and 1 main injection.

Fig.2) Magnified waveform of main injection at Fig.1)

Fig.3) Injector voltage and current waveforms are measured at the same time using current prove of scope meter.

Fig.4) Magnified waveform of pilot injection at Fig.3)

LGJF008F

# TERMINAL AND CONNECTOR INSPECTION EF4BC09A

- 1. Electrical systems consist of a lot of harness and connectors, poor connection of terminals can cause various problems and damge of component.
- 2. Perform checking procedure as follows.
  - 1) Check damage of harness and terminals : Check terminals for contact resistance, corrosion and deformation.
  - 2) Check connecting condition of ECM and component connector : Check terminal seperation, damage of locking device and connecting condition between terminal and wiring.

# 

Disconnect the pin which requires checking at male connector and insert it to the terminal at female connector for checking connecting condition. (after checking, reconnect the pin at correct position.)

3. Is the problem found?

# YES

Repair the trouble causing part and go to "Verification of Vehicle Repair".

### NO

Go to "Power Circuit Inspection".

#### POWER CIRCUIT INSPECTION EEB15A46

- 1. Check short to ground in power circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect injector connector.
  - 3) IG KEY "ON"
  - 4) Check the voltage of injector connector terminal 2.

Specification : 2.0V~2.5V

5) Is the measured voltage within the specification?

# YES

Go to "2. Check short between power circuit and control circuit".

#### NO

- ▶ Repair short to ground in injector power circuit and go to "Verification of Vehicle Repair".
- 2. Check short between power circuit and control circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect injector connector and ECM connector.
  - 3) Check continuity between injector connector terminal 1 and 2.

Specification : Discontinuity (Infinite  $\Omega$  )

4) Is the measured resistance within the specification?

# YES

Go to "Control Circuit Inspection".

## NO

Repair short between injector power circuit and control circuit and go to "Verification of Vehicle Repair".

### CONTROL CIRCUIT INSPECTION E86E6DF6

- 1. Check short to battery in control circuit
  - 1) IG KEY "OFF", ENGINE "OFF".

LGJF008I

- 2) Disconnect injector connector.
- 3) IG KEY "ON"
- 4) Check the voltage of injector connector terminal 1.

Specification : 0.4V~0.5V

5) Is the measured resistance within the specificaiton?

# YES

▶ Go to "Component Inspection".


NO

Repair short to battery in injector control circuit and go to "Verification of Vehicle Repair".

## COMPONENT INSPECTION EF694C21

- 1. Check injector component resistance
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect injector connector.
  - 3) Measure the resistance between injector component terminal 1 and 2.

Specification : 0.255Ω ±0.04 (20℃).



4) Is the measured resistance(of injector solenoid) within the specification?

# YES

Go to "Verification of Vehicle Repair".



Replace injector and go to "Verification of Vehicle Repair".

# **NOTE**

Replacing injectors, peculiar IQA code of each injector should be inputted to ECM Perform this process using "Injector data input" function on scantool, Refer to P1670, P1671 for more detailed information.

## VERIFICATION OF VEHICLE REPAIR E4B6A540

After a repair, it is essential to verify that the fault is corrected.

- 1. After connecting Scantool select "DIAGNOSTIC TROUBLE CODES(DTCs)" mode.
- 2. Clear recorded DTC using Scantool.
- 3. Drive the vehicle within DTC "Enable conditions" in "General information".
- 4. After selecting "DIAGNOSTIC TROUBLE CODES(DTCs)" mode and check if DTC is recorded again.
- 5. Are any DTCs recorded ?

# YES


Go to the DTC guide of recorded NO. in Scantool.

# NO

System operates within specification.

# DTC P0335 CRANKSHAFT POSITION SENSOR A CIRCUIT

## COMPONENT LOCATION E9AAA3F3



EWPF602U

### GENERAL DESCRIPTION EAOF791A

Crank Shaft Position Sensor(CKPS) is magnetic inductive type. Mounted on transaxle hausing, it senses tone wheel position of fly wheel.As tone wheel is devided with 58 teeth and 2 missing teeth (referrence point), 1 tooth corresponds to 6 degree.CKPS which calculates RPM and crank angle is important to determine fuel injection quantity and injection timing with APS.crank shaft position is closely related to engine starting.

# DTC DESCRIPTION E4CF730C


P0335 is set when CMPS signal is outputted while CKPS signal does not generate for more than 0.7 sec.. This code is due to CKPS circuit or component failure. If CKPS signal is not inputted during driving, RPM is calculated based on CMPS signal.

ltem	Detecting Condition			Possible Cause		
DTC Strategy	Signal monitoring					
Enable Conditions	Engine running			CKPS circuit     CKPS component		
ThresholdValue	<ul> <li>CMPS signal is outputted while CKPS signal does not generate.</li> <li>700ms</li> </ul>					
DiagnosticTime						
Fail Safe	Fuel Cut	YES		<ul> <li>Abnormal deformation of Crank Shaft tone wheel</li> </ul>		
	EGR Off	NO				
	Fuel Limit	NO				
	MIL	YES				

### SPECIFICATION EE46EA9F

Sensor Type	Output Signal Characteristic	Air Gab	Low RPM Minimum Detecting Voltage	High RPM Minimum Detecting Voltage
Magnetic inductive	A/C waveform	1.8mm	230mV	2769 mV

# SCHEMATIC DIAGRAM EBDEA046



EWPF003U

## SIGNAL WAVEFORM AND DATA E9690986




Fig.1) This shows waveform of Crank Shaft Position Sensor and Cam Shaft Position Sensor simulatneously. The middle area indicates reference points of Crank Shaft Position Sensor and Cam Shaft Position Sensor.


Fig.2) Crank Shaft Position Sensor and Cam Shaft Position Sensor signal are measured simultaneously.

Cam Shaft Position Sensor signal is outputted once when Crank Shaft Position sensor signal is outputted twice. LOW and HIGH output of Cam Shaft Position sensor reference point is detected at Crank Shaft Position sensor reference point.

(Injection sequence is determined based on LOW and HIGH signal of Cam Shaft Position Sensor reference point as detecting cylinder position.)

LGJF005U

#### **\* SIGNAL ANALYSIS**



- 1. The output voltage of CKPS signal varies according to rpm(the speed of tone wheel passing by sensor) (low voltage is inducted for low speed and high voltage is inducted for high speed.)
- CKPS should detect from low rpm at cranking to above 5000rpm. If minimum detecting voltage is set low for the ease of signal detection at low rpm, 1) the abnormal signal at high rpm from which high voltage generates or 2) electrical NOise through circuit can be recognized as Crank signal. Thus minimum detecting voltages at low rpm and high rpm are set differently.
- ECM convert analog signal like the waveform illustrated above into digital signal with A/D converter. The voltage above minimum detecting voltage of crank signal and "-"voltage below 0.0V is meaningless at converting process. RPM is detected as Hz.(signal detecting period)

### MONITOR SCANTOOL DATA EB065E45

1. Connect Scantool to Data Link Connector (DLC).

- 2. Warm engine up to normal operating temperature.
- 3. Turn "OFF" electrical devices and A/C.
- 4. Monitor "ENGINE SPEED SENSOR" parameter on the Scantool.

Specification: 800±50RPM at idle

	1.2 CURRENT DATA 48/	54
		Å
¥	FUEL PRESSURE MEASURED 28.2 MPa	
×	RAIL PRESS. REGULATOR1 22.7 %	
¥	AIR MASS PERCYLINDER 359.7mg/st	
×	EGR ACTUATOR 6.0 %	
×	WATER TEMP.SENSOR 94.3 °C	
¥	ACCEL PEDAL SENSOR 1 725 mV	
×	BOOST PRESSURE SENSOR 1015 hPa	
×	ENGINE SPEED SENSOR 794 rpm	龖
		Ţ
	FIX FULL GRPH RCRD	1

Fig.1) Check "ENGINE SPEED SENSOR" parameter carefully after warming engine up, also check engine stall and rpm instability or engine shut down.

LGJF005M

# TERMINAL AND CONNECTOR INSPECTION EC73BD98

- 1. Electrical systems consist of a lot of harness and connectors, poor connection of terminals can cause various problems and damge of component.
- 2. Perform checking procedure as follows.
  - 1) Check damage of harness and terminals : Check terminals for contact resistance, corrosion and deformation.
  - 2) Check connecting condition of ECM and component connector : Check terminal seperation, damage of locking device and connecting condition between terminal and wiring.

#### 

Disconnect the pin which requires checking at male connector and insert it to the terminal at female connector or checking connecting condition. (after checking, reconnect the pin at correct position.)

#### 3. Is the problem found?

### YES

Repair the trouble causing part and go to "Verification of Vehicle Repair".

#### NO

Go to "Signal Circuit Inspection ".

#### SIGNAL CIRCUIT INSPECTION EDOD7E38

1. Check signal circuit voltage

# DTC TROUBLESHOOTING PROCEDURES

- 1) IG KEY "OFF", ENGINE "OFF".
- 2) Disconnect CKPS connector.
- 3) IG KEY "ON".
- 4) Measure the voltage of CKPS connector terminal 2 and 3.

Specification : 2.4V~2.6V

5) Is the measured voltage within the specification?

## YES

Go to "3.Check short between signal circuits."



- Go to "2.Check open in signal circuit" as follows.
- 2. Check open in signal circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect CKPS connector and ECM connector.
  - 3) Check continuity between CKPS connector terminal 2 and ECM connector terminal 27.
  - 4) Check continuity between CKPS connector terminal 3 and ECM connector terminal 12.

Specification : continuity ( below  $1.0\Omega$  )

5) Is the measured resistance within the specification?

# YES

Go to "3. Check short between signal circuits".



- Repair open in signal circuit and go to "Verification of Vehicle Repair".
- 3. Check short between signal circuits
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect CKPS connector and ECM connector.
  - Check continuity between CKPS connector terminal 2 and 3.

Specification : Discontinuity (Infinite  $\Omega$ )

4) Is the measured resistance within the specification?



Go to "4. Check short to ground in signal circuit" as follows.

#### NO

- ▶ Repair short between signal circuits and go to "Verification of Vehicle Repair".
- 4. Check short to ground in signal circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect CKPS connector and ECM connector.
  - 3) Check continuity between CKPS connector terminal 1(shield ground) and 2,3(crank signal)

Specification : Discontinuity (Infinite  $\Omega$ )

4) Is the measured resistance within the specification?

### YES

▶ Go to "Ground Circuit Inspection".

#### NO

Repair the short between signal circuit and shield ground and go to "Verification of Vehicle Repair".

#### GROUND CIRCUIT INSPECTION E5EC8574

- 1. IG KEY "OFF", ENGINE "OFF".
- 2. Disconnect CKPS connector.
- 3. Check continuity between CKPS connector terminal 1(shield ground) and chassis ground.

Specification : continuity ( below  $1.0\Omega$  )

4. Is the measured resistance within the specification?

#### YES

Go to "Component Inspection".

#### NO


Repair open or poor connection in ground circuit and go to "Verification of Vehicle Repair".

#### COMPONENT INSPECTION EC5269E5

- 1. Check Resistance of CKPS component
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect CKPS connector.
  - 3) Check resistance between CKPS connector terminal 2 and 3 at component side.

Specification : 860Ω ±10% (20℃)

# DTC TROUBLESHOOTING PROCEDURES



4) Is the measured resistance within the specification?


# YES

Go to "Check short to ground in CKPS component" as follows.

### NO

- Replace CKPS and go to "Verification of Vehicle Repair".
- 2. Check short to ground in CKPS component
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect CKPS connector.
  - 3) Check resistance between CKPS connector terminal 1 and 3 at component side.

Specification : Discontinuity (Infinite  $\Omega$ )



4) Is the measured resistance within the specification? (Is the inside of component insulated correctly?)

# YES

▶ Go to "Check CKPS waveform".



- Replace CKPS and go to "Verification of Vehicle Repair".
- 3. Check CKPS waveform
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Connect CKPS connector.
  - 3) Connect Oscilloscope to CKPS connector terminal 2.

LGJF006B

LGJF006C

4) Check if CKPS waveform is outputted correctly as cranking or turning engine on.

Specification : Refer to "Signal waveform & data" of "General Information".

5) Is CKPS waveform outputted correctly?



Go to "Verification of Vehicle Repair".



Replace CKPS and go to "Verification of Vehicle Repair".

### VERIFICATION OF VEHICLE REPAIR ECE7BF89

After a repair, it is essential to verify that the fault is corrected.

- 1. After connecting Scantool select "DIAGNOSTIC TROUBLE CODES(DTCs)" mode.
- 2. Clear recorded DTC using Scantool.
- 3. Drive the vehicle within DTC "Enable conditions" in "General information".
- 4. After selecting "DIAGNOSTIC TROUBLE CODES(DTCs)" mode and check if DTC is recorded again.
- 5. Are any DTCs recorded ?

### YES

Go to the DTC guide of recorded NO. in Scantool.

#### NO

System operates within specification.

# DTC P0336 CRANKSHAFT POSITION SENSOR A CIRCUIT RANGE/PERFORMANCE

### COMPONENT LOCATION EAB38C09

Refer to DTC P0335.

# GENERAL DESCRIPTION E967A934

Refer to DTC P0335.

### DTC DESCRIPTION E000C424

P0336 is set when 1). engine speed detected by CKPS is above 6000RPM, or 2). CKPS signal pulse is abnormal. For repair, check temporary poor connection in CKPS circuit, component failure or deformation of tone wheel.

# DTC DETECTING CONDITION E2B2684F

ltem	Detecting Condition			Possible Cause	
DTC Strategy	<ul><li>Signal monitoring</li><li>Engine running</li></ul>				
Enable Conditions					
<ul> <li>ThresholdValue</li> <li>Engine speed sensed at CKPS above</li> <li>Abnormal crank signal pulse</li> </ul>			CKPS above 6000RPM pulse	CKPS circuit	
DiagnosticTime	Immediately			<ul> <li>CKPS component</li> </ul>	
	Fuel Cut	YES		<ul> <li>Abnormal deformation of Crank Shaft tone wheel</li> </ul>	
Fail Safe	EGR Off	NO			
	Fuel Limit	NO			
	MIL	YES			

# SPECIFICATION EFE26278

Sensor Type	Output Signal Characteristic	Air Gab	Low RPM Minimum Detecting Voltage	High RPM Minimum Detecting Voltage
Magnetic inductive	A/C waveform	1.8mm	230mV	2769 mV

# SCHEMATIC DIAGRAM E7870D61

Refer to DTC P0335.

### SIGNAL WAVEFORM AND DATA ETD2DBB5

Refer to DTC P0335.

# MONITOR SCANTOOL DATA EF7300D1

Refer to DTC P0335.

# TERMINAL AND CONNECTOR INSPECTION E9014124

Refer to DTC P0335.

#### SIGNAL CIRCUIT INSPECTION E1DC0A24

- 1. Check signal circuit voltage
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect CKPS connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of CKPS connector terminal 2 and 3.

Specification : 2.4V~2.6V

5) Is the measured voltage within the specification?

# YES

Go to "3.Check short between signal circuits."

#### NO

- ▶ Go to "2.Check open in signal circuit" as follows.
- 2. Check open in signal circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect CKPS connector and ECM connector.
  - 3) Check continuity between CKPS connector terminal 2 and ECM connector terminal 27.
  - 4) Check continuity between CKPS connector terminal 3 and ECM connector terminal 12.

Specification : continuity ( below  $1.0\Omega$  )

5) Is the measured resistance within the specification?

# YES

Go to "3. Check short between signal circuits".

#### NO-

- Repair open in signal circuit and go to "Verification of Vehicle Repair".
- 3. Check short between signal circuits
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect CKPS connector and ECM connector.
  - 3) Check continuity between CKPS connector terminal 2 and 3.

# DTC TROUBLESHOOTING PROCEDURES

Specification : Discontinuity ( Infinite  $\Omega$  )

4) Is the measured resistance within the specification?

## YES

Go to "4. Check short to ground in signal circuit" as follows.



- Repair short between signal circuits and go to "Verification of Vehicle Repair".
- 4. Check short to ground in signal circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect CKPS connector and ECM connector.
  - 3) Check continuity between CKPS connector terminal 1(shield ground) and 2,3(crank signal)

Specification : Discontinuity (Infinite  $\Omega$ )

4) Is the measured resistance within the specification?

# YES

Go to "Ground Circuit Inspection".

NO

Repair the short between signal circuit and shield ground and go to "Verification of Vehicle Repair".

## GROUND CIRCUIT INSPECTION EE9B17E6

- 1. IG KEY "OFF", ENGINE "OFF".
- 2. Disconnect CKPS connector.
- 3. Check continuity between CKPS connector terminal 1(shield ground) and chassis ground.

Specification : continuity ( below 1.0  $\!\Omega$  )

4. Is the measured resistance within the specification?

# YES

▶ Go to "Component Inspection".

NO

Repair open or poor connection in ground circuit and go to "Verification of Vehicle Repair".


### COMPONENT INSPECTION ED9E328D

1. Check Resistance of CKPS component

LGJF006B

- 1) IG KEY "OFF", ENGINE "OFF".
- 2) Disconnect CKPS connector.
- 3) Check resistance between CKPS connector terminal 2 and 3 at component side.

Specification : 860Ω ±10% (20℃)



4) Is the measured resistance within the specification?


## YES

Go to "Check short to ground in CKPS component" as follows.

NO

- Replace CKPS and go to "Verification of Vehicle Repair".
- 2. Check short to ground in CKPS component
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect CKPS connector.
  - 3) Check resistance between CKPS connector terminal 1 and 3 at component side.

Specification : Discontinuity (Infinite  $\Omega$ )



LGJF006C

4) Is the measured resistance within the specification? (Is the inside of component insulated correctly?)



▶ Go to "Check CKPS waveform".

#### NO

- Replace CKPS and go to "Verification of Vehicle Repair".
- 3. Check CKPS waveform
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Connect CKPS connector.
  - 3) Connect Oscilloscope to CKPS connector terminal 2.
  - 4) Check if CKPS waveform is outputted correctly as cranking or turning engine on.

Specification : Refer to "Signal waveform & data" of "General Information".

5) Is CKPS waveform outputted correctly?



Go to "Verification of Vehicle Repair".

## NO


▶ Replace CKPS and go to "Verification of Vehicle Repair".

## VERIFICATION OF VEHICLE REPAIR E4CAD69F

Refer to DTC P0335.

## DTC P0340 CAMSHAFT POSITION SENSOR A CIRCUIT MALFUNCTION (BANK 1 OR SINGLE SENSOR)

#### COMPONENT LOCATION E4A6324E



EWPF602V

#### **GENERAL DESCRIPTION** EEA8F910

Cam Shaft Position Sensor(CMPS) is hall sensor type. Sensing the teeth attatch at the end of exhaust cam shaft, CMPS detects rotation of Cam shaft (1 signal per 1 lotation)As Cam shaft rotates once while Crank shaft does twice. CMPS referrence point generates once while CKPS' do twice. As this signal inputted to ECM, it distinguishes crank angle and the cylinder which requires fuel injection in order to determine injection sequence and duration.

## DTC DESCRIPTION E2142264

P0340 is set when CKPS signal is outputted while CMPS signal does not generate for more than 0.7 sec.. This code is due to the failure relevant to CMPS related circuit and sensor component.

Item		Detecting	Possible Cause				
DTC Strategy	<ul> <li>Signal mon</li> </ul>	itoring					
Enable Conditions	<ul> <li>Engine runr</li> </ul>	ning(during	accelerating)				
ThresholdValue	<ul> <li>CKPS signa does not ge</li> </ul>	•	ed while CMPS signal				
DiagnosticTime	• 700ms			CMPS circuit			
	Fuel Cut	NO		CMPS component			
	EGR Off	NO	Engine does not turn				
Fail Safe	Fuel Limit	YES	"ON" at starting.				
	MIL	YES					


#### ATIMA AANDITIAN

## DTC TROUBLESHOOTING PROCEDURES

## SPECIFICATION EBEC0526

Sensor Type	Sensor Type Output Signal		LOW Signal	HIGH Signal	
	Characteristic		Detecting Voltage	Detecting Voltage	
Hall effect type	0V~5V Digital signal output	1.25mm	below 2.0V	above 3.8V	

## SCHEMATIC DIAGRAM EE63FF41



EWPF004A

## SIGNAL WAVEFORM AND DATA E95C796A





Fig.1) This shows waveform of Crank Shaft Position Sensor and Cam Shaft Position Sensor simulatneously. The middle area indicates reference points of Crank Shaft Position Sensor and Cam Shaft Position Sensor.

Fig.2) Crank Shaft Position Sensor and Cam Shaft Position Sensor signal are measured simultaneously. Cam Shaft Position Sensor signal is outputted once when Crank Shaft Position sensor signal is outputted twice. LOW and HIGH output of Cam Shaft Position sensor reference point is detected at Crank Shaft Position sensor reference point.

(Injection sequence is determined based on LOW and HIGH signal of Cam Shaft Position Sensor reference point as detecting cylinder position.)

**\* SIGNAL ANALYSIS** 



LGJF005K

LGJF005L

- 1. ECM recognizes HIGH signal as LOW signal when CMPS signal drops below 2.0V and LOW signal as HIGH signal when CMPS signal rises above 3.8V.
- 2. V0 the Minimum voltage of LOW signal does not drop below 0.0V due to the hall sensor inside resistance. When the Minimum voltage of LOW signal is above 0.6V during signal waveform inspection, check excessive resistance inside of CMPS component or in ground circuit.

#### MONITOR SCANTOOL DATA EBA196EF

- 1. Connect Scantool to Data Link Connector (DLC).
- 2. Warm engine up to normal operating temperature.
- 3. Turn "OFF" electrical devices and A/C.

## DTC TROUBLESHOOTING PROCEDURES

FLB -257

4. Monitor "ENGINE SPEED SENSOR" parameter on the Scantool.

Specification : 800±50RPM at idle

	1.2 CURRENT DATA	48/	54
			<u>å</u>
×	FUEL PRESSURE MEASURED 28.2	MPa	
×	RAIL PRESS. REGULATOR1 22.7	%	
×	AIR MASS PERCYLINDER 359.7	mg∕st	
×	EGR ACTUATOR 6.0	%	
×	WATER TEMP.SENSOR 94.3	°c	
×	ACCEL PEDAL SENSOR 1 725	mV	
×	BOOST PRESSURE SENSOR 1015	hPa	
×	ENGINE SPEED SENSOR 794	rpm	
			Ţ
[	FIX FULL GRPH	RCRD	

#### Fig.1

Fig.1) Check "ENGINE SPEED SENSOR" parameter carefully after warming engine up, also check engine stall and rpm instability or engine shut down.

LGJF005M

## TERMINAL AND CONNECTOR INSPECTION E940CA3A

- 1. Electrical systems consist of a lot of harness and connectors, poor connection of terminals can cause various problems and damge of component.
- 2. Perform checking procedure as follows.
  - 1) Check damage of harness and terminals : Check terminals for contact resistance, corrosion and deformation.
  - 2) Check connecting condition of ECM and component connector : Check terminal seperation, damage of locking device and connecting condition between terminal and wiring.

## **NOTE**

Disconnect the pin which requires checking at male connector and insert it to the terminal at female connector or checking connecting condition. (after checking, reconnect the pin at correct position.)

3. Is the problem found?

## YES

Repair the trouble causing part and go to "Verification of Vehicle Repair".

#### NO

▶ Go to "Power Circuit Inspection".

## POWER CIRCUIT INSPECTION EC36314D

- 1. IG KEY "OFF", ENGINE "OFF".
- 2. Disconnect CMPS connector.
- 3. IG KEY "ON".

#### **FUEL SYSTEM**

4. Measure the voltage of CMPS connector terminal 1.

Specification	:	11.0V~13.0V	( Main relay "ON" power )	)
---------------	---	-------------	---------------------------	---

5. Is the measured voltage within the specification?

## YES

Go to "Signal Circuit Inspection".

#### NO

▶ Repair open in Main relay power circuit and fuse, and go to "Verification of Vehicle Repair".

- [Check open in Engine room junction box 15A INJ and related circuit.]
- \* If the fuse is damaged again after replacing the damaged fuse, repair short to ground in Main relay power circuit.

#### SIGNAL CIRCUIT INSPECTION E284A117

- 1. Check CMPS signal voltage
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect CMPS connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of CMPS connector terminal 2.

Specification: 4.8V~5.1V

5) Is the measured voltage within the specification?

## YES

Go to "Ground Circuit Inspection".

NO

- ▶ Go to "Check open in signal circuit" as follows.
- 2. Check open in signal circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect CMPS connector and ECM connector.
  - 3) Check continuity between CMPS connector terminal 2 and ECM connector terminal 50.

Specification : continuity (below  $1.0\Omega$ )

4) Is the measured resistance within the specification? (Is continuity confirmed?)



▶ Go to "Check short to ground in signal circuit" as follows.

#### NO

▶ Repair open in the circuit between CMPS connector terminal 2 and ECM connector terminal 50 and go to "Verification of Vehicle Repair".

- 3. Check short to ground in signal circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect CMPS connector and ECM connector.
  - 3) Check continuity between CMPS connector terminal 2 and chassis ground.

Specification : Discontinuity (Infinite  $\Omega$ )

4) Is the measured resistance within the specification?



▶ Go to "Component Inspection".



Repair short to ground in signal circuit and go to "Verification of Vehicle Repair".

## GROUND CIRCUIT INSPECTION E49BAC3B

- 1. IG KEY "OFF", ENGINE "OFF".
- 2. Disconnect CMPS connector.
- 3. IG KEY "ON".
- 4. Check the voltage of CMPS connetor terminal 2. [ TEST "A" ]
- 5. Check the voltage between CMPS connetor terminal 2 and 3. [TEST "B"] (terminal 2 : Check + prove, terminal 3 : Check prove)

Specification : [TEST "A"] Voltage - [TEST "B"] Voltage = below 200mV

6. Is the measured voltage within the specification?

## YES.

▶ Go to "Component Inspection".

#### NO

When "B" voltage is not detected : Repair open in ground circuit and go to "Verification of Vehicle Repair".
 When the voltage difference between "A" and "B" is above 200mV : Eliminate the causes of excessive resistance and go to "Verification of Vehicle Repair".

## COMPONENT INSPECTION E03E16AF

- 1. Cam shaft detecting teeth inspection
  - 1) IG KEY "OFF", ENGINE "OFF".

- 2) Disconnect CMPS connector.
- 3) Disconnect CMPS.
- 4) Check the condition of Cam shaft detecting teeth through CMPS mounting hall.
- 5) Is abnormal deformation of Cam shaft detecting teeth found?

#### YES

Replace Cam shaft assy' or Cylinder head assy' and go to "Verification of Vehicle Repair".

#### NO

- ▶ Go to "CMPS waveform Inspection" as follows.
- 2. CMPS waveform inspection
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Connect CMPS connector.
  - 3) Connect Oscilloscope to CMPS connector terminal 2.
  - 4) Monitor if CMPS waveform is outputted normally as cranking or turning engine "ON".

Specification : Refer to "Signal waveform & Data" of "General Information".

5) Is CMPS waveform displayed correctly?



Go to "Verification of Vehicle Repair".



Replace CMPS and go to "Verification of Vehicle Repair".

#### VERIFICATION OF VEHICLE REPAIR ETAESCIE

After a repair, it is essential to verify that the fault is corrected.

- 1. After connecting Scantool select "DIAGNOSTIC TROUBLE CODES(DTCs)" mode.
- 2. Clear recorded DTC using Scantool.
- 3. Drive the vehicle within DTC "Enable conditions" in "General information".
- 4. After selecting "DIAGNOSTIC TROUBLE CODES(DTCs)" mode and check if DTC is recorded again.
- 5. Are any DTCs recorded ?

## YES

Go to the DTC guide of recorded NO. in Scantool.

## NO

System operates within specification.

## DTC P0341 CAMSHAFT POSITION SENSOR A CIRCUIT RANGE/PERFORMANCE (BANK 1 OR SINGLE SENSOR)

## COMPONENT LOCATION E6F3A553

Refer to DTC P0340.

#### GENERAL DESCRIPTION EB6DD8F9

Refer to DTC P0340.

#### DTC DESCRIPTION E23C24B5

P0341 is set when CMPS reference point is detected more or less than twice while CKPS reference point is recognized 4 times. This code is due to temporary poor connection or short to ground in CMPS circuit. CMPS component failure.

## DTC DETECTING CONDITION EC8C1E1C

ltem		Detecting Condition	Possible Cause
DTC Strategy	<ul> <li>Signal mon</li> </ul>	itoring	
Enable Conditions	<ul> <li>Engine runi</li> </ul>	ning(during accelerating)	
ThresholdValue		from CMPS correlates with RF abnormally.	RPM
DiagnosticTime	<ul> <li>Crank Shaf</li> </ul>	t 4 rotation	CMPS circuit
	Fuel Cut	YES	CMPS component
Fail Safe	EGR Off	YES	
	Fuel Limit	NO	
	MIL	NO	

#### SPECIFICATION E230C314

Sensor Type	Characteristic		LOW Signal Detecting Voltage	HIGH Signal Detecting Voltage	
Hall effect type	0V~5V Digital signal output	1.25mm	below 2.0V	above 3.8V	

## SCHEMATIC DIAGRAM E91BC9B9

Refer to DTC P0340.

## SIGNAL WAVEFORM AND DATA EC645B5C

Refer to DTC P0340.

## MONITOR SCANTOOL DATA ECC990DA

Refer to DTC P0340.

#### FLB -261

#### TERMINAL AND CONNECTOR INSPECTION EAC28AD0

Refer to DTC P0340.

#### POWER CIRCUIT INSPECTION EF2913BB

- 1. IG KEY "OFF", ENGINE "OFF".
- 2. Disconnect CMPS connector.
- 3. IG KEY "ON".
- 4. Measure the voltage of CMPS connector terminal 1.

Specification: 11.0V~13.0V (Main relay "ON" power)

5. Is the measured voltage within the specification?

## YES

▶ Go to "Signal Circuit Inspection".

#### NO

Repair open in Main relay power circuit and fuse, and go to "Verification of Vehicle Repair".

[Check open in Engine room junction box 15A INJ and related circuit.]

\* If the fuse is damaged again after replacing the damaged fuse, repair short to ground in Main relay power circuit.

#### SIGNAL CIRCUIT INSPECTION E5F9D9A5

- 1. Check CMPS signal voltage
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect CMPS connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of CMPS connector terminal 2.

Specification: 4.8V~5.1V

5) Is the measured voltage within the specification?

#### YES

Go to "Ground Circuit Inspection".

NO

- ▶ Go to "Check open in signal circuit" as follows.
- 2. Check open in signal circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect CMPS connector and ECM connector.

## DTC TROUBLESHOOTING PROCEDURES

- FLB -263
- 3) Check continuity between CMPS connector terminal 2 and ECM connector terminal 50.

Specification : continuity ( below  $1.0\Omega$  )

4) Is the measured resistance within the specification? (Is continuity confirmed?)



Go to "Check short to ground in signal circuit" as follows.



▶ Repair open in the circuit between CMPS connector terminal 2 and ECM connector terminal 50 and go to "Verification of Vehicle Repair".

- 3. Check short to ground in signal circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect CMPS connector and ECM connector.
  - 3) Check continuity between CMPS connector terminal 2 and chassis ground.

Specification : Discontinuity ( Infinite  $\Omega$  )

4) Is the measured resistance within the specification?



Go to "Component Inspection".



Repair short to ground in signal circuit and go to "Verification of Vehicle Repair".

#### GROUND CIRCUIT INSPECTION E06392E7

- 1. IG KEY "OFF", ENGINE "OFF".
- 2. Disconnect CMPS connector.
- 3. IG KEY "ON".
- 4. Check the voltage of CMPS connetor terminal 2. [ TEST "A" ]
- 5. Check the voltage between CMPS connetor terminal 2 and 3. [TEST "B"] (terminal 2 : Check + prove , terminal 3 : Check prove )

Specification : [TEST "A"] Voltage - [TEST "B"] Voltage = below 200mV

6. Is the measured voltage within the specification?



▶ Go to "Component Inspection".

#### NO

When "B" voltage is not detected : Repair open in ground circuit and go to "Verification of Vehicle Repair".
 When the voltage difference between "A" and "B" is above 200mV : Eliminate the causes of excessive resistance and go to "Verification of Vehicle Repair".

#### COMPONENT INSPECTION E562ACD0

- 1. Cam shaft detecting teeth inspection
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect CMPS connector.
  - 3) Disconnect CMPS.
  - 4) Check the condition of Cam shaft detecting teeth through CMPS mounting hall.
  - 5) Is abnormal deformation of Cam shaft detecting teeth found?



Replace Cam shaft assy' or Cylinder head assy' and go to "Verification of Vehicle Repair".

#### NO

- ▶ Go to "CMPS waveform Inspection" as follows.
- 2. CMPS waveform inspection
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Connect CMPS connector.
  - 3) Connect Oscilloscope to CMPS connector terminal 2.
  - 4) Monitor if CMPS waveform is outputted normally as cranking or turning engine "ON".

Specification : Refer to "Signal waveform & Data" of "General Information".

5) Is CMPS waveform displayed correctly?



Go to "Verification of Vehicle Repair".

#### NO


Replace CMPS and go to "Verification of Vehicle Repair".

## VERIFICATION OF VEHICLE REPAIR E9AF2CB4

Refer to DTC P0340.

## DTC P0381 GLOW INDICATOR LAMP - CIRCUIT MALFUNCTION

## COMPONENT LOCATION EEOF4F7E



EWPF602W

## GENERAL DESCRIPTION E6336FCA

Heating combustion chamber, glow plug increases fuel ignitibility and makes fuel foggy state easily when engine is cold. Thus, glow plug makes engine starting easily and decreases exhaust gas produced just after turning engine on when engine is cold.ECM controls operation and operating duration of glow plug relay which supplies power to glow plug with ECTS signal, battery voltage and IG KEY ON signal.Through glow lamp in cluster, ECM let drivers know if glow plug is ON.

## DTC DESCRIPTION E905B186


P0381 is set when 1)excessive voltage is detected or 2)no current is detected like open or short to ground in glow lamp control circuit for more than 1 sec. at glow lamp ON condition. This code is due to open in glow lamp control circuit or internal open in filament of glow lamp component.

## DTC DETECTING CONDITION E5D6610B

Item		Detecting	Condition	Possible Cause
DTC Strategy	<ul> <li>Voltage mo</li> </ul>	nitoring		
Enable Conditions	<ul> <li>IG KEY "ON lamp operation</li> </ul>		ng only performed within n)	
ThresholdValue	<ul><li>short to bat</li><li>Short to GN</li></ul>		pen	
DiagnosticTime	• 1.0 sec.			<ul> <li>Open in glow lamp</li> <li>Glow lamp circuit</li> </ul>
	Fuel Cut	NO		
Fail Safa	EGR Off	NO	1	
Fail Safe	Fuel Limit	NO	1	
	MIL	NO	1	

FLB -265

## SCHEMATIC DIAGRAM E80FC774



#### MONITOR SCANTOOL DATA ED51611E

- 1. Connect Scantool to Data Link Connector (DLC).
- 2. Warm engine up to normal operating temperature.
- 3. Turn "OFF" electrical devices and A/C.
- 4. Select "ACTUATION TEST" parameter on the scantool.

specification : Lamp turns ON at ACTUATION TEST of Glow lamp.

1	.5 ACTUATION TEST	10/17					
GLOW LAMP	Elisticita di esta consecto socione con presente i interes e consecuto e se un eseguio d	NA MANANA MA					
DURAT I ON	UNTIL STOP KEY						
METHOD	ACTIVATION						
CONDITION	THOD ACTIVATION						
PRESS [S	TRT], IF YOU ARE REA	YDY †					
STRT STO							
SIRI 510	<u>r</u>						

#### Fig.1) Diagnosing problem is convenient through ACTUATION TEST of glow lamp.

LGJF007Q

## TERMINAL AND CONNECTOR INSPECTION E274C90F

- 1. Electrical systems consist of a lot of harness and connectors, poor connection of terminals can cause various problems and damge of component.
- 2. Perform checking procedure as follows.
  - 1) Check damage of harness and terminals : Check terminals for contact resistance, corrosion and deformation.
  - 2) Check connecting condition of ECM and component connector : Check terminal seperation, damage of locking device and connecting condition between terminal and wiring.

## NOTE

Disconnect the pin which requires checking at male connector and insert it to the terminal at female connector for checking connecting condition. (after checking, reconnect the pin at correct position.)

3. Is the problem found?

## YES

Repair the trouble causing part and go to "Verification of Vehicle Repair".

## NO

Go to "Control Circuit Inspection".

## CONTROL CIRCUIT INSPECTION E171B544

- 1. Check voltage in control circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect ECM connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of terminal 69 of ECM connector.

Specification: 10.8V~13.0V

5) Is the measured voltage within the specification?

## YES

Go to "2. Grounding test of glow lamp control circuit".

## NO

- Check filament of glow lamp. (Refer to Component Inspection)
- 2. Grounding test of glow lamp control circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect ECM connector.
  - 3) IG KEY "ON".
  - 4) Ground ECM connector terminal 69 to chassis ground.

specification : Glow lamp turns ON.

5) Does glow lamp turn ON?

YES

▶ Go to "Verification of Vehicle Repair".



Repair short to battery in glow lamp control circuit and go to "Verification of Vehicle Repair".

#### COMPONENT INSPECTION E65DAD43

- 1. IG KEY "OFF", ENGINE "OFF".
- 2. Dismount cluster and disconnect glow lamp.
- 3. Check filament of glow lamp.
- 4. supply 12V to glow lamp to turn lamp ON.

specification : Lamp turns ON when 12V is supplied.

- 5. Does glow lamp turn ON?
  - 1)

#### YES

Go to "Verification of Vehicle Repair".

NO

Replace glow lamp and go to "Verification of Vehicle Repair".

## VERIFICATION OF VEHICLE REPAIR E5D16331

After a repair, it is essential to verify that the fault is corrected.

- 1. After connecting Scantool select "DIAGNOSTIC TROUBLE CODES(DTCs)" mode.
- 2. Clear recorded DTC using Scantool.
- 3. Drive the vehicle within DTC "Enable conditions" in "General information".
- 4. After selecting "DIAGNOSTIC TROUBLE CODES(DTCs)" mode and check if DTC is recorded again.
- 5. Are any DTCs recorded ?

#### YES


Go to the DTC guide of recorded NO. in Scantool.

#### NO

System operates within specification.

# DTC P0489 EXHAUST GAS RECIRCULATION CONTROL CIRCUIT LOW VOLTAGE

COMPONENT LOCATION E14C6704




EWPF602X

## GENERAL DESCRIPTION EB1A8139

Receiving ECM signal, linear solenoid type electronic EGR actuator operates EEGR valve directly.ECM performs EGR system feed back control with the information of measured mass air flow (The role of AFS in diesel engine is different from gasoline engine. Fuel injection quantity is decided by AFS signal in gasoline engine.)When EGR gas(contains no oxygen) flowing into combustion chamber increases, the air passing through AFS(contains oxygen) decreases. Thus, with the output signal change of AFS accompanied by EEGR actuator actuation, ECM determine the amount of recirculated EGR gas quantity.

## **NOTE**

NOx is produced from the reaction of nitrogen and oxygen. Controlling EGR gas(contains no oxyger) which is recirculated to combustion chamber, if least intake air required for complete combustion flows into combustion chamber, NOx decreases because there is no supplementary oxygen to react with nitrogen.



LGJF004W

## DTC DESCRIPTION E176EB59

P0489 is set when '0'A is detected in EEGR actuator circuit for more than 0.5 sec.. This code is due to open or short to ground in EEGR actuator circuit or internal open in EEGR component.


## DTC DETECTING CONDITION EDFA13A1

Item		Detecting	Condition	Possible Cause
DTC Strategy	<ul> <li>Signal mon</li> </ul>	itoring		
Enable Conditions	<ul> <li>Engine run</li> </ul>			
ThresholdValue	<ul> <li>short to GN</li> </ul>	ID, wiring o	pen	
DiagnosticTime	• 500ms			EGR actuator circuit
	Fuel Cut	NO		EGR actuator component
	EGR Off	YES	-	
Fail Safe	Fuel Limit	NO		
	MIL	YES		

## SPECIFICATION E65C1265

EGR actuator component resistance	EGR actuator operating Hz	EGR actuator operating duty
14.7 ~ 16.1Ω (20℃)	142Hz	5%(closed)~39%(opened)

## SCHEMATIC DIAGRAM E73ED84E



EWPF004G

## SIGNAL WAVEFORM AND DATA E8749714

MIN:- 35			13.5 V	MAX:	15.1 V	MIN: 1	78.0mV A	VE:	8.9 V	Max:
FREQ: 1	156.25	Hz	DUTY:	91 %		FREQ:	153.85	Hz	DUTY:	58 %
										~1
			·····		······					
	 [200m]	CURS	MEMO	RECD	MENU	HOM			MEMO	RECD

Fig.1) Approx. 6% duty signal waveform of EEGR actuator (with EEGR valve closed) Fig.2) Approx. 40% duty signal waveform of EEGR actuator(with EEGR valve opened)

## NOTE

The output of approx. 6% duty is mainly for the diagnosis of EEGR actuator circuit than actuating EEGR.

## MONITOR SCANTOOL DATA EA16A6EB

- Connect scantool to Data Link Cable. (DLC) 1.
- 2. Warm engine up to normal operating temperature.
- 3. Turn "OFF" electrical devices and A/C.
- Monitor "AIR MASS PERCYLINDER" parameter on the Scantool. 4.

Specification : When EEGR actuator does not operate 6% duty) at idle : 340mg/st ± 50 mg/st When EEGR actuator operates(50% duty) at idle : 200ms/st ± 50 mg/st

CH B 5.0 V

15.3 V

MAX:

RECD

MENII

LGJF004Y

	1.2 CURRENT DA	TA	12/	54			1.2	CURRENT I	)ATA	12/	54
				<u>à</u>							۸
×	FUEL PRESSURE-TARGET	28.5	MPa		×	FUE	PRESSUR	E-TARGET	28.5	MPa	
×	FUEL PRESSURE MEASURED	28.5	MPa	麣	×	FUEI	PRESSUR	e measurei	28.5	MPa	
×	AIR MASS PERCYLINDER	359.	7mg∕st		×	AIR	MASS PER	CYLINDER	192.	7mg∕st	
×	AIR TEMPERATURE SENSOR	38.6	°C	9 1	×	AIR	TEMPERAT	URE SENSOI	39.4	°C	
×	EGR ACTUATOR	6.0	%		×	EGR	ACTUATOR		56.6	%	
×	ACCEL PEDAL SENSOR	0.0	%		×	ACCI	EL PEDAL	SENSOR	0.0	%	
×	ENGINE SPEED SENSOR	794	rpm		×	ENG	NE SPEED	SENSOR	794	rpm	
	CALCULAT.LOAD VALUE.					CALC	CULAT . LOA	D VALUE.			
				Ŧ							ş
	FIX FULL	GRPH	RCRD	]		FIX		FULL	GRPH	RCRD	j –
F					Ē	<b>g.2</b>					

Fig.1) Check if "AIR MASS PERCYLINDER" output signal is 340mg/st ± 50mg/st without EEGR operation at warm idle (EEGR actuator 6% duty)

Fig.2) Check if "AIR MASS PERCYLINDER" output signal is 200mg/st ± 50mg/st with EEGR operation at warm idle (EEGR actuator 50% duty)

\* EEGR actuator operates as decelerating after rapid acceleration when idle EEGR does not operate, EEGR actuator operating duty decreases as time goes by. This controlling process lasts for about 3 min. and EEGR actuator turns "OFF" (duty 6%) after 3 min.

LGJF012R

## TERMINAL AND CONNECTOR INSPECTION E310D3B7

- 1. Electrical systems consist of a lot of harness and connectors, poor connection of terminals can cause various problems and damge of component.
- 2. Perform checking procedure as follows.
  - 1) Check damage of harness and terminals : Check terminals for contact resistance, corrosion and deformation.
  - 2) Check connecting condition of ECM and component connector : Check terminal seperation, damage of locking device and connecting condition between terminal and wiring.

## 

Disconnect the pin which requires checking at male connector and insert it to the terminal at female connector or checking connecting condition. (after checking, reconnect the pin at correct position.)

3. Is the problem found?

## YES

Repair the trouble causing part and go to "Verification of Vehicle Repair".


#### NO

Go to "Power Circuit Inspection".

## POWER CIRCUIT INSPECTION EDD6CE4C

- 1. Check power circuit voltage
  - 1) IG KEY "OFF", ENGINE "OFF".

- 2) Disconnect EGR actuator connector
- 3) IG KEY "ON"
- 4) Measure the voltage of terminal 2 of EGR actuator connector



5) Is the measured voltage within the specification?

## YES

Go to "Control Circuit Inspection".

NO

▶ Repair E/R FUSE & RELAY BOX 15A INJ fuse and related circuit and go to "Verification of Vehicle Repair".

### CONTROL CIRCUIT INSPECTION EB554984

- 1. Check control circuit monitoring voltage
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect EGR actuator connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of terminal 1 of EGR actuator connector.

Specification: 3.2V~3.7V

5) Is the measured voltage within the specification?

## YES

Go to "Component Inspection".

## NO

- ▶ When voltage is not detected : Go to "2. Check open in control circuit" as follows.
- ▶ When high voltage is detected : Repair short to battery and go to "Verification of Vehicle Repair".
- 2. Check open in control circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect EGR actuator connector and ECM connector.
  - 3) Check continuity between EGR actuator terminal 1 and ECM connector terminal 59.

specification : Continuity ( below  $1.0\Omega$  )

4) Is the measured resistance within the specification?

LGJE005C

## YES

Repair short to ground and go to "Verification of Vehicle Repair".

NO

Repair open in control circuit and go to "Verification of Vehicle Repair".

#### COMPONENT INSPECTION E68F32A9

- 1. Check EGR actuator component resistance
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect EGR actuator.
  - 3) Measure the resistance between EGR actuator component terminal 1 and 2.

Specification : 14.7 ~ 16.1Ω (20℃)



4) Is EEGR actuator component resistance within the specification?

## YES

▶ go to "Verification of Vehicle Repair".

#### NO

▶ Replace EEGR actuator and go to "Verification of Vehicle Repair".

#### VERIFICATION OF VEHICLE REPAIR EE5E822B

After a repair, it is essential to verify that the fault is corrected.

- 1. After connecting Scantool select "DIAGNOSTIC TROUBLE CODES(DTCs)" mode.
- 2. Clear recorded DTC using Scantool.
- 3. Drive the vehicle within DTC "Enable conditions" in "General information".
- 4. After selecting "DIAGNOSTIC TROUBLE CODES(DTCs)" mode and check if DTC is recorded again.
- 5. Are any DTCs recorded ?

## YES

▶ Go to the DTC guide of recorded NO. in Scantool.

## NO

System operates within specification.

# DTC P0490 EXHAUST GAS RECIRCULATION CONTROL CIRCUIT HIGH VOLTAGE

#### COMPONENT LOCATION E23D2FF6

Refer to DTC P0489.

## GENERAL DESCRIPTION ED3A37B7

Refer to DTC P0489.

#### DTC DESCRIPTION E3C2B92E

P0490 is set when excessive current is detected in EEGR actuator circuit for more than 0.5 sec.. This code is due to short to battery in EEGR actuator control circuit or internal short in EEGR component.

## DTC DETECTING CONDITION E2B00F25

Item	Detecting Condition			Possible Cause
DTC Strategy	Signal monitoring			
Enable Conditions	Engine run			-
ThresholdValue	Short to battery			
DiagnosticTime	• 500ms			<ul> <li>EGR actuator circuit</li> </ul>
	Fuel Cut	NO	• EGR actuator com	<ul> <li>EGR actuator component</li> </ul>
Fail Safe	EGR Off	YES		
	Fuel Limit	NO		
	MIL	YES		

## SPECIFICATION E673CDD6

EGR actuator component resistance	EGR actuator operating Hz	EGR actuator operating duty	
14.7 ~ 16.1Ω (20℃)	142Hz	5%(closed)~39%(opened)	

#### SCHEMATIC DIAGRAM E62E6A61

Refer to DTC P0489.

#### SIGNAL WAVEFORM AND DATA E9287B77

Refer to DTC P0489.

## MONITOR SCANTOOL DATA EA1E85EE

Refer to DTC P0489.

## TERMINAL AND CONNECTOR INSPECTION EF94F61E

Refer to DTC P0489.

## POWER CIRCUIT INSPECTION E156171A

- 1. Check power circuit voltage
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect EGR actuator connector
  - 3) IG KEY "ON"
  - 4) Measure the voltage of terminal 2 of EGR actuator connector

Specification : 11.5V~13.0V

5) Is the measured voltage within the specification?

## YES

▶ Go to "Control Circuit Inspection".

#### NO

▶ Repair E/R FUSE & RELAY BOX 15A INJ fuse and related circuit and go to "Verification of Vehicle Repair".

## CONTROL CIRCUIT INSPECTION E40087E2

- 1. Check control circuit monitoring voltage
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect EGR actuator connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of terminal 1 of EGR actuator connector.

Specification : 3.2V~3.7V

5) Is the measured voltage within the specification?

## YES

Go to "Component Inspection".



- ▶ When voltage is not detected : Go to "2. Check open in control circuit" as follows.
- ▶ When high voltage is detected : Repair short to battery and go to "Verification of Vehicle Repair".
- 2. Check open in control circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect EGR actuator connector and ECM connector.

3) Check continuity between EGR actuator terminal 1 and ECM connector terminal 59.

specification : Continuity ( below  $1.0\Omega$  )

4) Is the measured resistance within the specification?



Repair short to ground and go to "Verification of Vehicle Repair".




▶ Repair open in control circuit and go to "Verification of Vehicle Repair".

#### COMPONENT INSPECTION E827B2FD

- 1. Check EGR actuator component resistance
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect EGR actuator.
  - 3) Measure the resistance between EGR actuator component terminal 1 and 2.

Specification : 14.7 ~ 16.1Ω (20℃)



LGJF005C

4) Is EEGR actuator component resistance within the specification?



▶ Go to "Verification of Vehicle Repair".




▶ Replace EEGR actuator and go to "Verification of Vehicle Repair".

#### VERIFICATION OF VEHICLE REPAIR E29AB980

Refer to DTC P0489.

## DTC P0501 VEHICLE SPEED SENSOR A RANGE/PERFORMANCE

## COMPONENT LOCATION E45F6DE7



EWPF602Y

FLB -279

## GENERAL DESCRIPTION EADA07AE

Vehicle Speed Sensor(VSS) is hall sensor type and senses the rotating speed of differential gear mounted on transaxle. Comparing engine speed with vehicle speed calculated based on vehicle speed sensor signal, ECM recognizes engaged gear. And based on the information about engaged gear, ECM performs optimum fuel injection quantity correction. VSS signal is also used in speed meter of cluster, aircon control module, BCM, etc.

## DTC DESCRIPTION EBF6027F

P0501 is set when 1)vehicle speed below 13.8Km/h is detected for more than 1 sec. at above 4000RPM and above 38.5 cc of fuel injection quantity or 2)above 240Kph is detected for more than 0.5 sec.


Item	Detecting Condition			Possible Cause
DTC Strategy	Signal monitoring			<ul> <li>Vehicle speed sensor circuit</li> <li>Vehicle speed sensor</li> </ul>
Enable Conditions	During driving			
ThresholdValue	<ul> <li>Vehicle speed calculated by ECM is above 240Kph for more than 0.5 sec.</li> <li>When vehicle speed below 13.8Km/h is detected for more than 1.0 sec. at above 4000RPM and above 38.5mcc of fuel injection quantity.</li> </ul>			
DiagnosticTime	Refer to threshold Value			
	Fuel Cut	NO	<ul> <li>Clutch error monitoring inhibited</li> <li>Cruise control deactivated (for Cruise</li> </ul>	component
Fail Safe	EGR Off	NO		
	Fuel Limit	NO		
	MIL	NO	control option applied vehicle) • Idle correction deactivated at low battery voltage	

## DTC DETECTING CONDITION E1D518FC

## SPECIFICATION E4894978

Sensing Type	LOW Signal Voltage	HIGH Signal Voltage	Signal Duty
M/T : Hall sensor typeA/T : driven by TCM	below 1.5V	above 3.5V	50±5%

## SCHEMATIC DIAGRAM ECB6D480



EWPF008H

## SIGNAL WAVEFORM AND DATA E28094C7




Fig.1) This is the signal waveform of vehicle speed sensor. Digital waveform, LOW 0.8V, HIGH : 10V with 50% duty is outputted. ECM detects vehicle speed, sensing this ON-OFF period (Hz).

LGJF011T

## MONITOR SCANTOOL DATA EC499874

- 1. Connect Scantool to Data Link Connector (DLC).
- 2. Warm engine up to normal operating temperature.
- 3. Turn "OFF" electrical devices and A/C.
- 4. Monitor "VEHICLE SPEED SENSOR " parameter on the Scantool.

specification : current vehicle speed is displayed.




Fig.1) Check if current vehicle speed is same as vehicle speed displayed on the Scantool.

LGJF011U

## TERMINAL AND CONNECTOR INSPECTION EFEFDF71

1. Electrical systems consist of a lot of harness and connectors, poor connection of terminals can cause various problems and damge of component.

2. Perform checking procedure as follows.

- 1) Check damage of harness and terminals : Check terminals for contact resistance, corrosion and deformation.
- 2) Check connecting condition of ECM and component connector : Check terminal seperation, damage of locking device and connecting condition between terminal and wiring.

**NOTE** 

Disconnect the pin which requires checking at male connector and insert it to the terminal at female connector for checking connecting condition. (after checking, reconnect the pin at correct position.)

3. Is the problem found?

#### YES

Repair the trouble causing part and go to "Verification of Vehicle Repair".

NO

Go to "Power Circuit Inspection".

#### POWER CIRCUIT INSPECTION ED7CAA5A

- 1. Check power circuit voltage
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect Vehicle Speed Sensor connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of VSS connector terminal 2.

Specification : 11.5V~13.0V

5) Is the measured voltage within the specification?

## YES.

▶ Go to "Signal Circuit Inspection".



▶ Repair In-pannel junction box 10A ECU fuse and related circuit, and related circuit and go to "Verification of Vehicle Repair".

#### SIGNAL CIRCUIT INSPECTION ED91B845

- 1. Check signal circuit voltage at sensor side
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect VSS connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of VSS connector termianl 3.

## DTC TROUBLESHOOTING PROCEDURES

#### Specification : 8.0V~11.5V

5) Is the measured voltage within the specification?



Go to "2.Check open in signal circuit at ECM side".



- Repair poor connection or open in circuit and go to "Verification of Vehicle Repair".
- 2. Check open in signal circuit at ECM side
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect VSS connector and ECM connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of ECM connector terminal 75.

Specification : 8.0V~11.5V

5) Is the measured voltage within the specification?

## YES

Go to "Ground Circuit Inspection".



Repair poor connection or open in circuit and go to "Verification of Vehicle Repair".

#### GROUND CIRCUIT INSPECTION E038BA55

- 1. IG KEY "OFF", ENGINE "OFF".
- 2. Disconnect VSS connector.
- 3. IG KEY "ON".
- 4. Measure the voltage of VSS connector terminal 3. [ TEST "A" ]
- 5. Measure the voltage between VSS connector terminal 3 and 1. [TEST "B"] (terminal 3 : Check + prove, terminal 1 : Check prove)

Specification : [TEST "A"] Voltage - [TEST "B"] Voltage = below 200mV

6. Is the measured voltage within the specification?



Go to "Component Inspection".

FLB -283

#### NO

When "B" voltage is not detected : Repair open in ground circuit and go to "Verification of Vehicle Repair".
 When the voltage difference between "A" and "B" is above 200mV : Eliminate the causes of excessive resistance and go to "Verification of Vehicle Repair".

#### COMPONENT INSPECTION E53F0507

- 1. IG KEY "OFF", ENGINE "OFF".
- 2. Disconnect VSS connector.
- 3. Disconnect VSS and Driven gear assy'.
- 4. Check rotating state of VSS driven gear.
- 5. Connect VSS connector and IG KEY "ON".
- 6. Rotate Driven gear with hand.

Specification : Vehicle Speed Signal generates.

7. Does vehicle speed signal generate?

### YES

Go to "Verification of Vehicle Repair".

#### NO

Replace vehicle speed sensor and go to "Verification of Vehicle Repair".

## VERIFICATION OF VEHICLE REPAIR E3A65C9F

After a repair, it is essential to verify that the fault is corrected.

- 1. After connecting Scantool select "DIAGNOSTIC TROUBLE CODES(DTCs)" mode.
- 2. Clear recorded DTC using Scantool.
- 3. Drive the vehicle within DTC "Enable conditions" in "General information".
- 4. After selecting "DIAGNOSTIC TROUBLE CODES(DTCs)" mode and check if DTC is recorded again.
- 5. Are any DTCs recorded ?

#### YES


▶ Go to the DTC guide of recorded NO. in Scantool.

#### NO

System operates within specification.

## DTC P0504 BRAKE SWITCH "A"/"B" CORRELATION

## COMPONENT LOCATION E6C2B1FD



EWPF602Z

## GENERAL DESCRIPTION EA417B3E

Brake switch is connected to brake pedal and transmits brake operating state to ECM. When the output signal of APS is higher than what driver intended during driving (e.g. short to high voltage line in APS circuit, false signal), driver depresses brake pedal.Like this, if driver's decelerating intension is transmitted to ECM (break pedal depressed)when APS output voltage is high, ECM recognizes APS trouble and Limp Home mode is activated.At Limp Home mode, engine speed is fixed at 1200RPM and engine power generation is limitted.Even at Limp home mode, if correct APS signal is detected, Limp Home mode is deactivated. Brake switch, which monitors proper operation of APS, is devided 1 and 2 for the fidelity of brake switch.

## DTC DESCRIPTION E27F1976

When brake switch operates correctly, switch 1 is OFF and switch 2 is ON when releasing brake pedal, while switch 1 is ON and switch 2 is OFF when depressing brake pedal. thus when the signal from a switch is different from the other's, brake switch is in good condition. When the signal from a switch is same as the other's, brake switch is fault.

Item	Detecting Condition			Possible Cause	
DTC Strategy	<ul> <li>Signal mon</li> </ul>	itoring		· · · · · · · · · · · · · · · · · · ·	
Enable Conditions	• IG KEY "O	N"			
ThresholdValue	<ul> <li>Wiring oper</li> </ul>	<u>ו</u>			
DiagnosticTime	• 30 sec.		· · · · ·	<ul> <li>Brake switch component</li> </ul>	
	Fuel Cut	NO	- · ·	<ul> <li>Abnormal brake pedal height</li> <li>Brake switch circuit</li> </ul>	
Fail Safe	EGR Off	NO			
	Fuel Limit	NO			
	MIL	NO			


## DTC DETECTING CONDITION EB4F99BC

## FLB -285

#### SPECIFICATION E11EB387

Condition	Brake Pedal Released		Brake Pedal Depressed	
14 - K	Switch 1	Switch 2	Switch 1	Switch 2
switch activated	OFF	ON	ON	OFF

## SCHEMATIC DIAGRAM E488BFD7



#### SIGNAL WAVEFORM AND DATA EB9EC498





Fig.1) The waveform of brake signal 1 and 2 are measured simultaneously. Both waveforms are symmetrical.

LGJF003V

## MONITOR SCANTOOL DATA F434F5A2

- 1. Connect scantool to Data Link Cable. (DLC)
- 2. Warm engine up to normal operating temperature.
- 3. Turn "OFF" electrical devices and A/C.
- 4. Monitor "BRAKE SWITCH" and "REDUNDANT BRAKE SWITCH" parameter on the Scantool.

specification : When brake pedal is released : "BRAKE SWITCH" and "REDUNDANT BRAKE SWITCH" : OFF When brake pedal is depressed : "BRAKE SWITCH" and "REDUNDANT BRAKE SWITCH" : ON






Fig.1) Data when brake switch(brake pedal) is deactivated(released) : "BRAKE SWITCH" and "REDUNDANT BRAKE SWITCH" : OFF Fig.2) Data when brake switch(brake pedal) is activated(depressed) :

"BRAKE SWITCH" and "REDUNDANT BRAKE SWITCH" : ON

LGJF003W

## TERMINAL AND CONNECTOR INSPECTION E1E6400E

- 1. Electrical systems consist of a lot of harness and connectors, poor connection of terminals can cause various problems and damge of component.
- 2. Perform checking procedure as follows.
  - 1) Check damage of harness and terminals : Check terminals for contact resistance, corrosion and deformation.
  - 2) Check connecting condition of ECM and component connector : Check terminal seperation, damage of locking device and connecting condition between terminal and wiring.

## 🛈 ΝΟΤΕ

Disconnect the pin which requires checking at male connector and insert it to the terminal at female connector or checking connecting condition. (after checking, reconnect the pin at correct position.)

3. Is the problem found?

#### YES

Repair the trouble causing part and go to "Verification of Vehicle Repair".

#### NO

Go to "Power Circuit Inspection".

#### POWER CIRCUIT INSPECTION EB9246C7

- 1. Check brake switch 1 "HOT AT ALL TIMES"
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect brake switch connector.
  - 3) Measure the voltage of brake switch connector terminal 2.

Specification : 11.5V~13.0V

4) Is the measured voltage within the specification?

#### YES

▶ Go to "2.Check brake switch 2 main relay power" as follows.

#### NO

- Repair I/P juntion box 15A STOP FUSE and related circuit and go to "Verification of Vehicle Repair".
- 2. Check brake switch 2 main relay power
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect brake switch connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of brake switch connector terminal 4.

Specification : 11.5V~13.0V

5) Is the measured voltage within the specification?

#### YES

Go to "Signal Circuit Inspection".

#### NO

Repair Engine room juntion box 10A SNSR FUSE and related circuit and go to "Verification of Vehicle Repair".

#### SIGNAL CIRCUIT INSPECTION E6488B9F

- 1. Check brake switch signal circuit voltage
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect ECM connector with brake switch connector connected.
  - 3) Disconnect Engine room junction box main relay, connect main relay terminal 1 and 5 using jump wire.

#### DTC TROUBLESHOOTING PROCEDURES

4) Measure the voltage of ECM connector terminal 38 and 80 as depressing brake pedal.

#### SPECIFICATION :

	Brake Pedal Released	Brake Pedal Depressed
Brake switch 1 (terminal 59)	0.0V~0.1V	11.5V~13.0V
Brake switch 2 (terminal 54)	11.5V~13.0V	0.0V~0.1V

5) Is the measured voltage within the specification?

## YES

Go to "Verification of Vehicle Repair".



▶ If component has no problem after performing "Component Inspection" and go to "2. Check open in signal circuit".

- 2. Check open in signal circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect brake switch connector and ECM connector.
  - Check continuity between brake switch connector terminal 1 and ECM connector terminal 38. (brake switch 2 circuit)
  - Check continuity between brake switch connector terminal 3 and ECM connector terminal 80. (brake switch 1 circuit)

specification : Continuity ( below  $1.0\Omega$  )

5) Is the measured resistance within the specification?

#### YES

Repair short in signal circuit and go to "Verification of Vehicle Repair".




Repair open in signal circuit and go to "Verification of Vehicle Repair".

# COMPONENT INSPECTION E2141306

- 1. IG KEY "OFF", ENGINE "OFF".
- 2. Disconnect brake switch connector.
- 3. Check continuity between brake switch component terminal 1and 2 as depressing brake pedal. (brake switch 1)
- 4. Check continuity between brake switch component terminal 3and 4 as depressing brake pedal. (brake switch 2)

#### SPECIFICATION :

Brake Peda	al Released	Brake Pedal Depressed		
Switch 1	Switch 2	Switch 1	Switch 2	
Discontinuity	Continuity	Continuity	Discontinuity	



LGJF004B

5. Does brake switch operate correctly?

#### YES

Go to "Verification of Vehicle Repair".

NO

▶ Unless any problem is detected after checking height of brake pedal, replace brake switch component and go to "Verification of Vehicle Repair".

#### VERIFICATION OF VEHICLE REPAIR E1FCE9C8

After a repair, it is essential to verify that the fault is corrected.

- 1. After connecting Scantool select "DIAGNOSTIC TROUBLE CODES(DTCs)" mode.
- 2. Clear recorded DTC using Scantool.
- 3. Drive the vehicle within DTC "Enable conditions" in "General information".
- 4. After selecting "DIAGNOSTIC TROUBLE CODES(DTCs)" mode and check if DTC is recorded again.
- 5. Are any DTCs recorded ?



▶ Go to the DTC guide of recorded NO. in Scantool.



System operates within specification.

# DTC P0532 A/C REFRIGERANT PRESSURE SENSOR "A" CIRCUIT LOW INPUT

#### GENERAL DESCRIPTION EAED0811

A/C pressure transducer consists of piezoelectric element and it detects aircon refrigerant pressure. Piezoeletric type is more advantageous to obtain linear data of pressure than existing switch type. Thus, optimum control of aircon compressor and fan is realized and improved fuel efficiency follows with it.


#### DTC DESCRIPTION E8DC51E3

P0532 is set when the voltage below 0.3V - minimum voltage of A/C pressure transducer signal - is detected for more than 0.6 sec.. This code is due to open in power circuit or short to ground in signal circuit of A/C pressure transducer.

ltem		Detecting Condition		Possible Cause		
DTC Strategy	<ul> <li>Voltage mor</li> </ul>	nitoring	in an international second	· · · · · · · · · · · · · · · · · · ·		
Enable Conditions	• Engine run					
ThresholdValue	<ul> <li>When output value (below</li> </ul>	it voltage is below the m v 300mV)	inimum	A/C pressure transducer		
DiagnosticTime	• 600ms			circuit		
	Fuel Cut	NO		<ul> <li>A/C pressure transducer component</li> </ul>		
	EGR Off	NO				
Fail Safe	Fuel Limit	NO				
	MIL	NO				


#### DTC DETECTING CONDITION E98F1C03

#### SPECIFICATION E5A304CA





LGJE001O

#### SCHEMATIC DIAGRAM EE1EFF35



#### SIGNAL WAVEFORM AND DATA E7D5D257





LGJF001S

#### 🗊 ΝΟΤΕ

Output signal(voltage) changes in accordance with the amount of refrigerant and the change of weather. Check if normal pressure change occurs in accordance with aircon compressor operation at normal pressure range shown in "Specification".

#### MONITOR SCANTOOL DATA E5A4AAAA

1. Connect scantool to Data Link Cable (DLC).

#### DTC TROUBLESHOOTING PROCEDURES

- 2. Warm engine up to normal operating temperature.
- 3. Turn "OFF" electrical devices and A/C.
- 4. Monitor "A/C PRESSURE SENSOR" parameter on the scantool.

```
Specification : A/C "OFF" : 1200mV~1500mV
A/C " ON" : 1500mV~ 2400mV
```




Fig.1) Data at idle and aircon "OFF", Aircon pressure sensor output voltage is 1300mV.

Fig.2) Data at idle and aircon "ON". Aircon pressure sensor output voltage increases as aircon compressor operates.

```
LGJF001T
```

# TERMINAL AND CONNECTOR INSPECTION E72C337D

- 1. Electrical systems consist of a lot of harness and connectors, poor connection of terminals can cause various problems and damage of component.
- 2. Perform checking procedure as follows.
  - 1) Check damage of harness and terminals : Check terminals for contact resistance, corrosion and deformation.
  - 2) Check connecting condition of ECM and component connector : Check terminal seperation, damage of locking device and connecting condition between terminal and wiring.

# 🗊 ΝΟΤΕ

Disconnect the pin which requires checking at mail connector and insert it to the terminal at female connector for checking connecting condition. ( after checking, reconnect the pin at correct position )

3. Is the problem found?

# YES

Repair the trouble causing part and go to "Verification of Vehicle Repair".

#### NO

Go to "Power Circuit Inspection".

#### POWER CIRCUIT INSPECTION E70D1D34

- 1. IG KEY "OFF", ENGINE "OFF".
- 2. Disconnect A/C pressure transducer connector.
- 3. IG KEY "ON".
- 4. Measure the voltage of A/C pressure transducer terminal 3.

Specification: 4.8V~5.1V

5. Is the measured voltage within the specification ?

#### YES

▶ Go to "Signal Circuit Inspection".

#### NO

Repair open in power circuit of A/C pressure transducer and go to "Verification of Vehicle Repair". [ Check open between aircon pressure sensor connector terminal 3 and ECM connector terminal 22. ]

#### SIGNAL CIRCUIT INSPECTION E34BB8F6

- 1. Check signal circuit voltage
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect A/C pressure transducer connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of A/C pressure transducer terminal 2.

Specification : 4.8V~5.1V

5) Is the measured voltage within the specification?

#### YES

Go to "Component Inspection".



Repair short to ground in signal circuit and go to "Verification of Vehicle Repair".

#### COMPONENT INSPECTION E8EB5464

- 1. Aircon pressure sensor visual inspection
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect A/C pressure transducer connector.
  - 3) Check if corrosion and contamination at aircon pressure sensor terminal is detected.
  - 4) Check aircon pressure sensor connecting torque and aircon refrigerant leakage.

5) Does any problem is detected at aircon pressure sensor?

#### YES

▶ Replace aircon pressure sensor and go to "Verification of Vehicle Repair".

#### NO

- ▶ Go to "2. Check A/C pressure transducer waveform " as follows.
- 2. Check A/C pressure transducer waveform
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Connect A/C pressure transducer connector.
  - 3) Connect oscilloscope to A/C pressure transducer connector terminal 2.
  - 4) Monitor aircon pressure sensor waveform at idle as turning Aircon "ON".

Specification : Refer to "Siganl waveform & data"

5) Is A/C pressure transducer waveform outputted correctly?

#### YES

Go to "Verification of Vehicle Rapair".



Replace A/C pressure transducer and go to "Verification of Vehicle Rapair".

## VERIFICATION OF VEHICLE REPAIR E5AAFCC8

After a repair, it is essential to verify that the fault is corrected.

- 1. After connecting Scantool select "DIAGNOSTIC TROUBLE CODES(DTCs)" mode.
- 2. Clear recorded DTC using Scantool.
- 3. Drive the vehicle within DTC "Enable conditions" in "General information".
- After selecting "DIAGNOSTIC TROUBLE CODES(DTCs)" mode and check if DTC is recorded again.
- 5. Are any DTCs recorded ?

#### YES

Go to the DTC guide of recorded NO. in Scantool.

#### NO

System operates within specification.

# DTC P0533 A/C REFRIGERANT PRESSURE SENSOR "A" CIRCUIT HIGH INPUT

#### GENERAL DESCRIPTION EA55A910

Refer to DTC P0532.


#### DTC DESCRIPTION EB5954F3

P0533 is set when the voltage above 4800mV - maximum voltage of A/C pressure transducer signal - is detected for more than 0.6 sec.. This code is due to open or short in signal or ground circuit of A/C pressure transducer.

#### DTC DETECTING CONDITION E92CED73

ltem		Detecting	Possible Cause	
DTC Strategy	<ul> <li>Voltage more</li> </ul>	nitoring		
Enable Conditions	<ul> <li>IG KEY "OI</li> </ul>	N"		
ThresholdValue	<ul> <li>When output value ( abor</li> </ul>	-	<ul> <li>A/C pressure transducer circuit</li> </ul>	
DiagnosticTime	• 600ms			
	Fuel Cut	NO		A/C pressure transducer component
Fail Safe	EGR Off	NO		
	Fuel Limit	NO		$c_1 = -\sigma - \sigma \delta_{2,1}$
	MIL	NO		

#### SPECIFICATION EBC1CBFD



LGJF001Q

#### SCHEMATIC DIAGRAM E9907F7F

Refer to DTC P0532.

#### SIGNAL WAVEFORM AND DATA E2FE6AA8

Refer to DTC P0532.

#### MONITOR SCANTOOL DATA E214554F

Refer to DTC P0532.

#### TERMINAL AND CONNECTOR INSPECTION E159D86C

Refer to DTC P0532.

#### POWER CIRCUIT INSPECTION E151FB25

- 1. IG KEY "OFF", ENGINE "OFF".
- 2. Disconnect A/C pressure transducer connector.
- 3. IG KEY "ON".

4. Measure the voltage of A/C pressure transducer terminal 3.

Specification : 4.8V~5.1V

5. Is the measured voltage within the specification ?

#### YES

▶ Go to "Signal Circuit Inspection".

#### NO

Repair open in power circuit of A/C pressure transducer and go to "Verification of Vehicle Repair".
[Check open between aircon pressure sensor connector terminal 3 and ECM connector terminal 22.]

#### SIGNAL CIRCUIT INSPECTION E25CE64D

- 1. Check signal circuit voltage
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect A/C pressure transducer connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of A/C pressure transducer terminal 2.

#### Specification : 4.8V~5.1V

5) Is the measured voltage within the specification?



Go to "Ground Circuit Inspection".

#### NO

- ▶ Go to "2.Check open in signal circuit" as follows.
- 2. Check open in signal circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect A/C pressure transducer connector and ECM connector.
  - 3) Check continuity between A/C pressure transducer connector terminal 2 and ECM connector terminal 13.

Specification : Continuity (below  $1.0\Omega$ )

4) Is the measured resistance within the specification?

#### YES

Go to "3.Check short to battery in signal circuit " as follows.

#### NO

- Repair open in signal circuit and go to "Verification of Vehicle Repair".
- 3. Check short to battery in signal circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect A/C pressure transducer connector and ECM connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of A/C pressure transducer terminal 2.

Specification : 0.0V~0.1V

5) Is abnormal voltage detected in the circuit with both connector disconnected?

#### YES

Repair short to battery and go to "Verification of Vehicle Repair".

NO

▶ Go to "Component Inspection".

#### GROUND CIRCUIT INSPECTION E2154873

- 1. IG KEY "OFF", ENGINE "OFF".
- 2. Disconnect A/C pressure transducer connector.
- 3. IG KEY "ON".
- 4. Measure the voltage of A/C pressure transducer terminal 3. [ TEST "A" ]
- Measure the voltage of A/C pressure transducer terminal 3 and terminal 1. [TEST "B"] ( terminal 3: Check + prove , terminal 1 : Check - prove )

#### DTC TROUBLESHOOTING PROCEDURES

Specification : the voltage difference between TEST "A" and TEST "B" is within 200mV

6. Is the measured voltage within the specification?



▶ Go to "Component Inspection".

#### NO

When "B" voltage is not detected : Repair open in ground circuit and go to "Verification of Vehicle Repair".
 When the voltage difference between "A" and "B" is above 200mV : Eliminate the causes of excessive resistance and go to "Verification of Vehicle Repair".

#### COMPONENT INSPECTION E76921C7

- 1. Aircon pressure sensor visual inspection
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect A/C pressure transducer connector.
  - 3) Check if corrosion and contamination at aircon pressure sensor terminal is detected.
  - 4) Check aircon pressure sensor connecting torque and aircon refrigerant leakage.
  - 5) Does any problem is detected at aircon pressure sensor?

#### YES

Replace aircon pressure sensor and go to "Verification of Vehicle Repair".

#### NO

- Go to "2. Check A/C pressure transducer waveform " as follows.
- 2. Check A/C pressure transducer waveform
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Connect A/C pressure transducer connector.
  - 3) Connect oscilloscope to A/C pressure transducer connector terminal 2.
  - 4) Monitor aircon pressure sensor waveform at idle as turning Aircon "ON".

Specification : Refer to "Siganl waveform & data"

5) Is A/C pressure transducer waveform outputted correctly?



Go to "Verification of Vehicle Rapair".

# NO


▶ Replace A/C pressure transducer and go to "Verification of Vehicle Rapair".

VERIFICATION OF VEHICLE REPAIR E1088C21

Refer to DTC P0532.

# DTC P0562 SYSTEM VOLTAGE LOW

# COMPONENT LOCATION E685C627



EWPF603A

# GENERAL DESCRIPTION EDA2D 158

Normally, battery voltage fluctuates from 11.5V to 14.5V. Especially at cranking, voltage can drop to 9.8V. Therefore, actuators which require 12V power supply meet fluctuation of power by 5V.A little change of voltage supply can shift controlling characteristic of actuators, such as injectors, RPCV and EGR actuator, which should be controlled delicately. To correct controlling characteristic change arrised from voltage fluctuation, ECM performs actuator operating correction according to voltage change as detecting battery voltage change.

#### DTC DESCRIPTION E1EAD1A3

P0562 is set when battery voltage below 6V is detected for more than 5 sec. Check charging system.(charging circuit, alternator component)


ECM senses battery voltage as monitoring the voltages in ECM(C201-2) connector terminal 1,3,5 which are transmitted from main relay.

Item	Detecting Condition			Possible Cause	
DTC Strategy	<ul> <li>Voltage more</li> </ul>	nitoring			
Enable Conditions	IG KEY "OI	N"			
ThresholdValue	<ul> <li>when batter</li> </ul>	ry voltage is	below 6V		
DiagnosticTime	• 5 sec.		· · · · · · · · · · · · · · · · · · ·	Charging circuit	
	Fuel Cut	NO		Alternator component	
Fail Safe	EGR Off	NO	-		
	Fuel Limit	NO	-		
	MIL	NO	-		

# DTC DETECTING CONDITION ED9ED321

#### SCHEMATIC DIAGRAM EF671A2E

FLB -302



EWPF007U


#### SIGNAL WAVEFORM AND DATA EF21DBC9

FR	CH	<b>6</b> 5	.0	V	5.	O S		С	HE	8 0	.5	V	
										-		-	÷
		1		į								:	
										)			; : :
					••••••• •	••••••				·····		 	••••• •
		·····	 	··• :	·····				 	}			
		••••		··		·····;	•••••			·····			·····
	÷		جنابت	<u></u>		بنبت	<u></u>		•••••		-		<u></u>
	••••••• •	····;···· 	•••••••	······				•••••			•••••		 :
•••••		••••	•••••••	· • · · · · ·	·····								
··········								•••••					
: IRO	IID.	Zoc	m		RS	ME	:MO	16	REC	D	ME	NII	: 
H0 Fig.1	LD I	ZOC	m	CU	RS	ME	MO	][]	REC	D	ME	NU	

Fig.1) This is alternator charging waveform during engine running. Check if battery voltage drops dramatically as turning on the electrical device such as head lamp, defogger and A/C.

#### MONITOR SCANTOOL DATA EC096F04

- 1. Connect scantool to Data Link Cable. (DLC)
- 2. Warm engine up to normal operating temperature.
- 3. Turn "OFF" electrical devices and A/C.
- 4. Monitor "BATTERY VOLTAGE" parameter on the Scantool.
- specification :12.5V~14.5V at idle without any load(800RPM)



#### Fig.1

Fig 1) "BATTERY VOLTAGE" data at idle after warming engine up.

Check if the symptoms listed below occur as checking if battery voltage drops dramatically when turning on the electrical devices.

LGJF003P

- \* The vehicles with the alternator of poor charging efficiency
- 1. Lamps are dim at idle, while lamps are bright at acceleration.
- 2. Intermitently RPM drops excessively or engine shut down at low RPM close to idle state at times.

LGJF003O

3. Smooth cranking happens rarely. (Warning lamps in cluster turn dimmer excessively at cranking and poor cranking happen.)

4. Charging lamp turns on during driving.

#### TERMINAL AND CONNECTOR INSPECTION E989E702

- 1. Electrical systems consist of a lot of harness and connectors, poor connection of terminals can cause various problems and damge of component.
- 2. Perform checking procedure as follows.
  - 1) Check damage of harness and terminals : Check terminals for contact resistance, corrosion and deformation.
  - 2) Check connecting condition of ECM and component connector : Check terminal seperation, damage of locking device and connecting condition between terminal and wiring.

## NOTE

Disconnect the pin which requires checking at male connector and insert it to the terminal at female connector or checking connecting condition. (after checking, reconnect the pin at correct position.)

3. Is the problem found?

#### YES

Repair the trouble causing part and go to "Verification of Vehicle Repair".

#### NO

Go to "Power Circuit Inspection".

#### POWER CIRCUIT INSPECTION E923D3F5

- 1. Check power supply in alternator connector
  - 1) IG KEY "ON", Turn engine "OFF".
  - 2) Disconnect alternator connector.
  - 3) Measure the voltage of terminal 2 of alternator connector.

Specification : 10.5V~12.0V

4) Is the measured voltage within the specification?

# YES

▶ Go to "2. Check charging lamp operation".

#### NO

When no voltage is detected at terminal 2. Check charging lamp on cluster and charging lamp resistor and repair the open in related circuit and go to "Verification of Vehicle Repair".

- 2. Check charging lamp operation
  - 1) IG KEY "ON", ENGINE "OFF".

#### DTC TROUBLESHOOTING PROCEDURES

- 2) Disconnect alternator connector.
- 3) Ground alternator connector terminal 2 to chassis ground using jump wire.

specification : charging lamp "ON" when grounded to chassis ground.

4) Does charging lamp turn ON?



Go to "3.Check voltage drop of aternator B+ cable".

NO

- Replace lamp and go to "Verification of Vehicle Repair".
- 3. Check voltage drop of aternator B+ cable
  - 1) IG KEY "ON", Turn engine "ON".
  - Measure the voltage difference between alternator B+ terminal and battery + terminal. (connect + terminal of multimeter to alternator B+ and connect - terminal of multimeter to battery +terminal.)

specification : below 0.2V (below 200mV)

3) Is the measured voltage within the specification? (Is the voltage drop in alternator B+ cable normal?)

#### YES

<sup>▶</sup> Go to "Component Inspection".



After checking corrosion and deformation of alternator B+ cable and replace it if needed and go to "Verification of Vehicle Repair".

#### COMPONENT INSPECTION E5D28835

- 1. IG KEY "OFF", ENGINE "OFF".
- 2. Check belt tension which operates alternator .
- 3. Check battery terminal and fusible link, poor connection or corrosion of alternator B+ terminal.
- 4. Turn Engien "ON".
- 5. Operate the electrical device such as head lamp, defroster and blower motor.
- 6. Check battery voltage at above 2000 RPM.

Specification : 12.5V~14.5V

7. Is the measured voltage within the specification?

# YES

Alternator is performing within the specification.

#### NO

▶ Replace alternator and go to "Verification of Vehicle Repair".

#### VERIFICATION OF VEHICLE REPAIR E049D3A7

After a repair, it is essential to verify that the fault is corrected.

- 1. After connecting Scantool select "DIAGNOSTIC TROUBLE CODES(DTCs)" mode.
- 2. Clear recorded DTC using Scantool.
- 3. Drive the vehicle within DTC "Enable conditions" in "General information".
- 4. After selecting "DIAGNOSTIC TROUBLE CODES(DTCs)" mode and check if DTC is recorded again.
- 5. Are any DTCs recorded ?

#### YES

▶ Go to the DTC guide of recorded NO. in Scantool.

#### NO

System operates within specification.

# DTC P0563 SYSTEM VOLTAGE HIGH

#### COMPONENT LOCATION E1AF1894

Refer to DTC P0562.

### GENERAL DESCRIPTION EE33D8A0

Refer to DTC P0562.

#### DTC DESCRIPTION ED984E68

P0563 is set when battery voltage above 17.5V is detected for more than 5 sec.. Check alternator component. (overcharging of alternator)

ECM senses battery voltage as monitoring the voltages in ECM(C01-2)connector terminal 1,3,5 which are transmitted from main relay.

#### DTC DETECTING CONDITION E306BF10

Item	and the state of the	Detecting	Possible Cause	
DTC Strategy	<ul> <li>Voltage mo</li> </ul>	nitoring		
Enable Conditions	• IG KEY "O	N"		
ThresholdValue	<ul> <li>when batter</li> </ul>	ry voltage is	above 17.5V	en de la companya de
DiagnosticTime	• 5 sec.			Charging circuit
	Fuel Cut	NO		<ul> <li>Alternator component</li> </ul>
Foil Sofo	EGR Off	NO	and the second	
Fail Safe	Fuel Limit	NO		
	MIL	NO	- The second second	

#### SCHEMATIC DIAGRAM E83E8D4E

Refer to DTC P0562.

#### SIGNAL WAVEFORM AND DATA ECE 153B3

Refer to DTC P0562.

#### MONITOR SCANTOOL DATA EEC0173C

- 1. Connect scantool to Data Link Cable. (DLC)
- 2. Warm engine up to normal operating temperature.
- 3. Turn "OFF" electrical devices and A/C.
- 4. Monitor "BATTERY VOLTAGE" parameter on the Scantool.

#### specification :12.5V~14.5V at idle without any load(800RPM)

FLB -307




Fig 1) "BATTERY VOLTAGE" data at idle after warming engine up.

Check if the symptoms listed below occur as checking if battery voltage rises dramatically when turning on the electrical devices.

LG./F003L

\* The vehicles with the alternator of over charging efficiency

1. Electrolyte inside battery overflows, check corrosion of battery and around of it.

2. Check if the smell of hydrogen gas which is produced at charging process during engine running state generates excessively.

3. Lamps on cluster, tail lamp and head lamp turn brighter intermittently .

#### TERMINAL AND CONNECTOR INSPECTION E2E9B106

Refer to DTC P0562.

#### POWER CIRCUIT INSPECTION FF7BB4F1

- Check power supply in alternator connector 1.
  - 1) IG KEY "ON", Turn engine "OFF".
  - Disconnect alternator connector. 2)
  - Measure the voltage of terminal 2 of alternator connector. 3)

Specification : 10.5V~12.0V

4) Is the measured voltage within the specification?

#### YES

Go to "2. Check charging lamp operation".

NO

When no voltage is detected at terminal 2.

Check charging lamp on cluster and charging lamp resistor and repair the open in related circuit and go to "Verification of Vehicle Repair".

- Check charging lamp operation 2.
  - 1) IG KEY "ON", ENGINE "OFF".

# DTC TROUBLESHOOTING PROCEDURES

- 2) Disconnect alternator connector.
- 3) Ground alternator connector terminal 2 to chassis ground using jump wire.

specification : charging lamp "ON" when grounded to chassis ground.

4) Does charging lamp turn ON?



Go to "3.Check voltage drop of aternator B+ cable".

#### NO

- Replace lamp and go to "Verification of Vehicle Repair".
- 3. Check voltage drop of aternator B+ cable
  - 1) IG KEY "ON", Turn engine "ON".
  - Measure the voltage difference between alternator B+ terminal and battery + terminal. (connect + terminal of multimeter to alternator B+ and connect - terminal of multimeter to battery +terminal.)

specification : below 0.2V (below 200mV)

3) Is the measured voltage within the specification? (Is the voltage drop in alternator B+ cable normal?)



▶ Go to "Component Inspection".



After checking corrosion and deformation of alternator B+ cable and replace it if needed and go to "Verification of Vehicle Repair".

#### COMPONENT INSPECTION EA4208E3

- 1. IG KEY "OFF", ENGINE "OFF".
- 2. Check belt tension which operates alternator .
- 3. Check battery terminal and fusible link, poor connection or corrosion of alternator B+ terminal.
- 4. Turn Engien "ON".
- 5. Operate the electrical device such as head lamp, defroster and blower motor.
- 6. Check battery voltage at above 2000 RPM.

Specification: 12.5V~14.5V

7. Is the measured voltage within the specification?

#### YES

Alternator is performing within the specification.

#### NO

▶ Replace alternator and go to "Verification of Vehicle Repair".

# VERIFICATION OF VEHICLE REPAIR E3265360

Refer to DTC P0562.

的,就是我们是这个人的人,这一个人,这个人,这个人,这个人,我们就是这个人,我们是我们的,我们不是一个人,我们还是我们的。" 这个人,不是一个人的

이 같이 많이 물건값이 이 물건값이 있는 것

n a tha the same where a sub-


1997年,1997年末,1997年,1997年,1997年,1997年,1997年,1997年,1997年,1997年,1997年,1997年,1997年,1997年,1997年,1997年,1997年,1997年,19

the second second

 $\mathcal{L}_{\mathrm{ext}} = \mathcal{L}_{\mathrm{ext}} + \mathcal{L}_{\mathrm{ext}$ 

# DTC P0602 EEPROM-PROGRAMING ERROR

#### COMPONENT LOCATION ED1FB0F9



EWPF602Q

#### GENERAL DESCRIPTION EAC8376B

ECM is activated by power supply. Signals from several sensors, such as CKPS and APS, is inputted to ECM. Comparing inputted signals with control LOGIC saved at micro controller and EEPROM, ECM controlls engine as actuating injectors, solenoids and relays. To guarantee accurate control, ECM performs SELF TEST, DIAGNOSIS of several sensors and actuators. And if serious trouble which affects vehicle performance occurrs, ECM sets DTCs.At certain cases, ECM shuts down whole systems in order to prevent dangerous situation due to incorrect control.

#### DTC DESCRIPTION EE739B0B

P0602 is set when data writing on EEPROM inside of ECM is impossible. This code is due to the failure of ECM(ECM hardware failure).

# DTC DETECTING CONDITION EF39C68E

Item	Detecting Condition			Possible Cause
DTC Strategy	• EEPROM m	nonitorting		
Enable Conditions	IG KEY "Of	۷"		
ThresholdValue	<ul> <li>when data writing on EEPROM inside of ECM is impossible</li> </ul>			
DiagnosticTime	Immediately			ECM component failure
	Fuel Cut	YES		
Fail Safe	EGR Off	NO		
	Fuel Limit	NO		
	MIL	NO		

#### COMPONENT INSPECTION E86346E9

1. ECM Component Inspection

#### FLB -312

- 1) IG KEY "OFF", ENGINE "OFF".
- 2) Disconnect ECM.
- 3) Replace ECM, check if abnormal operations disappear.
- 4) If problems are corrected, replace ECM.

#### VERIFICATION OF VEHICLE REPAIR E87FA6D6

After a repair, it is essential to verify that the fault is corrected.

- 1. After connecting Scantool select "DIAGNOSTIC TROUBLE CODES(DTCs)" mode.
- 2. Clear recorded DTC using Scantool.
- 3. Drive the vehicle within DTC "Enable conditions" in "General information".
- 4. After selecting "DIAGNOSTIC TROUBLE CODES(DTCs)" mode and check if DTC is recorded again.
- 5. Are any DTCs recorded ?

#### YES

▶ Go to the DTC guide of recorded NO. in Scantool.

#### NO

System operates within specification.

# DTC P0605 INTERNAL CONTROL MODULE READ ONLY MEMORY(ROM) ERROR

#### COMPONENT LOCATION EA959A0A

Refer to DTC P0602.

### GENERAL DESCRIPTION EECDC284

Refer to DTC P0602.

## DTC DESCRIPTION E97F522A

P0605 is set when 1)communication error between micro controller inside of ECM and EEP ROM is detected or 2)a different vesion of ECM is installed.

#### DTC DETECTING CONDITION E2C4F1E7

Item		Detecting	Possible Cause	
DTC Strategy	EEPROM n	nonitorting		
Enable Conditions	• IG KEY "O	N"		
ThresholdValue	<ul> <li>(EEPROM of failure between ECM and ECM and E</li> <li>Each data r</li> <li>self test about cruise controls</li> </ul>	een micro o EPROM ange is acti out optional	<ul> <li>Version difference between ECM and ECMcommunication module</li> </ul>	
DiagnosticTime	<ul> <li>Immediately</li> </ul>	,		ECM component failure
	Fuel Cut	YES	1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1	
Fail Safe	EGR Off	NO		
	Fuel Limit	NO		
	MIL	NO		

#### COMPONENT INSPECTION E05300A8

- 1. ECM Component Inspection
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect ECM.
  - 3) Replace ECM, check if abnormal operations disappear.
  - 4) If problems are corrected, replace ECM.

# VERIFICATION OF VEHICLE REPAIR EAAFABDB

Refer to DTC P0602.

# DTC P0606 ECM/PCM PROCESSOR(ECM-SELF TEST FAILED)

#### COMPONENT LOCATION E238BEF3

Refer to DTC P0602.

#### GENERAL DESCRIPTION EC3C3B86

Refer to DTC P0602.


#### DTC DESCRIPTION E5F9C460

P0606 is set when 1) writing/reading error inside of ECM occur. 2) error of APS 2 ground checking which is repeated every 0.2 sec. or 3) the voltage of sensor power supply 1 and 2 ( the standard voltage of A/D converter) are below 4.7V or above 5.1V. This code is due to ECM internal failure.

#### DTC DETECTING CONDITION E84EAE86

Item	Detecting Condition				Possible Cause		
DTC Strategy	<ul> <li>Signal moni</li> </ul>	toring					
Enable Conditions	• IG KEY "01	٧"		a tanan arawa a sa araw Anarawa	i de la companya de l		
ThresholdValue	<ul> <li>writing/read</li> <li>APS 2 grou</li> <li>APS 2 grou</li> </ul>	nd checking					
DiagnosticTime	<ul> <li>Refer to the</li> </ul>	data above	this cell	• ECN	ECM component failure		
	Fuel Cut	NO					
<b>F</b> _11 <b>O</b> _6	EGR Off	NO					
Fail Safe	Fuel Limit	NO	· · ·	1			
	MIL	NO					

#### SIGNAL WAVEFORM AND DATA EA026B67



- Fig.1) Ground checking signal of APS 2 signal is for ECM to monitor APS 2. This signal drops APS 2 output voltage to below 200.39mV every 200msec. If APS 2 output voltage does not drop to below 200.39mV, ECM sets DTC as recognizing ground circuit error of APS 2.
- \* The waveform below 200.39mV is not detectable in ground checking signal waveform of APS 2 signal. Instead, the waveform which drops a little is detected. If APS 2 data of "SERVICE DATA" on the Scantool varies from 350mV to 0mV periodically, it means it works normally.
- Fig.2) APS 1 and APS 2 signals are measured simultaneously, Check if 5V sensor voltage(the standard voltage of A/D converter inside of ECM) is from 4.8V to 5.16V.

LGJF001Y

#### COMPONENT INSPECTION EGOCBEC8


- 1. ECM Component Inspection
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect ECM.
  - 3) Replace ECM, check if abnormal operations disappear.
  - 4) If problems are corrected, replace ECM.

#### VERIFICATION OF VEHICLE REPAIR EFA8429E

Refer to DTC P0602.

# DTC P0611 INJECTOR - CIRCUIT MALFUNCTION (MORE THAN TWO INJECTORS)


#### COMPONENT LOCATION E8EF5B95



EWPF602S

#### GENERAL DESCRIPTION E82D3904

Injectors spray fuel in the highly compressed combustion chamber, and power generates through combustion process. Fuel pressure is raised to 1600bar in common rail diesel engine for the purpose of making fuel into minute particles. And fuel devided into minute particles leads smoke reduction, high power generation, and improved fuel efficiency. To control pressure of 1600bar with solenoid, oil pressure surbo is applied. And injector solenoids is actuated by solenoid operating voltage raised to 80V with the method of current control. Niddle valve inside of injector is located between A and B chamber. If applied pressure to B chamber is relived by injector solenoid, niddle valve is raised by the pressure of A chamber then, fuel is injected. If same pressure is applied to A and B chamber, niddle valve closes by the elasticity then, fuel injection stops. As electronically controlled injector is applied instead of mechanical injector, pilot and post injection, injection duration and quantity control are achieved. And engine performance is improved by these control.



LGJF008D

#### DTC DESCRIPTION E1BAD5BD

P0611 is set when the problems of more than 2 injector circuits are detected thus, it is difficult to find abnormal injector. Check "Circuit Inspection" of all injectors


# DTC DETECTING CONDITION EB3173C5

Item	Detecting Condition			Possible Cause
DTC Strategy	<ul> <li>Current mo</li> </ul>	nitoring		· · · · · · · · · · · · · · · · · · ·
Enable Conditions	• IG KEY "O	N"		
ThresholdValue	<ul> <li>Cylinder red failure more</li> </ul>			
DiagnosticTime	<ul> <li>Immediately</li> </ul>	1		Short in Injector circuit
	Fuel Cut	YES		<ul> <li>Injector component</li> </ul>
	EGR Off	NO		
Fail Safe	Fuel Limit	NO		
	MIL	YES		

### SPECIFICATION E9C7EA7E

0.255Ω ±0.04 (20 °C).80VPeak current : 18±1A Hold in current : 12±1A Recharging current : 7ACurrent control	Injector Component Resistance	Injector Operating Voltage	Injector Operating Current	Injector Control Type
	0.255Ω ±0.04 (20℃).	80V		Current control

#### SCHEMATIC DIAGRAM E533DAD5



FUEL SYSTEM

EWPF002O




Fig.1) Injector operating waveform at Low side, It shows 2 pilot and 1 main injection.

Fig.2) Magnified waveform of main injection at Fig.1)

Fig.3) Injector voltage and current waveforms are measured at the same time using current prove of scope meter.

Fig.4) Magnified waveform of pilot injection at Fig.3)

LGJF008F

# TERMINAL AND CONNECTOR INSPECTION E3F571B9

- 1. Electrical systems consist of a lot of harness and connectors, poor connection of terminals can cause various problems and damge of component.
- 2. Perform checking procedure as follows.
  - 1) Check damage of harness and terminals : Check terminals for contact resistance, corrosion and deformation.
  - 2) Check connecting condition of ECM and component connector : Check terminal seperation, damage of locking device and connecting condition between terminal and wiring.

# 

Disconnect the pin which requires checking at male connector and insert it to the terminal at female connector for checking connecting condition. (after checking, reconnect the pin at correct position.)

3. Is the problem found?

#### YES

Repair the trouble causing part and go to "Verification of Vehicle Repair".

#### NO

Go to "Power Circuit Inspection".

#### POWER CIRCUIT INSPECTION E25DD5E0

- 1. Check injector connector terminal voltage (failed injector analysis)
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect all injectors.
  - 3) IG KEY "ON".
  - 4) Check the voltage of all injector connector terminal 1 and 2.

Specification : Terminal 1 : 0.4V~0.5V Terminal 2 : 2.0V~2.5V

5) Is the measured voltage within the specification?

#### YES

Go to "Component Inspection".

#### NO

Refer to "DTC" guide corresponding to each problem occurred injector.

Injector #1 related problem : Refer to P0201for open in injector circuit. Refer to P0262 for short in injectoer circuit.

Injector #2 related problem : Refer to P0202 for open in injector circuit. Refer to P0265 for short in injectoer circuit.

Injector #3 related problem : Refer to P0203 for open in injector circuit. Refer to P0268 for short in injectoer circuit.

Injector #4 related problem : Refer to P0204 for open in injector circuit. Refer to P0271 for short in injectoer circuit.

#### COMPONENT INSPECTION E735E07D

Check injector component resistance


1.

- 1) IG KEY "OFF", ENGINE "OFF".
- 2) Disconnect injector connector.

LGJE008

3) Measure the resistance between injector component terminal 1 and 2.

Specification : 0.255Ω ±0.04 (20℃).



4) Is the measured resistance(of injector solenoid) within the specification?

#### YES

Go to "Verification of Vehicle Repair".

#### NO

Replace injector and go to "Verification of Vehicle Repair".

**NOTE** 

Replacing injectors, peculiar IQA code of each injector should be inputted to ECM Perform this process using "Injector data input" function on scantool, Refer to P1670, P1671 for more detailed information.

# VERIFICATION OF AVEHICLE REPAIR DECOMPOSITION OF A OPTIMIZE A CONTRACT OF THE OPTIMIZED OF THE OPTIMICOPTIMICOPTICOPOTICOPOTI

After a repair, it is essential to verify that the fault is corrected.

- 1. After connecting Scantool select "DIAGNOSTIC TROUBLE CODES(DTCs)" mode.
- 2. Clear recorded DTC using Scantool.
- 3. Drive the vehicle within DTC "Enable conditions" in "General information".
- 4. After selecting "DIAGNOSTIC TROUBLE CODES(DTCs)" mode and check if DTC is recorded again.

#### 5. Are any DTCs recorded ?

#### YES


Go to the DTC guide of recorded NO. in Scantool.

#### NO

System operates within specification.

# DTC P062D VOLTAGE REGULATOR #1 FOR INJECTOR - MALFUNCTION

#### COMPONENT LOCATION E1246CEF



#### GENERAL DESCRIPTION E6460037

There are two transformer for injector operation in side of ECM. 1 pilot and 1 main injection are operated by ECM in EURO 3 diesel engine therefore one transformer device is sufficient to control injector however, 2 pilot and if CPF is applied, 2 post injection are performed additionally by ECM in EURO 4 diesel engine thus, two transformer is required.

#### DTC DESCRIPTION E5CBE54E

P062D is set when the problem of transforming system 1 for injector contol occurs. This code is due to the failure of transforming system inside of ECM.

\* If battery voltage is low, this code can be set. Therefore, beforehand, check DTC code relevant to battery voltage and charging system.

ltem	Detecting Condition			Possible Cause
DTC Strategy	Voltage monitoring			
Enable Conditions	<ul> <li>Engine runr</li> </ul>	ning	$\sum_{i=1}^{N} \sum_{j=1}^{N} P_{ij}(x_{ij}) = \sum_{i=1}^{N} \sum_{j=1}^{N} \sum_{i=1}^{N} \sum_{i=1}^{N} \sum_{i=1}^{N} \sum_{j=1}^{N} \sum_{i=1}^{N} \sum_{j=1}^{N} \sum_{i=1}^{N} \sum_{j=1}^{N} \sum_{i=1}^{N}	
ThresholdValue	<ul> <li>Power stage error for injector voltage control, CPU circuit failure</li> </ul>			
DiagnosticTime	<ul> <li>Immediately</li> </ul>	,	<ul> <li>ECM internal error</li> </ul>	
Fail Safe	Fuel Cut	YES		
	EGR Off	NO		and a second sec
	Fuel Limit	NO		
	MIL	YES		

#### DTC DETECTING CONDITION E8805628

#### COMPONENT INSPECTION E2A8763E

1. ECM Component Inspection

#### DTC TROUBLESHOOTING PROCEDURES

- 1) IG KEY "OFF", ENGINE "OFF".
- 2) Disconnect ECM.
- 3) Replace ECM, check if abnormal operations disappear.
- 4) If problems are corrected, replace ECM.

#### VERIFICATION OF VEHICLE REPAIR EF208FF0

After a repair, it is essential to verify that the fault is corrected.

- 1. After connecting Scantool select "DIAGNOSTIC TROUBLE CODES(DTCs)" mode.
- 2. Clear recorded DTC using Scantool.
- 3. Drive the vehicle within DTC "Enable conditions" in "General information".
- 4. After selecting "DIAGNOSTIC TROUBLE CODES(DTCs)" mode and check if DTC is recorded again.
- 5. Are any DTCs recorded ?

YES

Go to the DTC guide of recorded NO. in Scantool.



System operates within specification.

# DTC P062E VOLTAGE REGULATOR #2 FOR INJECTOR - MALFUNCTION

#### COMPONENT LOCATION EB6F2A8C

Refer to DTC P062D.

#### GENERAL DESCRIPTION EA9D4DD3

Refer to DTC P062D.

#### DTC DESCRIPTION E68D4F59

P062E is set when the problem of transforming system 2 for injector contol occurs. This code is due to the failure of transforming system inside of ECM.

\* If battery voltage is low, this code can be set. Therefore, beforehand, check DTC code relevant to battery voltage and charging system.

#### DTC DETECTING CONDITION EF03E617

Item		Detecting	Possible Cause	
DTC Strategy	<ul> <li>Voltage mor</li> </ul>	nitoring	the three of the second second	ny a na sa na sa sa sa sa sa sa sa
Enable Conditions	<ul> <li>Engine runr</li> </ul>	ning		
ThresholdValue	<ul> <li>Power stage CPU circuit</li> </ul>			
DiagnosticTime	<ul> <li>Immediately</li> </ul>	1	<ul> <li>ECM internal error</li> </ul>	
Fail Safe	Fuel Cut	YES	· .	
	EGR Off	NO		
	Fuel Limit	NO		
	MIL	YES		

#### COMPONENT INSPECTION ED9B276C


- 1. ECM Component Inspection
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect ECM.
  - 3) Replace ECM, check if abnormal operations disappear.
  - 4) If problems are corrected, replace ECM.

#### VERIFICATION OF VEHICLE REPAIR EBDE2696

Refer to DTC P062D.

# DTC P0642 SENSOR REFERENCE VOLTAGE "A" CIRCUIT LOW

# COMPONENT LOCATION EEB3E399



EWPF602Q

# GENERAL DESCRIPTION EFB83371

ECM is activated by power supply. Signals from several sensors, such as CKPS and APS, is inputted to ECM. Comparing inputted signals with control LOGIC saved at micro controller and EEPROM, ECM controlls engine as actuating injectors, solenoids and relays. To guarantee accurate control, ECM performs SELF TEST, DIAGNOSIS of several sensors and actuators. And if serious trouble which affects vehicle performance occurrs, ECM sets DTCs.At certain cases, ECM shuts down whole systems in order to prevent dangerous situation due to incorrect control.

# DTC DESCRIPTION E197F28D

P0642 is set when the voltage below 4700mV - minimum voltage of sensor power supply 1 generates from ECM - is detected for more than 0.1 sec.. This code is due to the short to ground in sensor power circuit or the voltage problem inside of ECM.


# DTC DETECTING CONDITION EE435E45

ltem		Detecting	Possible Cause	
DTC Strategy	<ul> <li>Voltage mo</li> </ul>	nitoring		
Enable Conditions	• IG KEY "OI	N"		
ThresholdValue	<ul> <li>when the void of sensor p</li> <li>( below 470)</li> </ul>	ower supply	ow the minimum voltage	<ul> <li>AFS power supply circuit</li> </ul>
DiagnosticTime	• 100ms			<ul> <li>APS 1 power supply circuit</li> </ul>
	Fuel Cut	NO	. Linna hanna mada ia	<ul> <li>ECM component</li> </ul>
Fail Safe	EGR Off	NO	<ul> <li>Limp home mode is activated. (engine</li> </ul>	
	Fuel Limit	YES	speed is fixed at	
	MIL	NO	1200RPM. )	

# SPECIFICATION E4981361

Sensor power 1	Sensor power 2	Sensor power 3
AFS, APS 1 4830mV~5158mV	RPS, APS 2,BPS 4830mV~5158mV	A/C pressure transducer, VSA position Sensor 4830mV~5158mV

# SCHEMATIC DIAGRAM ED022931



# SIGNAL WAVEFORM AND DATA E19351C0

FR	CH	Ĝ	1.0	0 V		5.	(2)		C	HE	3 1	.0	V	
÷					:	:		:	:	:	÷			
		•••••			·····			; :			 			
	A	PS	1 p	юw	er				•••••• •	!·····	 :		•••••	
<del>ى بۇر</del> ىمۇكە	rinani				***		مەلىمە مەلىمە	*141~*	<u>.</u>	<del>\$16*61</del> *	\$****¥		ትሳት	~~~~
الى يەتىب ئەتىپ ئى يەتەب ئەتىپ	All A	FS	poy	ver	inyan	iyy	يوليون	*165** <u>*</u>		imor	*****	<u></u>	ትንትን	
			fr											
	M	Z	100	1	CU		MI	EMO	16	REC	D	ME	NU	

#### Fig.1

Fig.1) APS 1 and AFS power supply is measured simultaneously, check if this waveform is within the specification (4.8~5.1V) when turning ignition "ON".

# TERMINAL AND CONNECTOR INSPECTION EA8D9034

- 1. Electrical systems consist of a lot of harness and connectors, poor connection of terminals can cause various problems and damage of component.
- 2. Perform checking procedure as follows.
  - 1) Check damage of harness and terminals : Check terminals for contact resistance, corrosion and deformation.
  - 2) Check connecting condition of ECM and component connector : Check terminal seperation, damage of locking device and connecting condition between terminal and wiring.

# NOTE

Disconnect the pin which requires checking at mail connector and insert it to the terminal at female connector for checking connecting condition. ( after checking, reconnect the pin at correct position )

3. Is the problem found?

# YES

Repair the trouble causing part and go to "Verification of Vehicle Repair".

#### NO

▶ Go to "Power Circuit Inspection".

#### POWER CIRCUIT INSPECTION EEB6F407

- 1. Check power circuit voltage
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnector AFS connector and APS connector.
  - 3) IG KEY "ON".

LGJF002S

4) Measure the voltage between AFS connector terminal 4 or APS connector terminal 6 and chassis ground.

Specification: 4.8V~5.1V

5) Is the measured voltage within the specification?



▶ Go to "Component Inspection".



- ▶ Go to "2. Check short to ground in power circuit" as follows.
- 2. Check short to ground in power circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect AFS connector, APS connector, ECM connectors.
  - 3) Check continuity between AFS connector terminal 4 or APS connector terminal 6 and chassis ground.

specification : Discontinuity (Infinite  $\Omega$ )

4) Is the measured resistance within the specification?

#### YES

▶ If the circuit is insulated well and the sensor power supply from ECM is low, replace ECM and "Verification of Vehicle Repair".

#### NO

Repair short to ground and go to "Verification of Vehicle Repair".

#### COMPONENT INSPECTION EB7AF2B9

- 1. IG KEY "OFF", ENGINE "OFF".
- 2. Disconnect AFS connector(C215) and APS connector(C202).
- Check that sensor connector power supply is within the specification after turning IG KEY "ON".
- 4. Connect AFS connector and APS connector in turn.

Specification : sensor power supply should not change as connecting AFS connector and APS connector. (If the change of sensor power supply occur as connecting sensor connector, this means the occurrence of short inside of sensor.)

5. Does change of sensor power supply occur as connecting sensor connector?

#### YES

Replace AFS or APS.

# NO

▶ go to "Verification of Vehicle Repair".

# VERIFICATION OF VEHICLE REPAIR EF72E215

After a repair, it is essential to verify that the fault is corrected.

- 1. After connecting Scantool select "DIAGNOSTIC TROUBLE CODES(DTCs)" mode.
- 2. Clear recorded DTC using Scantool.
- 3. Drive the vehicle within DTC "Enable conditions" in "General information".
- 4. After selecting "DIAGNOSTIC TROUBLE CODES(DTCs)" mode and check if DTC is recorded again.
- 5. Are any DTCs recorded ?

# YES

▶ Go to the DTC guide of recorded NO. in Scantool.

# NO

System operates within specification.

n an Santana an Santana San Santana Angela an Santa Santana Angela an Santana

# DTC P0643 SENSOR REFERENCE VOLTAGE "A" CIRCUIT HIGH

#### COMPONENT LOCATION E09EC336

Refer to DTC P0642.

#### GENERAL DESCRIPTION E2F38405

Refer to DTC P0642.

### DTC DESCRIPTION E5AB7A37

P0643 is set when the voltage above 5158mV - maximum voltage of sensor power supply 1 generates from ECM - is detected for more than 0.1 sec.. This code is due to the short to battery in sensor power circuit or the voltage problem inside of ECM.

# DTC DETECTING CONDITION E0A30B13

Item		Detecting	Possible Cause			
DTC Strategy	Voltage mor	nitoring				
Enable Conditions	• IG KEY "ON	٧"	and the state of the			
ThresholdValue	<ul> <li>when the vo of sensor po (above 5158)</li> </ul>	ower supply.	AFS power supply circuit			
DiagnosticTime	• 100ms			APS 1 power supply circuit     ECM component		
	Fuel Cut	NO	Limp home mode	ECM component		
	EGR Off	NO	is activated.(engine			
Fail Safe	Fuel Limit	YES	speed is fixed at			
	MIL	NO	1200RPM)			

#### SPECIFICATION E950B2CD

	Pedal released	Pedal depressed	Sensor Type
APS 1	0.7V~0.8V	3.8V~4.4V	Variable resistance
APS 2	0.275V~0.475V	1.75V~2.35V	type(Potentiometer)

#### SCHEMATIC DIAGRAM E079DCF5

Refer to DTC P0642.

#### SIGNAL WAVEFORM AND DATA E01393AB

Refer to DTC P0642.

#### TERMINAL AND CONNECTOR INSPECTION E5475790

Refer to DTC P0642.

# DTC TROUBLESHOOTING PROCEDURES

### FLB -331

# POWER CIRCUIT INSPECTION E49ECE9F

- 1. Check power circuit voltage
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnector AFS connector and APS connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage between AFS connector terminal 4 or APS connector terminal 6 and chassis ground.

specification: 4.8V~5.1V

5) Is the measured voltage within the specification?

# YES

Go to "Component Inspection".

#### NO

- Go to "2. Check short to battery in power circuit" as follows.
- 2. Check short to battery in power circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnector AFS connector and APS connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage between AFS connector terminal 4 or APS connector terminal 6 and chassis ground.

Specification : 0.0V~0.1V

5) Is abnormal voltate measured in this test?

# YES

Repair short to battery and go to "Verification of Vehicle Repair".



If the circuit is insulated well and the sensor power supply from ECM is high, replace ECM and go to "Verification of Vehicle Repair".

# COMPONENT INSPECTION E57A51D7

- 1. IG KEY "OFF", ENGINE "OFF".
- 2. Disconnect AFS connector(C215) and APS connector(C202).
- 3. Check that sensor connector power supply is within the specification after turning IG KEY "ON".
- 4. Connect AFS connector and APS connector in turn.

#### FLB -332

Specification : sensor power supply should not change as connecting AFS connector and APS connector. (If the change of sensor power supply occur as connecting sensor connector, this means the occurrence of short inside of sensor.)

5. Does change of sensor power supply occur as connecting sensor connector?

# YES

▶ Replace AFS or APS.




▶ go to "Verification of Vehicle Repair".

# VERIFICATION OF VEHICLE REPAIR EODOB3DC

Refer to DTC P0642.

# DTC P0646 A/C CLUTCH RELAY CONTROL CIRCUIT LOW

# COMPONENT LOCATION E09EC337



EWPF008U

# GENERAL DESCRIPTION E87B8656

Aircon Relay which is controled by ECM supplies and cut electrical power to Aircon compressor. ECM activates or deactivates Aircon Relay based on inputted signal such as aircon switch signal and Aircon switch signal. As controlling Aircon Relay, ECM 1)turns OFF aircon compressor at rapid acceleration to retain sufficient capacity for acceleration, 2)actively performs idle-up function to cope with the change of engine load which happens at aircom compressor operation.


# DTC DESCRIPTION ECAF1A9E

P0646 is set when '0A' is detected in Aircon relay control circuit for more than 1 sec. This code is due to open or short to ground in Aircon relay control circuit or internal open in relay component.

Item		Detecting C	Possible Cause	
DTC Strategy	<ul> <li>Voltage mo</li> </ul>	nitoring	*	
Enable Conditions	<ul> <li>IG KEY "OI</li> </ul>	N"		
ThresholdValue	<ul> <li>Short to GN</li> </ul>	D, Wiring ope	en	
DiagnosticTime	• 1.0 sec.			<ul> <li>A/C relay circuit</li> </ul>
	Fuel Cut	NO		<ul> <li>A/C relay component</li> </ul>
Fail Safa	EGR Off	NO		
Fail Safe	Fuel Limit	NO		
	MIL	NO		

# DTC DETECTING CONDITION ED2EE974

### SCHEMATIC DIAGRAM EC049137



# MONITOR SCANTOOL DATA E456D91E

- 1. Connect scantool to Data Link Cable (DLC).
- 2. Warm engine up to normal operating temperature.
- 3. Turn "OFF" electrical devices and A/C.
- 4. Monitor "A/C COMPRESSOR CONTROL" parameter on the scantool.

specification : A/C switch "ON" : A/C RELAY "ON" (Aircon compressor turns ON and OFF periodically by Aircon pressure S/W.) A/C switch "OFF" : A/C RELAY "OFF"

# DTC TROUBLESHOOTING PROCEDURES

				1.2	2 (	CUR	REN	r da	TA			26/	54
													4
×	FUEI	L PI	RES	SUI	RE	ME	asui	RED	28.	5	MP	a	
×	AIR	MA	SS	PEI	RCY	'LI	NDE	R	355	).7	'ng	∕st	
×	A/C	٥N	SI	GNA	۱L	SW	ITCI	-	ON				
×	A∕C	C01	iP;	DESS.	501	8 0	ONTI	ROL	061				BSW
¥	A/C	PRI	ESS	URE	2 2	SEN	SOR		172	:5	mŲ		
×	BLOW	<b>JER</b>	S₩	ITC	ж				٥N				
×	FAN-	LO	I S	PEE	ED				ON				
	FAN-	·HI(	GΗ	SPE	EE	)							
	FIX	٦			FL	ILL			GRP	н	R	CRD	1

A/C COMPRE	SSOR RELAY
DURATION	UNTIL STOP KEY
METHOD	ACTIVATION
CONDITION	IG.KEY ON ENGINE RUNNING
PRESS [S	TRT], IF YOU ARE READY !

Fig.1) The operating condition of aircon relay is shown. Check if aircon compressor works properly when aircon switch is turning ON.

Fig.2) Diagnosing problem of "A/C RELAY" and "AIRCON COMPRESSOR" is convenient through ACTUATION TEST on the Scantool.

LGJE001C

# TERMINAL AND CONNECTOR INSPECTION E9C5B10B

- Electrical systems consist of a lot of harness and connectors, poor connection of terminals can cause various prob-1. lems and damage of component.
- Perform checking procedure as follows. 2.
  - 1) Check damage of harness and terminals : Check terminals for contact resistance, corrosion and deformation,
  - 2) Check connecting condition of ECM and component connector : Check terminal seperation, damage of locking device and connecting condition between terminal and wiring.

# **NOTE**

Disconnect the pin which requires checking at mail connector and insert it to the terminal at female connector for checking connecting condition. (after checking, reconnect the pin at correct position)

3. is the problem found?

# YES

Repair the trouble causing part and go to "Verification of Vehicle Repair".

NO

Go to "Power Circuit Inspection".

#### POWER CIRCUIT INSPECTION E6075598

- 1. Check power circuit voltage
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect A/C relay.
  - 3) Measure the voltage of A/C relay terminal 1.

FLB -335

FUEL SYSTEM

specification : 11.5V~13.0V

4) Is the measured voltage within the specification?

# YES

▶ Go to "2. Check IG KEY "ON" power circuit".

#### NO

Repair problems of 10A FUSE in engineroom junction box and related circuit and go to "Verification of Vehicle Repair".

- 2. Check IG KEY "ON" power circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect A/C relay (E243).
  - 3) IG KEY "ON".
  - 4) Measure the voltage of glow relay terminal 5.

specification : 11.5V~13.0V

5) Is the measured voltage within the specification?



▶ Go to "Control Circuit Inspection".

NO

▶ Repair problems of E/R FUSE & RELAY BOX 10A FUSE in engineroom junction box and related circuit and go to "Verification of Vehicle Repair".

#### CONTROL CIRCUIT INSPECTION EEOC1FA9

- 1. Check monitoring voltage in control circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect A/C relay (E243).
  - 3) IG KEY "ON".
  - 4) Measure the voltage of glow relay terminal 3.

specification : 3.2V~3.7V

5) Is the measured voltage within the specification?



Go to "Component Inspection".

LGJF001H

# NO

- ▶ When voltage is not detected : Go to "2. Check open in control circuit" as follows.
- ▶ When high voltage is detected : Repair short to battery and go to "Verification of Vehicle Repair".
- 2. Check open in control circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect A/C relay and ECM connector.
  - 3) Check continuity between glow relay terminal 3 and ECM connector terminal 70.

specification : Continuity ( below  $1.0\Omega$  )

4) Is the measured resistance within the specification?

# YES

Repair short to ground and go to "Verification of Vehicle Repair".


#### NO

Repair open in control circuit and go to "Verification of Vehicle Repair".

# COMPONENT INSPECTION E325A4F3

- 1. Check A/C relay component resistance
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect A/C relay.
  - 3) Measure the coil resistance of A/C relay.

specification :  $85\pm5 \Omega$  (20°C)



4) Is the measured resistance within the specification?

# YES


▶ Go to "2. Check A/C relay component operation" as follows.

LGJF001I

#### NO

- Replace A/C relay and go to "Verification of Vehicle Repair".
- 2. Check A/C relay component operation
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect A/C relay
  - 3) Supplies random B+ and ground to coil sides of A/C relay (terminal 85, terminal 86)
  - 4) Check continuity between A/C relay terminal 30 and terminal 87.

specification : When power is supplied : Continuity ( below  $1.0\Omega$  ) When power is not supplied : Discontinuity ( Infinite  $\Omega$  )



5) Is the continuity test within the specification?

### YES

▶ Go to "Verification of Vehicle Repair".

#### NO

- ▶ Replace A/C relay and go to "Verification of Vehicle Repair".
- \* Repeat this process 2~3 times.

#### VERIFICATION OF VEHICLE REPAIR E3B37967

After a repair, it is essential to verify that the fault is corrected.

- 1. After connecting Scantool select "DIAGNOSTIC TROUBLE CODES(DTCs)" mode.
- 2. Clear recorded DTC using Scantool.
- 3. Drive the vehicle within DTC "Enable conditions" in "General information".
- 4. After selecting "DIAGNOSTIC TROUBLE CODES(DTCs)" mode and check if DTC is recorded again.
- 5. Are any DTCs recorded ?

#### YES

▶ Go to the DTC guide of recorded NO. in Scantool.



System operates within specification.

# DTC P0647 A/C CLUTCH RELAY CONTROL CIRCUIT HIGH

#### COMPONENT LOCATION E09EC338

Refer to DTC P0646.

#### GENERAL DESCRIPTION E27CB8B2

Refer to DTC P0646.

#### DTC DESCRIPTION E5351918

P0647 is set when excessive current is detected in Aircon relay control circuit for more than 1 sec.. This code is due to short to battery in Aircon relay control circuit or internal short in relay component.

#### DTC DETECTING CONDITION EF90EBE1

ltem		Detecting	Possible Cause	
DTC Strategy	<ul> <li>Voltage mor</li> </ul>	nitoring		
Enable Conditions	<ul> <li>IG KEY "Of</li> </ul>	۷"		
ThresholdValue	<ul> <li>Short to bat</li> </ul>	ttery		
DiagnosticTime	• 1.0 sec.			A/C relay circuit
	Fuel Cut	NO		<ul> <li>A/C relay component</li> </ul>
	EGR Off	NO		
Fail Safe	Fuel Limit	NO		
	MIL	NO		

#### SCHEMATIC DIAGRAM EBA7D4B7

Refer to DTC P0646.

#### MONITOR SCANTOOL DATA E2CD8649

Refer to DTC P0646.

#### TERMINAL AND CONNECTOR INSPECTION E09409B2

Refer to DTC P0646.

#### POWER CIRCUIT INSPECTION E514DA6F

- 1. Check power circuit voltage
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect A/C relay.
  - 3) Measure the voltage of A/C relay terminal 1.

specification : 11.5V~13.0V

4) Is the measured voltage within the specification?

# YES

▶ Go to "2. Check IG KEY "ON" power circuit".

NO

Repair problems of 10A FUSE in engineroom junction box and related circuit and go to "Verification of Vehicle Repair".

- 2. Check IG KEY "ON" power circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect A/C relay (E243).
  - 3) IG KEY "ON".
  - 4) Measure the voltage of glow relay terminal 5.

specification : 11.5V~13.0V

5) Is the measured voltage within the specification?

# YES.

▶ Go to "Control Circuit Inspection".

# NO

▶ Repair problems of E/R FUSE & RELAY BOX 10A FUSE and related circuit and go to "Verification of Vehicle Repair".

# CONTROL CIRCUIT INSPECTION ED65E6DE

- 1. Check monitoring voltage in control circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect A/C relay (E243).
  - 3) IG KEY "ON".
  - 4) Measure the voltage of glow relay terminal 3.

specification : 3.2V~3.7V

5) Is the measured voltage within the specification?



▶ Go to "Component Inspection".



- When voltage is not detected : Go to "2. Check open in control circuit" as follows.
- When high voltage is detected : Repair short to battery and go to "Verification of Vehicle Repair".

#### FLB -342

2. Check open in control circuit

- 1) IG KEY "OFF", ENGINE "OFF".
- 2) Disconnect A/C relay and ECM connector.

3) Check continuity between glow relay terminal 3 and ECM connector terminal 70.

LGJF001H

specification : Continuity ( below  $1.0\Omega$  )

4) Is the measured resistance within the specification?

# YES

Repair short to ground and go to "Verification of Vehicle Repair".


NO

Repair open in control circuit and go to "Verification of Vehicle Repair".

#### COMPONENT INSPECTION EC637E72

- 1. Check A/C relay component resistance
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect A/C relay.
  - 3) Measure the coil resistance of A/C relay.

```
specification : 85±5 Ω (20℃)
```



4) Is the measured resistance within the specification?

#### YES

Go to "2. Check A/C relay component operation" as follows.




- Replace A/C relay and go to "Verification of Vehicle Repair".
- 2. Check A/C relay component operation

# DTC TROUBLESHOOTING PROCEDURES

LGJE001L

- 1) IG KEY "OFF", ENGINE "OFF".
- 2) Disconnect A/C relay
- 3) Supplies random B+ and ground to coil sides of A/C relay (terminal 85, terminal 86)
- 4) Check continuity between A/C relay terminal 30 and terminal 87.

specification : When power is supplied : Continuity ( below 1.0  $\Omega$  ) When power is not supplied : Discontinuity ( Infinite  $\Omega$  )



- 5) Is the continuity test within the specification?
- YES
- Go to "Verification of Vehicle Repair".



Replace A/C relay and go to "Verification of Vehicle Repair".


-- An exact set access of an exact of the engine check large control cloud for more than 10 sect at an -- and 14 condition or 2 large calen or clusters are vid, no estrent is de semit 6~2 accord aid, teapen when ar -- and the exact to reactment of the common of the condition of the company is de semitimed and the common of the commo

# VERIFICATION OF VEHICLE REPAIR E48E1DA5

Refer to DTC P0646.

# DTC P0650 MALFUNCTION INDICATOR LAMP(MIL) CONTROL CIRCUIT

#### COMPONENT LOCATION E2828081



\_\_\_\_\_

#### GENERAL DESCRIPTION EB567B46

As monitoring the errors of several sensors and actuator circuit, TCM related problem and ECM error, if any problem occurs, ECM turns Engine Check Lamp ON at cluster to notify driver the occurence of a problem. Generally, Engine Check Lamp turns ON at Ignition ON and turns OFF within couple of seconds after turning engine ON. If engine check lamp turns on during driving, perform diagnosis of engine system and auto-transaxle system.


#### DTC DESCRIPTION E73B6941

P0650 is set when 1)excessive current is detected in engine check lamp control circuit for more than 1.0 sec. at engine check lamp ON condition or 2)like open or short to ground, no current is detected. This code is due to open in control circuit or opened filament of lamp component.

ltem		Detecting	Condition	Possible Cause
DTC Strategy	<ul> <li>Voltage mor</li> </ul>	nitoring		
Enable Conditions	<ul> <li>IG KEY "ON lamp operat</li> </ul>		ng only performed within n)	
ThresholdValue	<ul><li>Short to ba</li><li>Short to GN</li></ul>	•	<ul> <li>Open in engine check lamp</li> </ul>	
DiagnosticTime	• 1.0 sec.			<ul> <li>Engine check lamp circuit.</li> </ul>
	Fuel Cut	NO		
	EGR Off	NO		
Fail Safe	Fuel Limit	NO		
	MIL	NO		

#### DTC DETECTING CONDITION EAC105C2

# SCHEMATIC DIAGRAM E713A657



# TERMINAL AND CONNECTOR INSPECTION EBCE2296

- 1. Electrical systems consist of a lot of harness and connectors, poor connection of terminals can cause various problems and damge of component.
- 2. Perform checking procedure as follows.
  - 1) Check damage of harness and terminals : Check terminals for contact resistance, corrosion and deformation.
  - 2) Check connecting condition of ECM and component connector : Check terminal seperation, damage of locking device and connecting condition between terminal and wiring.

# 🛈 ΝΟΤΕ

Disconnect the pin which requires checking at male connector and insert it to the terminal at female connector for checking connecting condition. (after checking, reconnect the pin at correct position.)

3. Is the problem found?

#### YES

Repair the trouble causing part and go to "Verification of Vehicle Repair".

#### NO

Go to "Control Circuit Inspection".

# CONTROL CIRCUIT INSPECTION E201D8A5

1. Check control circuit voltage

- 1) IG KEY "OFF", ENGINE "OFF".
- 2) Disconnect ECM connector.
- 3) IG KEY "ON".
- 4) Measure the voltage of terminal 68 of ECM connector.

Specification : 10.8V~13.0V

5) Is the measured voltage within the specification?

# YES

▶ Go to "2. Grounding test of check lamp control circuit" as follows.



- Check open in filament of check lamp. (Refer to Component Inspection)
- ▶ Repair open between cluster connector(M07-1) terminal 1 and ECM connector(C201-2) terminal 68 and go
- to "Verification of Vehicle Repair",
- 2. Grounding test of check lamp control circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect ECM connector.
  - 3) IG KEY "ON".
  - 4) Ground ECM connector terminal 68 to chassis ground.

specification : check lamp turns ON.

5) Does check lamp turn ON?

#### YES

▶ Go to "Verification of Vehicle Repair".

NO

▶ Repair short to battery in check lamp control circuit and go to "Verification of Vehicle Repair".

#### COMPONENT INSPECTION E2D67246

- 1. IG KEY "OFF", ENGINE "OFF".
- 2. Dismount cluster and disconnect check lamp.
- 3. Check filament of check lamp.
- 4. supply 12V to "check lamp" to turn lamp ON

#### specification : lamp turns ON when 12V is supplied.

5. Does check lamp turn ON?

# YES

Go to "Verification of Vehicle Repair".

# NO

Replace check lamp and go to "Verification of Vehicle Repair".

# VERIFICATION OF VEHICLE REPAIR E55884C2

After a repair, it is essential to verify that the fault is corrected.

- 1. After connecting Scantool select "DIAGNOSTIC TROUBLE CODES(DTCs)" mode.
- 2. Clear recorded DTC using Scantool.
- 3. Drive the vehicle within DTC "Enable conditions" in "General information".
- 4. After selecting "DIAGNOSTIC TROUBLE CODES(DTCs)" mode and check if DTC is recorded again.
- 5. Are any DTCs recorded ?

# YES


Go to the DTC guide of recorded NO. in Scantool.

#### NO

System operates within specification.

# DTC P0652 SENSOR REFERENCE VOLTAGE "B" CIRCUIT LOW

#### COMPONENT LOCATION ED7BOEDA



EWPF602Q

### GENERAL DESCRIPTION E138733A

ECM is activated by power supply. Signals from several sensors, such as CKPS and APS, is inputted to ECM. Comparing inputted signals with control LOGIC saved at micro controller and EEPROM, ECM controlls engine as actuating injectors, solenoids and relays. To guarantee accurate control, ECM performs SELF TEST, DIAGNOSIS of several sensors and actuators. And if serious trouble which affects vehicle performance occurrs, ECM sets DTCs.At certain cases, ECM shuts down whole systems in order to prevent dangerous situation due to incorrect control.

#### DTC DESCRIPTION EBOFC3ED

P0652 is set when the voltage below 4700mV - minimum voltage of sensor power supply 2 generates from ECM - is detected for more than 0.1 sec.. This code is due to the short to ground in sensor power circuit or the voltage problem inside of ECM.

# DTC DETECTING CONDITION E8D91837

Item		Detecting	Possible Cause	
DTC Strategy	<ul> <li>Voltage mor</li> </ul>	nitoring		
Enable Conditions	<ul> <li>IG KEY "Of</li> </ul>	N"		
ThresholdValue			w the minimum voltage of pelow 4700mV)	RPS power supply circuit
DiagnosticTime	• 100ms			<ul> <li>APS 2 power supply circuit</li> <li>BPS power supply circuit</li> </ul>
	Fuel Cut	NO	<ul> <li>Limp home mode</li> </ul>	ECM component
	EGR Off	NO	is activated.(engine	
Fail Safe	Fuel Limit	YES	speed is fixed at	
	MIL	NO	1200RPM.)	


# DTC TROUBLESHOOTING PROCEDURES

### FLB -349

### SPECIFICATION E584A663

Sensor power 1	Sensor power 2	Sensor power 3
AFS, APS 1 4830mV~5158mV	RPS, APS 2,BPS 4830mV~5158mV	A/C pressure transducer, VSA position Sensor 4830mV~5158mV

# SCHEMATIC DIAGRAM E26D8A47



EWPF005D

と、記録の1000年の時

#### SIGNAL WAVEFORM AND DATA E4CE8FF9

FR	CH A	1	.0	Ų	G.	0 S	(	н	3 1	L.0	Ų		FR		CH A	1.0	Ų	5.	0 S	CH	B	1.0	Ų	
		-	÷				1				-							1		: :	÷			
		ļ		į						į		÷		Ì								Ì		
	AP	S 2	pc	wer			ļ			ł		Ì		Ì	BPS	S pov	ver	1						
1 	*******		- Cardon	~~~			-1 <del>14 - 1</del> 4		<b></b>		- <b>n</b> -0-		1	*****	*****		8Tr.4.4.	****	4	-1 <del>1.2.1.28</del> 5			<u> </u>	~~
	BP	Sr	, XOX	er				-340-04							RPS	3 pov	ver		*****	-Ve-1-1-1-11	.09.6.8.		40.4	~~
	<u>.</u>													<u>.</u>										
<b>.</b>									<u>.</u>				<u>م</u>											
												<u> </u>												
Ĥ	OLD	ZO	OM	Ol	RS	MEM	0	REC	D	M	enu			H	OLD Z	zoom	] C	JRS	MEM	0 RI	ECD	ME	NU	
Fig.1														ig 2	2									

Fig.1) APS2 and RPS power supply signals are measured simultaneously. Check if the voltages are within the specification (4.8~5.1V) at IG KEY "ON".

Fig.2) BPS and RPS power supply signals are measured simultaneously. Check if the voltages are within the specification (4.8~5.1V) at IG KEY "ON".

LGJF003A

# TERMINAL AND CONNECTOR INSPECTION EGIFCDB7

- 1. Electrical systems consist of a lot of harness and connectors, poor connection of terminals can cause various problems and damage of component.
- 2. Perform checking procedure as follows.
  - 1) Check damage of harness and terminals : Check terminals for contact resistance, corrosion and deformation.
  - 2) Check connecting condition of ECM and component connector : Check terminal seperation, damage of locking device and connecting condition between terminal and wiring.

# **NOTE**

Disconnect the pin which requires checking at mail connector and insert it to the terminal at female connector for checking connecting condition. (after checking, reconnect the pin at correct position)

#### 3. Is the problem found?

#### YES

Repair the trouble causing part and go to "Verification of Vehicle Repair".

#### NO

Go to "Power Circuit Inspection".

# POWER CIRCUIT INSPECTION EBCDF5E3

- 1. Check power circuit voltage
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnector RPS connector, APS connector and BPS connector.

# DTC TROUBLESHOOTING PROCEDURES

- 3) IG KEY "ON".
- 4) Measure the voltage of RPS connector terminal 1, APS connector terminal 3 and BPS terminal 2.

Specification: 4.8V~5.1V

5) Is the measured voltage within the specification?



▶ Go to "Component Inspection".



- Go to "2. Check short to ground in power circuit" as follows.
- 2. Check short to ground in power circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect RPS connector, APS connector, BPS connector, ECM connectors.
  - 3) Check continuity between RPS connector terminal 1(APS connector terminal 3, BPS connector terminal 2) and chassis ground.

specification : Discontinuity (Infinite  $\Omega$ )

4) Is the measured resistance within the specification?



▶ If the circuit is insulated well and the sensor power supply from ECM is low, replace ECM and "Verification of Vehicle Repair".

# NO

Repair short to ground and go to "Verification of Vehicle Repair".

#### COMPONENT INSPECTION E221DA47

- 1. IG KEY "OFF", ENGINE "OFF".
- 2. Disconnect RPS connector, APS connector, BPS connector.
- 3. Check that sensor connector power supply is within the specification after turning IG KEY "ON".
- 4. Connect RPS connector and APS connector in turn.

Specification : sensor power supply should not change as connecting RPS connector, APS connector, BPS connector. ( If the change of sensor power supply occur as connecting sensor connector, this means the occurrence of short inside of sensor.)

5. Does change of sensor power supply occur as connecting sensor connector?



Replace related sensors.(rail pressure sensor, accel pedal sensor, boost pressure sensor)

#### NO

▶ Go to "Verification of Vehicle Repair".

### VERIFICATION OF VEHICLE REPAIR E3C57D2B

After a repair, it is essential to verify that the fault is corrected.

- 1. After connecting Scantool select "DIAGNOSTIC TROUBLE CODES(DTCs)" mode.
- 2. Clear recorded DTC using Scantool.
- 3. Drive the vehicle within DTC "Enable conditions" in "General information".
- 4. After selecting "DIAGNOSTIC TROUBLE CODES(DTCs)" mode and check if DTC is recorded again.
- 5. Are any DTCs recorded ?

# YES

▶ Go to the DTC guide of recorded NO. in Scantool.

### NO

System operates within specification.

# DTC P0653 SENSOR REFERENCE VOLTAGE "B" CIRCUIT HIGH

# COMPONENT LOCATION E12CD23C

Refer to DTC P0652.

#### GENERAL DESCRIPTION EDE273D5

Refer to DTC P0652.

# DTC DESCRIPTION EEOE8E2B

P0653 is set when the voltage above 5158mV - maximum voltage of sensor power supply 2 generates from ECM - is detected for more than 0.1 sec.. This code is due to the short to battery in sensor power circuit or the voltage problem inside of ECM.

# DTC DETECTING CONDITION EGAD78DE

ltem		Detecting	Condition	Possible Cause
DTC Strategy	<ul> <li>Voltage mo</li> </ul>			
Enable Conditions	• IG KEY "OI			
ThresholdValue	<ul> <li>when the vo of sensor po</li> </ul>		RPS power supply circuit	
DiagnosticTime	• 100ms		APS 2 power supply circuit	
	Fuel Cut	NO		<ul> <li>BPS power supply circuit</li> <li>ECM component</li> </ul>
Fail Safe	EGR Off	NO	<ul> <li>Limp home mode is activated.(engine</li> </ul>	
		YES	speed is fixed at	활동 방법 같은 것은 것이 같이.
t and the second s	MIL		1200RPM.)	

# SPECIFICATION EC6D2A69

Sensor power 1	Sensor power 2	Sensor power 3
AFS, APS 1 4830mV~5158mV	RPS, APS 2,BPS 4830mV~5158mV	A/C pressure transducer, VSA position Sensor 4830mV~5158mV

# SCHEMATIC DIAGRAM E0E9614B

Refer to DTC P0652.

# SIGNAL WAVEFORM AND DATA EDD8143E

Refer to DTC P0652.

# TERMINAL AND CONNECTOR INSPECTION E74ABD40

Refer to DTC P0652.

### POWER CIRCUIT INSPECTION E65B334D

- 1. Check power circuit voltage
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnector RPS connector, APS connector and BPS connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of RPS connector terminal 1, APS connector terminal 3 and BPS terminal 2.

Specification: 4.8V~5.1V

5) Is the measured voltage within the specification?

#### YES

Go to "Component Inspection".

NO

- Go to "2. Check short to battery in power circuit" as follows.
- 2. Check short to battery in power circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect RPS connector, APS connector, BPS connector, ECM connectors.
  - 3) IG KEY "ON"
  - 4) Measure the voltage of RPS connector terminal 1 or APS connector terminal 3 and BPS connector terminal 2.

Specification : 0.0V~0.1V

5) Is abnormal voltate measured in this test?

#### YES

▶ Repair short to battery and go to "Verification of Vehicle Repair".



▶ If the circuit is insulated well and the sensor power supply from ECM is high, replace ECM and go to "Verification of Vehicle Repair".

#### COMPONENT INSPECTION EDEB9075

- 1. IG KEY "OFF", ENGINE "OFF".
- 2. Disconnect RPS connector, APS connector, BPS connector.
- 3. Check that sensor connector power supply is within the specification after turning IG KEY "ON".
- 4. Connect RPS connector and APS connector in turn.

#### DTC TROUBLESHOOTING PROCEDURES

Specification : sensor power supply should not change as connecting RPS connector, APS connector, BPS connector. (If the change of sensor power supply occur as connecting sensor connector, this means the occurrence of short inside of sensor.)

5. Does change of sensor power supply occur as connecting sensor connector?

# YES

Replace related sensors.(rail pressure sensor, accel pedal sensor, boost pressure sensor)

# NO


▶ Go to "Verification of Vehicle Repair".

# VERIFICATION OF VEHICLE REPAIR E4A748AF

Refer to DTC P0652.

# DTC P0670 GLOW RELAY - CIRCUIT MALFUNCTION

#### COMPONENT LOCATION ED7BOEDB



EWPF088T

# GENERAL DESCRIPTION EC12FD78

Heating combustion chamber, glow plug increases fuel ignitibility and makes fuel in the foggy state easily when engine is cold. Thus, glow plug makes engine starting easily and decreases exhaust gas produced just after turning engine on when engine is cold.ECM controls operation and operating duration of glow plug relay which supplies power to glow plug with ECTS signal, battery voltage and IG KEY ON signal.Through glow lamp in cluster, ECM let drivers know if glow plug is ON.

#### DTC DESCRIPTION E59FEC53

P0670 is set when 1)excessive voltage is detected or 2)no current is detected like open or short to ground in glow relay control circuit for more than 1 sec. at glow relay ON condition. This code is due to open in glow relay control circuit or internal open in glow relay component.

# DTC DETECTING CONDITION EA797CE8

ltem	Detecting Condition			Possible Cause
DTC Strategy	<ul> <li>Voltage more</li> </ul>	nitoring		
Enable Conditions	<ul> <li>IG KEY "ON relay operation</li> </ul>	•		
ThresholdValue	<ul><li>short to bat</li><li>Short to GN</li></ul>			
DiagnosticTime	• 1.0 sec.			<ul> <li>Glow relay control circuit</li> <li>Glow relay component</li> </ul>
	Fuel Cut	NO		
Fail Safe	EGR Off	NO		
	Fuel Limit	NO		
	MIL	NO		


# DTC TROUBLESHOOTING PROCEDURES

# SPECIFICATION E303121C

#### **\* RELAY OPERATING TIME**

	<b>-20</b> ℃	<b>-10</b> ℃	<b>10</b> ℃	<b>50</b> ℃
10V	16sec	10sec	4sec	2.0sec
14.9V	16sec	10sec	4sec	2.0sec

# SCHEMATIC DIAGRAM E52AACBA



# MONITOR SCANTOOL DATA EB14D2C2

- 1. Connect Scantool to Data Link Connector (DLC).
- 2. Warm engine up to normal operating temperature.
- 3. Turn "OFF" electrical devices and A/C.
- 4. Monitor "GLOW RELAY" parameter on the Scantool.

specification : After operating according to engine coolant temperature and battery voltage, Glow relay turns "OFF". at IG KEY "ON". (Refer to Specification)

	1.2 CURRENT D	ATA 31/54
		٨
×	BATTERY VOLTAGE	14.4 V
×	FUEL PRESSURE MEASURED	28.5 MPa
×	RAIL PRESS. REGULATOR1	22.7 %
×	AIR MASS PERCYLINDER	359.7mg/st
×	WATER TEMP.SENSOR	94.3 °C
¥	GLOW RELAY	ON
¥	GLOW CONTROL LAMP	OFF
¥	ENGINE SPEED SENSOR	794 rpm
	FIX FULL	GRPH RCRD

1	.5 ACTUATION TEST	09/1
GLOW RELAY		
DURAT I ON	UNTIL STOP KEY	
METHOD	ACTIVATION	
CONDITION	IG. KEY ON	
	ENGINE OFF	
PRESS [S	TRT], IF YOU ARE REA	DY ?
STRT STO	P	
ig.2		

Fig 1) Operating state of Glow relay is shown. However, it is difficult to check operating state because Glow relay turns OFF 2~3 sec. after operation at normal temp.

Fig.2) Checking glow relay operation and power supply to glow plug using "ACTUATION TEST" on Scantool is convenient.

LGJF007H

#### TERMINAL AND CONNECTOR INSPECTION EA26A620

- 1. Electrical systems consist of a lot of harness and connectors, poor connection of terminals can cause various problems and damge of component.
- 2. Perform checking procedure as follows.
  - 1) Check damage of harness and terminals : Check terminals for contact resistance, corrosion and deformation.
  - 2) Check connecting condition of ECM and component connector : Check terminal seperation, damage of locking device and connecting condition between terminal and wiring.

# 

Disconnect the pin which requires checking at male connector and insert it to the terminal at female connector for checking connecting condition. (after checking, reconnect the pin at correct position.)

3. Is the problem found?

#### YES

Repair the trouble causing part and go to "Verification of Vehicle Repair".

NO

▶ Go to "Power Circuit Inspection".

# POWER CIRCUIT INSPECTION ECEC3991

- 1. Check HOT AT ALL TIMES power circuit voltage
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect glow relay.
  - 3) Measure the voltage of glow relay connector terminal 3.

Specification : 11.5V~13.0V
4) Is the measured voltage within the specification?
YES
> Go to "2. Check IG KEY "ON" power circuit voltage" as follows.
NO
> Repair Diesel box 80A glow plug fuse and related circuit and go to "Verification of Vehicle Repair".
2. Check IG KEY "ON" power circuit voltage
1) IG KEY "OFF", ENGINE "OFF".

- 2) Disconnect glow relay.
- 3) IG KEY "ON".
- 4) Measure the voltage of glow relay connector terminal 4.

Specification : 11.5V~13.0V

5) Is the measured voltage within the specification?

# YES

▶ Go to "Control Circuit Inspection".



Repair E/R FUSE & RELAY BOX 15A INJ fuse and related circuit and go to "Verification of Vehicle Repair".

# CONTROL CIRCUIT INSPECTION EBD92322

- 1. Check control circuit monitoring voltage
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect glow relay.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of glow relay connector terminal 1.

Specification : 3.2V~3.7V

5) Is the measured voltage within the specification?



Go to "Component Inspection".



When no value is detected : Go to "2. Check open in control circuit".

LGJF007M

▶ When high voltage is detected : Repair short to battery in signal circuit and go to "Verification of Vehicle Repair".

- 2. Check open in control circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect glow relay and ECM connector.
  - 3) Check continuity between glow relay connector terminal 1 and ECM connector terminal 93.

specification : Continuity (below  $1.0\Omega$ )

4) Is the measured resistance within the specification?

#### YES

Repair short to ground and go to "Verification of Vehicle Repair".




Repair open in control circuit and go to "Verification of Vehicle Repair".

#### COMPONENT INSPECTION E3589B7E

1.	Che	ck golw relay component coil resistance		
	1)	IG KEY "OFF", ENGINE "OFF".		
	2)	Disconnect glow relay.		
	3)	Measure the resistance of glow relay component coil.	•	an a

Specification : 55±5 Ω (20℃)



4) Is the measured resistance within the specification?



▶ Go to "2. Check glow relay component operation" as follows.




Replace glow relay and go to "Verification of Vehicle Repair".

#### DTC TROUBLESHOOTING PROCEDURES

- 2. Check glow relay component operation
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect glow relay.
  - 3) Supplies random B+ and ground to coil sides of glow relay (terminal 85, terminal 86).
  - 4) Check continuity between glow relay terminal 30 and terminal 87.

specification : When power is supplied : Continuity ( below 1.0  $\Omega$  ) When power is not supplied : Discontinuity ( Infinite  $\Omega$  )



5) Is the measured resistance within the specification?

#### YES

Go to "Verification of Vehicle Repair".

#### NO

- Replace glow relay and go to "Verification of Vehicle Repair".
- \* Repeat this process 2~3 times.

### VERIFICATION OF VEHICLE REPAIR E6329976

After a repair, it is essential to verify that the fault is corrected.

- 1. After connecting Scantool select "DIAGNOSTIC TROUBLE CODES(DTCs)" mode.
- 2. Clear recorded DTC using Scantool.
- 3. Drive the vehicle within DTC "Enable conditions" in "General information".
- 4. After selecting "DIAGNOSTIC TROUBLE CODES(DTCs)" mode and check if DTC is recorded again.
- 5. Are any DTCs recorded ?

LGJF007N

「「「「「「「」」」をいていていた。


# YES

▶ Go to the DTC guide of recorded NO. in Scantool.

### NO

### DTC P0685 ECM/PCM POWER RELAY CONTROL CIRCUIT /OPEN

#### COMPONENT LOCATION E2CE8948



EWPF603B

#### GENERAL DESCRIPTION EFB6C192

Main relay operates when Ignition ON signal is inputted to terminal 28 of ECM C201-1 connector and it supplies power to ECM, fuel pump relay, CMP, EGR actuator, throttle flap actuator, PTC heater relay and brake switch, etc. Especially, the power supplied to ECM is used as a main power of injectors, rail pressure control valve and ECM operation. When IG KEY ON signal is shut off during turning engine OFF, ECM stops injector operation then engine turns OFF. Approx. after 5 sec., ECM shuts OFF main relay and system turns OFF. Main relay is very important for engine operation, so careful inspection is strongly required.

### DTC DESCRIPTION EF67D06C

When IG KEY OFF signal is imputted to ECM. ECM stops injector operation and nengine turns OFF. Then, After-run(turning off process of ECM intermal system) is performed in order to shut system down. During this process, if main relay power supply is cut too late or power supply is cut too early before After-run process completes, ECM detect main relay error and P0685 is set.

ltem		Detecting	Possible Cause	
DTC Strategy	<ul> <li>Voltage mo</li> </ul>	nitoring		
Enable Conditions	• IG KEY "O	N"		
ThresholdValue	<ul> <li>When main signal too f (After-run fii Main relay t before After</li> </ul>	ast or slow nished and o be deacti	• Main relay circuit	
DiagnosticTime	<ul> <li>Immediately</li> </ul>	1	<ul> <li>Main relay component</li> </ul>	
	Fuel Cut	NO		
Fail Safe	EGR Off	NO	-	
	Fuel Limit	NO		
	MIL	NO		


### DTC DETECTING CONDITION E1B9B486

#### SPECIFICATION E5FC61DD


Main Relay Coil Resistance

73±10 Ω (20℃)

#### SCHEMATIC DIAGRAM E9D11372



### SIGNAL WAVEFORM AND DATA E4CAB78B



#### Fig.1

Fig.1) Main relay operates when IG KEY "ON" (C201-1 terminal 28 ON signal), it turns "OFF" in 12 sec. after IG KEY "OFF".

## TERMINAL AND CONNECTOR INSPECTION EA92DCE7

- 1. Electrical systems consist of a lot of harness and connectors, poor connection of terminals can cause various problems and damge of component.
- 2. Perform checking procedure as follows.
  - 1) Check damage of harness and terminals : Check terminals for contact resistance, corrosion and deformation.
  - 2) Check connecting condition of ECM and component connector : Check terminal seperation, damage of locking device and connecting condition between terminal and wiring.

NOTE a bras Ausain traisfer

Disconnect the pin which requires checking at male connector and insert it to the terminal at female connector for checking connecting condition. (after checking, reconnect the pin at correct position.)

3. Is the problem found?

#### YES

Repair the trouble causing part and go to "Verification of Vehicle Repair".

#### NO

Go to "Power Circuit Inspection".

#### POWER CIRCUIT INSPECTION E6298777

- 1. Check power circuit voltage
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect main relay.
  - 3) Measure the voltage of main relay terminal 2 and 5.

EWPF005M

FUEL SYSTEM

Specification : 11.5V~13.0V

4) Is the measured voltage within the specification?

#### YES

▶ Go to "Check power supply line(relay→actuator)" as follows.

#### NO

▶ Repair E/R FUSE & RELAY BOX 30A ECU A fusible link and related circuit and go to "Verification of Vehicle Repair".

- 2. Check power supply line(relay→actuator)
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect main relay and ECM connector.
  - 3) Connect main relay terminal 1 and 5 using jump wire.
  - 4) Measure the voltage of ECM connector terminal 1,3,5.

specification : 11.5V~13.0V

5) Is the measured voltage within the specification?

#### YES

Go to "Control Circuit Inspection".



▶ Repair open in E/R FUSE & RELAY BOX ECU 1, ECU 2 fusible link and related circuit and go to "Verification of Vehicle Repair".

#### CONTROL CIRCUIT INSPECTION E279F9E7

1.	Che	eck open in control circuit	and the first state
	1)	IG KEY "OFF", ENGINE "OFF".	
	2)	Disconnect main relay and ECM connector.	
	3)	Check continuity between main relay terminal 4 and ECM connector 72.	
sp	oecifi	cation:Continuity(below 1.0Ω)	
	4)	Is the measured resistance within the specification?	1 <sup>27</sup> 48
		YES	* * ** ** ***
		▶ Go to "2. Check short to ground in control circuit" as follows.	
		NO	
		Repair open in control circuit and go to "Verification of Vehicle Repair".	

### DTC TROUBLESHOOTING PROCEDURES

2. Check short to ground in control circuit

- 1) IG KEY "OFF", ENGINE "OFF".
- 2) Disconnect main relay and ECM connector.
- 3) Check continuity between main relay terminal 4 and chassis ground.

specification : Discontinuity (Infinite  $\Omega$ )

4) Is the measured resistance within the specification?

### YES

Go to "3.Check short to battery in control circuit" as follows.

#### NO

- Repair short to ground in control circuit and go to "Verification of Vehicle Repair".
- 3. Check short to battery in control circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect main relay and ECM connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of main relay connector terminal 4.

specification : 0.0V~0.1V

5) Is abnormal voltage detected in the circuit with both connectors disconnected?

### YES

Repair short to battery in signal circuit and go to "Verification of Vehicle Repair".

NO


Go to "Component Inspection".

#### COMPONENT INSPECTION ED85BD08

- 1. Check main relay component resistance
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect main relay.
  - 3) Measure the resistance between main relay coil component terminal 85 and 86.

Specification : 73±10 Ω (20℃)

LGJF010F



4) Is the measured resistance within the specification?


1000月2023	62 E S	12.3477
BA VA		0.0
調整 協	125	- 2
1222-022	and a	ter di i

- Go to "2. Check main relay component operation" as follows.
- NO

Replace main relay and go to "Verification of Vehicle Repair".

- 2. Check main relay component operation
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect main relay.
  - 3) Supplies random B+ and ground to coil sides of main relay. (terminal 85, terminal 86)
  - 4) Check continuity between main relay component terminal 30 and 87.

specification : When power is supplied : Continuity ( below 1.0  $\Omega$  ) When power is not supplied : Discontinuity ( Infinite  $\Omega$  )



5) Is the continuity test within the specification?



go to "Verification of Vehicle Repair".



- Replace main relay and go to "Verification of Vehicle Repair".
- \* Repeat this process 2~3 times.

LGJF010G

### VERIFICATION OF VEHICLE REPAIR ED4C6691

After a repair, it is essential to verify that the fault is corrected.

- 1. After connecting Scantool select "DIAGNOSTIC TROUBLE CODES(DTCs)" mode.
- 2. Clear recorded DTC using Scantool.
- 3. Drive the vehicle within DTC "Enable conditions" in "General information".
- 4. After selecting "DIAGNOSTIC TROUBLE CODES(DTCs)" mode and check if DTC is recorded again.
- 5. Are any DTCs recorded ?


#### YES

Go to the DTC guide of recorded NO. in Scantool.

#### NO

### DTC P0698 SENSOR REFERENCE VOLTAGE "C" CIRCUIT LOW

#### COMPONENT LOCATION ECE788C8



EWPF602Q

### GENERAL DESCRIPTION EE2EEF4C

ECM is activated by power supply. Signals from several sensors, such as CKPS and APS, is inputted to ECM. Comparing inputted signals with control LOGIC saved at micro controller and EEPROM, ECM controlls engine as actuating injectors, solenoids and relays. To guarantee accurate control, ECM performs SELF TEST, DIAGNOSIS of several sensors and actuators. And if serious trouble which affects vehicle performance occurrs, ECM sets DTCs.At certain cases, ECM shuts down whole systems in order to prevent dangerous situation due to incorrect control.

### DTC DESCRIPTION E149E6B7

P0698 is set when the voltage below 4700mV - minimum voltage of sensor power supply 3 generates from ECM - is detected for more than 0.1 sec.. This code is due to the short to ground in sensor power circuit or the voltage problem inside of ECM.

### DTC DETECTING CONDITION ED3A80A9

Item		Detecting	Possible Cause		
DTC Strategy	<ul> <li>Voltage mo</li> </ul>	nitoring			
Enable Conditions	• IG KEY "O	N"			
ThresholdValue	<ul> <li>when the void of sensor p</li> <li>( below 470)</li> </ul>	ower supply	<ul> <li>A/C pressure transducer power supply circuit</li> <li>variable swirl control actuator</li> </ul>		
DiagnosticTime	• 100ms				
	Fuel Cut	NO	t limp home mode is	<ul> <li>power supply circuit</li> <li>ECM component</li> </ul>	
	EGR Off	NO	<ul> <li>Limp home mode is activated. (engine</li> </ul>		
Fail Safe	Fuel Limit	YES	speed is fixed at		
	MIL	NO	1200RPM. )		


### DTC TROUBLESHOOTING PROCEDURES

#### FLB -371

#### SPECIFICATION E5831A36

Sensor power 1	Sensor power 2	Sensor power 3
AFS, APS 1 4830mV~5158mV	RPS, APS 2,BPS 4830mV~5158mV	A/C pressure transducer, VSA position Sensor 4830mV~5158mV

### SCHEMATIC DIAGRAM EBCOC409



EWPF005S

#### SIGNAL WAVEFORM AND DATA E8D33577

FR	CH	A	1.0	9 V		5.	5) {		C	HE	3 1	.0	V	
į										-	-	-		
į	· Al	rcor	n pre	essi	lre	sen	sor	pov	ver	:				
				***				196-J						
Variat	le s	wirl				tuat	orr	osit	tion	sei	nsoi	· ····		
							r				;	; ;		
											; ;	; ;		
þ														
							-				:	: [		
মের বিরিয়া			100	1	CIJI	ġ.	lui	emo		REC	עי	ILLI	INU	L

Fig.1) A/C pressure transducer and VSA position Sensor power supply signals are measured simultaneously. Check if the voltages are within the specification (4.8~5.1V) at IG KEY "ON"

LGJF001X

#### TERMINAL AND CONNECTOR INSPECTION E7B 16885

- 1. Electrical systems consist of a lot of harness and connectors, poor connection of terminals can cause various problems and damage of component.
- 2. Perform checking procedure as follows.
  - 1) Check damage of harness and terminals : Check terminals for contact resistance, corrosion and deformation.
  - 2) Check connecting condition of ECM and component connector : Check terminal seperation, damage of locking device and connecting condition between terminal and wiring.

### NOTE

Disconnect the pin which requires checking at mail connector and insert it to the terminal at female connector for checking connecting condition. ( after checking, reconnect the pin at correct position )

3. Is the problem found?

#### YES

Repair the trouble causing part and go to "Verification of Vehicle Repair".

NO

▶ Go to "Power Circuit Inspection".

#### POWER CIRCUIT INSPECTION E5A801FE

- 1. Check power circuit voltage
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect A/C pressure transducer connector and variable swirl control actuator connector.
  - 3) IG KEY "ON".

#### DTC TROUBLESHOOTING PROCEDURES

4) Measure the voltage between A/C pressure transducer connector terminal 3 or variable swirl control actuator connector terminal 6 and chassis ground.

Specification : 4.8V~5.1V

5) Is the measured voltage within the specification?

### YES

▶ Go to "Component Inspection".

NO

- Go to "2. Check short to ground in power circuit" as follows.
- 2. Check short to ground in power circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect A/C pressure transducer connector, variable swirl control actuator connector, ECM connectors.
  - 3) Check continuity between A/C pressure transducer connector terminal 3 or variable swirl control actuator connector terminal 3 and chassis ground.

specification : Discontinuity (Infinite  $\boldsymbol{\Omega}$ )

4) Is the measured resistance within the specification?

### YES

▶ If the circuit is insulated well and the sensor power supply from ECM is low, replace ECM and go to "Verification of Vehicle Repair".

#### NO

Repair short to ground and go to go to "Verification of Vehicle Repair".

### COMPONENT INSPECTION E51B9FBD

- 1. IG KEY "OFF", ENGINE "OFF".
- 2. Disconnect A/C pressure transducer connector and variable swirl control actuator connector.
- 3. Check that sensor connector power supply is within the specification after turning IG KEY "ON".
- 4. Connect A/C pressure transducer connector and variable swirl control actuator connector in turn.

Specification : sensor power supply should not change as connecting A/C pressure transducer connector and variable swirl control actuator connector. ( If the change of sensor power supply occur as connecting sensor connector, this means the occurrence of short inside of sensor.)

5. Does change of sensor power supply occur as connecting sensor connector?

### YES

Replace A/C pressure transducer or variable swirl control actuator.

#### NO

▶ Go to "Verification of Vehicle Repair".

### VERIFICATION OF VEHICLE REPAIR E9A1787A

After a repair, it is essential to verify that the fault is corrected.

- 1. After connecting Scantool select "DIAGNOSTIC TROUBLE CODES(DTCs)" mode.
- 2. Clear recorded DTC using Scantool.
- 3. Drive the vehicle within DTC "Enable conditions" in "General information".
- 4. After selecting "DIAGNOSTIC TROUBLE CODES(DTCs)" mode and check if DTC is recorded again.
- 5. Are any DTCs recorded ?

#### YES

▶ Go to the DTC guide of recorded NO. in Scantool.

#### NO

### DTC P0699 SENSOR REFERENCE VOLTAGE "C" CIRCUIT HIGH

#### COMPONENT LOCATION ED436274

Refer to DTC P0698.

#### GENERAL DESCRIPTION E21D8E36

Refer to DTC P0698.

#### DTC DESCRIPTION EDA21A22

P0699 is set when the voltage above 5158mV - maximum voltage of sensor power supply 3 generates from ECM - is detected for more than 0.1 sec.. This code is due to the short to battery in sensor power circuit or the voltage problem inside of ECM.

#### DTC DETECTING CONDITION E2492C53

ltem		Detecting	Condition	Possible Cause		
DTC Strategy	<ul> <li>Voltage mo</li> </ul>	nitoring				
Enable Conditions	• IG KEY "O	N"	and the second			
ThresholdValue	<ul> <li>when the void of sensor p (above 515)</li> </ul>	ower supply	<ul> <li>A/C pressure transducer power supply circuit</li> </ul>			
DiagnosticTime	• 100ms	Anthon Inves	variable swirl control actuator			
	Fuel Cut	NO		<ul><li>power supply circuit</li><li>ECM component</li></ul>		
	EGR Off	NO	<ul> <li>Limp home mode is activated. (engine</li> </ul>			
Fail Safe	Fuel Limit	YES	speed is fixed at			
	MIL	NO				

#### SPECIFICATION E4652A4E

Sensor power 1	Sensor power 2	Sensor power 3
AFS, APS 1 4830mV~5158mV	RPS, APS 2,BPS 4830mV~5158mV	A/C pressure transducer, VSA position Sensor 4830mV~5158mV

#### SCHEMATIC DIAGRAM EDED1011

Refer to DTC P0698.

#### SIGNAL WAVEFORM AND DATA E3E455FB

Refer to DTC P0698.

### TERMINAL AND CONNECTOR INSPECTION E718043C

Refer to DTC P0698.

#### POWER CIRCUIT INSPECTION E2219227

- 1. Check power circuit voltage
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect A/C pressure transducer connector and variable swirl control actuator connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage between A/C pressure transducer connector terminal 3 or variable swirl control actuator connector terminal 6 and chassis ground.

#### Specification: 4.8V~5.1V

5) Is the measured voltage within the specification?

#### YES

Go to "Component Inspection".



- Go to "2. Check short to ground in power circuit" as follows.
- 2. Check short to ground in power circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect A/C pressure transducer connector, variable swirl control actuator connector, ECM connectors.
  - 3) IG KEY "ON".
  - Measure the voltage between A/C pressure transducer connector terminal 3 or variable swirl control actuator connector terminal 6 and chassis ground.

specification : 0.0V~0.1V

5) Is abnormal voltate measured in this test?



Repair short to battery and go to "Verification of Vehicle Repair".



If the circuit is insulated well and the sensor power supply from ECM is high, replace ECM and go to "Verification of Vehicle Repair".

#### COMPONENT INSPECTION E6229487

- 1. IG KEY "OFF", ENGINE "OFF".
- 2. Disconnect A/C pressure transducer connector and variable swirl control actuator connector.
- 3. Check that sensor connector power supply is within the specification after turning IG KEY "ON".
- 4. Connect A/C pressure transducer connector and variable swirl control actuator connector in turn.

#### DTC TROUBLESHOOTING PROCEDURES

Specification : sensor power supply should not change as connecting A/C pressure transducer connector and variable swirl control actuator connector. (If the change of sensor power supply occur as connecting sensor connector, this means the occurrence of short inside of sensor.)

5. Does change of sensor power supply occur as connecting sensor connector?

#### YES

Replace A/C pressure transducer or variable swirl control actuator.

#### NO

▶ Go to "Verification of Vehicle Repair".

### VERIFICATION OF VEHICLE REPAIR E3AE 13FB

Refer to DTC P0698.

### DTC P0700 TCU REQUEST FOR MIL ON

#### GENERAL DESCRIPTION E1A56511

ECM and TCM give and take various data through CAN communication each other. When the problem of TCM related sensor(input speed sensor, output speed sensor, inhibiter switch, etc.) and actuators(transaxle solenoid valve, etc.) occurs, gear is fixed at 3rd gear position. However, alam device which notifies drivers of the occurrence of TCM related problem directly like "TCM warning lamp". Instead of TCM lamp, including TCM, if power train related problem happens, Engine check lamp turns ON to let drivers recognize the occurrence of power train system(A/T system) related problem.

#### DTC DESCRIPTION E76707C1

P0700 is the code which notifies drivers of the occurrence of TCM related problem indirectly as illuminating engine check lamp. If this code is recorded, Do not check engine but auto transaxle.

ltem	Detecting Condition			Possible Cause
DTC Strategy	<ul> <li>Signal mon</li> </ul>	itoring		
Enable Conditions	Engine "ON"			
ThresholdValue	Engine check lamp ON requirement from TCM			
DiagnosticTime	Immediately			
	Fuel Cut	NO		Problem of TCM system
	EGR Off	NO		
Fail Safe	Fuel Limit	NO		
	MIL	YES		

#### DTC DETECTING CONDITION EA41C285

#### VERIFICATION OF VEHICLE REPAIR E5E4B963

After a repair, it is essential to verify that the fault is corrected.

- 1. After connecting Scantool select "DIAGNOSTIC TROUBLE CODES(DTCs)" mode.
- 2. Clear recorded DTC using Scantool.
- 3. Drive the vehicle within DTC "Enable conditions" in "General information".
- 4. After selecting "DIAGNOSTIC TROUBLE CODES(DTCs)" mode and check if DTC is recorded again.
- 5. Are any DTCs recorded ?

#### YES

Go to the DTC guide of recorded NO. in Scantool.

#### NO

## DTC P0701 TCM STATUS ERROR

### GENERAL DESCRIPTION E898A48C

ECM and TCM give and take various data through CAN communication each other. When the problem of TCM related sensor(input speed sensor, output speed sensor, inhibiter switch, etc.) and actuators(transaxle solenoid valve, etc.) occurs, gear is fixed at 3rd gear position. However, alam device which notifies drivers of the occurrence of TCM related problem directly like "TCM warning lamp". Instead of TCM lamp, including TCM, if power train related problem happens, Engine check lamp turns ON to let drivers recognize the occurrence of power train system(A/T system) related problem.

### DTC DESCRIPTION EC07E58D

P0701 is set when ECM detects TCM problem through CAN communication. Check whether TCM operatures or not.

### DTC DETECTING CONDITION E7F564AF

Item		Detecting	Possible Cause	
DTC Strategy	<ul> <li>Signal moni</li> </ul>	toring		
Enable Conditions	<ul> <li>Engine "ON</li> </ul>	01		
ThresholdValue	TCM failure			
DiagnosticTime	<ul> <li>Immediately</li> </ul>	,		
	Fuel Cut	NO		<ul> <li>TCM failure</li> </ul>
	EGR Off	NO		$\int dx  dx  dx  dx  dx  dx  dx  dx $
Fail Safe	Fuel Limit	NO	an a	
·····	MIL	NO		

### VERIFICATION OF VEHICLE REPAIR E60363CD

After a repair, it is essential to verify that the fault is corrected.

- 1. After connecting Scantool select "DIAGNOSTIC TROUBLE CODES(DTCs)" mode.
- 2. Clear recorded DTC using Scantool.
- 3. Drive the vehicle within DTC "Enable conditions" in "General information".
- 4. After selecting "DIAGNOSTIC TROUBLE CODES(DTCs)" mode and check if DTC is recorded again.
- 5. Are any DTCs recorded ?

### YES

▶ Go to the DTC guide of recorded NO. in Scantool.

### NO

### DTC P0820 NEUTRAL S/W MALFUNCTION

#### GENERAL DESCRIPTION EE44C891

Neutral Gear Switch is installed in M/T vehicle and senses driver's intension to shift gear(driver's intension to drive). ECM recognizes engaged gear based on vehicle speed sensor signal and engine RPM in M/T vehicle. And Black Smoke limiting fuel quantity value varies according to engaged gear. (As higher gear shift is engaged, maximum possible fuel injection quantity increases to raise power generation.) The recognition of engaged gear is available when vehicle speed reachs to 2Km/h - the minimum speed for ECM to detect. When vehicle starts to move after standing for a while and vehicle speed does not reach to 2Km/h, fuel quantity mapping value at neutral gear is adopted to vehicle. Moreover, this phenomenon is more serious when vehicle requires high power generation such as the situation when vehicle is on the slope. To cope with this problem, neutral gear switch which senses driver's intension of starting to move is applied. And fuel injection quantity mapping value suitable for 1st gear is adopted immediately.

### NOTE NOTE

To reduce black smoke produced during rapid acceleration when no load is applied, fuel injection quantity at none load condition is 70% of that at 1st gear.

#### DTC DESCRIPTION E4B02FD9

P0820 is set when 1)gear is engaged at non-neutral positon at engine ON, but clutch signal is not detected. or 2)only neutral signal is detected at above 600RPM or above 80Km/h. for more than 3 sec.. This code is due to open, short to battery or ground in neutral gear switch circuit.


#### DTC DETECTING CONDITION E3C8F4F5

				177
Item		Detecting	Possible Cause	
DTC Strategy	<ul> <li>Signal mon</li> </ul>	itoring		je je Statisticka (normalisticka) Statisticka (normalisticka)
Enable Conditions	During drivi	ing		
ThresholdValue	<ul> <li>Short to Ba</li> <li>short to GN</li> </ul>		pen	a Nortrol goor quitch
DiagnosticTime	• 3.0sec.		<ul> <li>Nertral gear switch component</li> </ul>	
	Fuel Cut	NO		Nertral gear switch circuit
	EGR Off	NO		
Fail Safe	Fuel Limit	NO		
i	MIL	NO		

#### SPECIFICATION E1D9B9CE

Signal Voltage	Neutral Position	Except Neutral Position
11.0V~13.5V	0.0V~0.2V(LOW)	11.0V~13.5V(HIGH)

#### SCHEMATIC DIAGRAM E580BAEA



#### SIGNAL WAVEFORM AND DATA E16F0674

FR	CH	Â	5.	0 1	V	200	) m	S	C	HI	35	.0	Ų	
÷					:		-	-	:		-		1	-
····;	:	•••••		 :	:	:	 :	÷	•••••• •	 :	 :	•••••• •		
	ļ	•••••		j	÷	•••••••				·····				÷
	į;			: 			: 	;	; 					
1	: :			÷	÷	1		:						
Ì					Ì	1								
····;	····•			 :		·			·····					
···· Ge	ar ing	gag	ed			·		· · · · · ·			; ;	: (• • • • • •	: ;	: ;
j	·			1							<u>.</u>	<u>.</u>		<u>.</u>
1					-						: :		·····	 :
	·		N	leu	tral	gea	l r			<b>l</b>				

### Fig.1

Fig 1) 0V at neutral gear position, 12V at any gear position except neutral position.

LGJF006V

### TERMINAL AND CONNECTOR INSPECTION EE2D84D4

- 1. Electrical systems consist of a lot of harness and connectors, poor connection of terminals can cause various problems and damge of component.
- 2. Perform checking procedure as follows.
  - 1) Check damage of harness and terminals : Check terminals for contact resistance, corrosion and deformation.
  - 2) Check connecting condition of ECM and component connector : Check terminal seperation, damage of locking device and connecting condition between terminal and wiring.

#### FLB -382

#### 🛈 ΝΟΤΕ

Disconnect the pin which requires checking at male connector and insert it to the terminal at female connector or checking connecting condition. ( after checking, reconnect the pin at correct position. )

3. Is the problem found?

#### YES

▶ Repair the trouble causing part and go to "Verification of Vehicle Repair".

#### NO

Go to "Signal Circuit Inspection".

#### SIGNAL CIRCUIT INSPECTION EBB9D7F6

- 1. Neutral gear switch Voltage Inspection
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect neutral gear switch connector.
  - 3) Check the voltage of neutral gear switch connector terminal 1.

Specification : 11.5V~13.0V

4) Is the measured voltage within the specification?



Go to "Ground Circuit Inspection".

#### NO

- ▶ Go to "2. Check open in neutral gear switch signal cicuit" as follows.
- 2. Check open in neutral gear switch signal cicuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect neutral gear switch connector and ECM connector.
  - 3) Check Continuity between neutral gear switch connector terminal 1 and ECM connector terminal 57.

specifications : Approx. below 10

4) Is the measured resistance within the specifications ?

#### YES

Repair short to ground in signal circuit and go to "Verification of Vehicle Repair".

#### NO

▶ Repair open in signal circuit and go to "Verification of Vehicle Repair".

### DTC TROUBLESHOOTING PROCEDURES

GROUND CIRCUIT INSPECTION E4CCF1BB

- 1. IG KEY "OFF", ENGINE "OFF".
- 2. Disconnect neutral gear switch connector and ECM connector.
- 3. IG KEY "ON".
- 4. Measure the voltage of neutral gear switch connector terminal 1. [TEST "A"]
- 5. Measure the voltage between neutral gear switch connector terminal 1 and terminal 2. [TEST "B"] (Terminal 1 : Check + prove, terminal 2 : Check - prove)

Specification : [TEST "A"] Voltage - [TEST "B"] Voltage = below 200mV

6. Is the measured voltage within the specification?

### YES

▶ Go to "Component Inspection".

#### NO

When "B" voltage is not detected : Repair open in ground circuit and go to "Verification of Vehicle Repair".
 When the voltage difference between "A" and "B" is above 200mV : Eliminate the causes of excessive resistance and go to "Verification of Vehicle Repair".

#### COMPONENT INSPECTION E50A0B9F

- 1. IG KEY "OFF", ENGINE "OFF".
- 2. Disconnect neutral gear switch connector and ECM connector.
- 3. Check the contituity between neutral gear switch component terminal 1 and 2 as shifting gear lever.

```
specifications : at neutral position : Continuity (below 1.0) at any gear position except neutral position : Discontinuity ( linfinite \Omega )
```



4. Is the measured resistance within the specification?



Go to "Verification of Vehicle Repair".

#### NO

Replace neutral gear switch and go to Verification of Vehicle Repair".

LGJF007A

#### VERIFICATION OF VEHICLE REPAIR EFOCB3C1

After a repair, it is essential to verify that the fault is corrected.

- 1. After connecting Scantool select "DIAGNOSTIC TROUBLE CODES(DTCs)" mode.
- 2. Clear recorded DTC using Scantool.
- 3. Drive the vehicle within DTC "Enable conditions" in "General information".
- 4. After selecting "DIAGNOSTIC TROUBLE CODES(DTCs)" mode and check if DTC is recorded again.
- 5. Are any DTCs recorded ?

#### YES

▶ Go to the DTC guide of recorded NO. in Scantool.

#### NO


System operates within specification.

#### antan tarak

n - Matcher Transcort

### DTC P0830 CLUTCH S/W MALFUNCTION

### COMPONENT LOCATION E09EC339



EWPF008V

#### GENERAL DESCRIPTION EF96B50B

Clutch switch is connected to clutch pedal and transmits clutch operating state to ECM.When clutch pedal is depressed during driving, engine load changes from loaded to none loaded condition. However, ECM regards vehicle to be loaded becuase VSS signal is still inputted to it. therefore, ECM controls none loaded engine with the condition suitable for loaded engine. Accordingly, optimum fuel injection control is not performed then, RPM becomes unstable and smoke is produced. Clutch operation is detected through clutch switch signal. This signal enables ECM to cope with instant change of load condition. Besides, clutch switch signal is used to detect engaged gear with vehicle speed and engine speed.

#### DTC DESCRIPTION E706314B

P0830 is set when no clutch switch signal change is detected 1). within 2 sec. after shifting gear during driving. 2). while gear shifts 4 times at above 10Km/h and 1000rpm. This code is due to 1) clutch switch component failure or 2) open or short in circuit 3) improper height of clutch pedal.

\* ECM recognize ingaged gear with rpm and vehicle speed sensor signal.


### DTC DETECTING CONDITION ED7C2950

ltem		Detecting	Possible Cause	
DTC Strategy	<ul> <li>Signal mon</li> </ul>	itoring		
Enable Conditions	<ul> <li>Engine run</li> </ul>			
ThresholdValue	<ul> <li>No clutch sv 2 sec. after</li> <li>No clutch sv shifted 4 tim</li> </ul>	shifting gea vitch signal	Clutch S/W circuit	
DiagnosticTime	<ul> <li>immediately</li> </ul>	<ul> <li>Clutch S/W component</li> <li>Clutch S/W pedal hight</li> </ul>		
	Fuel Cut	NO		, and a set of a set of
Fail Safe	EGR Off	NO		
	Fuel Limit	NO		
	MIL	NO		

### SPECIFICATION EA444E7B

Condition	Clutch Pedal Depressed	Clutch Pedal Released
Switch Operation	Switch ON	Switch OFF

#### SCHEMATIC DIAGRAM E3C8D248



#### SIGNAL WAVEFORM AND DATA E0F7A736

FR	CH	1 5.0	V		200	mS	3	C	J T	5	0	V	
:		1				:							
·····	·····	····	•••••			·····	····;	•••••	•••••		•••••		
		i						•••••					
						i	i						
		÷			~			امام	05	-			
	·····	····: 			U		ı.po	oai					
						·····		•••••					
			<b>.</b>										
<u></u>	····	;	L			;			l				
Clutc	h pec	dal:ON				:							
110	11.D	ZOOM	<u>ז</u> ה	CUI	38	ME	EMO	1 1	REC	D	ME	NU	1

Fig.1) The waveform of clutch switch when clutch pedal is depressed. The output voltage of clutch pedal is 0V when clutch pedal is depressed and 12V when released.


LGJF004D

### DTC TROUBLESHOOTING PROCEDURES

#### MONITOR SCANTOOL DATA EDCD400A

- 1. Connect scantool to Data Link Cable. (DLC)
- 2. Warm engine up to normal operating temperature.
- 3. Turn "OFF" electrical devices and A/C.
- 4. Select "CLUTCH SWITCH" parameter on the Scantool.

Specification : When clutch switch released : CLUTCH SWITCH : OFF When clutch switch depressed : CLUTCH SWITCH : ON



#### Fig.1

Fig. 1) Check if "CLUTCH SWITCH" parameter changes correctly from "ON" to "OFF" and vice versa as activating clutch pedal.

LGJF004E

### TERMINAL AND CONNECTOR INSPECTION E6E079DB

- 1. Electrical systems consist of a lot of harness and connectors, poor connection of terminals can cause various problems and damge of component.
- 2. Perform checking procedure as follows.
  - 1) Check damage of harness and terminals : Check terminals for contact resistance, corrosion and deformation.
  - 2) Check connecting condition of ECM and component connector : Check terminal seperation, damage of locking device and connecting condition between terminal and wiring.



Disconnect the pin which requires checking at male connector and insert it to the terminal at female connector or checking connecting condition. (after checking, reconnect the pin at correct position.)

3. Is the problem found?



Repair the trouble causing part and go to "Verification of Vehicle Repair".

#### NO

Go to "Signal Circuit Inspection".

#### SIGNAL CIRCUIT INSPECTION EB7B13C0

- 1. Check clutch switch pull-up voltage
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect clutch switch connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of clutch switch connector terminal 1.

Specification : 11.5V~13.0V

5) Is the measured voltage within the specification?

#### YES

▶ Go to "Ground Circuit Inspection".



- Go to "2.Check open in clutch switch signal circuit" as follows.
- 2. Check open in clutch switch signal circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect clutch switch connector and ECM connector.
  - 3) Check continuity between clutch switch connector terminal 1 and ECM connector terminal 79.

specification : Continuity (below  $1.0\Omega$ )

4) Is the measured resistance within the specification?

#### YES

Repair short to ground in signal circuit and go to "Verification of Vehicle Repair".

NO

Repair open in signal circuit and go to "Verification of Vehicle Repair".

#### GROUND CIRCUIT INSPECTION E376734A

1. IG KEY "OFF", ENGINE "OFF".

- 2. Disconnect clutch switch connector.
- 3. Check continuity between clutch switch connector terminal 2 and chassis ground.

specification : Continuity (below  $1.0\Omega$ )

4. Is the measured resistance within the specification?

### YES

▶ Go to "Component Inspection".


### NO

Repair open or poor connection in ground circuit and go to "Verification of Vehicle Repair".

### COMPONENT INSPECTION EBC7E82E

- 1. IG KEY "OFF", ENGINE "OFF".
- 2. Disconnect clutch switch connector.
- 3. Check continuity between clutch switch component terminal 1 and 2 as depressing clutch pedal.

```
Specification : Clutch pedal depressed : Continuity ( below 1.0\Omega ) Clutch pedal released : Discontinuity ( Infinite \Omega )
```



LGJF004I

4. Is the measured resistance within the specification?

### YES

Go to "Verification of Vehicle Repair".

#### NO

After checking height of clutch pedal, if therer is no problem, replace clutch switch and go to "Verification of Vehicle Repair".

### VERIFICATION OF VEHICLE REPAIR EAD4BD23

After a repair, it is essential to verify that the fault is corrected.

- 1. After connecting Scantool select "DIAGNOSTIC TROUBLE CODES(DTCs)" mode.
- 2. Clear recorded DTC using Scantool.
- 3. Drive the vehicle within DTC "Enable conditions" in "General information".
- 4. After selecting "DIAGNOSTIC TROUBLE CODES(DTCs)" mode and check if DTC is recorded again.
- 5. Are any DTCs recorded ?


### YES

▶ Go to the DTC guide of recorded NO. in Scantool.



### DTC P1145 OVERRUN MONITORING ERROR

#### COMPONENT LOCATION E320955F



EWPF602Q

#### GENERAL DESCRIPTION EFAE2959

ECM is activated by power supply. Signals from several sensors, such as CKPS and APS, is inputted to ECM. Comparing inputted signals with control LOGIC saved at micro controller and EEPROM, ECM controlls engine as actuating injectors, solenoids and relays. To guarantee accurate control, ECM performs SELF TEST, DIAGNOSIS of several sensors and actuators. And if serious trouble which affects vehicle performance occurrs, ECM sets DTCs.At certain cases, ECM shuts down whole systems in order to prevent dangerous situation due to incorrect control.

### DTC DESCRIPTION E2F6D81B

melleofficients antige scaloodic midity 2 of

P1145 is set if fuel to injector is not limited(fuel cut disabled) and injector operates when accelerator pedal is released after acceleraton(when vehicle coasts). This code is due to the case that ECM fails to cut power of injector operating system inside of ECM.

Item		Detecting	Condition	Possible Cause
DTC Strategy	<ul> <li>Software m</li> </ul>	onitoring		
Enable Conditions	During driv	ing	ан на траний на	
ThresholdValue	<ul> <li>Overrun las (fuel injection driver's interest</li> </ul>	on performe	ids. d regardless with	
DiagnosticTime	<ul> <li>Immediately</li> </ul>	1		ECM internal error
	Fuel Cut	YES		
Fail Safe	EGR Off	NO		
i ali Sale	Fuel Limit	NO		
	MIL	NO	1	

### DTC DETECTING CONDITION E1962D6F

#### COMPONENT INSPECTION E7DBF719

- 1. ECM Component Inspection
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect ECM.
  - 3) Replace ECM, check if abnormal operations disappear.
  - 4) If problems are corrected, replace ECM.

#### VERIFICATION OF VEHICLE REPAIR E3E9757F

After a repair, it is essential to verify that the fault is corrected.

- 1. After connecting Scantool select "DIAGNOSTIC TROUBLE CODES(DTCs)" mode.
- 2. Clear recorded DTC using Scantool.
- 3. Drive the vehicle within DTC "Enable conditions" in "General information".
- 4. After selecting "DIAGNOSTIC TROUBLE CODES(DTCs)" mode and check if DTC is recorded again.
- 5. Are any DTCs recorded ?


#### YES

▶ Go to the DTC guide of recorded NO. in Scantool.

#### NO

### DTC P1185 FUEL PRESSURE MONITORING-MAXIMUM PRESSURE EXCEEDED

#### COMPONENT LOCATION E21DE22F



EWPF603C

#### GENERAL DESCRIPTION ECB4EB83

As inputted rail pressure sensor signal, ECM of Commom rail diesel engine controls fuel metering unit(MPROP-intergrated with high press. pump) and rail pressure control valve(PCV-integrated with common rail) in order to maintain optimum rail pressure according to current engine rpm and load. However when the problem that leads rail pressure to out of target value intended by ECM occurs due to mechanical or electronical reason, ECM shuts engine down and sets DTC by limiting fuel (stops injector operation) in order to prevent engine from being controlled abnormally. "rail pressure monitoring error" is the DTC which diagnose 1) supplying state of low pressure fuel and 2) mechanical operating conditions of high pressure pump and 3). RPCV indirectly based on RPS output voltage and RPS duty. thus, repair relavant to this DTC requires mechanics the total understand of fuel system.

#### DTC DESCRIPTION EE67B8C6

P1185 is set when 1)rail press. is higher than target rail press. by 200bar in condition that rail press. is controlled by fuel metering unit(MPROP) or 2)rail press. exceeds maximum limiting value. This code is due to 1)more than intended fuel supply to common rail or 2)poor return of fuel supplied to common rail or 3)short to high voltage line in fuel press. sensor.

### DTC DETECTING CONDITION EE6B9CC5

ltem		Possible Cause		
DTC Strategy	<ul> <li>Voltage mor</li> </ul>	nitoring		
Enable Conditions	Engine runr	ning		
ThresholdValue	more than 2 operating co • Rail pressur	00bar at fue ondition 40 re is above a par) at fuel n	maximum limiting netering unit(MPROP)	<ul> <li>fuel metering unit (open stuck)</li> <li>rail pressure control valve (close stuck)</li> <li>Rail pressure sensor</li> </ul>
DiagnosticTime	<ul> <li>Refer to three</li> </ul>	eshold Value	(Output fixed at high	
	Fuel Cut	NO		voltage line)
	EGR Off	NO		
Fail Safe	Fuel Limit	YES		
	MIL	YES		

#### MONITOR SCANTOOL DATA E9B61A34

- 1. Monitoring rail pressure data
  - 1) Connect Scantool to Data Link Connector (DLC).
  - 2) Warm engine up to normal operating temperature.
  - 3) Turn "OFF" electrical devices and A/C.
  - 4) Monitor "FUEL PRESSURE MEASURED", "FUEL PRESSURE-TARGET", "RAIL PRESS. REGULATOR1", "INJ. PUMP REGULATOR" parameter on the Scantool.

Specification : Rail pressure at idle : FUEL PRESSURE MEASURED : similar to "FUEL PRESSURE-TARGET" FUEL PRESSURE-TARGET : 28 ± 5 Mpa RAIL PRESS. REGULATOR1 : 20 ± 5% INJ. PUMP REGULATOR : 40 ± 5%




Fig.1) Monitor "FUEL PRESSURE MEASURED" at idle after warming engine up.


LGJF010R


Check if "FUEL PRESSURE MEASURED" data is similar to "FUEL PRESSURE-TARGET". Not only former two data but also "RAIL PRESS. REGULATOR1" and "INJ. PUMP REGULATOR" should be monitored carefully. Although "FUEL PRESSURE MEASURED" is similar to "FUEL PRESSURE-TARGET", if "RAIL PRESS. REG-ULATOR1" and "INJ. PUMP REGULATOR" is out of specification, it means wear, leakage, stuck of fuel system.

- 2. Monitoring rail pressure data at acceleration(loading condition).
  - 1) Connect Scantool to Data Link Connector (DLC).
  - 2) Warm engine up to normal operating temperature.
  - 3) Turn "OFF" electrical devices and A/C.
  - 4) Monitor "FUEL PRESSURE MEASURED", "RAIL PRESS. REGULATOR1", "INJ. PUMP REGULATOR" parameter on the Scantool.

#### SPECIFICATION :

	Idle(without load)	Accelerating(stall test)	Diagnosis
INJ. PUMP REGULATOR	38 ± 5%	32 ± 5%	duty decreases
FUEL PRESSURE MEASURED	28.5 ± 5 Mpa	145 ± 10 Mpa	press. increases
RAIL PRESS. REGULATOR1	19 ± 5%	48 ± 5%	duty increases





# Fig.1) The position of curser on the graph represents idle data. Fig.2) Data during acceleration(stall test).


# LGJF010S

## 🗊 ΝΟΤΕ

The waveform of fuel metering unit installed at high pressure pump(fuel detecting MPROP) shows 38% duty at idle, duty drops to approx. 32% at acceleration to raise rail pressure. Duty drop means the decrease of current.  $\rightarrow$  Fuel delivered to common rail increases as current drops.

The waveform of rail pressure control valve installed at common rail shows 19% duty at idle, duty rises to approx. 48% at acceleration to raise rail pressure. Duty rise means the increase of current.

 $\rightarrow$  If current rises, the returning quantity of fuel deliverd to common rail decreases and common rail pressure rises.



LGJF014Q

### VERIFICATION OF VEHICLE REPAIR E6DD34F3

After a repair, it is essential to verify that the fault is corrected.

- 1. After connecting Scantool select "DIAGNOSTIC TROUBLE CODES(DTCs)" mode.
- 2. Clear recorded DTC using Scantool.
- 3. Drive the vehicle within DTC "Enable conditions" in "General information".
- 4. After selecting "DIAGNOSTIC TROUBLE CODES(DTCs)" mode and check if DTC is recorded again.
- 5. Are any DTCs recorded ?

#### YES

Go to the DTC guide of recorded NO. in Scantool.

#### NO

### DTC P1186 FUEL PRESSURE MONITORING-MINIMUM PRESSURE AT ENGINE SPEED TOO LOW

### COMPONENT LOCATION E9C302EC

Refer to DTC P1185.

### GENERAL DESCRIPTION E47BDA33

Refer to DTC P1185.

### DTC DESCRIPTION EDD033A5

P1186 is set when rail press. is lower than target rail press. by 200bar for more than 1.0 sec. in condition that rail press. is controlled by fuel metering unit(MPROP). This code is due to 1)less than intended fuel supply to common rail or 3)excessive return of fuel supplied to common rail or 3)short to low voltage line in fuel press. sensor.

### DTC DETECTING CONDITION E80D29AC

ltem		Detecting	Possible Cause	
DTC Strategy	<ul> <li>Voltage mo</li> </ul>	nitoring		
Enable Conditions	• Engine run	ning	化乙基酸白色医尿 建合合物 化	
ThresholdValue One year	<ul> <li>Rail pressu than 200ba operating c</li> </ul>	<ul> <li>fuel metering unit (close stuck)</li> <li>rail pressure control valve</li> </ul>		
DiagnosticTime	• 1.0 sec.		an ing tang tang ang ang ang ang ang ang ang ang ang	(open stuck)
	Fuel Cut	NO	ia: 81 is grounder. Mi is demontro weing ext	<ul> <li>Rail pressure sensor (Output fixed at low</li> </ul>
Fail Safe	EGR Off	NO	na funta dun de la deserva de la deserva.	voltage line)
	Fuel Limit	YES		·····································
	MIL	YES		

### MONITOR SCANTOOL DATA E74E7CCA

Refer to DTC P1185.


### VERIFICATION OF VEHICLE REPAIR EAG983FF

Refer to DTC P1185.

્ય

#### MT/AT ENCODING **DTC P1586**

### COMPONENT LOCATION ETDC5C71



#### **GENERAL DESCRIPTION** E4A71EB7

Because both A/T and M/T fuel control map is inputted in one type of ECM and selecting option is possible, one type is applied to both A/T and M/T option. When ECM is installed to vehicle, A/T and M/T recognition is performed by ECM automatically as checking whether ground line(ECM connector C201-2 terminal 81) is grounded or opened.(A/T and M/T recognition is performed every IG KEY ON process.) If A/T, M/T recognition is not fulfilled well or any error occurs during the process, engine power generation is not sufficient and glow lamp on cluster blinks.

A/T : ECM connector C201-2 terminal 81 is grounded M/T : ECM connector C201-2 terminal 81 is opened(no wiring exists)


### DTC DESCRIPTION E7707E54

P1586 is set when recognized A/T, M/T data based on ECM C201-2 terminal 81 state(grounded or opened) is not readable or writable at EEP ROM. This code is due to ECM failure.

### DTC DETECTING CONDITION E97A1E6D

Item		Detecting	Possible Cause	
DTC Strategy	software me	onitoring		
Enable Conditions	• IG KEY "O	N"		
ThresholdValue	<ul> <li>A/T, M/T lea (when data ECM is imp</li> </ul>	writing on I		
DiagnosticTime	• 4.0 sec.		ECM component failure	
	Fuel Cut	NO		
Fail Safe	EGR Off	NO		
	Fuel Limit	NO	<ul> <li>Glow Lamp blinks.</li> </ul>	
	MIL	NO		

### SCHEMATIC DIAGRAM E19C6DCD



### COMPONENT INSPECTION E9FBD360

- 1. ECM Component Inspection
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect ECM.
  - 3) Replace ECM, check if abnormal operations disappear.
  - 4) If problems are corrected, replace ECM.

### VERIFICATION OF VEHICLE REPAIR E09766C0

After a repair, it is essential to verify that the fault is corrected.

- 1. After connecting Scantool select "DIAGNOSTIC TROUBLE CODES(DTCs)" mode.
- 2. Clear recorded DTC using Scantool.
- 3. Drive the vehicle within DTC "Enable conditions" in "General information".
- 4. After selecting "DIAGNOSTIC TROUBLE CODES(DTCs)" mode and check if DTC is recorded again.
- 5. Are any DTCs recorded ?

### YES

▶ Go to the DTC guide of recorded NO. in Scantool.



System operates within specification.

## DTC P1587 CAN COMMUNICATION ERROR (MT/AT RECOGNITION ERROR)

#### COMPONENT LOCATION EBB1DD05

Refer to DTC P1586.

### GENERAL DESCRIPTION E5465A6F

Refer to DTC P1586.

### DTC DESCRIPTION E53EC7E9

P1587 is set when ECM is recognized as 1)A/T but CAN communication signal is not transmitted from TCM 2)M/T but CAN communication signal is transmitted from TCM. After checking if A/T, M/T auto recognition terminal is normal for each vehicle option, if no problem is detected, check poor connection in CAN communication circuit or CAN communication problem of TCM.

### DTC DETECTING CONDITION E942AB03

ltem		Detecting	Possible Cause	
DTC Strategy	<ul> <li>Voltage mo</li> </ul>	nitoring		
Enable Conditions	• Engine run		en ener and standing the s	
ThresholdValue	<ul> <li>When TCM opposite to at ECM is of</li> </ul>	recognized	• A/T, M/T recognition terminal circuit	
DiagnosticTime	• 1.0 sec.	6	CAN communication     linecircuit	
	Fuel Cut	NO	en Gondal (1997), 1997 (1997), 1997 (1997), 1997 (1997), 1997 (1997), 1997 (1997), 1997 (1997), 1997 (1997), 1 Na Gondal (1997), 1997 (1997), 1997 (1997), 1997 (1997), 1997 (1997), 1997 (1997), 1997 (1997), 1997 (1997), 19	• I Civi component failure
Fail Safe	EGR Off	NO	Glow Lamp blinks.	ECM component failure
	Fuel Limit	NO	• Glow Lamp blinks.	
	MIL	NO		이 가지 않는 것 같은 것을 가 있다. 

### SCHEMATIC DIAGRAM E2FE7FD9

Refer to DTC P1586.

### TERMINAL AND CONNECTOR INSPECTION EB4BE343

- 1. Electrical systems consist of a lot of harness and connectors, poor connection of terminals can cause various problems and damge of component.
- 2. Perform checking procedure as follows.
  - 1) Check damage of harness and terminals : Check terminals for contact resistance, corrosion and deformation.
  - 2) Check connecting condition of ECM and component connector : Check terminal seperation, damage of locking device and connecting condition between terminal and wiring.

### **NOTE**

Disconnect the pin which requires checking at male connector and insert it to the terminal at female connector for checking connecting condition. (after checking, reconnect the pin at correct position.)

FLB -401

3. Is the problem found?

### YES

▶ Repair the trouble causing part and go to "Verification of Vehicle Repair".

### NO

▶ Go to "Power Circuit Inspection".

### POWER CIRCUIT INSPECTION E106A442

- 1. IG KEY "OFF", ENGINE "OFF".
- 2. Disconnect ECM.
- 3. Check continuity between ECM connector(C201-2) terminal 81 and chassis ground.

specification : Discontinuity (Infinite  $\Omega$ )

4. Is A/T, M/T auto recognition terminal grounded well?

### YES

Go to "Check CAN communication line". Refer to "U0101" DTC guide for checking CAN communication line.

### NO

Repair open in circuit and go to "Verification of Vehicle Repair".

### VERIFICATION OF VEHICLE REPAIR EBAE32AF

Refer to DTC P1586.

# DTC P1588 SIGNAL CHANGE THROUGH MT/AT LINE (DURING ENGINE RUNNING)

### COMPONENT LOCATION EAF25C6F

Refer to DTC P1586.

#### GENERAL DESCRIPTION EB04131A

Refer to DTC P1586.

### DTC DESCRIPTION E983337E

P1588 is set when the signal from A/T, M/T auto recognition terminal(ECM C201-2 terminal 81) changes during engine run. This code is due to open in terminal for A/T option, grounded condition for M/T option. This code is normally arises from A/T option vehicle. Check the grounding condition of A/T, M/T auto recognition terminal.

### DTC DETECTING CONDITION E3BED57E

Item		Detecting	Possible Cause	
DTC Strategy	<ul> <li>Voltage more</li> </ul>	nitoring	Angle Con	
Enable Conditions	Engine run			
ThresholdValue	<ul> <li>A/T, M/T au at engine C</li> </ul>		on signal changes	
DiagnosticTime	• 1.0 sec.		17 an by that the second	A/T, M/T recognition     terminal circuit
	Fuel Cut	NO		ECM component failure
	EGR Off	NO		LINHY TO MOLARITARY
Fail Safe	Fuel Limit	NO	<ul> <li>Glow Lamp blinks.</li> </ul>	$\frac{2m}{2}$ $\frac{1}{2}$ $\frac{2m}{2}$
	MIL	NO		

### SCHEMATIC DIAGRAM EFA7C972

Refer to DTC P1586.

### TERMINAL AND CONNECTOR INSPECTION E28D7DD8

- 1. Electrical systems consist of a lot of harness and connectors, poor connection of terminals can cause various problems and damge of component.
- 2. Perform checking procedure as follows.
  - 1) Check damage of harness and terminals : Check terminals for contact resistance, corrosion and deformation.
  - 2) Check connecting condition of ECM and component connector : Check terminal seperation, damage of locking device and connecting condition between terminal and wiring.

### **NOTE**

Disconnect the pin which requires checking at male connector and insert it to the terminal at female connector for checking connecting condition. (after checking, reconnect the pin at correct position.)

3. Is the problem found?

### YES

▶ Repair the trouble causing part and go to "Verification of Vehicle Repair".

#### NO

▶ Go to "Ground Circuit Inspection".

### GROUND CIRCUIT INSPECTION E7B71D95

- 1. IG KEY "OFF", ENGINE "OFF".
- 2. Disconnect ECM.
- 3. Check continuity between ECM connector(C201-2) terminal 81 and chassis ground.

specification : Discontinuity (Infinite  $\Omega$ )

4. Is A/T, M/T auto recognition terminal grounded well?

### YES

▶ Go to "Component Inspection".

#### NO


▶ Repair open in circuit and go to "Verification of Vehicle Repair".

### VERIFICATION OF VEHICLE REPAIR E5D36FD8

Refer to DTC P1586.

## DTC P1610 NON-IMMOBILIZER-EMS CONNECTED TO AN IMMOBILIZER

### COMPONENT LOCATION E09EC331



EWPF602Q

### GENERAL DESCRIPTION EOEB1548

SMARTRA type immobilizer is an anti-theft device which allows engine to turn ON only when the key recognized in Transponder is inserted in the key hall. After checking that the inserted key is registered, immobilizer module transmits engine ON permitting signal to ECM. If engine is tried to turn ON when nonregistered key is inserted in the key hall or no key signal is detected (buglary), immobilizer module transmits engine ON prohibitting order to ECM and injector operation is disabled.

### \*SMARTRA : SMARt TRansponder Antenna

DTC DESCRIPTION EBCD90F3


P1610 is set when former ECM is equipped to immobilizer applied vehicle. This code exists to prevent different type of ECM from being equipped.Refer to immobilizer system DTC guide for more detailed information.

Item		Detecting	Possible Cause	
DTC Strategy	<ul> <li>Signal moni</li> </ul>	itoring		
Enable Conditions	• IG KEY "01	N"		
ThresholdValue	Non-Immob	ilizer-EMS		
DiagnosticTime	e		Refer to DTC guide of	
	Fuel Cut	NO		Immobilizer system
	EGR Off	NO	_	
Fail Safe	Fuel Limit	NO		and a second
	MIL	NO		

### DTC DETECTING CONDITION ED32B027

## DTC P1634 AUX. HEATER MALFUNCTION

### COMPONENT LOCATION E3237AAE



EWPF603D

### GENERAL DESCRIPTION EFC9FC70

Because thermal efficiency of electronically controlled diesel engine is higher than that of gasoline engine, heat loss to cylinder wall is lower. This enables electronically controlled diesel engine to generate high power and have high fuel efficiency. However in other point of view, due to low engine coolant temperature, heating efficiency lowered then, driver is unsatisfied with the heating. To cope with this situation, PTC heater is installed in coolant line and it raises heating efficiency and raise coolant temperature.ECM activates heater relay 1 and 2 when engine coolant temperature is below 70°C and engine speed is above 700RPM.

\* Heater relay operation inhibited condition : engine coolant temperature above 70°C, engine speed below 700RPM(to prevent battery discharge)

### DTC DESCRIPTION E7784043

P1634 is set when excessive current or "0"A is detected in heater relay control circuit for more than 1.0 sec. at heater relay operating condition. This code is due to 1)open or 2)short to battery or ground in heater relay control circuit or 3)component problem.

### DTC DETECTING CONDITION E25B8954


Item	Detecting Condition			Possible Cause
DTC Strategy	Voltage monitoring			
Enable Conditions	<ul> <li>IG KEY "ON relay operat</li> </ul>		PTC heater relay #1control	
ThresholdValue	<ul> <li>Short to bat</li> </ul>	ttery		
DiagnosticTime	• 1.0 sec.			circuit
namen dan pana di kana di kana di kana da kana di kana 	Fuel Cut	NO		<ul> <li>Heater relay component</li> </ul>
	EGR Off	NO		
Fail Safe	Fuel Limit	NO		
	MIL	NO		

### DTC TROUBLESHOOTING PROCEDURES

#### SPECIFICATION E6F4F057

Heater relay coil resistance	PTC heater operating temperature	PTC heater operating condition
52±5Ω (20℃)	Coolant temp. beolw 70℃ (Intake air temp.below 5℃)	Engine speed above 700RPM (Battery voltage above 8.9V)

### SCHEMATIC DIAGRAM EA9F04B1



### MONITOR SCANTOOL DATA EA21D6A2

- 1. Connect Scantool to Data Link Connector (DLC).
- 2. ENGINE "ON".(Engine coolant temp. below 70°C, Intake air temp. below 5°C)
- 3. Blower switch "ON".
- Monitor "Auxiliary Heater(PTC)" parameter on the Scantool.
   (As soon as turning engine ON "Auxiliary Heater(PTC)" parameter turns "ON". Check if the parameter turns "OFF" after engine is warmed up.)

specification : Engine coolant temp. below 70°C (Intake air temp. below 5°C) : "Auxiliary Heater(PTC)" "ON" Engine coolant temp. above 70°C : "Auxiliary Heater(PTC)" "OFF"

		1.2 CURRENT DA	NTA 33	/54			
	Γ			4			
×	BATTERY V	OLTAGE	14.4 V				
⋇	FUEL PRES	SURE MEASURED	28.5 MPa				
×	RAIL PRES	S. REGULATOR1	22.7 %				
×	AIR MASS	PERCYLINDER	346.9mg/s <sup>.</sup>	ŧ			
¥	AIR TEMPE	RATURE SENSOR	12.4 °C	8			
¥	WATER TEM	IP. SENSOR	50.7 °C				
×	Auxiliary	Heater(PTC)	ON				
×	ENGINE SP	EED SENSOR	887 rpm				
				Ţ			
	FIX	FULL	GRPH	D			
đ	<u>JEI</u>		-				
	1	.5 ACTUATION T	EST 03/	<b>'17</b>			
		- 40	· · · · ·				
A	UXILIARY	HEATER RELAY					
D	URAT I ON	UNTIL STOP KE	Ł				
M	ETHOD	ACTIVATION	<u> </u>				
CONDITION IG. KEY ON							
ENGINE RUNNING							
PRESS [STRT], IF YOU ARE READY ?							
STRT STOP							
đ	.3						

	1.2 CURRENT DATA 33/	54
		Å
¥	BATTERY VOLTAGE 14.4 V	
×	FUEL PRESSURE MEASURED 28.5 MPa	
×	RAIL PRESS. REGULATOR1 22.7 %	
×	AIR MASS PERCYLINDER 346.9mg/st	
×	AIR TEMPERATURE SENSOR 42.5 °C	abbus .
×	WATER TEMP.SENSOR 92.7 °C	
×	Auxiliary Heater(PTC) OFF	
×	ENGINE SPEED SENSOR 794 rpm	
		7
	FIX FULL GRPH RCRD	
	FIX FULL GRPH RCRD	

Fig.2

- Fig.1) "Auxiliary Heater(PTC)" operates only when Intake air temp. is below 5°C and Engine coolant temp. is below 70°C. "ON" state of "Auxiliary Heater(PTC)" lasts till Engine coolant temp. reaches 70°C.
- Fig.2) "Auxiliary Heater(PTC)" turns "OFF" as soon as engine coolant temp. reaches 70 °C.
- Fig.3) If it is difficult to cool engine when current condition does not meat "Auxiliary Heater(PTC)" operating condition, check relay operation using "Auxiliary Heater(PTC)" on the Scantool.

LGJF013K

### TERMINAL AND CONNECTOR INSPECTION E3E8FAB3

- 1. Electrical systems consist of a lot of harness and connectors, poor connection of terminals can cause various problems and damge of component.
- 2. Perform checking procedure as follows.
  - 1) Check damage of harness and terminals : Check terminals for contact resistance, corrosion and deformation.
  - 2) Check connecting condition of ECM and component connector : Check terminal seperation, damage of locking device and connecting condition between terminal and wiring.

### 🛈 ΝΟΤΕ

Disconnect the pin which requires checking at male connector and insert it to the terminal at female connector for checking connecting condition. (after checking, reconnect the pin at correct position.)

3. Is the problem found?

### YES

Repair the trouble causing part and go to "Verification of Vehicle Repair".

### NO

▶ Go to "Power Circuit Inspection".

### POWER CIRCUIT INSPECTION EFD43E3B

- 1. Check HOT AT ALL TIMES power circuit voltage
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect PTC heater relay #1.
  - 3) Measure the voltage of PTC heater relay #1 connector terminal 3.

Specification: 11.5V~13.0V

4) Is the measured voltage within the specification?

### YES

Go to "2. Check IG KEY "ON" power circuit voltage" as follows.

100	-	
	6	192
<b>N</b>		
	100	

Repair Fusible link box 50A PTC heater#1 fusible link and related circuit and go to "Verification of Vehicle Repair".

- 2. Check IG KEY "ON" power circuit voltage
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect PTC heater relay #1.
  - 3) IG KEY "ON".

4) Measure the voltage of PTC heater relay #1 connector terminal 4.

Specification: 11.5V~13.0V

5) Is the measured voltage within the specification?

### YES

Go to "Control Circuit Inspection".

### NO

Repair E/R FUSE & RELAY BOX 15A INJ fuse and related circuit and go to "Verification of Vehicle Repair".


### CONTROL CIRCUIT INSPECTION EE 148738

1. Check control circuit monitoring voltage

### FLB -410

Specification :  $52\pm5 \ \Omega \ (20 \ C)$ 

	1)	IG KEY "ON", ENGINE "OFF".	
	2)	Disconnect PTC heater relay #1.	
	3)	IG KEY "ON".	$[t_{ij}]_{ij}$
	4)	Measure the voltage of PTC heater relay #1connector terminal 1.	
S	pecif	ication : 8.0V~10.0V	
	<b>~</b> `\		
	5)	Is the measured voltage within the specification?	
		YES	
		Go to "Component Inspection".	
		When no value is detected : Go to "2. Check open in control circuit".	an di kana sa br>Kana sa kana sa
		When high voltage is detected : Repair short to battery in control c Repair".	
2.	Ch	eck open in control circuit	
<i>6</i>	1)	IG KEY "OFF", ENGINE "OFF".	n an she she ta ta
	,		
	2)	Disconnect PTC heater relay #1 and ECM connector.	
	3)	Check continuity between PTC heater relay #1 connector terminal 1 and	ECM connector terminal 94.
s	becifi	cation: Continuity (below 1.0Ω)	<u>a - Eleksko Stal Stak Arsek (</u> a
	4)	Is the measured resistance within the specification?	日本 (素句構成) 特定 1997 日本
	.,		an ar Grann a <sup>r C</sup> aracter a Ca
		Repair short to ground and go to "Verification of Vehicle Repair".	n 1999 (m. 1996) - Ch
		ΝΟ	a de la construir de la constru La construir de la construir de
		▶ Repair open in signal circuit and go to "Verification of Vehicle Repair"	Beneral Beneral Strate (St. 1997)
cc	MP	ONENT INSPECTION EA298A67	
1.	Che	eck PTC heater relay #1 component coil resistance	apak katali sa sa paka si
	1)	IG KEY "OFF", ENGINE "OFF".	
	2)	Disconnect PTC heater relay #1.	
	3)	Measure the resistance of PTC heater relay #1 component coil	
	- /		그는 방안에 가지 않는 것이 들었어?



4) Is the measured resistance within the specification?




▶ Go to "2. Check PTC heater relay #1 component operation" as follows.

### NO

- Replace PTC heater relay #1 and go to "Verification of Vehicle Repair".
- 2. Check PTC heater relay #1 component operation
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect PTC heater relay #1.
  - 3) Supplies random B+ and ground to coil sides of PTC heater relay #1. (terminal 85, 86)
  - 4) Check continuity between PTC heater relay #1 terminal 30 and terminal 87.

specification : When power is supplied : Continuity ( below  $1.0\Omega$  ) When power is not supplied : Discontinuity ( Infinite  $\Omega$  )



5) Is the measured resistance within the specification?



Go to "Verification of Vehicle Repair".

LGJF013Q

FLB -411

LGJF013P

### NO

- ▶ Replace PTC heater relay #1 and go to "Verification of Vehicle Repair".
- \* Repeat this process 2~3 times.

### VERIFICATION OF VEHICLE REPAIR E3864F5F

After a repair, it is essential to verify that the fault is corrected.

- 1. After connecting Scantool select "DIAGNOSTIC TROUBLE CODES(DTCs)" mode.
- 2. Clear recorded DTC using Scantool.
- 3. Drive the vehicle within DTC "Enable conditions" in "General information".
- 4. After selecting "DIAGNOSTIC TROUBLE CODES(DTCs)" mode and check if DTC is recorded again.
- 5. Are any DTCs recorded ?

### YES


▶ Go to the DTC guide of recorded NO. in Scantool.

### NO

System operates within specification.

### DTC P1652 IG S/W MALFUNCTION

### COMPONENT LOCATION E32F375C



LGJF013D

### GENERAL DESCRIPTION E21BF1BA

When a driver turns on IG KEY, IG KEY ON signal is inputted to ECM C201-1 connector terminal 28 through IG KEY switch. This signal initializes(boots) ECM accordingly, main relay operates. Main relay supplies powers for ECM, sensors and actuators in order to enable engine to start. When IG KEY ON signal is shut off during turning engine OFF, ECM stops injector operation then engine turns OFF. Approx. after 12 sec., ECM shuts OFF main relay and system turns OFF.

### DTC DESCRIPTION EE23C584


When the condition that IG KEY ON signal turns OFF while ECM, to which IG signal inputted, is initialized (booting, Approx. 25ms is required), IG KEY switch error is recognized and P1652 is set (monitored only once every IG KEY ON initialization process). This code is due to poor connection in IG KEY ON signal circuit.

Item		Detecting	Possible Cause	
DTC Strategy	<ul> <li>Voltage more</li> </ul>	nitoring		
Enable Conditions	IG KEY "OI	N"		
ThresholdValue	<ul> <li>No signal th</li> </ul>	rough IG li		
DiagnosticTime	<ul> <li>Immediately</li> </ul>	/	<ul> <li>IG KEY "ON"signal circuit</li> </ul>	
	Fuel Cut	NO		• IG KEY switch
Fail Safa	EGR Off	NO		
Fail Safe	Fuel Limit	NO		
	MIL	NO		and the second second second second

### DTC DETECTING CONDITION EOODBFE7

LGJF013F

### SCHEMATIC DIAGRAM EB6C82E5



### SIGNAL WAVEFORM AND DATA E5497F41

31	CH 6	5.0	V	2.0	S	CH B	5.0	V
÷				1		1	1	
		<u> </u>						
····	i lG l	ŒY-sigi	n <del>al</del>	••••	·····		····•	! <u>}</u>
	<b>.</b>		· · · · · · · · ·				····•	ŀ
	ļ		······				····	
	<u></u>							÷
<u>.</u>	Mai	n relay.						ļ
			• •					
	ſ							
	ſ							
	ръ							

Fig.1) The waveforms of IG KEY "ON" signal and main relay operation are measured simultaneously. Check poor connection at the point of IG KEY "ON".

TERMINAL AND CONNECTOR INSPECTION ED78DA2B

- 1. Electrical systems consist of a lot of harness and connectors, poor connection of terminals can cause various problems and damge of component.
- 2. Perform checking procedure as follows.
  - 1) Check damage of harness and terminals : Check terminals for contact resistance, corrosion and deformation.

2) Check connecting condition of ECM and component connector : Check terminal seperation, damage of locking device and connecting condition between terminal and wiring.

## 

Disconnect the pin which requires checking at male connector and insert it to the terminal at female connector for checking connecting condition. ( after checking, reconnect the pin at correct position. )

3. Is the problem found?



Repair the trouble causing part and go to "Verification of Vehicle Repair".


### NO

▶ Go to "Signal Circuit Inspection".

### SIGNAL CIRCUIT INSPECTION EF079C93

- 1. IG KEY "OFF", ENGINE "OFF".
- 2. Connect Oscilloscope to ECM connector terminal 28 with ECM connector being connected.
- 3. Check IG KEY "ON" signal waveform at IG KEY "ON".

specification : The signals indicate poor connection should not exist at IG KEY "ON" range.



EWPF006B

4. Does abnormal waveform generate at IG KEY "ON" range?

### YES

Repair IG KEY S/W and poor connection of In-pannel junction box 10A ECU fuse related circuit and go to "Verification of Vehicle Repair".

NO

- ▶ Go to "Verification of Vehicle Repair".
- \* Repeat this process 2~3 times.

### VERIFICATION OF VEHICLE REPAIR EA5BD44A

After a repair, it is essential to verify that the fault is corrected.

- 1. After connecting Scantool select "DIAGNOSTIC TROUBLE CODES(DTCs)" mode.
- 2. Clear recorded DTC using Scantool.
- 3. Drive the vehicle within DTC "Enable conditions" in "General information".
- 4. After selecting "DIAGNOSTIC TROUBLE CODES(DTCs)" mode and check if DTC is recorded again.
- 5. Are any DTCs recorded ?

### YES


Go to the DTC guide of recorded NO. in Scantool.

### NO

System operates within specification.

#### **DTC P1670 INJECTOR CLASSIFICATION ERROR**

### COMPONENT LOCATION EFO8956F



#### **GENERAL DESCRIPTION** E7756132

IQA (Injector Quantity Adjustment) means adjusting fuel injection quantity difference between injectors which occurs inevitably at manufacturing process as allotting serial number consists of 7 letters to each injectors. Inputting IQA code of injectors installed in each cylinder to ECM, ECM recognizes the fuel injection quantity difference between each injectors. ECM adjusts every injector to have same fuel injecting characteristic as recognizing specific fuel injection map which is different for each serial number.

IQA Mark	enter a serie de la constance d
	439年10月1日 2 - 20110月1月1日 11 - 20110月1日 11 - 20110 11 - 2
	化成果的工作性 正正 翻譯種或工作
	·····································
	网络心觉星子公 一会 发展了自己的原作
ł	
	LGJF004T
DTC DESCRIPTION EFEAF892	11月1日,1月1日,1月1日,1月1日,1月1日,1月1日,1月1日,1月1

#### DESCRIPTION EFEAF892

P1670 is set when 'IQA input error' or 'saving error' occurs in EEP ROM where IQA data is saved. This code is due to ECM internal error.

•

LGJF004U

### DTC DETECTING CONDITION EDA26AEC

Item	Detecting Condition			Possible Cause
DTC Strategy	EEPROM monitorting			
Enable Conditions	• IG KEY "OI	۷"		
ThresholdValue	<ul> <li>Input error,</li> <li>IQA code in</li> </ul>	-		
DiagnosticTime	Immediately			ECM internal error
	Fuel Cut	NO	Engine Check Lamp	
	EGR Off	NO		
Fail Safe	Fuel Limit	NO	blinks.	
	MIL	YES		

### COMPONENT INSPECTION E5469896

- 1. Check injector class input state
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Using Scantool, select "ENGINE CONTROL" "INJECTOR CORRECTION".
  - 3) Check currently inputted "injector class input state".

Specification : IQA data inputted to ECM should be identical with IQA data of injector.

INJECTOR 1	567MY 86	
INJECTOR 2	8HH4416	
INJECTOR 3	7PY26SB	
INJECTOR 4	71¥66AC	
KEY AND IN	CYLINDER I IPUT THE DAT	

4) Are both data identical?



▶ Go to "Verification of Vehicle Repair".

NO

▶ If error is not corrected after reperforming "INJECTOR CORRECTION" procedure, replace ECM.

### **NOTE**

Input iQA data of injector mounted at cylinder at replacing ECM using scantool.

If this process is not performed, engine check lamp on cluster blinks and normal engine power generation is impossible.

### VERIFICATION OF VEHICLE REPAIR E6D503C7

After a repair, it is essential to verify that the fault is corrected.

- 1. After connecting Scantool select "DIAGNOSTIC TROUBLE CODES(DTCs)" mode.
- 2. Clear recorded DTC using Scantool.
- 3. Drive the vehicle within DTC "Enable conditions" in "General information".
- 4. After selecting "DIAGNOSTIC TROUBLE CODES(DTCs)" mode and check if DTC is recorded again.
- 5. Are any DTCs recorded ?

### YES

▶ Go to the DTC guide of recorded NO. in Scantool.

### NO

System operates within specification.

## DTC P1671 CHECK-SUM ERROR

### COMPONENT LOCATION E7B03D90

Refer to DTC P1670.

### GENERAL DESCRIPTION E2B96A31

Refer to DTC P1670.

### DTC DESCRIPTION E71C3AD2

P1671 is set when IQA data is not inputted to ECM during initialization of ECM.

### DTC DETECTING CONDITION EEE66EA7

Item	Detecting Condition			Possible Cause	
DTC Strategy	• EEPROM m	nonitorting		A. S.	
Enable Conditions	• IG KEY "OI	٧"			
ThresholdValue	<ul> <li>IQA code is</li> </ul>	not inputte	d to ECM.	a the second second second second	
DiagnosticTime	<ul> <li>Immediately</li> </ul>	· · · · ·			
Fail Safe	Fuel Cut	NO		<ul> <li>IQA not inputted to ECM</li> </ul>	
	EGR Off	NO	Engine Check Lamp		
	Fuel Limit	NO	blinks.		
	MIL	YES	· · · ·	•	

### COMPONENT INSPECTION EB8B 1705

- 1. Check injector class input state
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Using Scantool, select "ENGINE CONTROL" "INJECTOR CORRECTION".
  - 3) Check currently inputted "injector class input state".

Specification : IQA data inputted to ECM should be identical with IQA data of injector.

### DTC TROUBLESHOOTING PROCEDURES

INJECTOR	1	567MYS6	
INJECTOR :	z	8HH4416	
INJECTOR :	3	7PY26SB	
INJECTOR 4	4	71Y66AC	

- SELECT THE CYLINDER BY SHIFT+ARROW KEY AND INPUT THE DATA BY FI~FG KEY AND PRESS [ENTER] KEY. [ABCD] [EFGH] [JKL] [MNOP] [QR-U] [VW-Z]

4) Are both data identical?



▶ Go to "Verification of Vehicle Repair".

NO

▶ If error is not corrected after reperforming "INJECTOR CORRECTION" procedure, replace ECM.

### NOTE

Input iQA data of injector mounted at cylinder at replacing ECM using scantool. If this process is not performed, engine check lamp on cluster blinks and normal engine power generation is impossible.

## VERIFICATION OF VEHICLE REPAIR


Refer to DTC P1670.

LGJF004U

FLB -421

### DTC P2009 INTAKE MANIFOLD RUNNER CONTROL CIRCUIT LOW(BANK 1)

#### COMPONENT LOCATION E8CB7963



GENERAL DESCRIPTION EB857349


Variable swirl control actuator consists of DC motor and motor position sensor(potentiometer) which detects the position of swirl valve. As closing one intake port out of two at idle and below 3000RPM, swirl effect is taken on intake air. This swirl effect increases air flow rate.

However, because air flow rate is too high, swirl effect is neglectable thus, swirl valve is opened for efficient intake of air.

To prevent swirl valve and shaft form being stuck by foreign metarial, and to learn max opening and closing position of swirl valve, it is fully opened and closed twice at turning engine OFF.

#### ≫Swirl

The air flow which indicates Intake air swirls with respect to the axis passing through the centre of piston with lengthdirection by intake port which is eccentric from the centre of combustion chamber.



LGJF011E


#### DTC DESCRIPTION E4983FF9

P2009 is set when open or short to ground in variable swirl actuator driving motor (+) output terminal. The polarity of (+) and (-) lines shift each other in accordance with the condition of swirl valve(opened or closed) thus, checking both (+) and (-) circuits is required.

### DTC DETECTING CONDITION E1617256


ltem	Detecting Condition			Possible Cause
DTC Strategy	<ul> <li>Voltage mor</li> </ul>	nitoring		
Enable Conditions	Engine runr	ning		
ThresholdValue	<ul><li>Short to gro</li><li>Open in mo</li></ul>			
DiagnosticTime	• 200ms	-	<ul> <li>Variable swirl valve motor</li> </ul>	
	Fuel Cut	NO	Swirl valve opened at	circuit
	EGR Off	NO		
Fail Safe	Fuel Limit	NO	<ul> <li>variable swirl control actuator failure</li> </ul>	
	MIL	NO		

### SPECIFICATION E4E6AF59



LGJF011F

### SCHEMATIC DIAGRAM EACFADC9



### SIGNAL WAVEFORM AND DATA E3EB10C4




Fig. 1) Waveform when variable swirl valve closed at idle. Terminal 1 is (+) and 2 is (-).

Fig. 2) Waveform when variable swirl valve opened at above 3000RPM. Terminal 1 is (-) and 2 is (+).

Fig. 3) Waveform of variable swirl control actuator motor position sensor at the point of turning engine OFF.

4.3V at swirl valve closed and 0.3V at swirl valve opened. Swirl valve is opened and closed twice at engine "OFF".

LGJF011H

### TERMINAL AND CONNECTOR INSPECTION E2FODEDA

- 1. Electrical systems consist of a lot of harness and connectors, poor connection of terminals can cause various problems and damge of component.
- 2. Perform checking procedure as follows.
  - 1) Check damage of harness and terminals : Check terminals for contact resistance, corrosion and deformation.
  - 2) Check connecting condition of ECM and component connector : Check terminal seperation, damage of locking device and connecting condition between terminal and wiring.

### **NOTE**

Disconnect the pin which requires checking at male connector and insert it to the terminal at female connector for checking connecting condition. (after checking, reconnect the pin at correct position.)

3. Is the problem found?

### YES

Repair the trouble causing part and go to "Verification of Vehicle Repair".

NO

▶ Go to "Control Circuit Inspection".

#### CONTROL CIRCUIT INSPECTION EE52044D

- 1. Check short to ground in control circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect variable swirl control actuator connector and ECM connector.
  - 3) Check continuity between variable swirl control actuator connector terminal 1(or 2) and chassis ground.

Specification : Discontinuity(Infinite  $\Omega$ )

4) Is the measured resistance within the specification?

#### YES

Go to "2.Check open in motor circuit" as follows.



- Repair short to ground in variable swirl control actuator motor circuit and go to "Verification of Vehicle Repair".
- 2. Check open in motor circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect variable swirl control actuator connector and ECM connector.
  - 3) Check continuity between variable swirl control actuator connector terminal 1 and ECM connector terminal 60.
  - Check continuity between variable swirl control actuator connector terminal 2 and ECM connector terminal 30.

Specification : Continuity (below 1.0Ω)

5) Is the measured resistance within the specification?

### YES

▶ Go to "Component Inspection".

#### NO

Repair open in control circuit and go to "Verification of Vehicle Repair".


### COMPONENT INSPECTION EBD7638A

- 1. Check motor coil resistance
  - 1) IG KEY "OFF", ENGINE "OFF".

LGJF011K

- 2) Disconnect variable swirl control actuator connector.
- 3) Measure the resistance between variable swirl control actuator component terminal 1 and 2.

#### Specification : $15.0 \pm 3 \Omega$ (20°C)



4) Is the measured resistance within the specification?

### YES

Go to "2. Check motor operation".

### NO

- Replace variable swirl control actuator assy'.
- 2. Check motor operation
  - 1) IG KEY "ON", ENGINE "ON".
  - 2) Keep engine at idle state.
  - 3) Monitor the waveform of variable swirl control actuator terminal 1 and 2 with two channel oscilloscope.
  - 4) Accelerating engine to above 3000RPM, let variable swirl control actuator be opened(operates).

Specification : Refer to Signal Waveform & Data "Fig.1)", " Fig.2)".

5) Does variable swirl control actuator operate correctly?

### YES

Go to "Verification of Vehicle Repair".

### NO

Replace variable swirl control actuator assy' and go to "Verification of Vehicle Repair".

### VERIFICATION OF VEHICLE REPAIR EF2C6A61

After a repair, it is essential to verify that the fault is corrected.

- 1. After connecting Scantool select "DIAGNOSTIC TROUBLE CODES(DTCs)" mode.
- 2. Clear recorded DTC using Scantool.
- 3. Drive the vehicle within DTC "Enable conditions" in "General information".

- 4. After selecting "DIAGNOSTIC TROUBLE CODES(DTCs)" mode and check if DTC is recorded again.
- 5. Are any DTCs recorded ?

### YES

▶ Go to the DTC guide of recorded NO. in Scantool.

### NO

System operates within specification.

# DTC P2010 INTAKE MANIFOLD RUNNER CONTROL CIRCUIT HIGH(BANK 1)

### COMPONENT LOCATION E0138514

Refer to DTC P2009.

### GENERAL DESCRIPTION E927704B

Refer to DTC P2009.


### DTC DESCRIPTION E45DA346

P2010 is set when short to battery in variable swirl control actuator driving motor (+) output terminal. The polarigy of (+) and (-) lines shift each other in accordance with the condition of swirl valve(opened or closed) thus, checking both (+) and (-) circuits is required.

### DTC DETECTING CONDITION E14DAD01

ltem	Detecting Condition			Possible Cause
DTC Strategy	<ul> <li>Voltage mo</li> </ul>	nitoring	enter 1000 creater.	en el composition de la companya de la composition de la composition de la composition de la composition de la
Enable Conditions	<ul> <li>Engine run</li> </ul>	ning		
ThresholdValue	<ul> <li>Short to ba</li> </ul>	ttery in motor	output terminal	n an
DiagnosticTime	• 200ms		· 四00000万花的小子 网络二口之	Variable swirl valve motor
	Fuel Cut	NO		circuit
Eall Oafa	EGR Off	NO	<ul> <li>Swirl valve opened at</li> </ul>	
Fail Safe to note	Fuel Limit	NOIOM	variable swirl control actuator failure	a yasheo isi hushe usay R. K
	MIL	NO		

### SPECIFICATION E90D3733



LGJF011F

### SCHEMATIC DIAGRAM E0F1D3F0

Refer to DTC P2009.

### SIGNAL WAVEFORM AND DATA EAD59089

Refer to DTC P2009.

### TERMINAL AND CONNECTOR INSPECTION EC270BC5

Refer to DTC P2009.

#### CONTROL CIRCUIT INSPECTION EC58E35A

- 1. Check control circuit voltage
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect variable swirl control actuator connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of variable swirl control actuator connector terminal 1 and 2.

Specification: 0.0V~0.1V		양학물일 같은 정소 사람이 있는 것이다. 	- 建物 建碳化 化学 选载运行 的第三人称单数
	The second se	The state of the s	

5) Is the measured voltage within the specification?

#### YES

Repair short to battery in variable swirl control actuator motor circuit and go to "Verification of Vehicle Repair".

#### NO

Check "2. Check open in motor circuit" as follows.

#### 2. Check open in motor circuit

- 1) IG KEY "OFF", ENGINE "OFF".
- 2) Disconnect variable swirl control actuator connector and ECM connector.
- 3) Check continuity between variable swirl control actuator connector terminal 1 and ECM connector terminal 60.
- 4) Check continuity between variable swirl control actuator connector terminal 2 and ECM connector terminal 30.

Specification : Continuity (below  $1.0\Omega$  )

5) Is the measured resistance within the specification?

### YES

▶ Go to "Component Inspection".




Repair open in control circuit and go to "Verification of Vehicle Repair".

### COMPONENT INSPECTION EDDDF6AE

- 1. Check motor coil resistance
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect variable swirl control actuator connector.
  - 3) Measure the resistance between variable swirl control actuator component terminal 1 and 2.

Specification :  $15.0 \pm 3 \Omega$  (20°C)



LGJF011K

4) Is the measured resistance within the specification?

### YES

▶ Go to "2. Check motor operation".



- Replace variable swirl control actuator assy'.
- 2. Check motor operation
  - 1) IG KEY "ON", ENGINE "ON".
  - 2) Keep engine at idle state.
  - 3) Monitor the waveform of variable swirl control actuator terminal 1 and 2 with two channel oscilloscope.
  - 4) Accelerating engine to above 3000RPM, let variable swirl control actuator be opened(operates).

Specification : Refer to Signal Waveform & Data "Fig.1)", " Fig.2)".

5) Does variable swirl control actuator operate correctly?

#### YES

Go to "Verification of Vehicle Repair".



Replace variable swirl control actuator assy' and go to "Verification of Vehicle Repair".

### VERIFICATION OF VEHICLE REPAIR E33AA265

Refer to DTC P2009.

# DTC P2015 INTAKE MANIFOLD RUNNER POSITION SENSOR/SWITCH CIRCUIT RANGE/PERFORMANCE(BANK 1)

#### COMPONENT LOCATION EB76BD5D

Refer to DTC P2009.

#### GENERAL DESCRIPTION EFB6DA35

Refer to DTC P2009.


#### DTC DESCRIPTION E8059CB4

P2015 is set if variable swirl valve position fails to reach target position within 3 sec. while ECM already outputted motor driving signal(swirl valve fully open or close signal). This code is due to 1)swirl valve shaft stuck or problem of link device or 2)variable swirl valve position sensor output value stuck.

#### DTC DETECTING CONDITION EDE88E26

Item		Detecting	Possible Cause	
DTC Strategy	<ul> <li>Voltage mor</li> </ul>	nitoring		
Enable Conditions	• IG KEY "Of	٧"		and a star of the starter
ThresholdValue	<ul> <li>Variable swi mechanicall</li> </ul>		erating motor	<ul> <li>Variable swirl valve shaft stuck</li> </ul>
DiagnosticTime	• 3.0 sec.		na ann an tha an tha an	<ul> <li>Variable swirl valve link</li> </ul>
	Fuel Cut	NO		device problem <ul> <li>Variable swirl valve position</li> </ul>
	EGR Off	NO	Swirl valve opened at	sensor component
Fail Safe	See Fuel Limito	NO	variable swirl control	1997年1月1日日日日日1月1日日 1997年日日日日日日日日日日日日日日日日日日日日日日日日日日日日日日日日日日日
	MIL	NO	1	and the second

#### SPECIFICATION E54DB30B



LGJF011F

#### SCHEMATIC DIAGRAM EA5D89A7

Refer to DTC P2009.

#### SIGNAL WAVEFORM AND DATA EODBFC7E

Refer to DTC P2009.

#### COMPONENT INSPECTION E803256B

- 1. Check variable swirl control actuator link device operation
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Wait for approx. 20 sec. and check Main relay turns "OFF".
  - 3) Disconnect variable swirl control actuator connector.
  - 4) Pressing variable swirl control actuator link with hands, check if shaft stuck, tightness or problem of link device is detected.

Specification : variable swirl control actuator link device should move smoothly.

5) Does variable swirl control actuator move slowly?




Go to "2. Check motor coil resistance".



Replace stuck or too tight parts of component(intake manifold assy' or swirl actuator) and go to "Verification of Vehicle Repair".

- 2. Check motor coil resistance
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect variable swirl control actuator.
  - 3) Measure the resistance between variable swirl control actuator component terminal 1 and 2.

Specification :  $15.0 \pm 3 \Omega$  (20°C)



4) Is the measured resistance within the specification?

LGJF011K

#### YES

▶ Go to "3. Check variable swirl control actuator position sensor resistance".

NO

- ▶ Replace variable swirl control actuator and go to "Verification of Vehicle Repair".
- 3. Check variable swirl control actuator position sensor resistance
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect variable swirl control actuator.
  - Measure the resistance of variable swirl control actuator component terminal 3,4,5 referring "Terminal resistance table" as follows.

Specification : Terminal resistance table

	Detecting	Resistance(KΩ 20℃)			Component
	terminal	valve fully opend	valve fully closed	Characteristic	connector shape
	3(power)- 5(ground)	4.47±0.1KΩ	4.47±0.1KΩ	stable	
variable swirl control actuator position sensor	3(power)- 4(signal)	4.81±0.1KΩ	0.85±0.1KΩ	resistance drops	(CIERID)
position sensor	4(signal)- 5(ground)	0.75±0.1KΩ	4.71±0.1KΩ	resistance rises	LGJF011L Source (Station

4) Is the measured resistance within the specification?

# YES

▶ Go to "4. Check motor operation" as follows.

NO

- Replace variable swirl control actuator assy' and go to "Verification of Vehicle Repair".
- 4. Check motor operation
  - 1) IG KEY "ON", ENGINE "ON".
  - 2) Keep engine at idle state.
  - 3) Monitor the waveform of variable swirl control actuator terminal 1 and 2 with two channel oscilloscope.
  - 4) Accelerating engine to above 3000RPM, let variable swirl control actuator be opened(operates).

Specification : Refer to Signal Waveform & Data "Fig.1)", " Fig.2)".

5) Does variable swirl control actuator operate correctly?

# YES

Go to "5. Check variable swirl control actuator position sensor operation".

#### NO

- ▶ Replace variable swirl control actuator assy' and go to "Verification of Vehicle Repair".
- 5. Check variable swirl control actuator position sensor operation
  - 1) IG KEY "ON", ENGINE "ON".
  - 2) Keep engine at idle state.
  - 3) Monitor the waveform of variable swirl control actuator terminal 4 with oscilloscope.
  - 4) Turning off engine, monitor the waveform of variable swirl control actuator at the point of operation stop.

Specification : Refer to Signal Waveform & Data "Fig.3)"

5) Does variable swirl control actuator and position sensor operations are OK?

#### YES

▶ Go to "Verification of Vehicle Repair".

#### NO

▶ Replace variable swirl control actuator assy' and go to "Verification of Vehicle Repair".

#### VERIFICATION OF VEHICLE REPAIR E5845692

Refer to DTC P2009.

# DTC P2016 INTAKE MANIFOLD RUNNER POSITION SENSOR/SWITCH **CIRCUIT LOW(BANK 1)**

#### COMPONENT LOCATION EE54D523

Refer to DTC P2009.

#### **GENERAL DESCRIPTION** EEA490ED

Refer to DTC P2009.


#### DTC DESCRIPTION E0ABE6D6

P2016 is set when variable swirl valve position sensor output voltage below 0.18V is detected for more than 0.6 sec. This code is due to open in power circuit or short to ground in signal circuit.

#### DTC DETECTING CONDITION EA21CBA9

Item	Detecting Condition			Possible Cause
DTC Strategy	<ul> <li>Voltage monitoring</li> </ul>			
Enable Conditions	• IG KEY "ON"			
ThresholdValue			inimum value( below 180mV )	
DiagnosticTime	• 600ms	· · · · · · · · · · · · · · · · · · ·		<ul> <li>Variable swirl valve position sensor circuit</li> </ul>
	Fuel Cut	NO	. "Gra	<ul> <li>Variable swirl valve position</li> </ul>
Eail Oafa	EGR Off	NO	<ul> <li>Swirl valve opened at</li> </ul>	sensor component
Fail Safe	Fuel Limit	NO	actuator failure	reader waard
	MIL	NO	1	netta e contra de parte de la contra de la c

#### SPECIFICATION E2CE55F0



#### LGJF011F

#### SCHEMATIC DIAGRAM E68F11BB

Refer to DTC P2009.

#### SIGNAL WAVEFORM AND DATA E694C2C3

Refer to DTC P2009.

#### TERMINAL AND CONNECTOR INSPECTION E1161AB8

- 1. Electrical systems consist of a lot of harness and connectors, poor connection of terminals can cause various problems and damge of component.
- 2. Perform checking procedure as follows.
  - 1) Check damage of harness and terminals : Check terminals for contact resistance, corrosion and deformation.
  - 2) Check connecting condition of ECM and component connector : Check terminal seperation, damage of locking device and connecting condition between terminal and wiring.

## 🗊 ΝΟΤΕ

Disconnect the pin which requires checking at male connector and insert it to the terminal at female connector for checking connecting condition. (after checking, reconnect the pin at correct position.)

3. Is the problem found?

#### YES

Repair the trouble causing part and go to "Verification of Vehicle Repair".

#### NO

Go to "Power Circuit Inspection".

#### POWER CIRCUIT INSPECTION E899BE4E

- 1. Check power circuit voltage
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect variable swirl control actuator connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of variable swirl control actuator connector terminal 3.

Specification: 4.8V~5.1V

5) Is the measured voltage within the specification?

## YES

Go to "Signal Circuit Inspection".



Repair open in power circuit and go to "Verification of Vehicle Repair".

#### SIGNAL CIRCUIT INSPECTION EC 19A97A

1. Check signal circuit voltage

#### DTC TROUBLESHOOTING PROCEDURES

- 1) IG KEY "OFF", ENGINE "OFF".
- 2) Disconnect variable swirl control actuator connector.
- 3) IG KEY "ON".
- 4) Measure the voltage of variable swirl control actuator connector terminal 4.

Specification : 4.8V~5.1V

5) Is the measured voltage within the specification?



Go to "Component Inspection".



- Go to "2. Check short to ground in signal circuit" as follows.
- 2. Check short to ground in signal circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect variable swirl control actuator connector and ECM connector.
  - 3) Check continuity between variable swirl control actuator connector terminal 4 and chassis ground.

Specification : Discontinuity(Infinite Ω) (Σαριτικόνου διατογαναλλακαρά με μάρτε μουστάλιας

4) Is the measured resistance within the specification? polition but adjusted in the adjusted and

## YES

▶ Go to "Component Inspection".

#### NO

Repair short to ground in signal circuit and go to "Verification of Vehicle Repair".

#### COMPONENT INSPECTION E99DFF43

- 1. Check variable swirl control actuator position sensor resistance
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect variable swirl control actuator.
  - 3) Measure the resistance of variable swirl control actuator component terminal 3,4,5 referring "Terminal resistance table" as follows.

Specification : Terminal resistance table

Detecting	Resistance	(KΩ 20℃)		Component
terminal	valve fully opend	valve fully closed	Characteristic	connector shape

#### **FUEL SYSTEM**

	3(power)- 5(ground)	4.47±0.1KΩ	4.47±0.1KΩ	stable	
variable swirl control actuator position sensor	3(power)- 4(signal)	4.81±0.1KΩ	0.85±0.1KΩ	resistance drops	(12345)
position senser	4(signal)- 5(ground)	0.75±0.1KΩ	4.71±0.1KΩ	resistance rises	LGJF011L

4) Is the measured resistance within the specification?

#### YES

> "2. Check variable swirl control actuator position sensor operation".



- Replace variable swirl control actuator assy' and go to "Verification of Vehicle Repair".
- 2. Check variable swirl control actuator position sensor operation
  - 1) IG KEY "ON", ENGINE "ON".
  - 2) Keep engine at idle state.
  - 3) monitor the waveform of variable swirl control actuator terminal 4 with oscilloscope.
  - 4) Turning off engine, monitor the waveform of variable swirl control actuator at the point of operation stop.

Specification : Refer to Signal Waveform & Data "Fig.3)"

5) Does variable swirl control actuator and position sensor operations are OK?

#### YES

▶ Go to "Verification of Vehicle Repair".

#### NO

▶ Replace variable swirl control actuator assy' and go to "Verification of Vehicle Repair".

#### VERIFICATION OF VEHICLE REPAIR E87199C1

Refer to DTC P2009.

# DTC P2017 INTAKE MANIFOLD RUNNER POSITION SENSOR/SWITCH CIRCUIT HIGH(BANK 1)

#### COMPONENT LOCATION E5B3A019

Refer to DTC P2009.

#### GENERAL DESCRIPTION E3249335

Refer to DTC P2009.


#### DTC DESCRIPTION EB2E7708

P2017 is set when variable swirl valve position sensor output voltage above 4.9V is detected for more than 0.6 sec. This code is due to 1)open in signal circuit or ground circuit or 2)short to battery in power circuit or signal circuit.

# DTC DETECTING CONDITION E786EFB2

ltem		Detecting	Possible Cause	
DTC Strategy	<ul> <li>Voltage mor</li> </ul>	nitoring		
Enable Conditions	• IG KEY "OI	N" M No. 19		
ThresholdValue	<ul> <li>Output volta above 4900</li> </ul>		ninimum value(	<ul> <li>Variable swirl valve position</li> </ul>
DiagnosticTime	• 600ms			sensor circuit
	Fuel Cut	soo,NO <sub>isiris</sub>	V to consettnew" at ap lune the	Variable swirl valve position     sensor component
Fail Safe	EGR Off	NO	<ul> <li>Swirl valve opened at</li> </ul>	
	Fuel Limit	NO	variable swirl control actuator failure	
	MIL	NO	g æ 7	n Nemperatur, presidente en est

#### SPECIFICATION EBC93E0E



LGJF011F

#### SCHEMATIC DIAGRAM E3627E52

Refer to DTC P2009.

#### SIGNAL WAVEFORM AND DATA EA1D5EBD

Refer to DTC P2009.

#### TERMINAL AND CONNECTOR INSPECTION E10EB70C

- 1. Electrical systems consist of a lot of harness and connectors, poor connection of terminals can cause various problems and damge of component.
- 2. Perform checking procedure as follows.
  - 1) Check damage of harness and terminals : Check terminals for contact resistance, corrosion and deformation.
  - 2) Check connecting condition of ECM and component connector : Check terminal seperation, damage of locking device and connecting condition between terminal and wiring.

## 🗊 ΝΟΤΕ

Disconnect the pin which requires checking at male connector and insert it to the terminal at female connector for checking connecting condition. (after checking, reconnect the pin at correct position.)

#### 3. Is the problem found?

#### YES

Repair the trouble causing part and go to "Verification of Vehicle Repair".

#### NO

Go to "Power Circuit Inspection".

#### POWER CIRCUIT INSPECTION EE03F891

- 1. Check power circuit voltage
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect variable swirl control actuator connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of variable swirl control actuator connector terminal 3.

Specification : 4.8V~5.1V

5) Is the measured voltage within the specification?



Go to "Signal Circuit Inspection".



Repair open in power circuit and go to "Verification of Vehicle Repair".

ನಗಳು ನಿರ್ದೇಶನ ನಗಳ ಸಂಕಾರಗಳು

#### SIGNAL CIRCUIT INSPECTION EBA14C57

- 1. Check signal circuit voltage
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect variable swirl control actuator connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of variable swirl control actuator connector terminal 4.

Specification : 4.8V~5.1V

5) Is the measured voltage within the specification?

#### YES

▶ Go to "Ground Circuit Inspection".

#### NO

- Go to "2. Check open in signal circuit" as follows.
- 2. Check open in signal circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect variable swirl control actuator connector and ECM connector.
  - 3) Check continuity between variable swirl control actuator connector terminal 4 and ECM connector terminal 56.

Specification : Discontinuity(Infinite  $\Omega$ )

4) Is the measured resistance within the specificaiton?

## YES

Go to "Ground Circuit Inspection".



Repair open in signal circuit and go to "Verification of Vehicle Repair".

#### GROUND CIRCUIT INSPECTION E66DFF16

- 1. IG KEY "OFF", ENGINE "OFF".
- 2. Disconnect variable swirl control actuator connector.
- 3. IG KEY "ON".
- 4. Measure the voltage of variable swirl control actuator connector terminal 3. [TEST "A"]
- 5. Measure the voltage between variable swirl control actuator connector terminal 3 and 5. [TEST "B"] (terminal 3 : Check + prove, terminal 5 : Check prove)

Specification : [TEST "A"] Voltage - [TEST "B"] Voltage = below 200mV

6. Is the measured voltage within the specification?

#### YES

▶ Go to "Component Inspection".

NO

When "B" voltage is not detected : Repair open in ground circuit and go to "Verification of Vehicle Repair".
 When the voltage difference between "A" and "B" is above 200mV : Eliminate the causes of excessive resistance and go to "Verification of Vehicle Repair".

#### COMPONENT INSPECTION EOD7A96F

- 1. Check variable swirl control actuator position sensor resistance
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect variable swirl control actuator.

3) Measure the resistance of variable swirl control actuator component terminal 3,4,5 referring "Terminal resistance table" as follows.

Specification : Terminal resistance table

	utb. 4 4 *	Resistance	(KΩ 20℃)		Component
n Maria ang kabupatèn kabupatèn kabupatèn kabupatèn kabupatèn kabupatèn kabupatèn kabupatèn kabupatèn kabupatèn Kabupatèn kabupatèn k	Detecting terminal	valve fully opend	valve fully closed	Characteristic	connector shape
	3(power)- 5(ground)	4.47±0.1KΩ	4.47±0.1KΩ	stable	
variable swirl control actuator position sensor	3(power)- 4(signal)	4.81±0.1KΩ	0.85±0.1KΩ	resistance drops	(12314)5)
position sensor	4(signal)- 5(ground)	0.75±0.1KΩ	4.71±0.1KΩ	resistance rises	LGJF011L

4) Is the measured resistance within the specification?



"2. Check variable swirl control actuator position sensor operation".

#### NO

- Replace variable swirl control actuator assy' and go to "Verification of Vehicle Repair".
- 2. Check variable swirl control actuator position sensor operation
  - 1) IG KEY "ON", ENGINE "ON".
  - 2) Keep engine at idle state.
  - 3) monitor the waveform of variable swirl control actuator terminal 4 with oscilloscope.
  - 4) Turning off engine, monitor the waveform of variable swirl control actuator at the point of operation stop.

Specification : Refer to Signal Waveform & Data "Fig.3)"

5) Does variable swirl control actuator and position sensor operations are OK?

# YES

▶ Go to "Verification of Vehicle Repair".




Replace variable swirl control actuator assy' and go to "Verification of Vehicle Repair".

# VERIFICATION OF VEHICLE REPAIR E96AC2C4

Refer to DTC P2009.

# DTC P2111 THROTTLE FLAP VACCUM MODULATOR- CIRCUIT HIGH

#### COMPONENT LOCATION EC09A183



EWPF603F

#### GENERAL DESCRIPTION EA996009

As closing or opening vacuum line from vacuum pump which is installed at the end of cam shaft, with the method of duty control, Throttle Flap Actuator controls throttle flap valve when engine is turning OFF. When turning engines OFF, Throttle flap valve cuts intake air to prevent overrun phenomena. (In spite of turning engine OFF, engine does not stop and runs for a while due to rotating inertia of engine and fuel leakage at injector nozzle.) To check its operation, watch if it operate when turning engine OFF.

#### DTC DESCRIPTION E7386104

P2111 is set when excessive current in throttle flap actuator is detected for more than 0.11 sec. this code is due to short to battery in control circuit or internal short of actuator component.


#### DTC DETECTING CONDITION EF638DAD

Item	Detecting Condition		Condition	Possible Cause
DTC Strategy	<ul> <li>Voltage more</li> </ul>	nitoring		
Enable Conditions	IG KEY "OI	• IG KEY "ON"		
ThresholdValue	<ul> <li>Short to ba</li> </ul>	Short to battery		
DiagnosticTime	• 110ms			• TFA circuit
	Fuel Cut	NO		<ul> <li>TFA component</li> </ul>
	EGR Off	YES		
Fail Safe	Fuel Limit	NO		
	MIL	NO		

#### SPECIFICATION E1D0627F

Throttle flap actuator component resistance	Th <del>r</del> ottle flap actuator operating Hz	Throttle flap actuator operating duty
23.8~31.3Ω (20℃)	300Hz	38%(no vacuum)~90%(vacuum)

#### SCHEMATIC DIAGRAM E75A9D9D



EWPF006L

SIGNAL WAVEFORM AND DATA E8184986

NOTOHARME ROTORMMOD (MAL LUPICITY)




Fig.1) Waveform of throttle flap actuator without throttle flap operation(idle) : At IG KEY "ON", ENGINE "ON", 38% duty is outputted continuously.

Fig.2) Waveform of throttle flap actuator with throttle flap operation(engine "OFF") : At IG KEY "OFF", 90% duty is outputted for about 1 sec.

LGJF010X

# MONITOR SCANTOOL DATA E1B9C53C

1. Connect Scantool to Data Link Connector (DLC).

- 2. Warm engine up to normal operating temperature.
- 3. Turn "OFF" electrical devices and A/C.
- 4. Monitor "INLET THROTTLE ACTU." parameter on the Scantool.

Specification : "ON" except the operation of throttle flap "OFF" with the operation of throttle flap




Fig 1) The duty of "INLET THROTTLE ACTU." is 94.5% at IG KEY "ON" and ENGINE "ON". The duty of "INLET THROTTLE ACTU." is 9.4% at IG KEY "OFF" and ENGINE "OFF".

```
LGJF010Y
```

#### TERMINAL AND CONNECTOR INSPECTION EA362FAD

- 1. Electrical systems consist of a lot of harness and connectors, poor connection of terminals can cause various problems and damge of component.
- 2. Perform checking procedure as follows.
  - 1) Check damage of harness and terminals : Check terminals for contact resistance, corrosion and deformation.
  - 2) Check connecting condition of ECM and component connector : Check terminal seperation, damage of locking device and connecting condition between terminal and wiring.

#### 🛈 ΝΟΤΕ

Disconnect the pin which requires checking at male connector and insert it to the terminal at female connector for checking connecting condition. (after checking, reconnect the pin at correct position.)

3. Is the problem found?

#### YES

Repair the trouble causing part and go to "Verification of Vehicle Repair".

#### NO

▶ Go to "Power Circuit Inspection".

#### POWER CIRCUIT INSPECTION E9CA99E0

- 1. Check power circuit voltage
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect Throttle flap actuator.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of Throttle flap actuator connector terminal 2.

Specification: 11.5V~13.0V

5) Is the measured voltage within the specification?

## YES

▶ Go to "Control Circuit Inspection".

#### NO

▶ Repair E/R FUSE & RELAY BOX 15A INJ fuse and related circuit and go to "Verification of Vehicle Repair".

#### CONTROL CIRCUIT INSPECTION E196CECB

- 1. Check monitoring voltage in control circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect throttle flap actuator connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of throttle flap actuator connector terminal 1.

specification: 3.2V~3.7V

5) Is the measured voltage within the specification?

## YES

Go to "Component Inspection".



When voltage is not detected : Go to "2. Check open in control circuit" as follows.
 When high voltage is detected : Repair short to battery in control circuit and go to "Verification of Vehicle Repair".

- 2. Check open in control circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect throttle flap actuator connector and ECM connector.
  - 3) Check continuity between throttle flap actuator connector terminal 1 and ECM connector terminal 90.

LGJF011C

specification : Continuity ( below  $1.0\Omega$  )

4) Is the measured resistance within the specification?

#### YES

Repair short to ground in control circuit and go to "Verification of Vehicle Repair".




Repair open in control circuit and go to "Verification of Vehicle Repair".

#### COMPONENT INSPECTION E95BE967

- 1. Check throttle flap actuator component resistance
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect throttle flap actuator.
  - 3) Check the resistance of throttle flap actuator.

Specification : 23.8~31.3Ω (20℃)



4) Is the measured resistance within the specification?

#### YES

▶ Go to "Verification of Vehicle Repair".

#### NO

Replace throttle flap actuator and go to "Verification of Vehicle Repair".

#### VERIFICATION OF VEHICLE REPAIR EA30F5E0

After a repair, it is essential to verify that the fault is corrected.

- 1. After connecting Scantool select "DIAGNOSTIC TROUBLE CODES(DTCs)" mode.
- 2. Clear recorded DTC using Scantool.

#### DTC TROUBLESHOOTING PROCEDURES

- 3. Drive the vehicle within DTC "Enable conditions" in "General information".
- 4. After selecting "DIAGNOSTIC TROUBLE CODES(DTCs)" mode and check if DTC is recorded again.
- 5. Are any DTCs recorded ?

# YES

▶ Go to the DTC guide of recorded NO. in Scantool.

# NO

System operates within specification.

i S

# DTC P2112 THROTTLE FLAP VACCUM MODULATOR- CIRCUIT LOW

COMPONENT LOCATION E797C8FD

Refer to DTC P2111.

#### GENERAL DESCRIPTION E05F64D9

Refer to DTC P2111.

#### DTC DESCRIPTION E1FF1410

P2112 is set when "0"A in throttle flap actuator is detected for more than 0.11 sec. this code is due to 1)open or short to ground in control circuit or 2)internal open in actuator component.

#### DTC DETECTING CONDITION E165B178

ltem	Detecting Condition		Condition	Possible Cause
DTC Strategy	<ul> <li>Voltage mor</li> </ul>	Voltage monitoring		
Enable Conditions	• IG KEY "ON"			
ThresholdValue	Short to GND, Wiring open		pen	
DiagnosticTime	• 110ms			TFA circuit
	Fuel Cut	NO		TFA component
	EGR Off	YES		
Fail Safe	Fuel Limit	NO		
	MIL	NO		

#### SPECIFICATION E3ACC6C9

Throttle flap actuator component resistance	Throttle flap actuator operating Hz	Throttle flap actuator operating duty
23.8~31.3Ω (20℃)	300Hz	38%(no vacuum)~90%(vacuum)

#### SCHEMATIC DIAGRAM ED1FC6EC

Refer to DTC P2111.

#### SIGNAL WAVEFORM AND DATA EF68C299

Refer to DTC P2111.

#### MONITOR SCANTOOL DATA EFCD3E49

Refer to DTC P2111.

#### TERMINAL AND CONNECTOR INSPECTION E7472939

Refer to DTC P2111.

- 1. Check power circuit voltage
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect Throttle flap actuator.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of Throttle flap actuator connector terminal 2.

Specification : 11.5V~13.0V

5) Is the measured voltage within the specification?



Go to "Control Circuit Inspection".

FIGURE 15		
et en en	1.1	169 X
1.0		

▶ Repair E/R FUSE & RELAY BOX 15A INJ fuse and related circuit and go to "Verification of Vehicle Repair".

#### CONTROL CIRCUIT INSPECTION E89C75CE

- 1. Check monitoring voltage in control circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect throttle flap actuator connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of throttle flap actuator connector terminal 1.

specification: 3.2V~3.7V

5) Is the measured voltage within the specification?

# YES

▶ Go to "Component Inspection".



When voltage is not detected : Go to "2. Check open in control circuit" as follows.
 When high voltage is detected : Repair short to battery in control circuit and go to "Verification of Vehicle Repair".

- 2. Check open in control circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect throttle flap actuator connector and ECM connector.
  - 3) Check continuity between throttle flap actuator connector terminal 1 and ECM connector terminal 90.

고양관 그 환자방법 문가적으로 수송을

LGJF011C

specification : Continuity ( below  $1.0\Omega$  )

4) Is the measured resistance within the specification?



Repair short to ground in control circuit and go to "Verification of Vehicle Repair".




Repair open in control circuit and go to "Verification of Vehicle Repair".

#### COMPONENT INSPECTION E140993D

- 1. Check throttle flap actuator component resistance
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect throttle flap actuator.
  - 3) Check the resistance of throttle flap actuator.

Specification : 23.8~31.3Ω (20℃)



4) Is the measured resistance within the specification?

#### YES

▶ Go to "Verification of Vehicle Repair".

#### NO


▶ Replace throttle flap actuator and go to "Verification of Vehicle Repair".

#### VERIFICATION OF VEHICLE REPAIR EB42677F

Refer to DTC P2111.

# DTC P2123 THROTTLE/PEDAL POSITION SENSOR/SWITCH "D" CIRCUIT HIGH INPUT

#### COMPONENT LOCATION E7010FOC



GENERAL DESCRIPTION E160F061

Driver's intension to accelerate is transmitted to ECM through Accelerator Pedal Sensor(APS). And APS, whose mechanism is same as TPS, is required for ECM to determine optimum fuel injection quantity. As fidelity of APS is strongly required, APS is devided into two. One is APS1, which outputs main signals and the other is APS2, which monitors APS1 performance.APS1 and 2 do not share power supply and ground. Normally, APS2 output voltage is the half of APS1 and if the ratio of two signal is out of specified value, error is recognized then, Limp Home mode is activated.When Limp Home mode is activated, engine speed is fixed at 1200RPM and driving performance is limited to prevent excessive power generation due to APS false signal.

## DTC DESCRIPTION EA86797A

P2123 is set when output voltage of APS 1 is above the maximum value of 4.9V for more than 0.18 sec. This code is due to the short to battery in APS 1 power circuit and signal circuit or open in sensor ground circuit.

FLB -455

South and the state of the

# DTC DETECTING CONDITION EBE759D4


Item		Detecting	Condition	Possible Cause
DTC Strategy	<ul> <li>Voltage mor</li> </ul>	nitoring		
Enable Conditions	• IG KEY "Of	N"		
ThresholdValue	<ul> <li>When output value (above</li> </ul>	-		
DiagnosticTime	• 180ms			
	Fuel Cut	NO	<ul> <li>APS standard value is 0%.</li> <li>Limp home idle is fixed at (1200RPM)</li> </ul>	
	EGR Off	NO		<ul> <li>APS 1 Circuit</li> <li>APS component</li> </ul>
	Fuel Limit	YES		A 5 component
Fail Safe	MIL	YES	<ul> <li>A/C operation stops according to Vehicle/Engine speed</li> <li>Cruise control deactivated (for Cruise control option applied vehicle)</li> </ul>	

# SPECIFICATION ECD5DAB3

	Pedal released	Pedal depressed	Sensor Type
APS 1	0.7V~0.8V	3.8V~4.4V	Variable resistance
APS 2	0.275V~0.475V	1.75V~2.35V	type(Potentiometer)

#### FLB -457

#### SCHEMATIC DIAGRAM E8E7F17D



#### SIGNAL WAVEFORM AND DATA ED6189A9

				V	and an interest	) m		1	10		0.	5	Ŷ.	
				ł		;	-			:				
			[	APS	¥1	<u>г.н.ч.</u>		*****	****** :	<u> </u>		•••••		 
									-		<u></u>	•••••	 	 :
		ļ			2							•••••	 :	÷
		1			¢			<	-		ľ			
		1	1-15		) "	····1·		$\mathcal{I}$		ر <del>.</del> ا	ţ			÷
		17				oun	d ch	eck		÷	ľ			••••• •
		7	••••	sign	al i				-		ſ	<u> </u>		
		·····	••••							: :		·		
														·····
nn)	Z	100	1	CU	RS	M	EMO	71	RE	ĊD	ÌÌ	ME	NU	1
		and the second	Contraction of the owner	LD [200M]	APS APS sign	LD ZOOM CURS	APS 2 APS 2 groun signal	APS 2 APS 2 ground ch signal LD ZOOM CURS MEMO	APS 2 APS 2 ground check signal D ZOOM CURS MEMO	APS 2 ground check signal	APS 2 ground check signal	APS 2 APS 2 ground check signal	APS 2 APS 2 ground check signal D ZOOM CURS MEMO RECD ME	APS 2 ground check signal

Fig.1) APS 1 and APS 2 signals are measured simultaneously, Check if output value is rising and APS 2 is 1/2 of APS 1 signal.

LGJF014R

# NOTE


APS 2 Ground checking signal is for ECM to monitor APS 2. This signal drops APS 2 output voltage to below 200.39mV per 200msec. If APS 2 output voltage does not drop to below 200.39mV, ECM sets DTC as recognizing ground circuit error of APS 2.

\* The waveform below 200.39mV is not detectable in Ground checking signal waveform of APS 2 signal. Instead, the waveform which drops a little is detected. If APS 2 data of "SERVICE DATA" on the Scantool varies from 350mV to 0mV periodically, it means it works well.

#### MONITOR SCANTOOL DATA EB96C7F6

- 1. Connect scantool to Data Link Cable (DLC).
- 2. Warm engine up to normal operating temperature.
- 3. Turn "OFF" electrical devices and A/C.
- Monitor "ACCEL PEDAL SENSOR", "ACCEL PEDAL SENSOR 1", "ACCEL PEDAL SENSOR 2 " parameter on the scantool.

Specification : at idle( 0% ) ACCEL PEDAL SENSOR 1 : 600mV~800mV ACCEL PEDAL SENSOR 2 : 1/2 of ACCEL PEDAL SENSOR 1



#### Fig.1

Fig.1) APS output data at warm idle. Check if output value is rising and "ACCEL PEDAL SENSOR 2" is 1/2 of "ACCEL PEDAL SENSOR 1" signal.

LGJF002J

#### TERMINAL AND CONNECTOR INSPECTION EC423BD2

- 1. Electrical systems consist of a lot of harness and connectors, poor connection of terminals can cause various problems and damage of component.
- 2. Perform checking procedure as follows.
  - 1) Check damage of harness and terminals : Check terminals for contact resistance, corrosion and deformation.
  - 2) Check connecting condition of ECM and component connector : Check terminal seperation, damage of locking device and connecting condition between terminal and wiring.



Disconnect the pin which requires checking at mail connector and insert it to the terminal at female connector for checking connecting condition. (after checking, reconnect the pin at correct position)

3. Is the problem found?

#### DTC TROUBLESHOOTING PROCEDURES

#### FLB -459

#### YES

Repair the trouble causing part and go to "Verification of Vehicle Repair".

#### NO

▶ Go to "Power Circuit Inspection" as follows.

#### POWER CIRCUIT INSPECTION EBA0642D

- 1. IG KEY "OFF", ENGINE "OFF".
- 2. Disconnect APS connector.
- 3. IG KEY "ON".
- 4. Measure the voltage of terminal 6 of APS connector.

Specification: 4.8V~5.1V

5. Is the measured voltage within the specification?

#### YES

Go to "Signal Circuit Inspection".



If the measured voltage is not within the specified value, find and repair short to battery in APS 1 power circuit and go to "Verification of Vehicle Repair".

#### SIGNAL CIRCUIT INSPECTION EB3D05FA

- 1. Check open in signal circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect APS connector and ECM connector.
  - 3) Check continuity between APS connector terminal 2 and ECM connector terminal 9

Specification : Continuity (below 1.02)

4) Is the measured resistance within the specification?

#### YES

Go to "Check short to battery in signal circuit" as follows.

NO

- Repair open in signal circuit and go to "Verification of Vehicle Repair".
- 2. Check short to battery in signal circuit
  - 1) IG KEY "OFF", ENGINE "OFF".

- 2) Disconnect APS connector and ECM connector.
- 3) IG KEY "ON".
- 4) Measure the voltage of terminal 2 of APS connector.

Specification: 0.0V~0.1V

5) Is abnormal voltage detected in signal circuit with both connector disconnected?

#### YES

Repair short to battery and go to "Verification of Vehicle Repair".

NO

▶ Go to "Ground Circuit Inspection".

#### GROUND CIRCUIT INSPECTION E6A14007

- 1. IG KEY "OFF", ENGINE "OFF".
- 2. Disconnect APS connector.
- 3. IG KEY "ON".
- 4. Measure the voltage of APS terminal 6. [ TEST "A" ]
- 5. Measure the voltage of APS terminal 6 and terminal 5. [TEST "B"] (terminal 6 : Check + prove, terminal 5 : Check - prove)

Specification : [TEST "A"] Voltage - [TEST "B"] Voltage = below 200mV

6. Is the measured voltage within the specification?

#### YES

▶ Go to "Component Inspection".



When "B" voltage is not detected : Repair open in ground circuit and go to "Verification of Vehicle Repair".
 When the voltage difference between "A" and "B" is above 200mV : Eliminate the causes of excessive resistance and go to "Verification of Vehicle Repair".

#### COMPONENT INSPECTION EE3A7C13

- 1. IG KEY "OFF", ENGINE "OFF".
- 2. Disconnect APS connector.
- 3. Check resistance for each terminal refering to Resistance characteristic table.

Specification : Resistance characteristic table for each terminal

#### DTC TROUBLESHOOTING PROCEDURES

		Resistance	e(KΩ 20℃)	ì	Component	
	checking point	Pedal Depressed	Pedal released	Characteristic	Connector Shape	
	6(power)- 5(ground)	1.0±0.1KΩ	1.0±0.1KΩ	Unchanged	•	
APS 1	6(power)- 2(signal)	1.8±0.1KΩ	1.1±0.1KΩ	Resistance drops		
	2(signal)- 5(ground)	1.1±0.1KΩ	1.8±0.1KΩ	Resistance rises	(321) (321)	
	3(power)- 4(ground)	<b>2.0±0.1K</b> Ω	<b>2.0±0.1K</b> Ω	Unchanged		
APS 2	3(power)- 1(signal)	<b>2.9±0.1K</b> Ω	2.1±0.1KΩ	Resistance drops	LGJF0020	
	1(signal)- 4(ground)	1.1±0.1KΩ	1.8±0.1KΩ	Resistance rises		

4. Are resistances for each terminal measured correctly?

#### YES

Go to "Verification of Vehicle Rapair".

#### NO

Replace APS and go to "Verification of Vehicle Rapair".

VERIFICATION: OF: VEHICLE REPAIR EC7F52D9

crime tome talls is trad . • APS component

After a repair, it is essential to verify that the fault is corrected.

- 1. After connecting Scantool select "DIAGNOSTIC TROUBLE CODES(DTCs)" mode.
- 2. Clear recorded DTC using Scantool.
- 3. Drive the vehicle within DTC "Enable conditions" in "General information".
- 4. After selecting "DIAGNOSTIC TROUBLE CODES(DTCs)" mode and check if DTC is recorded again.
- 5. Are any DTCs recorded ?

## YES

Go to the DTC guide of recorded NO. in Scantool.

#### NO

System operates within specification.

# DTC P2128 THROTTLE/PEDAL POSITION SENSOR/SWITCH "E" CIRCUIT HIGH INPUT

#### COMPONENT LOCATION E2550FF7

Refer to DTC P2123.

#### GENERAL DESCRIPTION E2967B1D

Refer to DTC P2123.

#### DTC DESCRIPTION E4FAFA62

P2128 is set when output voltage of APS 2 is above the maximum value of 2463 mV for more than 0.18 sec. This code is due to the short to battery in APS 2 power circuit and signal circuit or open in sensor ground circuit.

#### DTC DETECTING CONDITION EBBC33E7

ltem		Detecting	Condition	Possible Cause
DTC Strategy	<ul> <li>Voltage mor</li> </ul>	nitoring		
Enable Conditions	• IG KEY "ON"			an an tha tha an tha Tha an tha an t
ThresholdValue	<ul> <li>When output value (above</li> </ul>			
DiagnosticTime	• 180ms			
	Fuel Cut	NO	APS standard value	
	EGR Off	NO	is 0%. • Limp home idle is fixed	<ul> <li>APS 2 Circuit</li> <li>APS component</li> </ul>
	Fuel Limit	YES	at (1200RPM)	
Fail Safe			<ul> <li>A/C operation stops according to Vehicle/Engine speed</li> </ul>	na ing kang bagi kan Kang bagi kang bagi ka
	MIL YES		Cruise control	and the second
			deactivated (for Cruise control option applied	
			vehicle)	

#### SPECIFICATION EC469B45

	Pedal released	Pedal depressed	Sensor Type
APS 1	0.7V~0.8V	3.8V~4.4V	Variable resistance
APS 2	0.275V~0.475V	1.75V~2.35V	type(Potentiometer)

#### SCHEMATIC DIAGRAM E5A29AE7

Refer to DTC P2123.

#### SIGNAL WAVEFORM AND DATA E77AC376

Refer to DTC P2123.

#### MONITOR SCANTOOL DATA EC3123B8

Refer to DTC P2123.

# TERMINAL AND CONNECTOR INSPECTION E5D3E156

Refer to DTC P2123.

# POWER CIRCUIT INSPECTION E3B1E5D9

- 1. IG KEY "OFF", ENGINE "OFF".
- 2. Disconnect APS connector.
- 3. IG KEY "ON".
- 4. Measure the voltage of terminal 3 of APS connector.

Specification: 4.8V~5.1V

5. Is the measured voltage within the specification?

## YES

▶ Go to "Signal Circuit Inspection".



If the measured voltage is not within the specified value, find and repair short to battery in APS 2 power circuit and go to "Verification of Vehicle Repair".

F"A" TREFF Elistencial SIGA in epalacy service.

#### SIGNAL CIRCUIT INSPECTION EF7FFB5F

- 1. Check open in signal circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect APS connector and ECM connector.
  - 3) Check continuity between APS connector terminal 1 and ECM connector terminal 31.

Specification : Continuity (below 1.02)

4) Is the measured resistance within the specification?

# YES

Go to "Check short to battery in signal circuit" as follows.

NO

- ▶ Repair open in signal circuit and go to "Verification of Vehicle Repair".
- 2. Check short to battery in signal circuit
  - 1) IG KEY "OFF", ENGINE "OFF".

- 2) Disconnect APS connector and ECM connector.
- 3) IG KEY "ON".
- 4) Measure the voltage of terminal 1 of APS connector.

Specification : 0.0V~0.1V

5) Is abnormal voltage detected in signal circuit with both connector disconnected?

#### YES

Repair short to battery and go to "Verification of Vehicle Repair".

NO

Go to "Ground Circuit Inspection".

#### GROUND CIRCUIT INSPECTION EE068745

- 1. IG KEY "OFF", ENGINE "OFF".
- 2. Disconnect APS connector.
- 3. IG KEY "ON".
- 4. Measure the voltage of APS terminal 3. [TEST "A"]
- Measure the voltage of APS terminal 3 and terminal 4. [TEST "B"] (terminal 3 : Check + prove, terminal 4 : Check - prove)

Specification : [TEST "A"] Voltage - [TEST "B"] Voltage = below 200mV

6. Is the measured voltage within the specification?

#### YES

▶ Go to "Component Inspection".

#### NO

When "B" voltage is not detected : Repair open in ground circuit and go to "Verification of Vehicle Repair".
 When the voltage difference between "A" and "B" is above 200mV : Eliminate the causes of excessive resistance and go to "Verification of Vehicle Repair".

#### COMPONENT INSPECTION E3E5A2C7

- 1. IG KEY "OFF", ENGINE "OFF".
- 2. Disconnect APS connector.
- 3. Check resistance for each terminal refering to Resistance characteristic table.

Specification : Resistance characteristic table for each terminal

#### DTC TROUBLESHOOTING PROCEDURES

	and the second	<b>Resistance( K</b> Ω <b>20</b> ℃ )			Component
	checking point	6(power)-	Characteristic	Connector Shape	
APS 1	6(power)- 5(ground)	1.0±0.1KΩ	1 <i>.</i> 0±0.1KΩ	Unchanged	
	6(power)- 2(signal)	1.8±0.1KΩ	1.1±0.1KΩ	Resistance drops	
	2(signal)- 5(ground)	1.1±0.1KΩ	1.8±0.1KΩ	Resistance rises	
	3(power)- 4(ground)	2.0±0.1KΩ	2.0±0.1KΩ	Unchanged	(CLSL)
APS 2	3(power)- 1(signal)	2.9±0.1KΩ	2.1±0.1KΩ	Resistance drops	LGJF00
	1(signal)- 4(ground)	1.1±0.1KΩ	1.8±0.1KΩ	Resistance rises	

4. Are resistances for each terminal measured correctly?

#### YES

Go to "Verification of Vehicle Rapair".

#### NO

▶ Replace APS and go to "Verification of Vehicle Rapair". As a Submed 25% repeated

# VERIFICATION OF VEHICLE REPAIR SCIESSEDCED

Refer to DTC P2123. NOO 251A

#### FLB -465

# DTC P2138 THROTTLE/PEDAL POSITION SENSOR/SWITCH "D" / "E" VOLTAGE CORRELATION

COMPONENT LOCATION ECC7334B

Refer to DTC P2123.

#### GENERAL DESCRIPTION EEF4097E

Refer to DTC P2123.

#### DTC DESCRIPTION E318B154

P2138 is set when APS 2 output voltage which is not 1/2 of APS 1 output voltage is detected for more than 0.24 sec. Careful inspection of poor connection between APS 1 and APS 2, resistance characteristic of APS component is needed.

## DTC DETECTING CONDITION ECBC5FDA

Item		Detecting	Condition	Possible Cause
DTC Strategy	<ul> <li>Voltage mor</li> </ul>	nitoring		
Enable Conditions	IG KEY "ON"(APS depressed)			New Conference on State Conference
ThresholdValue	<ul> <li>When APS 1,2 is depressed 1.8~6%, the difference between APS 1 and 2is above 308mV</li> <li>When APS 1,2 is depressed above 7%, the difference between APS 1 and 2 is above 406mV</li> </ul>			
DiagnosticTime	• 240ms			
	Fuel Cut	NO	<ul> <li>APS standard value is 0%.</li> <li>Limp home idle is fixed at (1200RPM)</li> </ul>	APS 1 Circuit     APS 2 Circuit
	EGR Off	NO		APS component
	Fuel Limit	YES		
Fail Safe	MIL	YES	<ul> <li>A/C operation stops according to Vehicle/Engine speed</li> <li>Cruise control deactivated (for Cruise control option applied vehicle)</li> </ul>	

#### SPECIFICATION E989B811

	Pedal released	Pedal depressed	Sensor Type
APS 1	0.7V~0.8V	3.8V~4.4V	Variable resistance
APS 2	0.275V~0.475V	1.75V~2.35V	type(Potentiometer)

#### SCHEMATIC DIAGRAM E45C5519

Refer to DTC P2123.

# SIGNAL WAVEFORM AND DATA E535F06A

Refer to DTC P2123.

#### MONITOR SCANTOOL DATA E2A3FE07

Refer to DTC P2123.

#### **TERMINAL AND CONNECTOR INSPECTION** E76D6C98

Refer to DTC P2123.

#### POWER CIRCUIT INSPECTION E88CFB14

- IG KEY "OFF", ENGINE "OFF". 1.
- 2. **Disconnect APS connector.**
- IG KEY "ON". 3.
- Measure the voltage of terminal 3 and 6 of APS connector. 4.

# Specification: 4.8V~5.1V Is the measured voltage within the specification? 5. YES

		eef mode and a state
Go to "Signal Circuit I	nspection".	
NO	to "Verification of Vehicle Rapeir".	op bon fluctio ni "upite mano?"
If the measured voltag go to "Verification of Veh	e is not within the specified value, find and repai cle Repair".	
	ge is higher than the specified value :	
Refer to P0643 Circuit In		
Refer to P0653 Circuit In	spection.(AF52)	
Befer to P0642 Circuit In	ige is lower than the specified value : spection.(APS1)	
Refer to P0652 Circuit In	spection.(APS2)	· 영상 · 영상 · 상황 유민이 · 영경 · 영상 · 이 · ·
	the provide the first of the second	
SIGNAL CIRCUIT INSP	ECTION E95335D6	and the second
1. Check open in signal circ		an an an an Arresta an Arresta an Angela. Arresta an Angela an Arresta an Ar

IG KEY "OFF", ENGINE "OFF". 1)

- 2) Disconnect APS connector and ECM connector.
- 3) Check continuity between APS connector terminal 2 and ECM connector terminal 9. (APS 1) Check continuity between APS connector terminal 1 and ECM connector terminal 31. (APS 2)

Specification : Continuity (below 1.02)

4) Is the measured resistance within the specification?

# YES

Go to "Check short in signal circuit".

NO

- ▶ Repair open in signal circuit and go to "Verification of Vehicle Repair".
- 2. Check short in signal circuit (APS 1)
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect APS connector and ECM connector.
  - 3) IG KEY "ON".
  - 4) Check continuity between APS connector terminal 2 and chassis ground. (check short to ground ) Measure the voltage of terminal 2 of APS connector. ( check short to battery )

Specification : Check short to ground :	: Discontinuity (Infinite $\Omega$	)
Check short to battery : 0.0V~0.1V		

5) Is APS 1 signal circuit insulated normally?

# YES

▶ Go to "3.Signal Circuit Inspection (APS 2)" as follows.

NO

▶ Repair short in circuit and go to "Verification of Vehicle Repair".

- 3. Signal Circuit Inspection (APS 2)
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect APS connector and ECM connector.
  - 3) IG KEY "ON".
  - 4) Check continuity between APS connector terminal 1 and chassis ground. (check short to ground ) Measure the voltage of terminal 1 of APS connector. (check short to battery)

```
Specification : Check short to ground : Discontinuity ( Infinite \Omega ) Check short to battery : 0.0V{\sim}0.1V
```

5) Is APS 2 signal circuit insulated normally?



▶ Go to "Ground Circuit Inspection".



▶ Repair short in circuit and go to "Verification of Vehicle Repair".

### GROUND CIRCUIT INSPECTION E1EBB675

- 1. Check ground circuit (APS1)
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect APS connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of APS terminal 6. [TEST "A"]
  - 5) Measure the voltage of APS terminal 6 and terminal 5. [TEST "B"] (terminal 6: Check + prove, terminal 5: Check - prove)

Specification : [TEST "A"] Voltage - [TEST "B"] Voltage = below 200mV

6) Is the measured voltage within the specification?

## YES

Go to "2. Check ground circuit (APS2)".

#### NO

When "B" voltage is not detected : Repair open in ground circuit and go to "Verification of Vehicle Repair".
 When the voltage difference between "A" and "B" is above 200mV : Eliminate the causes of excessive resistance and go to "Verification of Vehicle Repair".

- 2. Check ground circuit (APS2)
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect APS connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of APS terminal 3. [ TEST "A" ]
  - 5) Measure the voltage of APS terminal 3 and terminal 4. [TEST "B"] (terminal 3: Check + prove, terminal 4 : Check - prove)

Specification : [TEST "A"] Voltage - [TEST "B"] Voltage = below 200mV

6) Is the measured voltage within the specification?

## YES

Go to "Component Inspection".



When "B" voltage is not detected : Repair open in ground circuit and go to "Verification of Vehicle Repair".
 When the voltage difference between "A" and "B" is above 200mV : Eliminate the causes of excessive resistance and go to "Verification of Vehicle Repair".

## COMPONENT INSPECTION EE0405AE

- 1. IG KEY "OFF", ENGINE "OFF".
- 2. Disconnect APS connector.
- 3. Check resistance for each terminal refering to Resistance characteristic table.

Specification : Resistance characteristic table for each terminal

		Resistance	e(KΩ 20℃)		Component	
	checking point	Pedal Depressed	Pedal released	Characteristic	Connector Shape	
	6(power)- 5(ground)	1.0±0.1KΩ	1.0±0.1KΩ	Unchanged	· · · · · · · · · · · · · · · · · · ·	
APS 1	6(power)- 2(signal)	<b>1.8±0.1</b> KΩ	1.1±0.1KΩ	Resistance drops		
	2(signal)- 5(ground)	1.1±0.1KΩ	1.8±0.1KΩ	Resistance rises		
	3(power)- 4(ground)	<b>2.0±0.1K</b> Ω	2.0±0.1KΩ	Unchanged	LGJF002C	
APS 2	3(power)- 1(signal)	<b>2.9±0.1K</b> Ω	2.1±0.1KΩ	Resistance drops		
	1(signal)- 4(ground)	1.1±0.1KΩ	1.8±0.1KΩ	Resistance rises		

4. Are resistances for each terminal measured correctly?

## YES

▶ Go to "Verification of Vehicle Rapair".

## NO


▶ Replace APS and go to "Verification of Vehicle Rapair".

## VERIFICATION OF VEHICLE REPAIR E34F0554

Refer to DTC P2123.

# DTC P2238 HO2S PUMPING CURRENT CIRCUIT LOW-BANK 1, SENSOR 1

## COMPONENT LOCATION EA7ABA01



LGJF009C

## GENERAL DESCRIPTION EB85AE8A

O2 sensor installed at exhaust manifold is linear O2 sensor and it senses O2 density of exhaust gas for accurate EGR control through fuel correction. It also limits smoke which is generated by reach air-fuel mixture at engine maximum loading condition. ECM controls pumping current in order to fit  $\lambda$  -value from linear O2 sensor to 1.0.

Lean air-fuel mixture  $(1.0 < \lambda < 1.1)$ : ECM supplies pumping current to O2 sensor (+pumping current) and activates it for O2 sensor to have the characteristic at  $\lambda = 1.0$  (0.0 pumping current). With the value of pumping current supplied to O2 sensor, ECM detects O2 density of exhaust gas.

Rich air-fuel mixture ( $0.9 < \lambda < 1.0$ ): ECM takes away pumping current from O2 sensor (-pumping current) and deactivates it for O2 sensor to have the characteristic at  $\lambda = 1.0$  (0.0 pumping current). With the value of pumping current taken away from O2 sensor, ECM detects O2 density of exhaust gas.

This performance is the most active and fast at normal operating temp. $(450 \degree \sim 600 \degree)$  thus, in order to reach normal operating temp. and last at that temp., heater(heating coil) is integrated with O2 sensor.Heater coil is controlled by ECM as PWM. the resistance of heater coil is low when coil is cold thus, current through it increases while resistance is high when coil is hot thus, current decreases. With this principle, O2 sensor temp. is measured and O2 sensor heater operation varies based on the data.


## DTC DESCRIPTION E4133DBF

P2238 is set when 1) short to ground in signal line(terminal 4), ground line(terminal 3), power line(terminal 1), pumping current line(terminal 6) or 2) open in ground line is detected. This code is due to the problem of O2 sensor circuit.

## DTC DETECTING CONDITION E02AF549


Item		Detecting	Condition	Possible Cause		
DTC Strategy	<ul> <li>Voltage monitoring</li> </ul>					
Enable Conditions	Engine running					
ThresholdValue	<ul> <li>Short to bat</li> <li>Open in O2</li> </ul>	tery in O2 sensor circ	sensor circuit cuit			
DiagnosticTime	● 2.0 sec.			<ul> <li>O2 sensor circuit</li> <li>O2 sensor component</li> </ul>		
	Fuel Cut	NO		• Oz sensor component		
	EGR Off	NO				
Fail Safe	Fuel Limit	NO				
	MIL	NO	]			

## SPECIFICATION EAE6935A



$\lambda$ value	0.65	0.70	0.80	0.90	1.01	1.18	1.43	1.70	2.42	Air
Pump- ing cur- rent	-2.22	-1.82	-1.11	-0.50	0.00	0.33	0.67	0.94	1.38	2.54

## SCHEMATIC DIAGRAM EDDDOF1D



と認

## SIGNAL WAVEFORM AND DATA E7042622

at 🖸	) A 1.0	V 0.5	d WS	CHB	0.5 V		Aî 🧕	ih a	1.0	0 200	3 mS	CH B Ø	.5 V	
1I N :	1.1 V A	VE:	1.9 V	MAX:	2.8	v	MIN:	2.5	VA	VE:	2.5 V	MAX:	2.6	V
FREQ:	3.33	KHz	DUTY:	54 %			FREQ:	25	. 00	Hz	DUTY:	43 %		
АЛАА	<u>እ ለ ለ ለ ለ</u>	AAA	ነለአለ	ΛΛΛΛ	AAAI	۲A		~~~~~~			Baa Moundowed	เลาสาราชาวารระกา	å	
VVVV	AAAAA	IVVV	VVV	1444	VVVV	VΥ								
								····•						
P	••••••••••••••••••••••	·····					P			······································				
1		CURS	MEMO	RECD	MENU	<u>†</u>	HOI	n z	OOM	CURS	MEMO	RECD	MENU	
HOLI	D ZOOM	CULO												
HOLI Fig. 1	<u>12001</u>	CONO		d barransanan		theorem of the second se	Fig.2							
Fig.1				СНВР	15 U		Fig.2		1 9	0 200		СНВИ	.5 V	e.4410794
Fig.1	I A 1.0	200	mS		1.5 V 2.6		AT .		1.0 U A		3 mS 2.5 V	CH B Ø MAX:		v
Fig.1 11 CI 11 N :	) A 1.0 0.5 V A	200 Je:	mS 2.5 V	MAX:	3.5 V 2.6	V	At 🚺 MIN:	0.5	VA	VE:	2.5 V	MAX:	.5 V 2.6	Ų
Fig.1 11 CI 11 N :	I A 1.0	200 Je:	mS	MAX:		Ų	AT .	0.5				MAX:		v
Fig.fl nt Cl IIN:	) A 1.0 0.5 V A	200 Je:	mS 2.5 V	MAX:		Ų	At 🚺 MIN:	0.5	VA	VE:	2.5 V	MAX:		V
Fig.1 nt Cl	) A 1.0 0.5 V A	200 Je:	mS 2.5 V	MAX:		V	At 🚺 MIN:	0.5	VA	VE:	2.5 V	MAX:		V
Fig.1 nt Cl	) A 1.0 0.5 V A	200 Je:	mS 2.5 V	MAX:		V	At 🚺 MIN:	0.5	VA	VE:	2.5 V	MAX:		V
Fig.fl nt Cl IIN:	) A 1.0 0.5 V A	200 Je:	mS 2.5 V	MAX:		V	At 🚺 MIN:	0.5	VA	VE:	2.5 V	MAX:		V
Fig.1 ht Cl	) A 1.0 0.5 V A	200 Je:	mS 2.5 V	MAX:		V	At 🚺 MIN:	0.5	VA	VE:	2.5 V	MAX:		V
Fig.1 ht Cl htN:	) A 1.0 0.5 V A	200 Je:	mS 2.5 V	MAX:		V	At 🚺 MIN:	0.5	VA	VE:	2.5 V	MAX:		Ų
Fig.1 ht Cl htN:	) A 1.0 0.5 V A	200 Je:	mS 2.5 V	MAX:		V	At 🚺 MIN:	0.5	VA	VE:	2.5 V	MAX:		V
Fig.1 11 CI 11 N :	1 A 1.0 0.5 V A 25.00	200 Je:	mS 2.5 V	MAX:		V	At 🚺 MIN:	0.5	VA	VE:	2.5 V	MAX:		V

Fig.1) Waveform of O2 sensor power(terminal 1) at IG KEY "ON" and Engine running. It fluctuates between 1V and 3V periodically.

Fig.2) Waveform of O2 sensor ground(terminal 3) at IG KEY "ON" and Engine running. 2.5V is displayed. Fig.3) Waveform of O2 sensor signal(terminal 4) at IG KEY "ON" and Engine running. 850mV is displayed.

(same value at idle and acceleration)

Fig.4) Waveform of O2 sensor pump(terminal 6) at IG KEY "ON" and Engine running. 850mV is displayed. (same value at idle and acceleration)

LGJF009F

## TERMINAL AND CONNECTOR INSPECTION E3E21813

- 1. Electrical systems consist of a lot of harness and connectors, poor connection of terminals can cause various problems and damge of component.
- 2. Perform checking procedure as follows.
  - 1) Check damage of harness and terminals : Check terminals for contact resistance, corrosion and deformation.
  - 2) Check connecting condition of ECM and component connector : Check terminal seperation, damage of locking device and connecting condition between terminal and wiring.

## NOTE

Disconnect the pin which requires checking at male connector and insert it to the terminal at female connector for checking connecting condition. (after checking, reconnect the pin at correct position.)

3. Is the problem found?

### FLB -475

## YES

Repair the trouble causing part and go to "Verification of Vehicle Repair".

## NO

▶ Go to "Power Circuit Inspection".

### POWER CIRCUIT INSPECTION EE9A61A5

- 1. Check voltage & waveform in sensor power circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect O2 sensor connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of O2 sensor connector terminal 1.
  - 5) Monitor the waveform in O2 sensor connector terminal 1.

Specification : Measured voltage : 2.0 V waveform : Refer to "Signal Waveform & Data" of "General Information". The waveform similar to Fig.1) is displayed.

6) Is the measured voltage within the specification?

## YES

Go to "Signal Circuit Inspection". A lanimer robernoo MOA bas & lanimet robonnoo scaras.



No voltage detected in O2 sensor power circuit : Go to "2. Check open in sensor power circuit" as follows.
 High voltage detected in O2 sensor power circuit : Repair short to battery in O2 sensor power circuit and go to "Verification of Vehicle Repair".

- 2. Check open in O2 sensor power circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect O2 sensor connector and ECM connector.
  - 3) Check continuity between O2 sensor connector terminal 1 and ECM connector terminal 64.

Specification : Continuity(below  $1.0\Omega$ )

4) Is the measured voltage within the specification?



Repair short to ground in O2 sensor power circuit and go to "Verification of Vehicle Repair".

NO

Reapir open in O2 sensor power circuit and go to "Verification of Vehicle Repair".

#### SIGNAL CIRCUIT INSPECTION E52FC0E0

- 1. Check voltage in sensor signal circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect O2 sensor connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of O2 sensor connector terminal 4.

#### Specification : 0.8V~0.9 V

5) Is the measured voltage within the specification?

#### YES

▶ Go to "3. Check sensor pump circuit".

#### NO

- No voltage detected in O2 sensor signal circuit : Go to "2. Check open in sensor signal circuit" as follows.
   High voltage detected in O2 sensor power circuit : Repair short to battery in O2 sensor signal circuit and go to "Verification of Vehicle Repair".
- 2. Check open in O2 sensor signal circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect O2 sensor connector and ECM connector.
  - 3) Check continuity between O2 sensor connector terminal 4 and ECM connector terminal 87.

Specification : Continuity (below  $1.0\Omega$  )

4) Is the measured resistance within the specification?

## YES

Repair short to ground in O2 sensor signal circuit and go to "Verification of Vehicle Repair".

NO

- ▶ Repair open in O2 sensor signal circuit and go to "Verification of Vehicle Repair".
- 3. Check voltage in sensor pump circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect O2 sensor connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of O2 sensor connector terminal 6.

#### Specification : 0.8V~0.9 V

5) Is the measured voltage within the specification?

## YES

▶ Go to "Ground Circuit Inspection".



- No voltage detected in O2 sensor pumpl circuit : Go to "4. Check open in sensor pump circuit" as follows.
   High voltage detected in O2 sensor power circuit : Repair short to battery in O2 sensor pump circuit and go to "Verification of Vehicle Repair".
- 4. Check open in sensor pump circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect O2 sensor connector and ECM connector.
  - 3) Check continuity between O2 sensor connector terminal 6 and ECM connector terminal 65.

Specification : Continuity (below  $1.0\Omega$  )

4) Is the measured resistance within the specification?

## YES

Repair short to ground in O2 sensor pump circuit and go to "Verification of Vehicle Repair".

NO

Repair open in O2 sensor pump circuit and go to "Verification of Vehicle Repair".

> 000032109 Diffeeport concettor: ct O2 sensor component, outset O2 second and there dotamation, do raion unation of O5 datastica power

GROUND CIRCUIT INSPECTION E2FOA6DC

- 1. Check voltage in sensor ground circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect O2 sensor connector.
  - 3) IG KEY "ON".

4) Measure the voltage of O2 sensor connector terminal 3.

Specification: 2.3V~2.7V

5) Is the measured voltage within the specification?

YES

Go to "Component Inspection".

NO

No voltage detected in O2 sensor ground circuit : Go to "2. Check open in sensor ground circuit" as follows.
 High voltage detected in O2 sensor ground circuit : Repair short to battery in O2 sensor ground circuit and go to "Verification of Vehicle Repair".

2. Check open in sensor ground circuit

- 1) IG KEY "OFF", ENGINE "OFF".
- 2) Disconnect O2 sensor connector and ECM connector.
- 3) Check continuity between O2 sensor connector terminal 3 and ECM connector terminal 86.

Specification : Continuity (below  $1.0\Omega$  )

4) Is the measured resistance within the specification?

## YES

Repair short to ground in O2 sensor ground circuit and go to "Verification of Vehicle Repair".

NO

Repair open in O2 sensor ground circuit and go to "Verification of Vehicle Repair".

#### COMPONENT INSPECTION E5AC8D29

- 1. O2 sensor Visual Inspection
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect O2 sensor connector.
  - 3) Perform visual inspection for each checking point as follows.
    - a. Check corrosion inside of O2 sensor terminal.
    - b. Check damaged coverring and open in component wiring.
    - c. Check connecting torque(poor connection) of O2 sensor component.
    - d. Disconnect O2 sensor and check deformation, clogging, melting of O2 detecting prove.

#### Specification : Everyting OK

4) Is any problem of O2 sensor detected?

## YES

▶ Replace O2 sensor and go to "Verification of Vehicle Repair".



Refer to "NOTE" as follows.

## 🛈 ΝΟΤΕ

In diesel engine, ultra lean combustion generates at normal operating condition. Therefore, O2 sensor signal change in accordance with engine acceleration and various loading condition rarely happens, unlikely to linear O2 sensor of gasoline engine. Moreover, pumping current is not measurable with normal measuring device(ampere meter) because maximum value is 3mA. If DTC code is recorded continuously eventhough circuit inspection is correctly performed and no problem at visual inspection of component is detected, replace O2 sensor.

### VERIFICATION OF VEHICLE REPAIR EAD893FC

After a repair, it is essential to verify that the fault is corrected.

1. After connecting Scantool select "DIAGNOSTIC TROUBLE CODES(DTCs)" mode.

## DTC TROUBLESHOOTING PROCEDURES

- 2. Clear recorded DTC using Scantool.
- 3. Drive the vehicle within DTC "Enable conditions" in "General information".
- 4. After selecting "DIAGNOSTIC TROUBLE CODES(DTCs)" mode and check if DTC is recorded again.
- 5. Are any DTCs recorded ?

## YES

▶ Go to the DTC guide of recorded NO. in Scantool.

## NO

System operates within specification.

# DTC P2239 HO2S PUMPING CURRENT CIRCUIT HIGH-BANK 1, SENSOR 1

#### COMPONENT LOCATION ED7D4F04

Refer to DTC P2238.

#### GENERAL DESCRIPTION ETABBE16

Refer to DTC P2238.


### DTC DESCRIPTION E247852D

P2239 is set when 1) short to battery in signal line(terminal 4), ground line(terminal 3), power line(terminal 1), pumping current line(terminal 6) or 2) short to ground is detected. This code is due to the problem of O2 sensor circuit.

## DTC DETECTING CONDITION E549B9FA

ltem		Detecting	Condition	Possible Cause		
DTC Strategy	<ul> <li>Voltage more</li> </ul>	nitoring				
Enable Conditions	Engine runr	ning				
ThresholdValue	<ul><li>Short to bat</li><li>Open in O2</li></ul>					
DiagnosticTime	• 2.0 sec.			O2 sensor circuit		
	Fuel Cut	NO		<ul> <li>O2 sensor component</li> </ul>		
	EGR Off	NO				
Fail Safe	Fuel Limit	NO				
	MIL	NO				

### SPECIFICATION E019BB56



LGJF009D

## DTC TROUBLESHOOTING PROCEDURES

FLB -481

$\lambda$ value	0.65	0.70	0.80	0.90	1.01	1.18	1.43	1.70	2.42	Air
Pump- ing cur- rent	-2.22	-1.82	-1.11	-0.50	0.00	0.33	0.67	0.94	1.38	2.54

## SCHEMATIC DIAGRAM ETATDO5B

Refer to DTC P2238.

## SIGNAL WAVEFORM AND DATA EB613A4E

Refer to DTC P2238.

## TERMINAL AND CONNECTOR INSPECTION E69D72EC

Refer to DTC P2238.

## POWER CIRCUIT INSPECTION E3E74C19

- 1. Check voltage & waveform in sensor power circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect O2 sensor connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of O2 sensor connector terminal 1.
  - 5) Monitor the waveform in O2 sensor connector terminal 1.

Specification : Measured voltage : 2.0 V waveform : Refer to "Signal Waveform & Data" of "General Information". The waveform similar to Fig.1) is displayed.

6) Is the measured voltage within the specification?

## YES

▶ Go to "Signal Circuit Inspection".



- No voltage detected in O2 sensor power circuit : Go to "2. Check open in sensor power circuit" as follows.
- High voltage detected in O2 sensor power circuit : Repair short to battery in O2 sensor power circuit and go to "Verification of Vehicle Repair".
- 2. Check open in O2 sensor power circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect O2 sensor connector and ECM connector.
  - 3) Check continuity between O2 sensor connector terminal 1 and ECM connector terminal 64.

Specification : Continuity(below 1.0  $\ensuremath{\Omega}$  )

4) Is the measured voltage within the specification?

#### YES

▶ Repair short to ground in O2 sensor power circuit and go to "Verification of Vehicle Repair".

NO

Reapir open in O2 sensor power circuit and go to "Verification of Vehicle Repair".

#### SIGNAL CIRCUIT INSPECTION EDCDBF4E

- 1. Check voltage in sensor signal circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect O2 sensor connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of O2 sensor connector terminal 4.

Specification: 0.8V~0.9 V

5) Is the measured voltage within the specification?



Go to "3. Check sensor pump circuit".



- No voltage detected in O2 sensor signal circuit : Go to "2. Check open in sensor signal circuit" as follows.
- ▶ High voltage detected in O2 sensor power circuit : Repair short to battery in O2 sensor signal circuit and go to "Verification of Vehicle Repair".
- 2. Check open in O2 sensor signal circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect O2 sensor connector and ECM connector.
  - 3) Check continuity between O2 sensor connector terminal 4 and ECM connector terminal 87.

Specification : Continuity (below 1.0<sup>Ω</sup>)

4) Is the measured resistance within the specification?



Repair short to ground in O2 sensor signal circuit and go to "Verification of Vehicle Repair".

NO

- ▶ Repair open in O2 sensor signal circuit and go to "Verification of Vehicle Repair".
- 3. Check voltage in sensor pump circuit

## DTC TROUBLESHOOTING PROCEDURES

- 1) IG KEY "OFF", ENGINE "OFF".
- 2) Disconnect O2 sensor connector.
- 3) IG KEY "ON".
- 4) Measure the voltage of O2 sensor connector terminal 6.

Specification: 0.8V~0.9 V

5) Is the measured voltage within the specification?

## YES

▶ Go to "Ground Circuit Inspection".



- No voltage detected in O2 sensor pumpl circuit : Go to "4. Check open in sensor pump circuit" as follows.
- ▶ High voltage detected in O2 sensor power circuit : Repair short to battery in O2 sensor pump circuit and go to "Verification of Vehicle Repair".
- 4. Check open in sensor pump circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect O2 sensor connector and ECM connector.
  - 3) Check continuity between O2 sensor connector terminal 6 and ECM connector terminal 65.

(1917) - 관련 '이너' (2018) - -'이너' (2018) - -

Specification : Continuity (below 1.0Ω)

4) Is the measured resistance within the specification?



Repair short to ground in O2 sensor pump circuit and go to "Verification of Vehicle Repair".

NO

▶ Repair open in O2 sensor pump circuit and go to "Verification of Vehicle Repair".

#### GROUND CIRCUIT INSPECTION E8C11FB2

- 1. Check voltage in sensor ground circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect O2 sensor connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of O2 sensor connector terminal 3.

#### Specification : 2.3V~2.7V

5) Is the measured voltage within the specification?

## YES

▶ Go to"Component Inspection".

NO

No voltage detected in O2 sensor ground circuit : Go to "2. Check open in sensor ground circuit" as follows.
 High voltage detected in O2 sensor ground circuit : Repair short to battery in O2 sensor ground circuit and go to "Verification of Vehicle Repair".

- 2. Check open in sensor ground circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect O2 sensor connector and ECM connector.
  - 3) Check continuity between O2 sensor connector terminal 3 and ECM connector terminal 86.

Specification : Continuity (below  $1.0\Omega$  )

4) Is the measured resistance within the specification?

## YES

Repair short to ground in O2 sensor ground circuit and go to "Verification of Vehicle Repair".

NO

Repair open in O2 sensor ground circuit and go to "Verification of Vehicle Repair".

#### COMPONENT INSPECTION E8BCE4B8

- 1. O2 sensor Visual Inspection
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect O2 sensor connector.
  - 3) Perform visual inspection for each checking point as follows.
    - a. Check corrosion inside of O2 sensor terminal.
    - b. Check damaged coverring and open in component wiring.
    - c. Check connecting torque(poor connection) of O2 sensor component.
    - d. Disconnect O2 sensor and check deformation, clogging, melting of O2 detecting prove.

#### Specification : Everyting OK

4) Is any problem of O2 sensor detected?



▶ Replace O2 sensor and go to "Verification of Vehicle Repair".



▶ Refer to "NOTE" as follows.

# 

In diesel engine, ultra lean combustion generates at normal operating condition. Therefore, O2 sensor signal change in accordance with engine acceleration and various loading condition rarely happens, unlikely to linear O2 sensor of gasoline engine. Moreover, pumping current is not measurable with normal measuring device(ampere meter) because maximum value is 3mA. If DTC code is recorded continuously eventhough circuit inspection is correctly performed and no problem at visual inspection of component is detected, replace O2 sensor.

## VERIFICATION OF VEHICLE REPAIR E16EC30F

Refer to DTC P2238.

## DTC P2251 HO2S REFERENCE GROUND CIRCUIT/OPEN-BANK 1 SENSOR 1

#### COMPONENT LOCATION EFF02163

Refer to DTC P2238.

#### GENERAL DESCRIPTION E849A294

Refer to DTC P2238.


### DTC DESCRIPTION E5A2D509

P2251 is set when ground line(terminal 3) is opened. This code is due to the problem of O2 sensor circuit.

## DTC DETECTING CONDITION E28DAF5A

ltem		Detecting	Condition	Possible Cause			
DTC Strategy	Voltage monitoring						
Enable Conditions	Engine running						
ThresholdValue	<ul> <li>Open in O2</li> </ul>	sensor gro	nd circuit				
DiagnosticTime	• 2.0 sec.		4-99,499,99,99,79,	O2 sensor circuit			
	Fuel Cut	NO		O2 sensor component			
	EGR Off	NO					
Fail Safe	Fuel Limit	NO					
	MIL	NO					

## SPECIFICATION E6505B50



LGJF009D

## DTC TROUBLESHOOTING PROCEDURES

$\lambda$ value	0.65	0.70	0.80	0.90	1.01	1.18	1.43	1.70	2.42	Air
Pump- ing cur- rent	-2.22	-1.82	-1.11	-0.50	0.00	0.33	0.67	0.94	1.38	2.54

## SCHEMATIC DIAGRAM E2015D40

Refer to DTC P2238.

## SIGNAL WAVEFORM AND DATA E37ED3B1

Refer to DTC P2238.

## TERMINAL AND CONNECTOR INSPECTION E975F619

Refer to DTC P2238.

## POWER CIRCUIT INSPECTION E988C8D3

- 1. Check voltage & waveform in sensor power circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect O2 sensor connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of O2 sensor connector terminal 1.
  - 5) Monitor the waveform in O2 sensor connector terminal 1.

Specification: Measured voltage: 2.0 V waveform: Refer to "Signal Waveform & Data" of "General Information". The waveform similar to Fig.1) is displayed.

6) Is the measured voltage within the specification?

## YES

▶ Go to "Signal Circuit Inspection".



- ▶ No voltage detected in O2 sensor power circuit : Go to "2. Check open in sensor power circuit" as follows.
- ▶ High voltage detected in O2 sensor power circuit : Repair short to battery in O2 sensor power circuit and go to "Verification of Vehicle Repair".
- 2. Check open in O2 sensor power circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect O2 sensor connector and ECM connector.
  - 3) Check continuity between O2 sensor connector terminal 1 and ECM connector terminal 64.

Specification : Continuity(below  $1.0\Omega$ )

4) Is the measured voltage within the specification?

#### YES

Repair short to ground in O2 sensor power circuit and go to "Verification of Vehicle Repair".

NO

▶ Reapir open in O2 sensor power circuit and go to "Verification of Vehicle Repair".

#### SIGNAL CIRCUIT INSPECTION E93C111F

- 1. Check voltage in sensor signal circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect O2 sensor connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of O2 sensor connector terminal 4.

Specification : 0.8V~0.9 V

5) Is the measured voltage within the specification?

## YES

▶ Go to "3. Check sensor pump circuit".



- No voltage detected in O2 sensor signal circuit : Go to "2. Check open in sensor signal circuit" as follows.
- ▶ High voltage detected in O2 sensor power circuit : Repair short to battery in O2 sensor signal circuit and go to "Verification of Vehicle Repair".
- 2. Check open in O2 sensor signal circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - Disconnect O2 sensor connector and ECM connector.
  - 3) Check continuity between O2 sensor connector terminal 4 and ECM connector terminal 87.

Specification : Continuity (below  $1.0\Omega$ )

的后来的东西是 医疗法

4) Is the measured resistance within the specification?

#### YES

Repair short to ground in O2 sensor signal circuit and go to "Verification of Vehicle Repair".

NO

- Repair open in O2 sensor signal circuit and go to "Verification of Vehicle Repair".
- 3. Check voltage in sensor pump circuit

- 1) IG KEY "OFF", ENGINE "OFF".
- 2) Disconnect O2 sensor connector.
- 3) IG KEY "ON".
- 4) Measure the voltage of O2 sensor connector terminal 6.

Specification: 0.8V~0.9 V

5) Is the measured voltage within the specification?

## YES

Go to "Ground Circuit Inspection".



No voltage detected in O2 sensor pumpl circuit : Go to "4. Check open in sensor pump circuit" as follows.
 High voltage detected in O2 sensor power circuit : Repair short to battery in O2 sensor pump circuit and go to "Verification of Vehicle Repair".

- 4. Check open in sensor pump circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect O2 sensor connector and ECM connector.
  - 3) Check continuity between O2 sensor connector terminal 6 and ECM connector terminal 65.

Specification : Continuity (below  $1.0\Omega$  )

4) Is the measured resistance within the specification?

YES

Repair short to ground in O2 sensor pump circuit and go to "Verification of Vehicle Repair".

NO

Repair open in O2 sensor pump circuit and go to "Verification of Vehicle Repair".

#### GROUND CIRCUIT INSPECTION E81A3386

- 1. Check voltage in sensor ground circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect O2 sensor connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of O2 sensor connector terminal 3.

Specification : 2.3V~2.7V

5) Is the measured voltage within the specification?

## YES

Go to"Component Inspection".

NO

No voltage detected in O2 sensor ground circuit : Go to "2. Check open in sensor ground circuit" as follows.
 High voltage detected in O2 sensor ground circuit : Repair short to battery in O2 sensor ground circuit and go to "Verification of Vehicle Repair".

- 2. Check open in sensor ground circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect O2 sensor connector and ECM connector.
  - 3) Check continuity between O2 sensor connector terminal 3 and ECM connector terminal 86.

Specification : Continuity (below  $1.0\Omega$ )

4) Is the measured resistance within the specification?

## YES

Repair short to ground in O2 sensor ground circuit and go to "Verification of Vehicle Repair".

NO

▶ Repair open in O2 sensor ground circuit and go to "Verification of Vehicle Repair".

#### COMPONENT INSPECTION E24FC0BA

- 1. O2 sensor Visual Inspection
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect O2 sensor connector.
  - 3) Perform visual inspection for each checking point as follows.
    - a. Check corrosion inside of O2 sensor terminal.
    - b. Check damaged coverring and open in component wiring.
    - c. Check connecting torque(poor connection) of O2 sensor component.
    - d. Disconnect O2 sensor and check deformation, clogging, melting of O2 detecting prove.

#### Specification : Everyting OK

4) Is any problem of O2 sensor detected?



Replace O2 sensor and go to "Verification of Vehicle Repair".



▶ Refer to "NOTE" as follows.

## NOTE

In diesel engine, ultra lean combustion generates at normal operating condition. Therefore, O2 sensor signal change in accordance with engine acceleration and various loading condition rarely happens, unlikely to linear O2 sensor of gasoline engine. Moreover, pumping current is not measurable with normal measuring device(ampere meter) because maximum value is 3mA. If DTC code is recorded continuously eventhough circuit inspection is correctly performed and no problem at visual inspection of component is detected, replace O2 sensor.

## VERIFICATION OF VEHICLE REPAIR E6F286E8

Refer to DTC P2238.


m mentu dan olara opalo elang inake dala artika teran dara kontenen dan omeran konten konten soorten oo terinamene, biaalaat oo sudatuu tera dare eeda artiko take oorditet tareditet taregina, "Water wanting last, " He oorditet erver reiname getareen water inee affar and asgina powar ganaration is finlitet. .

(a) A start of the first of an and contacts where water, impressed voltage the provering nounded to chasely a start of the start of the start of the tribule of BCM recordings the smount of water.

 $\sum_{i=1}^{n} ||g_i||^2 = \sum_{i=1}^{n} ||g_i||^2 = \sum_{i$ 

## DTC P2264 DETECTION OF WATER IN FUEL

## COMPONENT LOCATION ED5BBF00




EWPF603H

### GENERAL DESCRIPTION EB08B426

Diesel fuel filter can seperate water from fuel. If water more than specified amount is detected by "water in fuel sensor" installed at the bottom of fuel filter, "Fuel warning lamp" on cluster turns ON.Especially for high pressure pump or injectors of common rail diesel engine is fatal. because water causes poor lubrication and corrosion in such accurate devices, furthermore, it leads engine hesitation. In order to prevent this harsh condition to engine, "Water warning lamp" turns ON to let driver relief the gathered water from the filter and engine power generation is limited.

#### 🛈 ΝΟΤΕ

If sensing prove of water in fuel sensor contacts with water, impressed voltage on prove is grounded to chassis ground, then 12V is outputted from signal line. With this method, ECM recognizes the amount of water.



LGJF006N


## DTC DESCRIPTION E0507D3D

P2246 is set when water in fuel sensor operates for more than 4 sec. Water warning lamp turns on and engine power generation is limited in this condition. When this code is set, water in the filter should be removed to prevent engine from water contained fuel. If same code is set even after removing water, check short to battery in water in fuel sensor signal circuit or component failure.

#### DTC DETECTING CONDITION E47B8386

Item		Detecting	Condition	Possible Cause	
DTC Strategy	<ul> <li>Voltage Mor</li> </ul>	nitoring			
Enable Conditions	<ul> <li>IG KEY "OI</li> </ul>	N"		<ul> <li>Water stored inside of</li> </ul>	
ThresholdValue	<ul> <li>Signal volta</li> </ul>	ge detected	fuel filter		
DiagnosticTime	• 4.0sec.			<ul> <li>( remove water inside of filter</li> <li>• Water in Fuel sensor</li> </ul>	
	Fuel Cut	NO		circuit(short to battery)	
	EGR Off	NO		Water in Fuel sensor	
Fail Safe	Fuel Limit	YES		component	
	MIL	NO	1		

#### SCHEMATIC DIAGRAM E9A2F1C6



EWPF007H

#### TERMINAL AND CONNECTOR INSPECTION EE3F5142

- Electrical systems consist of a lot of harness and connectors, poor connection of terminals can cause various prob-1. lems and damge of component.
- Perform checking procedure as follows. 2.
  - 1) Check damage of harness and terminals : Check terminals for contact resistance, corrosion and deformation.

2) Check connecting condition of ECM and component connector : Check terminal seperation, damage of locking device and connecting condition between terminal and wiring.

## 🗊 ΝΟΤΕ

Disconnect the pin which requires checking at male connector and insert it to the terminal at female connector or checking connecting condition. (after checking, reconnect the pin at correct position.)

3. Is the problem found?



Repair the trouble causing part and go to "Verification of Vehicle Repair".

#### NO

▶ Go to "Power Circuit Inspection".

#### POWER CIRCUIT INSPECTION E7015626

- 1. Ignition "OFF", Turn Engine "OFF".
- 2. Disconnect Water in Fuel sensor connector.
- 3. IG KEY "ON".
- 4. Measure the voltage of Water in Fuel sensor connector terminal 1.

Specification: 11.0V~12.5V	
Specification . 11.0V~12.5V	
	<u>, , , , , , , , , , , , , , , , , , , </u>

5. Is the measured voltage within the specification?

## YES

▶ Go to "Signal Circuit Inspection".

NO.

Repair open in In-pannel junction box 10A ECU fuse and related circuit and go to "Verification of Vehicle Repair".

#### SIGNAL CIRCUIT INSPECTION EE56A33B

- 1. Check signal circuit voltage
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect Water in Fuel sensor connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of Water in Fuel sensor connector terminal 2.

Specification: 0.0V~0.1V

5) Is the measured voltage within the specification?

## YES

▶ Go to "2. Water warning lamp operation test" as follows.

NO

- Repair short to battery and go to "Verification of Vehicle Repair".
- 2. Water warning lamp operation test
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect Water in Fuel sensor connector.
  - 3) IG KEY "ON".
  - 4) Connect water in fuel sensor connector terminal 1 and 2 using jump wire.

```
Specification : Water warning lamp on cluster turns ON. 12V battery voltage is detected at ECM connector(C201-2) terminal 40.
```

5) Does water warning lamp turn ON? And is 12V battery voltage detected at ECM connector(C201-2) terminal 40?

YES

▶ Go to "Ground Circuit Inspection".

NO

▶ Repair open in water warning lamp filament and related circuit and go to "Verification of Vehicle Repair".

ennos gablic belsenno colo di norma ladi a enco frema.

#### GROUND CIRCUIT INSPECTION E853F5DE

- 1. IG KEY "OFF", ENGINE "OFF".
- 2. Disconnect Water in Fuel sensor connector.
- 3. Check continuity between Water in Fuel sensor connector terminal 3 and chassis ground.

Specification : Discontinuity (Infinite  $\Omega$ )

4. Is the measured resistance within the specification?

## YES

▶ Go to "Component Inspection".

### NO

Repair short to ground in signal circuit and go to "Verification of Vehicle Repair".

#### COMPONENT INSPECTION ED5982BC

- 1. Check water inside of fuel filter
  - 1) IG KEY "OFF", ENGINE "OFF".

- Disconnect fuel filter assy' from vehicle. (note : fuel filter should be maintained to stand up vertically at disconnecting.)
- 3) Set up clean vessel like beaker to collect fuel outflowed from filter.
- 4) Disconnect water in fuel sensor and collect fuel and water mixed to it.

Specification : Outflowed fuel must not contain much water.

5) Does fuel contains much water?

## YES

Checking odometer and filter used duration, replace fuel filter if needed. If too much water flowed to fuel filter, check if water flowed into fuel tank and clean up inside of fuel tank.
After replacing filter and clean up fuel tank and go to "Verification of Vehicle Repair".

NO

- ▶ Go to "2.Check water in fuel sensor component" as follows.
- 2. Check water in fuel sensor component
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect fuel filter assy' from vehicle. (note : fuel filter should be maintained to stand up vertically at disconnecting.)
  - 3) Set up clean vessel like beaker to collect fuel outflowed from filter.
  - 4) Disconnect fuel warning sensor from disconnected fuel filter.
  - 5) Connect water in fuel sensor to disconnected wiring connector.
  - 6) IG KEY "ON".
  - 7) Touch water sensing prove of water in fuel sensor to chassis ground.

Specification : Water warning lamp turns ON when touching water sensing prove to chassis ground.

8) Does water warning lamp operate well?

#### YES

Go to "Verification of Vehicle Repair".

#### NO

Replace water in fuel sensor and go to "Verification of Vehicle Repair".

#### VERIFICATION OF VEHICLE REPAIR EB716EB6

After a repair, it is essential to verify that the fault is corrected.

- 1. After connecting Scantool select "DIAGNOSTIC TROUBLE CODES(DTCs)" mode.
- 2. Clear recorded DTC using Scantool.
- 3. Drive the vehicle within DTC "Enable conditions" in "General information".

## DTC TROUBLESHOOTING PROCEDURES

- 4. After selecting "DIAGNOSTIC TROUBLE CODES(DTCs)" mode and check if DTC is recorded again.
- 5. Are any DTCs recorded ?

## YES

▶ Go to the DTC guide of recorded NO. in Scantool.

## NO


System operates within specification.

The second Witten and the set of a subscription of the second set of the second sec

가수가 가지 나가가 가지 않는 것을 가지 않을 것을 것 수 있습니다. 이상을 가지 않는 것을 가지 않을 것을 것 않는 것을 것 같다. 것을 것 같다. 것과 한 것을 가지 않는 것을 가지 않는 것을 것 같은 것을 가지 않는 것을 가지 않는 것을 것 같다. 이것은 것을 것 같은 것을 것 같다. 것을 것 같다. 것을 것 같다. 가지 않는 것을 하는 것을 것 같은 것을 것 같은 것을 것 같다. 것을 것 같은 것을 것 같은 것을 것 같다. 것을 것 하는 것을 수 있는 것을 것 같은 것을 것 같다. 것을 것 같다. 것 같은 것 같은 것 같다. 것을 것 같다. 것을 것 같다. 것 같은 것 같다. 것 같은 것 같다. 것 같은 것 같다. 것 같은 것 같다. 것을 것 같은 것 같은 것 같은 것 같다. 것 같은 것 같은 것 같다. 것 같

## DTC P2299 BRAKE SWITCH " ACC PEDAL SENSOR SIGNALS INPUT SIMULTANEOUSLY AT TIMES

#### COMPONENT LOCATION EDEC7E16



EWPF603I

### GENERAL DESCRIPTION E9381738

Brake switch monitors malfunction of accel pedal sensor(APS).Drivers depress brake pedal when 1).the voltage higher than driver's intension is detected due to APS malfunction(signal circuit short to high voltage) 2).engine power generates excessively due to fault signal.Like previous example, if driver's intension to decelerate is transmitted to ECM(brake pedal depressed) when APS signal is high, ECM consider APS to be fault and Limp Home mode is activated.When Limp Home mode is activated, engine speed is fixed at 1200RPM and driving performance is limited, later, if correct APS signal is detected, Limp Home mode is deactivated immediately.

## DTC DESCRIPTION EF75C112

P2299 is set when brake signal is inputted to ECM for more than 0.5 sec. while APS is depressed more than 5% at above 870RPM, 2Km/h. And Limp Home mode is activated with the DTC code occurence. Later, if correct APS signal is detected, Limp Home mode is deactivated immediately. This code is set when APS signal is a bit higher than the voltage at accelerator released position and driver's pedal manipulation, therfore careful inspection of APS and checking driver's pedal depressing habit is required.


## DTC DETECTING CONDITION E7F259B4

Item		Detecting	Condition	Possible Cause
DTC Strategy	<ul> <li>Voltage mo</li> </ul>	nitoring		
Enable Conditions	<ul> <li>Engine run vehicle sperenter</li> </ul>			
ThresholdValue	<ul> <li>Brake peda voltage abo (Enabled wh pedal depre</li> </ul>	ve 5% nen brake p		
DiagnosticTime	• 500ms		APS 1 Circuit	
	Fuel Cut	NO	<ul> <li>APS standard value</li> </ul>	APS 1 Circuit     APS 2 Circuit
	EGR Off	NO	is 0%. • Limp home idle is fixed	<ul> <li>APS component</li> </ul>
	Fuel Limit	YES	at (1200RPM)	
Fail Safe	MIL	NO	<ul> <li>A/C operation stops according to Vehicle/Engine speed</li> <li>Cruise control deactivated (for Cruise control option applied vehicle)</li> </ul>	

# SPECIFICATION EE4B4309

557	Pedal released	Pedal depressed	Sensor Type	
APS 1	0.7V~0.8V	3.8V~4.4V	Variable resistance	
APS 2	0.275V~0.475V	1.75V~2.35V	type(Potentiometer)	
		CARDER A REAL FOR THE		

## SCHEMATIC DIAGRAM E0219C40



## SIGNAL WAVEFORM AND DATA ED96820C

A†	CH A	0.5	V 26	8 mS	CH B	0.5	V
1		1				:	
		1	APS 1	<u></u>		Ì	
		<u> </u>	APS 2		;		
			1	·····		<u>م</u> ا : ما :	
		$\left\{ \right\}$	APS:20	round ch	eck		·
		<u> </u>	signal				
		7					
D					()- 	····;····	·•····
	040	ZOOM		MEMO	RECI	M	ENU

Fig.1) APS 1 and APS 2 signals are measured simultaneously, Check if output value is rising and APS 2 is 1/2 of APS 1 signal.

LGJF014R

## **NOTE**

APS 2 Ground checking signal is for ECM to monitor APS 2. This signal drops APS 2 output voltage to below 200.39mV per 200msec. If APS 2 output voltage does not drop to below 200.39mV, ECM sets DTC as recognizing ground circuit error of APS 2.

\* The waveform below 200.39mV is not detectable in Ground checking signal waveform of APS 2 signal. Instead, the waveform which drops a little is detected. If APS 2 data of "SERVICE DATA" on the Scantool varies from 350mV to 0mV periodically, it means it works well.

## MONITOR SCANTOOL DATA E4982F5A

- 1. Connect scantool to Data Link Cable (DLC).
- 2. Warm engine up to normal operating temperature.
- 3. Turn "OFF" electrical devices and A/C.
- 4. Monitor "ACCEL PEDAL SENSOR", "ACCEL PEDAL SENSOR 1", "ACCEL PEDAL SENSOR 2 " parameter on the scantool.

Specification : at idle( 0% ) ACCEL PEDAL SENSOR 1 : 600mV~800mV ACCEL PEDAL SENSOR 2 : 1/2 of ACCEL PEDAL SENSOR 1

	1.2 CURRENT DA	TA	21/	54		
				\$		
×	FUEL PRESSURE MEASURED	28.2	2 MPa			a shatashat
×	RAIL PRESS. REGULATOR1	22.7	2 %			
×	AIR MASS PERCYLINDER	359.	7mg/st			
×	ACCEL PEDAL SENSOR	0.0	2	圜	and the second	
×	ACCEL PEDAL SENSOR 1	725	mV			
×	ACCEL PEDAL SENSOR 2	333	μŲ			8-50 - EMA
×	ENGINE SPEED SENSOR	794	rpm		of aulsy bailloaga son of the tao of epsilon in the	
	BOOST PRESSURE SENSOR	-				
				T	we before a l'and part of a contrar of the	
	FIX FULL	GRPH	RCRD	1		
F		- hucenesses	and <u>bonnesseene</u> and	d		

Fig.1) APS output data at warm idle. Check if output value is rising and "ACCEL PEDAL SENSOR 2" is 1/2 of "ACCEL PEDAL SENSOR 1" signal.

#### LGJF002J

## TERMINAL AND CONNECTOR INSPECTION EE7B81A9

- 1. Electrical systems consist of a lot of harness and connectors, poor connection of terminals can cause various problems and damage of component.
- 2. Perform checking procedure as follows.
  - 1) Check damage of harness and terminals : Check terminals for contact resistance, corrosion and deformation.
  - 2) Check connecting condition of ECM and component connector : Check terminal seperation, damage of locking device and connecting condition between terminal and wiring.

## NOTE

Disconnect the pin which requires checking at mail connector and insert it to the terminal at female connector for checking connecting condition. (after checking, reconnect the pin at correct position)

3. Is the problem found?

## YES

Repair the trouble causing part and go to "Verification of Vehicle Repair".

NO

Go to "Power Circuit Inspection".

#### POWER CIRCUIT INSPECTION EDCF0654

- 1. IG KEY "OFF", ENGINE "OFF".
- 2. Disconnect APS connector.
- 3. IG KEY "ON".
- 4. Measure the voltage of APS connector terminal 3 and 6.

Specification: 4.8V~5.1V

5. Is the measured voltage within the specification?

## YES

▶ Go to "Signal Circuit Inspection".

### NO

 If the measured voltage is not within the specified value, find and repair trouble causing part in circuits and go to "Verification of Vehicle Repair".
 When the measured voltage is higher than the specified value : Refer to P0643 Circuit Inspection. (APS1)
 Refer to P0653 Circuit Inspection.(APS2)
 When the measured voltage is lower than the specified value : Refer to P0642 Circuit Inspection.(APS1)

Refer to P0652 Circuit Inspection.(APS2)

#### SIGNAL CIRCUIT INSPECTION E7B79A39

- 1. Check open in signal circuit
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect APS connector and ECM connector.
  - 3) Check continuity between APS connector terminal 2 and ECM connector terminal 9 (APS 1) Check continuity between APS connector terminal 1 and ECM connector terminal 31 (APS 2)

Specification : Continuity (below 1.02)

4) Is the measured resistance within the specification?

## YES

▶ Go to "Check short in signal circuit".

#### NO

- Repair open in signal circuit and go to "Verification of Vehicle Repair".
- 2. Check short in signal circuit (APS 1)
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect APS connector and ECM connector.
  - 3) IG KEY "ON"
  - Check continuity between APS connector terminal 2 and chassis ground. (check short to ground ) Measure the voltage of terminal 2 of APS connector. (check short to battery)

Specification : Check short to ground : Discontinuity ( Infinite  $\Omega$  ) Check short to battery : 0.0V~0.1V

5) Is APS 1 signal circuit insulated normally?

#### YES

Go to "3.Signal Circuit Inspection (APS 2)" as follows.

#### NO

- Repair short in circuit and go to "Verification of Vehicle Repair".
- 3. Signal Circuit Inspection (APS 2)
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect APS connector and ECM connector.
  - 3) IG KEY "ON"
  - 4) Check continuity between APS connector terminal 1 and chassis ground. (check short to ground ) Measure the voltage of terminal 1 of APS connector. ( check short to battery )

Specification : Check short to ground : Discontinuity (Infinite  $\Omega$ ) Check short to battery : 0.0V~0.1V

en an an

5) Is APS 2 signal circuit insulated normally?

## YES

▶ Go to "Ground Circuit Inspection".

#### NO

Repair short in circuit and go to "Verification of Vehicle Repair".

## GROUND CIRCUIT INSPECTION E33B7A54

- 1. Check ground circuit (APS1)
  - 1) IG KEY "OFF", ENGINE "OFF".

#### FLB -504

- 2) Disconnect APS connector.
- 3) IG KEY "ON".
- 4) Measure the voltage of APS terminal 6. [TEST "A"]
- 5) Measure the voltage of APS terminal 6 and terminal 5. [TEST "B"] (terminal 6: Check + prove, terminal 5: Check - prove)

Specification : [TEST "A"] Voltage - [TEST "B"] Voltage = below 200mV

6) Is the measured voltage within the specification?

## YES

▶ Go to "2. Check ground circuit (APS2)".



When "B" voltage is not detected : Repair open in ground circuit and go to "Verification of Vehicle Repair".
 When the voltage difference between "A" and "B" is above 200mV : Eliminate the causes of excessive resistance and go to "Verification of Vehicle Repair".

- 2. Check ground circuit (APS2)
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect APS connector.
  - 3) IG KEY "ON".
  - 4) Measure the voltage of APS terminal 3. [TEST "A"]
  - 5) Measure the voltage of APS terminal 3 and terminal 4. [TEST "B"] (terminal 3: Check + prove, terminal 4 : Check - prove)

Specification : [TEST "A"] Voltage - [TEST "B"] Voltage = below 200mV

6) Is the measured voltage within the specification?

## YES

▶ Go to "Component Inspection".



When "B" voltage is not detected : Repair open in ground circuit and go to "Verification of Vehicle Repair".
 When the voltage difference between "A" and "B" is above 200mV : Eliminate the causes of excessive resistance and go to "Verification of Vehicle Repair".

#### COMPONENT INSPECTION E6FCE124

- 1. IG KEY "OFF", ENGINE "OFF".
- 2. Disconnect APS connector.
- 3. Check resistance for each terminal refering to Resistance characteristic table.

# DTC TROUBLESHOOTING PROCEDURES

		Resistanc	e(KΩ 20°C)		Component
	checking point	Pedal Depressed	Pedal released	Characteristic	Connector Shape
	6(power)- 5(ground)	1.0±0.1KΩ	1.0±0.1KΩ	Unchanged	
APS 1	6(power)- 2(signal)	1.8±0.1KΩ	1.1±0.1KΩ	Resistance drops	
	2(signal)- 5(ground)	1.1±0.1KΩ	1.8±0.1KΩ	Resistance rises	
	3(power)- 4(ground)	<b>2.0±0.1K</b> Ω	2.0±0.1KΩ	Unchanged	
APS 2	3(power)- 1(signal)	2.9±0.1KΩ	2.1±0.1KΩ	Resistance drops	LGJF002
	1(signal)- 4(ground)	1.1±0.1KΩ	1.8±0.1KΩ	Resistance rises	

Specification : Resistance characteristic table for each terminal

4. Are resistances for each terminal measured correctly?

# YES

▶ Go to "Verification of Vehicle Rapair".



▶ Replace APS and go to "Verification of Vehicle Rapair".

# VERIFICATION OF VEHICLE REPAIR

After a repair, it is essential to verify that the fault is corrected.

- 1. After connecting Scantool select "DIAGNOSTIC TROUBLE CODES(DTCs)" mode.
- 2. Clear recorded DTC using Scantool.
- 3. Drive the vehicle within DTC "Enable conditions" in "General information".
- 4. After selecting "DIAGNOSTIC TROUBLE CODES(DTCs)" mode and check if DTC is recorded again.

E8315EBD

5. Are any DTCs recorded ?

# YES


Go to the DTC guide of recorded NO. in Scantool.

## NO

System operates within specification.

# DTC U0001 CAN COMMUNICATION MALFUNCTION

#### COMPONENT LOCATION EBOBC3CO




EWPF603J

LGJF014H

## GENERAL DESCRIPTION E77E6068

Several control units are applied to electronically controlled vehicles. These units perform each control with informations from various sensors. Thus, sharing signal information from sensors is needed, so CAN communication type whose communication speed is high and insensitive to electrical noise by spark generation is adopted to controlling power-train(engine, atutomatic transaxle, ABS, TCS, ECS)As sharing signals of engine speed, APS, engaged gear and torque reduction through CAN communication, ECM and TCM modules control vehicle actively.



DTC DESCRIPTION EA34673E

U0001 is set when signal transmission through CAN communication line is impossible for more than 0.1 sec. because of open or short to ground in CAN communication line. Checking CAN communication BUS and signals from ECM, TCM module is required.

# DTC DETECTING CONDITION EE6A5BAA


ltem		Detecting	<b>Condition</b>		Possible Cause
DTC Strategy	<ul> <li>Signal moni</li> </ul>	itoring			
Enable Conditions	<ul> <li>IG KEY "OI</li> </ul>	<b>N</b> "			
ThresholdValue	CAN BUS	ərror		-	
DiagnosticTime	• 100ms				CAN BUS     CAN communication module
	Fuel Cut	NO			component
	EGR Off	NO			
Fail Safe	Fuel Limit	NO			
	MIL	NO			

# SPECIFICATION E4F3D920

	DIGITA	\L "0"	DIGITAL "1"(	BUS IDLE)	CAN Commu Resis	
Communica- tion Format	HIGH	LOW	HIGH	LOW	Inside of ECM	Inside of In-pannel junction box
CAN 2.0B	3.5V	1.5V	2.5V	2.5V	120Ω (20℃)	120Ω (20℃)


FLB -507

# SCHEMATIC DIAGRAM EGAAEEC4



EWPF008L

#### SIGNAL WAVEFORM AND DATA E340D7ED



#### Fig.1

Fig.1) CAN communication waveform

Monitoring CAN HIGH and LOW simultaneously is important in monitoring CAN communication waveform. When CAN HIGH signal rise to 3.5V and LOW signal drops to 1.5V - voltage difference between HIGH and LOW signal is 2V - at BUS IDLE state (DIGITAL "1") whose reference voltage is 2.5V, "0" is recognized. Besides, comparing HIGH and LOW signal if opposite waveform is detected with the reference voltage of 2.5V, Check if current cam signal transfers correctly. Continuous "0"signal above 6BIT means the occurence of error in CAN communication.

1BIT is easily distinguished as calculating the time when "SOF"(START OF FRAME) which notifies the start of frame occurs.

Check if "0"signal above 6BIT is detected continuously when monitoring CAN communication waveform.

LGJF014J

#### TERMINAL AND CONNECTOR INSPECTION E851D40E

- 1. Electrical systems consist of a lot of harness and connectors, poor connection of terminals can cause various problems and damge of component.
- 2. Perform checking procedure as follows.
  - 1) Check damage of harness and terminals : Check terminals for contact resistance, corrosion and deformation.
  - 2) Check connecting condition of ECM and component connector : Check terminal seperation, damage of locking device and connecting condition between terminal and wiring.

## **NOTE**

Disconnect the pin which requires checking at male connector and insert it to the terminal at female connector for checking connecting condition. (after checking, reconnect the pin at correct position.)

3. Is the problem found?



Repair the trouble causing part and go to "Verification of Vehicle Repair".



Go to "Signal Circuit Inspection".

#### SIGNAL CIRCUIT INSPECTION E3629480

- 1. Check CAN BUS resistance
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Measure the resistance between diagnostic connector 3 and 11.
  - 3) Disconnect ECM and TCM connector.
  - 4) Measure the resistance between diagnostic connector 3 and 11.

Specification : Both ECM and TCM connected :  $60 \pm 3\Omega$  (Test 1) Both ECM and TCM disconnected :  $120 \pm 3\Omega$  (Test 2)

5) Is CAN BUS resistance within the specification?

# YES

▶ Go to "2.Check short to ground in CAN BUS" as follows.

#### NO

▶ Below 10Ω for both conditions(disconnected, connected) : Repair short between CAN BUS and go to "Verification of Vehicle Repair".

▶ 120Ω for both conditions(disconnected, connected) : Go to "4. Check CAN BUS continuity".

Infinite  $\Omega$  for both conditions(disconnected, connected) :Repair open in CAN communication circuit between DLC terminal and In-pannel junction box.

- 2. Check short to ground in CAN BUS
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect ECM and TCM connectors.
  - 3) Check continuity between DLC terminal 3 and chassis ground. (CAN HIGH)
  - 4) Check continuity between DLC terminal 11 and chassis ground. (CAN LOW)

Specification : Discontinuity (Infinite  $\Omega$ )

5) Is measured resistance within the specification?

## YES

▶ Go to "3. Check short to battery in CAN BUS".

#### NO

- Repair short to ground in circuit and go to "Verification of Vehicle Repair".
- 3. Check short to battery in CAN BUS
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect ECM and TCM connectors.
  - 3) IG KEY "ON".

## DTC TROUBLESHOOTING PROCEDURES

- 4) Measure the voltage of DLC terminal 3. (CAN HIGH)
- 5) Measure the voltage of DLC terminal 11. (CAN LOW)

Specification: 0.0V~0.1V

6) Is measured resistance within the specification with both connector disconnected?

# YES

▶ Go to"4. Check CAN BUS continuity" as follows.

## NO

- Repair short to battery and go to "Verification of Vehicle Repair".
- 4. Check CAN BUS continuity
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect ECM and TCM connectors.
  - 3) Check continuity between DLC terminal 3 and CAN HIGH terminal of each module.
     ( CAN HIGH : ECM connector terminal 84, TCM connector terminal 38, multipurpose check connector terminal 9 )
  - 4) Check continuity between DLC terminal 11 and CAN LOW terminal of each module.
     ( CAN LOW : ECM connector terminal 83, TCM connector terminal 36, multipurpose check connector terminal 17 )

Specification : Continuity(below  $1.0\Omega$ )

5) Is the measured resistance within the specification? Control Control

# YES

▶ Go to "Component Inspection".


NO

▶ Repair open in CAN BUS and go to "Verification of Vehicle Repair".

## COMPONENT INSPECTION EF576C94

- 1. Check CAN communication waveform generation
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Connect 2 channel scope to DLC terminal 3(CAN HIGH) and 11(CAN LOW).
  - 3) IG KEY "ON" after connecting only ECM to CAN BUS.
  - 4) IG KEY "ON" after connecting only TCM to CAN BUS.

Specification : At IG KEY "ON", the waveform same as "Signal Waveform & Data" of this code generates. \* Different from "Signal Waveform & Data", if 1) both CAN HIGH and LOW signal are fixed at 2.5 V or 2) HIGH and LOW signal are fixed at 3.5 V and 1.5 V, respectively, it is due to communication error between modules.



5) Does correct waveform generate from each module?

#### YES

▶ Go to "Verification of Vehicle Repair".

#### NO

▶ Replace the module which generates poor communication waveform, and go to "Verification of Vehicle Repair".

## VERIFICATION OF VEHICLE REPAIR EBBDF619

After a repair, it is essential to verify that the fault is corrected.

- 1. After connecting Scantool select "DIAGNOSTIC TROUBLE CODES(DTCs)" mode.
- 2. Clear recorded DTC using Scantool.
- 3. Drive the vehicle within DTC "Enable conditions" in "General information".
- 4. After selecting "DIAGNOSTIC TROUBLE CODES(DTCs)" mode and check if DTC is recorded again.
- 5. Are any DTCs recorded ?

#### YES

▶ Go to the DTC guide of recorded NO. in Scantool.

#### NO

System operates within specification.

# DTC U0100 CAN-TIME OUT ECU

#### COMPONENT LOCATION EBAA2650

Refer to DTC U0001.

# GENERAL DESCRIPTION E94348EB

Refer to DTC U0001.

#### DTC DESCRIPTION EA3FBF4A

U0100 is set when no signal transmission through CAN BUS occurs for more than 0.5 sec.. This code is due to CAN BUS problem or CAN communication module failure.

# DTC DETECTING CONDITION E724140A

Item		Detecting	Condition	Possible Cause
DTC Strategy	<ul> <li>Signal moni</li> </ul>	itoring		
Enable Conditions	<ul> <li>IG KEY "OI</li> </ul>	N"		
ThresholdValue	<ul> <li>No signal transmission</li> </ul>	ansmission	· · · · · · · · · · · · · · · · · · ·	
DiagnosticTime	• 500ms			CAN BUS
Contraction of the second s	Fuel Cut	NÓ	kon antina antina kon antina a conserva- kon oodona <sup>ta</sup> ontoi	
	EGR Off	NO	つり(高) (清査合)	
Fail Safe	Fuel Limit	NO		
	MIL	NO		n de la constante de la constan La constante de la constante de

and the second second second second

# SPECIFICATION EBF02EDF

	DIGIT	AL "0"	DIGITAL "1"	(BUS IDLE)	CAN Commu Resis	
Communica- tion Format	HIGH	LOW	HIGH	LOW	Inside of ECM	Inside of In-pannel junction box
CAN 2.0B	3.5V	1.5V	2.5V	2.5V	120Ω (20℃)	120Ω (20℃)

#### SCHEMATIC DIAGRAM E69CF34A

Refer to DTC U0001.

#### SIGNAL WAVEFORM AND DATA E4751A13

Refer to DTC U0001.

# TERMINAL AND CONNECTOR INSPECTION ECDD2765

Refer to DTC U0001.

#### SIGNAL CIRCUIT INSPECTION EE38852A

- 1. Check CAN BUS resistance
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Measure the resistance between diagnostic connector 3 and 11.
  - 3) Disconnect ECM and TCM connector.
  - 4) Measure the resistance between diagnostic connector 3 and 11.

Specification : Both ECM and TCM connected :  $60 \pm 3\Omega$  (Test 1) Both ECM and TCM disconnected :  $120 \pm 3\Omega$  (Test 2)

5) Is CAN BUS resistance within the specification?

#### YES

▶ Go to "2.Check short to ground in CAN BUS" as follows.

#### NO

Below 10Ω for both conditions(disconnected, connected) : Repair short between CAN BUS and go to "Verification of Vehicle Repair".

▶ 120Ω for both conditions(disconnected, connected) : Go to "4. Check CAN BUS continuity".

Infinite  $\Omega$  for both conditions(disconnected, connected) :Repair open in CAN communication circuit between DLC terminal and In-pannel junction box.

- 2. Check short to ground in CAN BUS
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect ECM and TCM connectors.
  - 3) Check continuity between DLC terminal 3 and chassis ground. (CAN HIGH)
  - 4) Check continuity between DLC terminal 11 and chassis ground. (CAN LOW)

Specification : Discontinuity (Infinite  $\Omega$ )

5) Is measured resistance within the specification?

#### YES

Go to "3. Check short to battery in CAN BUS".

#### NO

- ▶ Repair short to ground in circuit and go to "Verification of Vehicle Repair".
- 3. Check short to battery in CAN BUS
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect ECM and TCM connectors.
  - 3) IG KEY "ON".

## DTC TROUBLESHOOTING PROCEDURES

- 4) Measure the voltage of DLC terminal 3. (CAN HIGH)
- 5) Measure the voltage of DLC terminal 11. (CAN LOW)

Specification : 0.0V~0.1V

6) Is measured resistance within the specification with both connector disconnected?

# YES

▶ Go to"4. Check CAN BUS continuity" as follows.

## NO

- Repair short to battery and go to "Verification of Vehicle Repair".
- 4. Check CAN BUS continuity
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect ECM and TCM connectors.
  - 3) Check continuity between DLC terminal 3 and CAN HIGH terminal of each module.
     ( CAN HIGH : ECM connector terminal 84, TCM connector terminal 38, multipurpose check connector terminal 9 )
  - 4) Check continuity between DLC terminal 11 and CAN LOW terminal of each module.
     ( CAN LOW : ECM connector terminal 83, TCM connector terminal 36, multipurpose check connector terminal 17 )

Specification : Continuity(below 1.0 Ω)

5) Is the measured resistance within the specification?

# YES

▶ Go to "Component Inspection".


NO

Repair open in CAN BUS and go to "Verification of Vehicle Repair".

#### COMPONENT INSPECTION E01F35A2

- 1. Check CAN communication waveform generation
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Connect 2 channel scope to DLC terminal 3(CAN HIGH) and 11(CAN LOW).
  - 3) IG KEY "ON" after connecting only ECM to CAN BUS.
  - 4) IG KEY "ON" after connecting only TCM to CAN BUS.

Specification : At IG KEY "ON", the waveform same as "Signal Waveform & Data" of this code generates. \* Different from "Signal Waveform & Data", if 1) both CAN HIGH and LOW signal are fixed at 2.5 V or 2) HIGH and LOW signal are fixed at 3.5 V and 1.5 V, respectively, it is due to communication error between modules.



5) Does correct waveform generate from each module?

## YES

▶ Go to "Verification of Vehicle Repair".

# NO

▶ Replace the module which generates poor communication waveform, and go to "Verification of Vehicle Repair".

## VERIFICATION OF VEHICLE REPAIR E2F9795E

Refer to DTC U0001.

# DTC U0101 SERIAL COMMUNICATION PROBLEM WITH TCU (TIMEOUT)

#### COMPONENT LOCATION E6B4E50C

Refer to DTC U0001.

## GENERAL DESCRIPTION ECDF6819

Refer to DTC U0001.

#### DTC DESCRIPTION E2EEC1E6

U0101 is set when ECM send data requiring signal to TCM, but no return signal is transmitted to ECM within 0.5 sec.. This code is due to TCM CAN line related problem or TCM module failure.

#### DTC DETECTING CONDITION E95271FD

ltem		Detecting	Condition	Possible Cause
DTC Strategy	<ul> <li>Signal mon</li> </ul>	itoring		
Enable Conditions	<ul> <li>IG KEY "OI</li> </ul>	N"	N	
ThresholdValue	<ul> <li>CAN comm</li> </ul>	unication err	ror between ECM and TCS1	
DiagnosticTime	• 500ms			CAN BUS
	Fuel Cut	NŎ	n an	<ul> <li>CAN communication module component</li> </ul>
	EGR Off	NO	مر . بر مر . بر	•
Fail Safe	Fuel Limit	NO		ARE AN AREAR AND A CARD AND A STREET
	MIL	NO	-14(	

a dagana Alatika ta

# SPECIFICATION E96B87B1

Communica-	DIGIT	AL "0"	DIGITAL "1"	(BUS IDLE)	CAN Commu Resis	
tion Format	HIGH	LOW	HIGH	LOW	Inside of ECM	Inside of In-pannel junction box
CAN 2.0B	3.5V	1.5V	2.5V	2.5V	120Ω (20℃)	120Ω (20℃)

# SCHEMATIC DIAGRAM E06089B5

Refer to DTC U0001.

## SIGNAL WAVEFORM AND DATA E8858101

Refer to DTC U0001.

# TERMINAL AND CONNECTOR INSPECTION E500790A

Refer to DTC U0001.

## SIGNAL CIRCUIT INSPECTION ESB7B971

- 1. Check CAN BUS resistance
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Measure the resistance between diagnostic connector 3 and 11.
  - 3) Disconnect ECM and TCM connector.
  - 4) Measure the resistance between diagnostic connector 3 and 11.

Specification : Both ECM and TCM connected :  $60 \pm 3\Omega$  (Test 1) Both ECM and TCM disconnected :  $120 \pm 3\Omega$  (Test 2)

5) Is CAN BUS resistance within the specification?

# YES

▶ Go to "2.Check short to ground in CAN BUS" as follows.

#### NO

▶ Below 10Ω for both conditions(disconnected, connected) : Repair short between CAN BUS and go to "Verification of Vehicle Repair".

▶ 120Ω for both conditions(disconnected, connected) : Go to "4. Check CAN BUS continuity".

Infinite  $\Omega$  for both conditions(disconnected, connected) :Repair open in CAN communication circuit between DLC terminal and In-pannel junction box.

- 2. Check short to ground in CAN BUS
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect ECM and TCM connectors.
  - 3) Check continuity between DLC terminal 3 and chassis ground. (CAN HIGH)
  - 4) Check continuity between DLC terminal 11 and chassis ground. (CAN LOW)

Specification : Discontinuity (Infinite  $\Omega$ )

5) Is measured resistance within the specification?

# YES

▶ Go to "3. Check short to battery in CAN BUS".

#### NO

- Repair short to ground in circuit and go to "Verification of Vehicle Repair".
- 3. Check short to battery in CAN BUS
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect ECM and TCM connectors.
  - 3) IG KEY "ON".

## DTC TROUBLESHOOTING PROCEDURES

5) Measure the voltage of DLC terminal 11. (CAN LOW)

Specification : 0.0V~0.1V

6) Is measured resistance within the specification with both connector disconnected?

YES

▶ Go to"4. Check CAN BUS continuity" as follows.

NO

- Repair short to battery and go to "Verification of Vehicle Repair".
- 4. Check CAN BUS continuity
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect ECM and TCM connectors.
  - 3) Check continuity between DLC terminal 3 and CAN HIGH terminal of each module.
     ( CAN HIGH : ECM connector terminal 84, TCM connector terminal 38, multipurpose check connector terminal 9 )
  - 4) Check continuity between DLC terminal 11 and CAN LOW terminal of each module.
     ( CAN LOW : ECM connector terminal 83, TCM connector terminal 36, multipurpose check connector terminal 17 )

Specification : Continuity(below 1.0 Ω)

5) Is the measured resistance within the specification?



Go to "Component Inspection".


NO

▶ Repair open in CAN BUS and go to "Verification of Vehicle Repair".

# COMPONENT INSPECTION E5B753AE

- 1. Check CAN communication waveform generation
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Connect 2 channel scope to DLC terminal 3(CAN HIGH) and 11(CAN LOW).
  - 3) IG KEY "ON" after connecting only ECM to CAN BUS.
  - 4) IG KEY "ON" after connecting only TCM to CAN BUS.

Specification : At IG KEY "ON", the waveform same as "Signal Waveform & Data" of this code generates. \* Different from "Signal Waveform & Data", if 1) both CAN HIGH and LOW signal are fixed at 2.5 V or 2) HIGH and LOW signal are fixed at 3.5 V and 1.5 V, respectively, it is due to communication error between modules.



EWPF008Q

5) Does correct waveform generate from each module?

# YES

▶ Go to "Verification of Vehicle Repair".

# NO

▶ Replace the module which generates poor communication waveform, and go to "Verification of Vehicle Repair".

# VERIFICATION OF VEHICLE REPAIR E007766E

Refer to DTC U0001.

# DTC U0122 ECM-TCS CAN ERROR

#### COMPONENT LOCATION EGEA6886

Refer to DTC U0001.

## GENERAL DESCRIPTION E180B77F

Refer to DTC U0001.

#### DTC DESCRIPTION EC5AB378

U0122 is set when ECM sends data requiring signal to TCS, but no return signal is transmitted to ECM by within 0.5 sec.. This code is due to TCS CAN line related problem or TCS module failure.

# DTC DETECTING CONDITION EBB8B13E

ltem		Detecting	g Condition		Possible Cause
DTC Strategy	<ul> <li>Signal mon</li> </ul>	itoring			
Enable Conditions	IG KEY "OI	N"			
ThresholdValue	CAN comm	unication er	ror between EC	M and TCS1	
DiagnosticTime	• 500ms			$M_{\rm eff} = 2^{10}$	• CAN BUS
	Fuel Cut	NO		· · · · · · · · · · · · · · · · · · ·	<ul> <li>CAN communication module component</li> </ul>
Fail Safe	EGR Off	NO			
	Fuel Limit	NO			a station of Market and Station and Station
	MIL	NO		4.	的建设减温,产利用学习的利用。

androanmod MOT bris MUD (manimum)

SPECIFICATION EFF98C6F (MCBEL4100) Sector Distance Contraction Contraction Contraction Contraction

Communica-	DIGIT	AL "0"	DIGITAL "1"	(BUSIDLE)	CAN Commu Resis	
tion Format	HIGH	LOW	HIGH	LOW	Inside of ECM	Inside of In-pannel junction box
CAN 2.0B	3.5V	1.5V	2.5V	2.5V	120Ω (20℃)	120Ω (20℃)

## SCHEMATIC DIAGRAM E087FFF8

Refer to DTC U0001.

# SIGNAL WAVEFORM AND DATA E4C28665

Refer to DTC U0001.

# TERMINAL AND CONNECTOR INSPECTION E1261E57

Refer to DTC U0001.

#### SIGNAL CIRCUIT INSPECTION E39E7712

- 1. Check CAN BUS resistance
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Measure the resistance between diagnostic connector 3 and 11.
  - 3) Disconnect ECM and TCM connector.
  - 4) Measure the resistance between diagnostic connector 3 and 11.

Specification : Both ECM and TCM connected :  $60 \pm 3\Omega$  (Test 1) Both ECM and TCM disconnected :  $120 \pm 3\Omega$  (Test 2)

5) Is CAN BUS resistance within the specification?

## YES

▶ Go to "2.Check short to ground in CAN BUS" as follows.

#### NO

Below 10Ω for both conditions(disconnected, connected) : Repair short between CAN BUS and go to "Verification of Vehicle Repair".

- ▶ 120Ω for both conditions(disconnected, connected) : Go to "4. Check CAN BUS continuity".
- Infinite  $\Omega$  for both conditions(disconnected, connected) :Repair open in CAN communication circuit between DLC terminal and In-pannel junction box.
- 2. Check short to ground in CAN BUS
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect ECM and TCM connectors.
  - 3) Check continuity between DLC terminal 3 and chassis ground. (CAN HIGH)
  - 4) Check continuity between DLC terminal 11 and chassis ground. (CAN LOW)

Specification : Discontinuity (Infinite  $\Omega$ )

5) Is measured resistance within the specification?

# YES

▶ Go to "3. Check short to battery in CAN BUS".

#### NO

- ▶ Repair short to ground in circuit and go to "Verification of Vehicle Repair".
- 3. Check short to battery in CAN BUS
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect ECM and TCM connectors.
  - 3) IG KEY "ON".

# DTC TROUBLESHOOTING PROCEDURES

- 4) Measure the voltage of DLC terminal 3. (CAN HIGH)
- 5) Measure the voltage of DLC terminal 11. (CAN LOW)

Specification : 0.0V~0.1V

6) Is measured resistance within the specification with both connector disconnected?

YES

▶ Go to"4. Check CAN BUS continuity" as follows.

NO

- Repair short to battery and go to "Verification of Vehicle Repair".
- 4. Check CAN BUS continuity
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect ECM and TCM connectors.
  - 3) Check continuity between DLC terminal 3 and CAN HIGH terminal of each module.
     ( CAN HIGH : ECM connector terminal 84, TCM connector terminal 38, multipurpose check connector terminal 9 )
  - 4) Check continuity between DLC terminal 11 and CAN LOW terminal of each module.
     ( CAN LOW : ECM connector terminal 83, TCM connector terminal 36, multipurpose check connector terminal 17 )

Specification : Continuity(below  $1.0\Omega$  )

5) Is the measured resistance within the specification?

# YES

▶ Go to "Component Inspection".


NO


▶ Repair open in CAN BUS and go to "Verification of Vehicle Repair".

#### COMPONENT INSPECTION EOE3AABE

- 1. Check CAN communication waveform generation
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Connect 2 channel scope to DLC terminal 3(CAN HIGH) and 11(CAN LOW).
  - 3) IG KEY "ON" after connecting only ECM to CAN BUS.
  - 4) IG KEY "ON" after connecting only TCM to CAN BUS.

Specification : At IG KEY "ON", the waveform same as "Signal Waveform & Data" of this code generates. \* Different from "Signal Waveform & Data", if 1) both CAN HIGH and LOW signal are fixed at 2.5 V or 2) HIGH and LOW signal are fixed at 3.5 V and 1.5 V, respectively, it is due to communication error between modules.





EWPF008Q

5) Does correct waveform generate from each module?

## YES

▶ Go to "Verification of Vehicle Repair".

## NO

▶ Replace the module which generates poor communication waveform, and go to "Verification of Vehicle Repair".

# VERIFICATION OF VEHICLE REPAIR E251190A

Refer to DTC U0001.

# DTC U0416 ABNORMAL TORQUE RISE REQUEST FROM TCS

#### COMPONENT LOCATION ECODO1A6

Refer to DTC U0001.

#### GENERAL DESCRIPTION EF79B360

Refer to DTC U0001.

#### DTC DESCRIPTION E098E9B6

U0416 is set when ECM detects the signal requires abnormal torque increase from ECM for more than 0.5 sec. Checking CAN communication line or TCS module is required.

# DTC DETECTING CONDITION EOD07F12

Item		Detecting	g Condition		Possible Cause
DTC Strategy	<ul> <li>Signal moni</li> </ul>	itoring			
Enable Conditions	• IG KEY "OI	N"			
ThresholdValue	<ul> <li>Abnormal to</li> </ul>	orque incre	ase request fro	om TCS	A data
DiagnosticTime	• 500ms		$= \sum_{i=1}^{n-1} e^{i x_i L_{i}^{2/2}} = x_{i} + \cdots + x_{i}$		CAN BUS
	Fuel Cut	NO			<ul> <li>CAN communication module component</li> </ul>
Toil Cofe	EGR Off	NO	_		
Fail Safe	Fuel Limit	NO		$\langle z_{i}^{1},z_{i}\rangle k_{i}^{2}$	$\mathbb{E}^{\frac{1}{2}\int_{-\infty}^{\infty} \left\{\frac{1}{2}\int_{-\infty}^{\infty} \frac{1}{2}\int_{-\infty}^{\infty} \left(\frac{1}{2}\int_{-\infty}^{\infty} \frac{1}{2}\int_{-\infty}^{\infty} $
	MIL	NO		- 백력종	

ang in the

# SPECIFICATION E312F32C

Communica-	DIGIT	AL "0"	DIGITAL "1"	(BUS IDLE)	CAN Commu Resis	
tion Format	HIGH	LOW	HIGH	LOW	Inside of ECM	Inside of In-pannel junction box
CAN 2.0B	3.5V	1.5V	2.5V	2.5V	120Ω (20℃)	120Ω (20℃)
· · · · · · · · · · · · · · · · · · ·		*****	•			i je Alexandre da se

#### SCHEMATIC DIAGRAM E8278ABE

Refer to DTC U0001.

#### SIGNAL WAVEFORM AND DATA E4046D8C

Refer to DTC U0001.

# TERMINAL AND CONNECTOR INSPECTION ED693327

Refer to DTC U0001.

#### SIGNAL CIRCUIT INSPECTION E8364581

- 1. Check CAN BUS resistance
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Measure the resistance between diagnostic connector 3 and 11.
  - 3) Disconnect ECM and TCM connector.
  - 4) Measure the resistance between diagnostic connector 3 and 11.

Specification : Both ECM and TCM connected :  $60 \pm 3\Omega$  (Test 1) Both ECM and TCM disconnected :  $120 \pm 3\Omega$  (Test 2)

5) Is CAN BUS resistance within the specification?

## YES

▶ Go to "2.Check short to ground in CAN BUS" as follows.

#### NO

▶ Below 10Ω for both conditions(disconnected, connected) : Repair short between CAN BUS and go to "Verification of Vehicle Repair".

- ▶ 120Ω for both conditions(disconnected, connected) : Go to "4. Check CAN BUS continuity".
- left Infinite  $\Omega$  for both conditions(disconnected, connected) :Repair open in CAN communication circuit between DLC terminal and In-pannel junction box.
- 2. Check short to ground in CAN BUS
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect ECM and TCM connectors.
  - 3) Check continuity between DLC terminal 3 and chassis ground. (CAN HIGH)
  - 4) Check continuity between DLC terminal 11 and chassis ground. (CAN LOW)

Specification : Discontinuity (Infinite  $\Omega$ )

5) Is measured resistance within the specification?

# YES

▶ Go to "3. Check short to battery in CAN BUS".

#### NO

- ▶ Repair short to ground in circuit and go to "Verification of Vehicle Repair".
- 3. Check short to battery in CAN BUS
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect ECM and TCM connectors.
  - 3) IG KEY "ON".

# DTC TROUBLESHOOTING PROCEDURES

- 4) Measure the voltage of DLC terminal 3. (CAN HIGH)
- 5) Measure the voltage of DLC terminal 11. (CAN LOW)

Specification : 0.0V~0.1V

6) Is measured resistance within the specification with both connector disconnected?

YES

▶ Go to"4. Check CAN BUS continuity" as follows.

NO

- Repair short to battery and go to "Verification of Vehicle Repair".
- 4. Check CAN BUS continuity
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Disconnect ECM and TCM connectors.
  - 3) Check continuity between DLC terminal 3 and CAN HIGH terminal of each module.
     ( CAN HIGH : ECM connector terminal 84, TCM connector terminal 38, multipurpose check connector terminal 9 )
  - 4) Check continuity between DLC terminal 11 and CAN LOW terminal of each module.
     ( CAN LOW : ECM connector terminal 83, TCM connector terminal 36, multipurpose check connector terminal 17 )

Specification : Continuity(below  $1.0\Omega$  )

5) Is the measured resistance within the specification?

# YES

Go to "Component Inspection".


NO


Repair open in CAN BUS and go to "Verification of Vehicle Repair".

#### COMPONENT INSPECTION EC434FC4

- 1. Check CAN communication waveform generation
  - 1) IG KEY "OFF", ENGINE "OFF".
  - 2) Connect 2 channel scope to DLC terminal 3(CAN HIGH) and 11(CAN LOW).
  - 3) IG KEY "ON" after connecting only ECM to CAN BUS.
  - 4) IG KEY "ON" after connecting only TCM to CAN BUS.

Specification : At IG KEY "ON", the waveform same as "Signal Waveform & Data" of this code generates. \* Different from "Signal Waveform & Data", if 1) both CAN HIGH and LOW signal are fixed at 2.5 V or 2) HIGH and LOW signal are fixed at 3.5 V and 1.5 V, respectively, it is due to communication error between modules.





EWPF008Q

5) Does correct waveform generate from each module?

## YES

▶ Go to "Verification of Vehicle Repair".

# NO


▶ Replace the module which generates poor communication waveform, and go to "Verification of Vehicle Repair".

## VERIFICATION OF VEHICLE REPAIR EDF4232C

Refer to DTC U0001.

# FUEL DELIVERY SYSTEM-DIESEL

# COMPONENTS EA561E11




- 1. Injector
- 2. High Pressure (HP) Pump
- 3. Fuel pressure regulator
- 4. Common rail
- 5. High pressure pipe (injector ← Common rail)
- 6. High pressure pipe (common rail ← HP pump)
- 7. Fuel filter
- 8. Fuel sender
- 9. Fuel tank
- 10. Rail pressure control valve

EWPF600U

# CAUTION

- Common Rail Fuel Injection System is subject to extremely high pressure (Approximately 1,600 bar)
- Never perform any work on injection system wth engine running or within 30 seconds after the engine stops.
- Always pay attention to safety precaution.
- Ensure the absolute cleanliness.
- It is not recommanded to remove the injectors without any notice.

# SCHEMATIC DIAGRAM E1C4C626



- 1. Fuel Tank
- 2. Pre-filter
- 3. Fuel sender
- 4. Fuel Filter
- 5. Low Pressure Fuel Line
- 6. High Pressure Pump
- 7. High Pressure Fuel Line


- 8. Common Rail
- 9. Injector
- 10. Fuel Return Line
- 11. ECM
- 12. Rail Pressure Sensor
- 13. Rail Pressure regulator
- 14. Rail Pressure control valve

LGJF502N

and the second 
# INJECTOR

#### DESCIRPTION EODEBBEE

## COMPONENTS



#### CLEANING E3CB64D5

# CAUTION

- Common Rail Fuel Injection System is subject to extremely high pressure (Approximately 1,600 bar)
- Never perform any work on injection system wth engine running or within 30 seconds after the engine stops.
- Always pay attention to safety precaution.
- Ensure the absolute cleanliness.
- It is not recommanded to remove the injectors without any notice.

It must be needed to clean the injector when injector is used again.

- 1. Clean the injector in vertical position in an ultra-sound bath.
- If necessary, clean the injector body and sealing surface on the nozzle retaining nut also, using a fine cleaning cloth to remove any dirt residue.
   Do not remove the protection caps to do that.
- The nozzle-shaft must only be cleaned in an ultrasound bath and in a vertical position.
   A mechanical cleaning of the nozzle-shaft by wirebrush is not permitted.


REMOVAL E45F3375

# CAUTION

- Common Rail Fuel Injection System is subject to extremely high pressure (Approximately 1,600 bar)
- Never perform any work on injection system with engine running or within 30 seconds after the engine stops.
- Always pay attention to safety precaution.
- Ensure the absolute cleanliness.
- It is not recommended to remove the injectors without any notice.
- 1. Turn ignition switch to OFF position.
- 2. Disconnect the negative battery (-) terminal and wait for about 30 seconds.
- 3. Pull off the injector electric connector (A).


# \Lambda CAUTION

- Plugs must be installed and/or uninstalled only with the ignition switch turned OFF.
- Do not extremely bend or squeeze the cable, do not bring them in contact with sharp edges, and also secure cables against vibrations.
- 4. Unfasten the high-pressure pipe (B) connecting the common rail and the injector.



LXGF570A

5. Remove the injector return hose (C) by pulling the fixing-clip (D) and unscrew the injector fixing bolt(E).



LGJF502P


6. Pull the injector assembly.

# CAUTION

When pulling the injector, pull the injector upright so that the nozzle needle cannot be scratched or damaged.

# NOTE

When the injector is stuck on cylinder head, pull it out with SST (09351-4A200, 09351-2A100).



AWJF333Z


# REPLACEMENT EF30BF60

# CAUTION

When exchanging injectors be sure to input injector data(7 digits) of new one into the ECM using a Hi-Scan(Pro).

- 1. Remove the injector according to removal procedure.
- 2. Check the class of injector, and then replace the used injector with the new one.
- 3. Check injector data (7 digits) of new injector.


Injector data (7 digits)



LGJF502Q

4. Using Hi-Scan(Pro), input the injector data(7 digits) into ECM as next procedure.

LGJF502A



LXGF573A

# CAUTION

- Whenever using the used injector again, the clamp fixing bolt and seal-ring are replaced with a new one.
- Before re-installing injector, clean the cylinder head bore and sealing surface.
- 2. Insert the injector assembly into the cylinder block.


# CAUTION

Do not touch the nozzle tip.

- 3. Spread oil on the injector tip and the cylinder head.
- 4. Install the injector by installing the clamp with clamp bolt

Tightening Torques (Injector Clamp Bolt installation): 27.5 ~ 29.4 N·m (20.3 ~ 21.7 lbf·ft)


5. After screwing thr high pressure pipe installation nuts by hand, tighten them at accurate torque using special service tools (09354-27110, 09314-27130).



LGJF502R

Tightening Torque (High Pressure Pipe installation nut): 24.5 ~ 28.4 N·m (18.1 ~ 21.0 lbf·ft)


6. Connect the return hose (A) by inserting the fixing clip (B).



LXGF571A

# CAUTION Do not reuse a fixing clip.

7. Connect the injector electric connector (A).



LXGF570C

- 8. Connect the battery (-) cable.
- 9. Start the engine and check for leakage on high pressure fuel line.

# 

Check the fuel-system visually for any leakage. If a leakage is detected even have been used the correct torque, the component(s) must be exchanged.

## INSPECTION E3B20E38


#### USING HI-SCAN(PRO)

- COMPRESSION TEST
- IDLE SPEED COMPARISON
- INJECT QUANTITY COMPARISON


#### FLB -536

#### TEST PROCEDURE

- 1. Connect Hi-Scan(Pro) and select "Vehicle" and "Engine Test Function".
- 2. Information for ECM version is displayed as below.




<Available system>



<Not available system>


LXGF577A

 After pressing "[ENTER]", select "COMPRESSION TEST" mode and press "[ENTER]".



LFIF660D

4. Set the test condition described as below screen and then, crank engine. When engine stop message being appeared, stop cranking.



LFIF660E

#### 5. Press "ANAL" and the test result is appeared.


	Cylinder engin	e speed(RPM)	
#1	#2	#3	#4
356	355	355	355
356	356	357	356
356	356	356	355
356	356	356	356
357	356	355	356
356	355	355	355
355	356	355	355
	And the owner of the owner owner owner owner owner owner own	a second	No. of Concession, Name

When the stop message appear, stop cranking.

LFIF660F

During cranking engine does not start.


# FUEL DELIVERY SYSTEM-DIESEL



LFIF660G


6. Press "AVG" and the data average of each cylinder is appeared.

Press "HELP" and description of the data is appeared.



- LFIF660H
- 7. After pressing "ESC", select "IDLE SPEED COMPAR-ISON" and press "[ENTER]".

8. Set the test condition described as below screen and press "[ENTER]".



LFIF660J

9. The rpm data of each cylinder is appeared.

Cylinder engine speed(RPM)#1#2#3#4790800752770796798756772794800752770794802754772794802754770794802754770794802756774792802752772Analyze the test result.	7.2 IDLE SPEED COMPARISON						
790         800         752         770           796         798         756         772           794         800         752         770           794         802         754         772           794         802         754         770           794         802         754         770           794         802         754         770           794         802         754         770           794         802         755         774           792         802         752         772	Cylinder engine speed(RPM)						
796         798         756         772           794         800         752         770           794         802         754         772           794         802         754         770           794         802         754         770           794         802         754         770           794         802         754         770           794         802         755         774           792         802         752         772	#1	#2	#3	#4			
794         800         752         770           794         802         754         772           794         802         754         770           794         802         754         770           794         802         754         770           794         802         756         774           792         802         752         772	790	800	752	770			
794         802         754         772           794         802         754         770           794         802         756         774           792         802         752         772	796 798 756 772						
794         802         754         770           794         802         756         774           792         802         752         772	794 800 752 770						
794         802         756         774           792         802         752         772	794	802	754	772			
792         802         752         772	794	802	754	770			
	794	802	756	774			
Analyze the test result.	792	802	752	772			
	ANAL)						




7.2 IDLE SPEED COMPARISON								
Cylinder engine speed(RPM)								
#1	#2	2	#3	#4				
784	77	4	788	764				
786	77	778 788		766				
786	77	6	788	766				
788	78	0	790	768				
784	77	6	786	764				
788	78	0	792	770				
786	77	6	788	766				
			AVG	HELP				

あるとしていた たまして 林林にたたまた ゆると


10. Press "AVG" and the data average of each cylinder is appeared.

Press "HELP" and description of the data is appeared.



LFIF660M


- 11. After pressing "ESC", select "INJECTOR QUANTITY COMPARISON" and press "[ENTER]".
- 12. Set the test condition described as below screen and press "[ENTER]".



LFIF660O


13. The data od each cylinder about RPM and compensating injection quantity is appeared.

STATES OF STREET, STRE						· .			
7.3 INJECT. QUANTITY COMPARISON									
Eng. Speed(RPM)			Injection quantity(mm3)						
#1	#2	#3	#4	#1	#2	#3	#4		
792	800	758	774	4.0	-2.9	-2.8	-2.4		
788	798	760	774	4.0	-2.9	-2.7	-2.4		
794 802 758 776 4.0 -2.9 -2.7 -2.4									
792	798	758	774	4.0	-2.8	-2.7	-2.4		
788	798	758	772	4.0	-2.8	-2.6	-2.4		
794	802	758	772	4.0	-2.8	-2.8	-2.5		
790 798 754 770 4.0 -2.9 -2.8 -2.5									
Analyze the test result.									
ANAL									



LFIF660P

14. Press "HELP" and description of the data is displayed as below.



LFIF660R


## FUEL DELIVERY SYSTEM-DIESEL

15. Replace the default injector, and then repeat previous test modes to check if the injector is normal.

#### COMPONENT INSPECTION

- 1. Turn ignition switch "OFF".
- 2. Disconnect injector connector.
- 3. Measure resistance between the terminals 1 and 2 of injector connector.

Resistance : 0.22 ~ 0.30Ω (20 ~ 70℃)







and the second

na secondaria de la construcción d Reconstrucción de la construcción de

# ACCUMULATOR

#### DESCRIPTION EGB968A8

The common rail stores the fuel at high pressure. At the same time, the pressure oscillations which are generated due to the high-pressure pump delivery and the injection of fuel are damped by the rail volume. This common rail is common to all cylinders, hence its name ""common rail"". Even when large quantities of fuel are extracted, the common rail maintains its inner pressure practically constant. This ensures that the injection pressure remains constant from the moment the injector opens.

In order to comply with the wide variety of engine installation conditions, the common rail with its flow limiters and the provisions for attaching rail pressure sensor, fuel pressure control valve, and pressure limiter valve is available in a number of different designs.


The available common rail volume is permanently filled with pressurized fuel. The compressibility of the fuel resulting from the high pressure is utilized to achieve the accumulator effect. When fuel leaves the rail for injection, the pressure in the common rail remains practically constant. Similarly, the pressure variations resulting from the pulsating fuel supply from the high-pressure pump are compensated for.

#### REMOVAL E3940FED

# CAUTION


- Common Rail Fuel Injection System is subject to extremely high pressure (Approximately 1,600 bar)
- Never perform any work on injection system with engine running or within 30 seconds after the engine stops.
- Always pay attention to safety precaution.
- Ensure the absolute cleanliness.
- It is not recommended to remove the injectors without any notice.
- 1. urn ignition switch to OFF position.
- 2. Disconnect the negative battery (-) terminal and wait for about 30 seconds.
- 3. Remove the high pressure pipe (A) connecting injectors and common rail.
- 4. Remove the high pressure pipe (B) connecting high pressure pump and common rail.

5. Disconnect the return lines (C).



EWPF600V

- 6. Disconnect rail pressure sensor and rail pressure control valve connectors.
- 7. Remove intake manifold. (Refer to "EM" group)
- 8. Remove the common rail (E) by unscrewing the two mounting bolts (F).




LGJF502T


## FUEL DELIVERY SYSTEM-DIESEL

## INSTALLATION E6B5706F

1. Install the common rail(A) with two mounting bolts(B).

Tightening Torque : 14.7 ~ 21.6 N·m (10.9 ~ 15.9 lbf·ft)






- EWPF600W
- 6. Connect the negative battery(-) terminal.
- 7. Start the engine and check for leakage on fuel line.

LGJF502U

- 2. Install the intake manifold. (Refer to "EM" group).
- 3. Connect rail pressure sensor and rail pressure control valve connectors.
- 4. After screwing the high pressure pipe installation nuts by hand, tighten them at accutate torque using special service tools(09314-27110, 09314-27130).



LGJF502R

5. Connect return line(C).

# HIGH PRESSURE FUEL PUMP


#### DESCRIPTION E2DA516F

The high-pressure pump is the interface between the lowpressure and the high-pressure stages. Under all operating conditions, it is responsible for providing adequate high-pressure fuel through out the vehicle's complete service life. This also includes the provision of extra fuel as needed for rapid starting and for rapid build-up of pressure in the rail. The high pressure pump continually generates the system pressure as needed in the high-pressure accumulator (common rail). This means therefore, that in contrast to conventional systems, the fuel does not have to be specially compressed for each individual injection process.

#### REMOVAL E59DB4F5


## 

- Common Rail Fuel Injection System is subject to extremely high pressure(Approximately 1,600 bar)
- Never perform any work on injection system with engine running or within 30 seconds after the engine stops.
- Always pay attention to safety precaution.
- Ensure the absolute cleanliness
- It is not recommended to remove the injectiors without any notice.
- 1. Turn ignition switch OFF position.
- 2. Disconnect the negative battery(-) terminal and wait for about 30 seconds.
- 3. Disconnect the wiring connector of fuel pressure regulator.
- 4. Remove the high pressure pipe (A) connecting high pressure pump and common rail.




EWPF600X

- 5. Disconnect the return hose(B) and the hose(C) connecting to the fuel filter.
- 6. Unscrew the three high pressure mounting bolts(D).
- 7. Remove the drive belt.(Refer to "EM" group.)
- Turn the crankshaft pulley and align its groove with timing mark "T" of the timing chain cover. (NO.1 cylinder compression TDC position.)




LCGF089A

9. Remove the high pressure pump sprocket nut(G) after removing the timing chain cover plug(F).




LGJF502W

10. Install the high pressure pump sprocket stopper(H) (SST: 09331-2A000) rotating it clockwise.



LGJF502X

- Fix the high pressure pump remover(I) and sprocket stopper(J) with two fixing bolts(K).
- 12. Install the high pressure pump remover(I) with three mounting bolts(E).
- Rotate the bolt(L) of the high pressure pump remover(I) clockwise till the high pressure pump is pushed out.




LGJF502Y

# INSTALLATION E2729664


1. Install the high pressure pump assembly and screw the three high pressure mounting bolts(D).

Tightening Torque: 14.7 ~ 19.6 N·m (10.9 ~ 14.5 lbf·ft)



EWPF600Y

- 2. Install the drive belt.(Refer to "EM" group.)
- Screw the timing chain cover plug(G) after fastening the high pressure pump sprocket nut(F).




LGJF502W

# **NOTE**

Don't reuse the O-ring of the timing chain cover plug.

4. Connect the return hose(B) and the hose(C) connecting to the fuel filter.




EWPF600Z

- 5. Connect the high pressure pipe(A) connecting high pressure pump and common rail.
- 6. Connect the negative battery(-) terminal.
- 7. Start the engine and check for leakage on fuel line connected to the high pressure pump.

# FUEL FILTER


# COMPONENT E475FA24



EWPF601A


## REMOVAL E2A51AB8

- 1. Turn ignition switch to OFF position.
- 2. Disconnect the negative battery (-) terminal and wait for about 30 seconds.
- 3. Unscrew the three mounting nuts(A).



EWPF601B


4. Disconnect the heater connector (B), water sensor connector (C) and thermo switch connector (D).



EWPF601C

5. Remove air cleaner assembly (Refer to "EM" group).

6. Disconnect the fuel inlet hose (E) and fuel outlet hose (F).



EWPF601D


# A CAUTION

Cover the hose connection with a shop towel to prevent splashing of fuel caused by residual pressure in the fuel line.

7. Remove the fuel filter assembly.

#### INSTALLATION EAAD75CE


1. Connect the fuel inlet hose(A) and fuel outlet hose(B).



EWPF601E


2. Remove air cleaner assembly (Refer to "EM" group).

Connect the heater connector(C), water sensor con-3. nector(D) and thermo switch connector(E).



EWPF601F

4. Fasten the three mounting nuts(F).



EWPE601G

- Connect the negative(-) terminal. 5.
- Start the engine and check for leakage on fuel line 6. connected to fuel filter.


#### INSPECTION EC565877


- · General insepction.
  - Hose and pipe for bent, damage, clogging or cora) rosion.
  - b) Fuel filter for cologging and damage.

# NOTE

- · The fuel filter inspection must be completes in case of below.
  - a) Draining fuel in fuel tank and then refilling fuel.
  - b) Replacing the fuel filter.
  - c) Removing the main fuel hose (pipe).

- Fuel filter deflation. a) Remove the air plug(I) of fuel filter.
  - b)
  - Cover the air plug with service towel, and then push the manual pump(J) until a bubble dose not flow out.
  - C) Faten the air plug(I), and then push the manual pump again until pushing the manual pump gets to be difficult.
- · Pulling out water from fuel filter.
  - Unfasten the drain plug(K). a)
  - Push the manual pump(J) until water dose not b) flow out.
  - C) Fasten the drain plug(K).






EWPF601H

# FUEL TANK


## REMOVAL ED097785

- 1. Remove the rear seat cushion (Refer to "BD" group in this WORKSHOP MANUAL).
- 2. Open the service cover (A) under the rear seat cushion.



EWPF601I

- 3. Turn ignition switch to off position and disconnect the battery (-) cable.
- 4. Disconnector the fuel sender connector (B).




EWPF601J

5. Disconnect the fuel feed hose (C) and the return hose(D).


# CAUTION

Cover the hose connection with a shop towel to prevent splashing of fuel caused by residual pressure in the fuel line 6. Lift the vehicle.



EWPF601K

7. Disconnect the fuel filler hose (F), and the breather hose (G).



EWPF601L

8. Unfasten the two mounting bolts(A) and the two mounting nuts(B), and then remove the fuel tank from the vehicle.

